



# **ACPI Component Architecture**

## **User Guide and Programmer Reference**

**OS-Independent Kernel Subsystem, Debugger, and Utilities**

---

**Revision 5.22**

***March 25, 2014***





Information in this document is provided in connection with Intel® products. No license, express or implied, by estoppel or otherwise, to any intellectual property rights is granted by this document. Except as provided in Intel's Terms and Conditions of Sale for such products, Intel assumes no liability whatsoever, and Intel disclaims any express or implied warranty, relating to sale and/or use of Intel products including liability or warranties relating to fitness for a particular purpose, merchantability, or infringement of any patent, copyright or other intellectual property right. Intel products are not intended for use in medical, life saving, or life sustaining applications.

Intel may make changes to specifications and product descriptions at any time, without notice.

Designers must not rely on the absence or characteristics of any features or instructions marked "reserved" or "undefined." Intel reserves these for future definition and shall have no responsibility whatsoever for conflicts or incompatibilities arising from future changes to them.

The ACPI Component Architecture may contain design defects or errors known as errata which may cause the product to deviate from published specifications. Current characterized errata are available on request.

Copyright © 2000 – 2014 Intel Corporation

\*Other brands and names are the property of their respective owners.



# Contents

---

<b>1</b>	<b>Introduction .....</b>	<b>14</b>
1.1	Document Structure .....	14
1.2	Rationale and Justification .....	14
1.3	Reference Documents .....	15
1.4	Document History .....	15
1.5	Overview of the ACPI Component Architecture .....	17
<b>2</b>	<b>Architecture Overview .....</b>	<b>19</b>
2.1	Overview of the ACPICA Subsystem .....	19
2.1.1	OS-independent ACPICA Subsystem .....	19
2.1.2	Operating System Services Layer .....	20
2.1.3	Relationships Between Host OS, ACPICA, and Host OSL .....	21
2.1.3.1	General Architectural Model .....	21
2.1.3.2	Host Operating System Interaction .....	21
2.1.3.3	OS Services Layer Interaction .....	21
2.1.3.4	ACPICA Subsystem Interaction .....	21
2.2	Architecture of the ACPICA Subsystem .....	22
2.2.1	ACPI Table Management .....	23
2.2.2	Early ACPI Table Access .....	23
2.2.3	AML Interpreter .....	23
2.2.4	Namespace Management .....	24
2.2.5	Resource Management .....	24
2.2.6	ACPI Hardware Management .....	24
2.2.7	Event Handling .....	24
2.2.8	Requests from Host OS to ACPICA Subsystem .....	25
2.3	Architecture of the OS Services Layer (OSL) .....	25
2.3.1	Types of OSL Services .....	26
2.3.2	Requests from ACPICA Subsystem to OS .....	26
<b>3</b>	<b>Design Details .....</b>	<b>28</b>
3.1	ACPI Namespace Fundamentals .....	28
3.1.1	Named Objects .....	28
3.1.2	Scopes .....	28
3.1.2.1	Example Namespace Scopes, Names, and Objects .....	28
3.1.3	Predefined Objects .....	29
3.1.4	Logical Namespace Layout .....	29
3.2	Execution Model .....	30
3.2.1	Initialization .....	30
3.2.2	Memory Allocation .....	31
3.2.2.1	Caller Allocates All Buffers .....	31
3.2.2.2	ACPI Allocates Return Buffers .....	31
3.2.3	Parameter Validation .....	32
3.2.4	Exception Handling .....	32
3.2.5	Multitasking and Reentrancy .....	32
3.2.6	Event Handling .....	32
3.2.6.1	Fixed Events .....	33
3.2.6.2	General Purpose Events .....	33
3.2.6.3	Notify Events .....	33
3.2.7	Address Spaces and Operation Regions .....	33



	3.2.7.1	Installation of Address Space Handlers .....	34
	3.2.7.2	ACPI-Defined Address Spaces .....	34
	3.2.7.3	Sharing Resources between Device Drivers and AML .....	35
3.3		Policies and Philosophies .....	37
	3.3.1	External Interfaces .....	37
	3.3.1.1	Exception Codes .....	37
	3.3.1.2	Memory Buffers .....	37
	3.3.2	Subsystem Initialization .....	38
	3.3.2.1	ACPI Table Validation .....	38
	3.3.2.2	Required ACPI Tables.....	38
	3.3.3	Major Design Decisions .....	38
	3.3.3.1	Performance versus Code/Data Size.....	38
	3.3.3.2	Object Management – No Garbage Collection .....	39
<b>4</b>		<b>Implementation Details .....</b>	<b>40</b>
4.1		Required Host OS Initialization Sequence.....	40
	4.1.1	Bootload and Low Level Kernel Initialization .....	40
	4.1.2	ACPICA Subsystem Initialization .....	40
	4.1.3	Other OS Initialization .....	40
	4.1.4	Device Enumeration, Configuration, and Initialization .....	41
	4.1.5	Final OS Initialization .....	41
4.2		Required ACPICA Initialization Sequence.....	41
	4.2.1	Global Initialization – AcpiInitializeSubsystem.....	41
	4.2.2	ACPI Table and Namespace Initialization .....	41
	4.2.2.1	AcpiInitializeTables.....	41
	4.2.2.2	AcpiGetTable, AcpiGetTableHeader, AcpiGetTableByIndex..	41
	4.2.2.3	AcpiLoadTables.....	42
	4.2.2.4	Internal ACPI Namespace Initialization.....	42
	4.2.3	Hardware Initialization – AcpiEnableSubsystem .....	42
	4.2.3.1	ACPI Hardware and Event Initialization .....	42
	4.2.4	Handler Installation .....	43
	4.2.4.1	Handler Types .....	43
	4.2.5	Object Initialization – AcpiInitializeObjects .....	44
	4.2.5.1	ACPI Device Initialization .....	44
	4.2.5.2	Other ACPI Object Initialization.....	45
	4.2.6	Other Operating System ACPI-related Initialization.....	45
	4.2.7	Just-in-time Operation Region Initialization .....	45
	4.2.7.1	SystemMemory Region Initialization .....	46
	4.2.7.2	PCI_Config Region Initialization.....	46
	4.2.8	System Shutdown – AcpiTerminate.....	47
4.3		Multithreading Support.....	47
	4.3.1	Reentrancy.....	47
	4.3.2	Mutual Exclusion and Synchronization .....	47
	4.3.2.1	Internal use of Mutex Objects .....	47
	4.3.2.2	Internal use of Spinlock Objects.....	48
	4.3.3	Control Method Execution.....	49
	4.3.3.1	Control Method Blocking .....	49
	4.3.3.2	Control Method Execution Rules.....	49
	4.3.3.3	A Simple Multithreading Model .....	50
	4.3.3.4	A More Complex Multithreading Model .....	51
	4.3.4	ACPI Global Lock Support.....	52
	4.3.4.1	Obtaining The Global Lock.....	53
	4.3.4.2	Releasing the Global Lock .....	53
	4.3.4.3	Global Lock Interrupt Handler .....	53
	4.3.5	Single Thread Environments.....	53



4.4	General Purpose Event (GPE) Support .....	54
4.4.1	Runtime and Wake GPEs .....	54
4.4.1.1	Execution of _PRW Methods .....	54
4.4.1.2	Implicit Notify Support .....	55
4.4.2	Using the ACPICA GPE Support Code .....	55
4.4.2.1	Host OS Initialization .....	56
4.4.2.2	GPE Handlers .....	56
4.4.2.3	GPE Handler Execution .....	56
4.4.2.4	Load and LoadTable ASL/AML Operators .....	57
4.4.2.5	GPE Block Devices .....	57
4.5	Miscellaneous ACPICA Behavior .....	58
4.5.1	Why ACPICA Cannot Use C Bitfields .....	58
4.5.2	Dynamically Loaded ACPI Tables .....	58
4.5.3	Bus Master Arbitration (ARB_DIS) .....	59
<b>5</b>	<b>ACPICA Subsystem Features -----</b>	<b>60</b>
5.1	ACPI 5.0 Support .....	60
5.1.1	Reduced Hardware Platforms .....	60
5.1.1.1	Runtime Reduced Hardware Support .....	60
5.1.1.2	Compile-Time Reduced Hardware Support .....	60
5.1.2	New and Existing ACPI Tables .....	61
5.1.3	Operation Regions and Space IDs .....	61
5.1.4	Resource Descriptors .....	62
5.1.5	ASL/AML Support .....	62
5.1.6	Predefined ACPI Names .....	62
5.1.7	ACPICA External Interfaces .....	63
5.1.8	Miscellaneous and Tools .....	63
5.1.9	ACPI Table Definition Language .....	63
5.1.10	GPIO Event Model for ACPICA .....	64
5.2	AML Interpreter Slack Mode .....	64
5.3	AML Interpreter Math Mode (32-bit or 64-bit) .....	65
5.4	Predefined Control Method Validation .....	65
5.5	I/O Port Protection .....	65
5.6	Debugging Support .....	66
5.6.1	Error and Warning Messages .....	66
5.6.2	Execution Debug Output (ACPI_DEBUG_PRINT Macro) .....	67
5.6.3	Function Tracing (ACPI_FUNCTION_TRACE Macro) .....	67
5.6.4	ACPICA Debugger .....	68
5.7	Environmental Support Requirements .....	68
5.7.1	Resource Requirements .....	68
5.7.2	C Library Functions .....	68
5.7.3	Source Code Organization .....	70
5.7.4	System Include Files .....	71
5.7.4.1	Customization to the Target Environment .....	71
<b>6</b>	<b>Data Types and Interface Parameters -----</b>	<b>72</b>
6.1	ACPICA Interface Parameters .....	72
6.1.1	ACPI Names and Pathnames .....	72
6.1.2	Pointers .....	72
6.1.3	Buffers .....	72
6.2	ACPICA Basic Data Types .....	73
6.2.1	UINT64 and COMPILER_DEPENDENT_UINT64 .....	73
6.2.2	ACPI_PHYSICAL_ADDRESS .....	73
6.2.3	ACPI_IO_ADDRESS .....	73
6.2.4	ACPI_SIZE .....	73



6.2.5	ACPI_STRING – ASCII String .....	73
6.2.6	ACPI_BUFFER – Input and Output Memory Buffers .....	73
6.2.6.1	Input Buffer .....	74
6.2.6.2	Output Buffer .....	74
6.2.7	ACPI_STATUS – Interface Exception Return Codes .....	75
6.2.8	ACPI_HANDLE – Object Handle .....	75
6.2.8.1	Predefined Handles .....	75
6.2.9	ACPI_OBJECT_TYPE – Object Type Codes .....	76
6.2.10	ACPI_OBJECT – Method Parameters and Return Objects .....	76
6.2.10.1	Using the ACPI_OBJECT .....	78
6.2.11	ACPI_OBJECT_LIST – List of Objects .....	79
6.2.12	ACPI_EVENT_TYPE – Fixed Event Type Codes .....	79
6.2.13	ACPI_TABLE_HEADER – Common ACPI Table Header .....	79
6.3	ACPI Resource Data Types .....	79
6.3.1	PCI IRQ Routing Tables .....	79
6.3.2	Device Resources .....	80
6.3.2.1	ACPI_RESOURCE_TYPE – Resource Data Types .....	80
6.4	ACPICA Exception Codes .....	82
<b>7</b>	<b>Subsystem Configuration .....</b>	<b>86</b>
7.1	Configuration Files .....	86
7.2	Component Selection .....	86
7.2.1	ACPI_DISASSEMBLER .....	86
7.2.2	ACPI_DEBUGGER .....	86
7.2.3	ACPI_REDUCED_HARDWARE .....	87
7.3	Configurable Data Types .....	88
7.3.1	ACPI_SPINLOCK .....	88
7.3.2	ACPI_SEMAPHORE .....	88
7.3.3	ACPI_MUTEX .....	88
7.3.4	ACPI_CPU_FLAGS .....	89
7.3.5	ACPI_THREAD_ID .....	89
7.3.6	ACPI_CACHE_T .....	89
7.3.7	ACPI_UINTPTR_T .....	89
7.4	Subsystem Compile-Time Options .....	89
7.4.1	ACPI_USE_SYSTEM_CLIBRARY .....	89
7.4.2	ACPI_USE_STANDARD_HEADERS .....	89
7.4.3	ACPI_DEBUG_OUTPUT .....	90
7.4.4	ACPI_USE_LOCAL_CACHE .....	90
7.4.5	ACPI_DBG_TRACK_ALLOCATIONS .....	90
7.4.6	ACPI_MUTEX_TYPE .....	90
7.4.7	ACPI_MUTEX_DEBUG .....	91
7.4.8	ACPI_SIMPLE_RETURN_MACROS .....	91
7.4.9	ACPI_USE_DO_WHILE_0 .....	91
7.5	Per-Compiler Configuration .....	91
7.5.1	COMPILER_DEPENDENT_INT64 .....	91
7.5.2	COMPILER_DEPENDENT_UINT64 .....	92
7.5.3	ACPI_INLINE .....	92
7.5.4	ACPI_USE_NATIVE_DIVIDE .....	92
7.5.5	ACPI_DIV_64_BY_32 (Short 64-bit Divide) .....	92
7.5.6	ACPI_SHIFT_RIGHT_64 (64-bit Shift) .....	93
7.5.7	ACPI_EXPORT_SYMBOL .....	93
7.5.8	ACPI_EXTERNAL_XFACE .....	93
7.5.9	ACPI_INTERNAL_XFACE .....	94
7.5.10	ACPI_INTERNAL_VAR_XFACE .....	94
7.5.11	ACPI_SYSTEM_XFACE .....	94



7.5.12	ACPI_PRINTF_LIKE .....	94
7.5.13	ACPI_UNUSED_VAR .....	94
7.6	Per-Machine Configuration .....	94
7.6.1	ACPI_MACHINE_WIDTH .....	95
7.6.2	ACPI_FLUSH_CPU_CACHE .....	95
7.6.3	ACPI_OS_NAME .....	95
7.6.4	ACPI_ACQUIRE_GLOBAL_LOCK .....	95
7.6.5	ACPI_RELEASE_GLOBAL_LOCK .....	96
7.7	Subsystem Runtime Configuration .....	97
7.7.1	Interpreter Slack Mode .....	97
7.7.2	ACPI Register Widths .....	97
7.7.3	Auto-Serialization of Control Methods .....	98
7.7.4	Output from the AML Debug Object .....	98
7.7.5	Copy the System DSDT to Local Memory .....	99
7.7.6	Creation of _OSI Method .....	99
7.7.7	I/O Address Truncation .....	99
7.7.8	Runtime Validation/Repair of Predefined Names .....	99
7.7.9	Reduced ACPI Hardware Flag .....	99
7.7.10	Ignore XSDT, Use RSDT Instead .....	99
7.7.11	Use 32-bit FADT Addresses to Resolve Conflicts .....	100
7.8	Subsystem Configuration Constants .....	100
7.8.1	ACPI_CHECKSUM_ABORT .....	100
7.8.2	ACPI_MAX_LOOP_ITERATIONS .....	100
7.8.3	ACPI_MAX_STATE_CACHE_DEPTH .....	100
7.8.4	ACPI_MAX_PARSE_CACHE_DEPTH .....	100
7.8.5	ACPI_MAX_OBJECT_CACHE_DEPTH .....	101
7.8.6	ACPI_MAX_WALK_CACHE_DEPTH .....	101
<b>8</b>	<b>ACPICA Subsystem - External Interface Definition .....</b>	<b>102</b>
8.1	ACPICA Subsystem Initialization and Control .....	102
8.1.1	AcpiInitializeSubsystem .....	102
8.1.2	AcpiInstallInitializationHandler .....	103
8.1.2.1	Interface to User Callback Function .....	103
8.1.3	AcpiEnableSubsystem .....	104
8.1.4	AcpiInitializeObjects .....	105
8.1.5	AcpiSubsystemStatus .....	106
8.1.6	AcpiTerminate .....	106
8.1.7	AcpiInstallInterface .....	107
8.1.7.1	Default Supported _OSI Strings .....	108
8.1.7.2	Why ACPICA responds TRUE to _OSI (Windows) .....	108
8.1.7.3	ACPICA Policy for New _OSI Strings .....	109
8.1.8	AcpiUpdateInterfaces .....	110
8.1.9	AcpiRemoveInterface .....	111
8.1.10	AcpiInstallInterfaceHandler .....	111
8.1.10.1	Interface to _OSI Interface Handlers .....	112
8.2	ACPI Table Management .....	113
8.2.1	AcpiInitializeTables .....	113
8.2.2	AcpiReallocateRootTable .....	114
8.2.3	AcpiFindRootPointer .....	114
8.2.4	AcpiInstallTable .....	115
8.2.5	AcpiLoadTables .....	116
8.2.6	AcpiLoadTable .....	117
8.2.7	AcpiUnloadParentTable .....	118
8.2.8	AcpiGetTableHeader .....	119
8.2.9	AcpiGetTable .....	120
8.2.10	AcpiGetTableByIndex .....	121



8.2.11	AcpiInstallTableHandler .....	122
8.2.11.1	Interface to the Table Event Handler .....	122
8.2.12	AcpiRemoveTableHandler .....	123
8.3	ACPI Namespace Management .....	124
8.3.1	AcpiEvaluateObject .....	124
8.3.2	AcpiEvaluateObjectTyped .....	128
8.3.3	AcpiGetObjectInfo .....	129
8.3.4	AcpiGetNextObject .....	132
8.3.5	AcpiGetParent .....	134
8.3.6	AcpiGetType .....	134
8.3.7	AcpiGetHandle .....	135
8.3.8	AcpiGetName .....	137
8.3.9	AcpiGetDevices .....	138
8.3.10	AcpiAttachData .....	139
8.3.11	AcpiDetachData .....	140
8.3.12	AcpiGetData .....	141
8.3.13	AcpiInstallMethod .....	142
8.3.14	AcpiWalkNamespace .....	144
8.3.14.1	Interface to User Callback Function .....	145
8.3.15	AcpiAcquireMutex .....	146
8.3.16	AcpiReleaseMutex .....	147
8.4	ACPI Hardware Management .....	148
8.4.1	AcpiEnable .....	148
8.4.2	AcpiDisable .....	149
8.4.3	AcpiReset .....	149
8.4.4	AcpiReadBitRegister .....	150
8.4.5	AcpiWriteBitRegister .....	151
8.4.6	AcpiRead .....	152
8.4.7	AcpiWrite .....	153
8.4.8	AcpiAcquireGlobalLock .....	154
8.4.9	AcpiReleaseGlobalLock .....	154
8.4.10	AcpiGetTimerResolution .....	155
8.4.11	AcpiGetTimerDuration .....	156
8.4.12	AcpiGetTimer .....	156
8.5	ACPI Sleep/Wake Support .....	157
8.5.1	AcpiSetFirmwareWakingVector .....	157
8.5.2	AcpiSetFirmwareWakingVector64 .....	158
8.5.3	AcpiGetSleepTypeData .....	158
8.5.4	AcpiEnterSleepStatePrep .....	159
8.5.5	AcpiEnterSleepState .....	160
8.5.6	AcpiEnterSleepStateS4Bios .....	161
8.5.7	AcpiLeaveSleepStatePrep .....	162
8.5.8	AcpiLeaveSleepState .....	162
8.6	ACPI Fixed Event Management .....	163
8.6.1	AcpiEnableEvent .....	163
8.6.2	AcpiDisableEvent .....	164
8.6.3	AcpiClearEvent .....	165
8.6.4	AcpiGetEventStatus .....	165
8.6.5	AcpiInstallFixedEventHandler .....	166
8.6.5.1	Interface to Fixed Event Handlers .....	167
8.6.6	AcpiRemoveFixedEventHandler .....	168
8.7	ACPI General Purpose Event (GPE) Management .....	169
8.7.1	AcpiUpdateAllGpes .....	169
8.7.2	AcpiEnableGpe .....	169
8.7.3	AcpiDisableGpe .....	171
8.7.4	AcpiClearGpe .....	172





8.7.5	AcpiSetGpe .....	173
8.7.6	AcpiFinishGpe .....	174
8.7.7	AcpiSetupGpeForWake .....	175
8.7.8	AcpiSetGpeWakeMask .....	176
8.7.9	AcpiGetGpeStatus .....	177
8.7.10	AcpiGetGpeDevice .....	178
8.7.11	AcpiDisableAllGpes .....	179
8.7.12	AcpiEnableAllRuntimeGpes .....	180
8.7.13	AcpiInstallGpeBlock .....	180
8.7.14	AcpiRemoveGpeBlock .....	181
8.7.15	AcpiInstallGpeHandler .....	182
8.7.15.1	Interface to General Purpose Event Handlers .....	183
8.7.16	AcpiRemoveGpeHandler .....	184
8.8	Miscellaneous Handler Support .....	185
8.8.1	AcpiInstallSciHandler .....	185
8.8.1.1	Interface to SCI Handlers .....	185
8.8.2	AcpiRemoveSciHandler .....	186
8.8.3	AcpiInstallGlobalEventHandler .....	187
8.8.3.1	Interface to the Global Event Handler .....	187
8.8.4	AcpiInstallNotifyHandler .....	188
8.8.4.1	Interface to Notification Event Handlers .....	190
8.8.5	AcpiRemoveNotifyHandler .....	190
8.8.6	AcpiInstallAddressSpaceHandler .....	192
8.8.6.1	Interface to Address Space Setup Handlers .....	193
8.8.6.2	Interface to Address Space Handlers .....	194
8.8.6.3	Context for the Default PCI Address Space Handler .....	195
8.8.6.4	Context for the GPIO/SerialBus Address Space Handlers .....	195
8.8.7	AcpiRemoveAddressSpaceHandler .....	196
8.8.8	AcpiInstallExceptionHandler .....	197
8.8.8.1	Interface to Exception Handlers .....	198
8.9	ACPI Resource Management .....	199
8.9.1	AcpiGetCurrentResources .....	199
8.9.2	AcpiGetPossibleResources .....	200
8.9.3	AcpiSetCurrentResources .....	201
8.9.4	AcpiGetEventResources .....	202
8.9.5	AcpiGetIRQRoutingTable .....	203
8.9.6	AcpiGetVendorResource .....	204
8.9.7	AcpiBufferToResource .....	205
8.9.8	AcpiResourceToAddress64 .....	206
8.9.9	AcpiWalkResourceBuffer .....	206
8.9.9.1	Interface to User Callback Function .....	207
8.9.10	AcpiWalkResources .....	208
8.10	Memory Management .....	209
8.10.1	ACPI_ALLOCATE .....	209
8.10.2	ACPI_ALLOCATE_ZEROED .....	210
8.10.3	ACPI_FREE .....	210
8.11	Formatted Output .....	211
8.11.1	AcpiInfo and ACPI_INFO .....	211
8.11.2	AcpiWarning and ACPI_WARNING .....	212
8.11.3	AcpiError and ACPI_ERROR .....	213
8.11.4	AcpiException and ACPI_EXCEPTION .....	214
8.11.5	AcpiBiosWarning and ACPI_BIOS_WARNING .....	215
8.11.6	AcpiBiosError and ACPI_BIOS_ERROR .....	216
8.11.7	AcpiDebugPrint and ACPI_DEBUG_PRINT .....	217
8.11.8	AcpiDebugPrintRaw and ACPI_DEBUG_PRINT_RAW .....	219



8.12	Miscellaneous Utilities .....	219
8.12.1	AcpiCheckAddressRange .....	219
8.12.2	AcpiDebugTrace .....	220
8.12.3	AcpiDecodePldBuffer .....	221
8.12.4	AcpiFormatException .....	222
8.12.5	AcpiGetStatistics .....	222
8.12.6	AcpiGetSystemInfo .....	223
8.12.7	AcpiPurgeCachedObjects .....	225
8.13	Global Variables .....	225
8.13.1	AcpiDbgLevel & AcpiDbgLayer .....	225
8.13.2	AcpiGbl_FADT .....	225
8.13.3	AcpiCurrentGpeCount .....	225
8.13.4	AcpiGbl_SystemAwakeAndRunning .....	226
<b>9</b>	<b>OS Services Layer - External Interface Definition -----</b>	<b>227</b>
9.1	Environmental and ACPI Tables .....	227
9.1.1	AcpiOsInitialize .....	227
9.1.2	AcpiOsTerminate .....	228
9.1.3	AcpiOsGetRootPointer .....	228
9.1.4	AcpiOsPredefinedOverride .....	229
9.1.5	AcpiOsTableOverride .....	229
9.1.6	AcpiOsPhysicalTableOverride .....	231
9.2	Memory Management .....	232
9.2.1	AcpiOsCreateCache .....	232
9.2.2	AcpiOsDeleteCache .....	233
9.2.3	AcpiOsPurgeCache .....	233
9.2.4	AcpiOsAcquireObject .....	234
9.2.5	AcpiOsReleaseObject .....	234
9.2.6	AcpiOsMapMemory .....	235
9.2.7	AcpiOsUnmapMemory .....	236
9.2.8	AcpiOsGetPhysicalAddress .....	236
9.2.9	AcpiOsAllocate .....	237
9.2.10	AcpiOsFree .....	237
9.2.11	AcpiOsReadable .....	238
9.2.12	AcpiOsWritable .....	238
9.3	Multithreading and Scheduling Services .....	239
9.3.1	AcpiOsGetThreadId .....	239
9.3.2	AcpiOsExecute .....	239
9.3.3	AcpiOsSleep .....	240
9.3.4	AcpiOsStall .....	241
9.3.5	AcpiOsWaitEventsComplete .....	241
9.4	Mutual Exclusion and Synchronization .....	242
9.4.1	AcpiOsCreateMutex .....	242
9.4.2	AcpiOsDeleteMutex .....	242
9.4.3	AcpiOsAcquireMutex .....	243
9.4.4	AcpiOsReleaseMutex .....	244
9.4.5	AcpiOsCreateSemaphore .....	244
9.4.6	AcpiOsDeleteSemaphore .....	245
9.4.7	AcpiOsWaitSemaphore .....	245
9.4.8	AcpiOsSignalSemaphore .....	246
9.4.9	AcpiOsCreateLock .....	247
9.4.10	AcpiOsDeleteLock .....	248
9.4.11	AcpiOsAcquireLock .....	248
9.4.12	AcpiOsReleaseLock .....	249



9.5	Interrupt Handling.....	249
9.5.1	AcpiOsInstallInterruptHandler .....	249
9.5.1.1	Interface to OS-independent Interrupt Handlers .....	250
9.5.2	AcpiOsRemoveInterruptHandler .....	251
9.6	Memory Access and Memory Mapped I/O .....	251
9.6.1	AcpiOsReadMemory .....	252
9.6.2	AcpiOsWriteMemory .....	252
9.7	Port Input/Output.....	253
9.7.1	AcpiOsReadPort .....	253
9.7.2	AcpiOsWritePort .....	254
9.8	PCI Configuration Space Access.....	254
9.8.1	AcpiOsReadPciConfiguration .....	255
9.8.2	AcpiOsWritePciConfiguration.....	255
9.9	Formatted Output .....	256
9.9.1	AcpiOsPrintf .....	256
9.9.2	AcpiOsVprintf .....	257
9.9.3	AcpiOsRedirectOutput .....	257
9.10	System ACPI Table Access .....	258
9.10.1	AcpiOsGetTableByAddress .....	258
9.10.2	AcpiOsGetTableByIndex.....	259
9.10.3	AcpiOsGetTableByName.....	261
9.11	Miscellaneous .....	262
9.11.1	AcpiOsGetTimer .....	262
9.11.2	AcpiOsSignal.....	263
9.11.3	AcpiOsGetLine .....	264
<b>10</b>	<b>ACPICA Deployment Guide .....</b>	<b>265</b>
10.1	Using the ACPICA Subsystem Interfaces.....	265
10.1.1	Initialization Sequence .....	265
10.1.2	ACPICA Initialization Examples .....	265
10.1.2.1	Full ACPICA Initialization .....	265
10.1.2.2	ACPICA Initialization With Early ACPI Table Access .....	266
10.1.3	Shutdown Sequence.....	267
10.1.4	Traversing the ACPI Namespace (Low Level).....	268
10.1.5	Traversing the ACPI Namespace (High Level).....	270
10.2	Implementing the OS Services Layer .....	271
10.2.1	Parameter Validation .....	271
10.2.2	Memory Management .....	271
10.2.3	Scheduling Services .....	271
10.2.4	Mutual Exclusion and Synchronization .....	271
10.2.5	Interrupt Handling .....	271
10.2.6	Stream I/O.....	272
10.2.7	Hardware Abstraction (I/O, Memory, PCI Configuration) .....	272
<b>11</b>	<b>User-Mode Tools and Utilities.....</b>	<b>273</b>
11.1	Generating the ACPICA Tools/Utilities from Source.....	273
11.1.1	Generic Unix Makefiles .....	273
11.1.2	Visual Studio Project Files .....	274
11.1.2.1	Visual Studio 2008 Installation Notes.....	274
11.1.2.2	Flex/Bison for Windows Installation Notes .....	275



11.2	iASL Compiler .....	276
11.3	AcpiExec – User Mode ACPI Execution/Simulation .....	278
11.4	AcpiHelp – Display ACPI Help Information .....	279
11.5	AcpiDump – Dump System ACPI Tables .....	280
11.6	AcpiXtract – Extract ACPI Tables .....	280
11.7	AcpiSrc – Convert ACPICA Source Code .....	281
11.8	AcpiNames – Example Namespace Dump .....	282
<b>12</b>	<b>ACPICA Debugger Reference -----</b>	<b>283</b>
12.1	Overview .....	283
12.2	Supported Environments .....	283
12.2.1	The AcpiExec Utility .....	283
12.3	Debugger Architecture .....	283
12.4	Configuration and Installation .....	284
12.5	Command Overview .....	286
12.6	Command Summary .....	286
12.7	General Purpose Commands .....	288
12.7.1	Allocations .....	288
12.7.2	Dump .....	288
12.7.3	Exit .....	288
12.7.4	Handlers .....	288
12.7.5	Help .....	289
12.7.6	History (! And !!) .....	289
12.7.7	Level .....	290
12.7.8	Locks .....	290
12.7.9	Osi .....	290
12.7.10	Quit .....	291
12.7.11	Stats .....	291
12.7.12	Tables .....	291
12.7.13	Unload .....	292
12.8	Namespace Access Commands .....	292
12.8.1	BusInfo .....	292
12.8.2	Disassemble .....	292
12.8.3	Find .....	292
12.8.4	Integrity .....	293
12.8.5	Methods .....	293
12.8.6	Namespace .....	293
12.8.7	Notify .....	293
12.8.8	Objects .....	294
12.8.9	Owner .....	294
12.8.10	Paths .....	295
12.8.11	Predefined .....	295
12.8.12	Prefix .....	295
12.8.13	References .....	295
12.8.14	Resources .....	296
12.8.15	Set N .....	296
12.8.16	Template .....	296
12.8.17	Terminate .....	296
12.8.18	Type .....	297
12.9	Control Method Execution Commands .....	297
12.9.1	Arguments .....	297
12.9.2	Breakpoint .....	297
12.9.3	Call .....	297
12.9.4	Debug .....	298



12.9.5	Execute .....	298
12.9.5.1	Specifying Method Arguments .....	298
12.9.6	Go .....	299
12.9.7	Information .....	299
12.9.8	Into .....	299
12.9.9	List.....	300
12.9.10	Locals.....	300
12.9.11	Results .....	300
12.9.12	Set.....	300
12.9.13	Stop.....	301
12.9.14	Thread.....	301
12.9.15	Trace .....	301
12.9.16	Tree.....	301
12.10	Hardware-Related Commands .....	302
12.10.1	Event .....	302
12.10.2	Gpe .....	302
12.10.3	Gpes.....	302
12.10.4	Sci .....	302
12.10.5	Sleep .....	303
12.11	File I/O Commands .....	303
12.11.1	Close .....	303
12.11.2	Load .....	303
12.11.3	Open .....	303
12.12	Debug Test Commands .....	304
12.12.1	Test Objects .....	304
12.12.2	Test Predefined.....	304

## Figures

Figure 1. The ACPI Component Architecture .....	18
Figure 2. ACPICA Subsystem Architecture .....	20
Figure 3. Interaction between the Architectural Components.....	22
Figure 4. Internal Modules of the ACPICA Subsystem.....	23
Figure 5. Operating System to ACPICA Subsystem Request Flow .....	25
Figure 6. ACPICA Subsystem to Operating System Request Flow .....	27
Figure 7. Internal Namespace Structure .....	30
Figure 8. Global Lock Architecture.....	52
Figure 9. ACPICA Debugger Architecture .....	284

## Tables

Table 1. C Library Functions Used within the Subsystem .....	69
Table 2. ACPI Object Type Codes.....	76
Table 3. Exception Code Values.....	83



# 1 Introduction

## 1.1 Document Structure

This document consists of these major sections:

**Introduction:** Contains a brief overview of the ACPI Component Architecture (CA) and the interfaces for both the ACPICA Subsystem and OS Services Layers.

**Architecture Overview:** Overview of the main architectural components and interface to the host operating system. Summary of the computational and architectural model that is implemented by the ACPI component architecture.

**Design Details:** Details concerning design decisions and execution model.

**Implementation Details:** Details concerning implementation specifics.

**ACPICA Subsystem Features:** Details concerning features that are specific to ACPICA (independent of ACPI itself.)

**Data Types and Interface Parameters:** Descriptions of the major data types and data structures that are exposed via the external interfaces. Other related information required to use the ACPICA subsystems and interfaces.

**Subsystem Configuration:** Description of the available configuration options to tailor the subsystem to different compilers and machines, as well as run-time tuning options.

**ACPICA Subsystem – External Interface Definition:** Detailed description of the programmatic interfaces that are implemented by the kernel-resident, OS-independent component of the ACPI Component Architecture.

**OS Services Layer – External Interface Definition:** Detailed description of the programmatic interfaces that must be implemented by operating system vendors in the layer that interfaces the ACPICA Subsystem to the host operating system.

**ACPICA Deployment Guide:** Tips and techniques on how to use the ACPICA Subsystem interfaces, and how to implement the OSL interfaces to host a new operating system.

**User-Mode Tools and Utilities:** A brief overview and guide to the miscellaneous tools and utilities that are part of the ACPICA package.

**ACPICA Debugger Reference:** Overview, installation and configuration, and detailed descriptions of the command set.

## 1.2 Rationale and Justification

The complexity of the ACPI specification leads to a lengthy and difficult implementation in operating system software. The purpose of the ACPI component architecture is to simplify ACPI implementations for operating system vendors (OSVs) by providing major portions of an ACPI implementation in OS-independent ACPI modules that can be integrated into any operating system.

The ACPICA software can be hosted on any operating system by writing a small and relatively simple translation service between the ACPICA subsystem and the host operating system (This service is known as the OS Services Layer).



## 1.3 Reference Documents

ACPI documents are available at <http://www.acpi.info>

*Advanced Configuration and Power Interface Specification*, Revision 1.0, December 1, 1996  
*Advanced Configuration and Power Interface Specification*, Revision 1.0a, July 1, 1998  
*Advanced Configuration and Power Interface Specification*, Revision 1.0b, February 8, 1999  
*Advanced Configuration and Power Interface Specification*, Revision 2.0, July 27, 2000  
*Advanced Configuration and Power Interface Specification*, Revision 2.0a, March 32, 2002  
*Advanced Configuration and Power Interface Specification*, Revision 2.0b, October 11, 2002  
*Advanced Configuration and Power Interface Specification*, Revision 2.0c, August 23, 2003  
*Advanced Configuration and Power Interface Specification*, Revision 3.0, September 2, 2004  
*Advanced Configuration and Power Interface Specification*, Revision 3.0a, December 30, 2005  
*Advanced Configuration and Power Interface Specification*, Revision 3.0b, October 10, 2006  
*Advanced Configuration and Power Interface Specification*, Revision 4.0, June 16, 2009  
*Advanced Configuration and Power Interface Specification*, Revision 4.0a, April 5, 2010  
*Advanced Configuration and Power Interface Specification*, Revision 5.0, December 6, 2011  
*Advanced Configuration and Power Interface Specification*, Revision 5.0a, November 13, 2013

ACPICA documents are available at <http://www.acpica.org/documentation/>

*iASL: ACPI Source Language Optimizing Compiler and Disassembler User Guide*

## 1.4 Document History

January 2000: Original version.

09 July 2005: Added example and description of OS initialization sequence.

26 November 2008: Major update and overhaul. Update all interfaces and text to match reality

18 March 2009: Removed `AcpiOsValidateAddress`. Added section for feature descriptions. Added description of I/O port protection.

14 May 2009: Add new `AcpiInstallMethod` function.

03 November 2009: Changes to `AcpiWalkNamespace`. Added documentation of ACPICA source code tree.

21 January 2009: Removed obsolete `ACPI_INTEGER` data type.

04 March 2009: Add new global for the AML debug object. Clarify use of the `ACPI_OBJECT` data type.

30 March 2010: Update for GPE interface changes. Added DSDT copy option.

04 April 2010: Add description of GPE support for `LoadTable`.

05 August 2010: Add new `host_OSI` interface functions, `AcpiInstallInterface`, `AcpiRemoveInterface`, `AcpiInstallInterfaceHandler`. Add new debugger command, “OSI”.



17 August 2010: Remove obsolete `AcpiOsDerivePciId` OSL function. This function has been implemented within ACPICA in an OS-independent manner.

21 September 2010: Fix/clarify the initialization sequence for installation of user/host address space handlers. This can only happen after `AcpiEnableSubsystem` is called.

December 2010: Support for new GPE handling features. Full description of GPE support in ACPICA as well as updated descriptions for GPE interfaces.

May 2011: Debugger: Add description of new mechanism to pass complex arguments to control methods (Integer, Strings, Buffers, and Packages.)

October 2011: Add new ACPI 5.0 interfaces – `AcpiGetEventResource`, `AcpiAcquireMutex`, `AcpiReleaseMutex`.

November 2011: Full update for ACPI 5.0 features – add overall description and miscellaneous updates throughout.

December 2011: Update for new interface, `AcpiCheckAddressRange`.

February 2012: Add note that the sleep/wake interfaces now support the V5 FADT with standalone sleep registers. Widen the `AcpiOsReadMemory` and `AcpiOsWriteMemory` interfaces to 64 bits. Add `ACPI_REDUCED_HARDWARE` option. Add `AcpiOsPhysicalTableOverride` and `AcpiLeaveSleepStatePrep`.

March 2012: Added flags parameter to `AcpiEnterSleepState` and `AcpiLeaveSleepStatePrep` to enable optional execution of the `_GTS` and `_BFS` methods.

April 2012: Add support for multiple `Notify()` handlers.

May 2012: Add `AcpiOsWaitEventsComplete` OSL interface.

June 2012: Add multiple device support to the Implicit Notify feature.

July 2012: Add `AcpiLoadTable` and `AcpiUnloadParentTable` external interfaces for dynamic load/unload of hotplug related SSDTs. Add `AcpiBiosWarning` and `AcpiBiosError` interfaces for reporting issues specific to the platform BIOS/firmware.

August 2012: Add `AcpiDecodePldBuffer` interface. Remove all support of the deprecated `_GTS` (Going To Sleep) and `_BFS` (Back From Sleep) methods.

October 2012: Add support for `_SUB` to `AcpiGetObjectInfo` interface. Rename `ACPI_DEVICE_ID` to `ACPI_PNP_DEVICE_ID`.

March 2013: Add section to describe the rules that ACPICA uses for the use of internal mutex objects.

May 2013: Add `AcpiDump` utility and related interfaces used to obtain system ACPI tables. Add sections describing the sharing of resources between device drivers and AML code.

June 2013: Add support for multiple instances of the UEFI table.

July 2013: Add `AcpiUpdateInterfaces` interface.

August 2013: Add `AcpiInstallSciHandler`, `AcpiRemoveSciHandler` interfaces. Add Debugger Path and SCI commands.

September 2013: Add description of the ACPICA GPIO event model.





November 2013: Add section describing generation of ACPICA tools from source code.

December 2013: Add new runtime options: `AcpiGbl_DoNotUseXsdt` and `AcpiGbl_Use32BitFadtAddresses`.


## 1.5 Overview of the ACPI Component Architecture

The ACPI Component Architecture (also referred to by the term “ACPICA” in this document) defines and implements a group of software components that together create an implementation of the ACPI specification. A major goal of the architecture is to isolate all operating system dependencies to a relatively small translation or conversion layer (the OS Services Layer) so that the bulk of the ACPICA code is independent of any individual operating system. Therefore, hosting the ACPICA code on new operating systems requires no source changes within the ACPICA code itself. The components of the architecture include:

- An OS-independent, kernel-resident ACPICA Subsystem component that provides the fundamental ACPI services such as the AML interpreter and namespace management.
- An OS-dependent OS Services Layer for each host operating system to provide OS support for the OS-independent ACPICA Subsystem.
- An ASL compiler-disassembler for translating ASL code to AML byte code and for disassembling existing binary ACPI tables back to ASL source code.
- Several ACPI utilities for executing the interpreter in ring 3 user space, extracting binary ACPI tables from the output of the `AcpiDump` utility, and translating the ACPICA source code to Linux/Unix format.

This document describes the ACPICA Subsystem, OS Services Layer, AML Debugger, and related user-space utilities. The iASL compiler is documented in the *iASL: ACPI Source Language Optimizing Compiler and Disassembler User Guide*.

In the diagram below, the ACPICA subsystem is shown in relation to the host operating system, device driver, OSPM software, and the ACPI hardware.

**Figure 1. The ACPI Component Architecture**



## 2 Architecture Overview

### 2.1 Overview of the ACPICA Subsystem

The ACPICA Subsystem implements the low level or fundamental aspects of the ACPI specification. Included are an AML parser/interpreter, ACPI namespace management, ACPI table and device support, and event handling. Since the ACPICA subsystem provides low-level system services, it also requires low-level operating system services such as memory management, synchronization, scheduling, and I/O.

To allow the ACPICA Subsystem to easily interface to any operating system that provides such services, an *Operating System Services Layer* translates ACPICA-to-OS requests into the system calls provided by the host operating system. The OS Services Layer is the only component of the ACPICA that contains code that is specific to a host operating system.

Thus, the ACPICA Subsystem consists of two major software components:

1. The basic kernel-resident ACPICA Subsystem provides the fundamental ACPI services that are independent of any particular operating system.
1. The OS Services Layer (OSL) provides the conversion layer that interfaces the OS-independent ACPICA Subsystem to a particular host operating system.

When combined into a single static or loadable software module such as a device driver or kernel subsystem, these two major components form the *ACPICA Subsystem*. Throughout this document, the term “ACPICA Subsystem” refers to the combination of the OS-independent ACPICA Subsystem with an OS Services Layer components combined into a single module, driver, or load unit.

#### 2.1.1 OS-independent ACPICA Subsystem

The OS-independent ACPICA Subsystem supplies the major building blocks or subcomponents that are required for all ACPI implementations — including an AML interpreter, a namespace manager, ACPI event and resource management, and ACPI hardware support.

One of the goals of the ACPICA Subsystem is to provide an abstraction level high enough such that the host operating system does not need to understand or know about the very low-level ACPI details. For example, all AML code is hidden from the host. Also, the details of the ACPI hardware are abstracted to higher-level software interfaces.

The ACPICA Subsystem implementation makes no assumptions about the host operating system or environment. The only way it can request operating system services is via interfaces provided by the *OS Services Layer*.

The primary user of the services provided by the ACPICA Subsystem are the host OS device drivers and power/thermal management software.



## 2.1.2 Operating System Services Layer


The OS Services Layer (or *OSL*) operates as a translation service for requests from the OS-independent ACPICA subsystem back to the host OS. The OSL implements a generic set of OS service interfaces by using the primitives available from the host OS.

Because of its nature, the OS Services Layer must be implemented anew for each supported host operating system. There is a single OS-independent ACPICA Subsystem, but there must be an OS Services Layer for each operating system supported by the ACPI component architecture.

The primary function of the OSL in the ACPI Component Architecture is to be the small glue layer that binds the much larger ACPICA Subsystem to the host operating system. Because of the nature of ACPI itself — such as the requirement for an AML interpreter and management of a large namespace data structure — most of the implementation of the ACPI specification is independent of any operating system services. Therefore, the OS-independent ACPICA Subsystem is the larger of the two components.

The overall ACPI Component Architecture in relation to the host operating system is diagrammed below.

**Figure 2. ACPICA Subsystem Architecture**





## 2.1.3 Relationships Between Host OS, ACPICA, and Host OSL

### 2.1.3.1 General Architectural Model

The model employed can be described in two parts, the ACPICA-to-host interaction, and the host-to-ACPICA interaction.

- 1) The host OSL implements all OS services required by ACPICA. All ACPICA-to-host interactions pass through the OSL via direct calls to the **AcpiOs\*** interfaces from ACPICA.
- 2) There are two types of host-to-ACPICA interactions, synchronous and asynchronous:

Synchronous: These are host-initiated interactions that are performed by the host making direct calls to the various public **Acpi\*** interfaces.

Asynchronous: These are host-requested interactions that happen in response to various asynchronous events such as ACPI general purpose and fixed events. For these interactions, the host calls ACPICA to install an appropriate handler at initialization time. This handler is then invoked by ACPICA whenever the requested event occurs. Typically, the handlers are optional, and these are *optional* interactions.

### 2.1.3.2 Host Operating System Interaction

The Host Operating System makes direct calls to the **Acpi\*** interfaces within the ACPICA Subsystem to request ACPI services.

Whenever the ACPICA Subsystem requires operating system services, it makes calls the OS Services Layer. The OSL component “calls up” to the host operating system whenever operating system services are required, either for the OSL itself, or on behalf of the ACPICA Subsystem component. All native (OS-dependent) calls made directly to the host are confined to the OS Services Layer. The basic OS-independent ACPICA code contains no operating system-specific code.


### 2.1.3.3 OS Services Layer Interaction

The OS Services Layer provides operating system dependent implementations of the predefined **AcpiOs\*** interfaces. These interfaces provide common operating system services to the ACPICA Subsystem such as memory allocation, mutual exclusion, hardware access, and I/O. The ACPICA Subsystem component uses these interfaces to gain access to OS services in an OS-independent manner. Therefore, the OSL component makes calls to the host operating system to implement the **AcpiOs \*** interfaces.

### 2.1.3.4 ACPICA Subsystem Interaction

The *ACPICA Subsystem* implements a set of external interfaces that can be directly called from the host OS. These **Acpi\*** interfaces provide the actual ACPI services for the host. When operating system services are required during the servicing of an ACPI request, the Subsystem makes requests to the host OS indirectly via the fixed **AcpiOs\*** interfaces.

The diagram below illustrates the relationships and interaction between the various architectural elements by showing the flow of control between them. Note that the OS-independent ACPICA Subsystem never calls the host directly – instead it makes calls to the **AcpiOs \*** interfaces in the OSL. This provides the ACPICA code with OS-independence.

**Figure 3. Interaction between the Architectural Components**


## 2.2 Architecture of the ACPICA Subsystem

The ACPICA Subsystem is divided into several logical modules or sub-components. Each module implements a service or group of related services. This section describes each sub-component and identifies the classes of external interfaces to the components, the mapping of these classes to the individual components, and the interface names.

These ACPICA modules are the OS-independent parts of an ACPI implementation that can share common code across all operating systems. These modules are delivered in source code form (the language used is ANSI C), and can be compiled and integrated into an OS-specific ACPI driver or subsystem (or whatever packaging is appropriate for the host OS.)

The diagram below shows the various internal modules of the ACPICA Subsystem and their relationship to each other. The AML interpreter forms the foundation of the component, with additional services built upon this foundation.

**Figure 4. Internal Modules of the ACPICA Subsystem**



## 2.2.1 ACPI Table Management

This component manages all ACPI tables such as the RSDT/XSDT, FADT, FACS, DSDT, SSDT, etc. The tables may be loaded from the firmware or directly from a buffer provided by the host operating system. Services include:

- ACPI Table Verification
- ACPI Table installation and removal
- Access to all available ACPI tables

## 2.2.2 Early ACPI Table Access

In many cases, certain ACPI tables are required by the host OS very early during system/kernel initialization. For example, the ECDT (Embedded Controller Boot Resources Table) and MADT (Multiple APIC Description Table) may be required before hardware elements can be initialized properly. This initialization and thus these ACPI tables may be required before the kernel dynamic memory (and virtual memory) is available.

To support this need, the ACPICA Table Manager component is designed as a standalone service that can be initialized and used independently from the rest of the ACPICA subsystem. It can be executed with no need for any dynamic memory, and only the need for a single memory mapping at any given time.

## 2.2.3 AML Interpreter

The AML interpreter is responsible for the parsing and execution of the AML byte code that is provided by the computer system vendor. Most of the other services are built upon the AML interpreter. Therefore, there are no direct external interfaces to the interpreter. The services that the interpreter provides to the other services include:



- ACPI Table Parsing
- AML Control Method Execution
- Evaluation of Namespace Objects

## **2.2.4 Namespace Management**

The Namespace component provides ACPI namespace services on top of the AML interpreter. It builds and manages the internal ACPI namespace. Services include:

- Namespace Initialization from ACPI tables
- Device Enumeration
- Namespace Access
- Access to ACPI data and tables

## **2.2.5 Resource Management**

The Resource component provides resource query and configuration services on top of the Namespace manager and AML interpreter. Services include:

- Getting and Setting Current Resources
- Getting Possible Resources
- Getting IRQ Routing Tables
- Getting Power Dependencies

## **2.2.6 ACPI Hardware Management**

The hardware manager controls access to the ACPI registers, timers, and other ACPI-related hardware. Services include:

- ACPI Status register and Enable register access
- ACPI Register access (generic read and write)
- Power Management Timer access
- ACPI mode enable/disable
- Global Lock support
- Sleep Transitions support (S-states)

## **2.2.7 Event Handling**

The Event Handling component manages the ACPI System Control Interrupt (SCI). The single SCI multiplexes the ACPI timer, Fixed Events, and General Purpose Events (GPEs). This component also manages dispatch of notification and Address Space/Operation Region events. Services include:





ACPI event enable/disable (Fixed Events, GPEs)

Fixed Event Handlers (Installation, removal, and dispatch)

General Purpose Event (GPE) Handlers (Installation, removal, and dispatch)

Notify Handlers (Installation, removal, and dispatch)

Address Space and Operation Region Handlers (Installation, removal, and dispatch)


## 2.2.8 Requests from Host OS to ACPIA Subsystem

The host operating system can make direct calls to the Acpi\* external interfaces to request ACPI services.

The exact ACPI services required (and the requests made to those services) will vary from OS to OS. However, it can be expected that most OS requests will fit into the broad categories of the functional service groups described earlier: boot time functions, device load time functions, and runtime functions.

The flow of OS to ACPIA requests is shown in the diagram below.

**Figure 5. Operating System to ACPIA Subsystem Request Flow**



## 2.3 Architecture of the OS Services Layer (OSL)

The OS Services Layer component of the architecture enables the rehosting or retargeting of the ACPIA components to execute under different operating systems, or to even execute in environments where there is no host operating system. In other words, the OSL component provides the glue that joins ACPIA to a particular operating system and/or environment. The OSL implements interfaces and services using the system calls and utilities that are available from the host OS. Therefore, an OS Services Layer must be written for each target operating system.



The OSL component implements a standard set of interfaces that perform OS dependent functions (such as memory allocation and hardware access) on behalf of the OS-independent ACPICA Subsystem component. These interfaces are themselves *OS-independent* because they are constant across all OSL implementations. It is the *implementations* of these interfaces that are OS-dependent, because they must use the native services and interfaces of the host operating system.

These standard interfaces (defined in this document as the **AcpiOs\*** interfaces) include functions such as memory management and thread scheduling, and must be implemented using the available services of the host operating system.

### 2.3.1 Types of OSL Services

The services provided for the OS-independent ACPICA Subsystem by the OS Services Layer can be categorized into the following groups:

- **Environmental** – global initialization and environment setup.
- **Memory Management** – dynamic memory allocation and memory mapping.
- **Multitasking Support** – scheduling and asynchronous execution.
- **Mutual Exclusion and Synchronization** – Mutexes, Semaphores, and Spin Locks.
- **Interrupt handling** – interrupt handlers.
- **Address Spaces** – memory, I/O port, and PCI configuration space access.
- **Stream I/O** – support for console I/O with printf-like functions. This provides error, warning, debug, and trace output from the subsystem.


### 2.3.2 Requests from ACPICA Subsystem to OS

ACPI to OS requests are requests for OS services made by the ACPICA subsystem. These requests must be serviced (and therefore implemented) in a manner that is appropriate to the host operating system. These requests include calls for OS dependent functions such as I/O, resource allocation, error logging, and user interaction. The ACPI Component Architecture defines interfaces to the OS Services Layer for this purpose. These interfaces are constant (i.e. they are *OS-independent*), but they must be implemented uniquely for each target OS.

The flow of ACPI to OS requests is shown in the diagram below.



**Figure 6. ACPICA Subsystem to Operating System Request Flow**





## 3 Design Details

This section contains information about concepts, data types, and data structures that are common to both the OS-independent and OSL components of the ACPICA Subsystem.

### 3.1 ACPI Namespace Fundamentals

The *ACPI Namespace* is a large data structure that is constructed and maintained by the ACPICA Subsystem component. Constructed primarily from the AML defined within an ACPI Differentiated System Description Table (DSDT), the namespace contains a hierarchy of named ACPI objects.

#### 3.1.1 Named Objects

Each object in the namespace has a fixed 4-character name (32 bits) associated with it. The *root object* is referenced by the backslash as the first character in a pathname. Pathnames are constructed by concatenating multiple 4-character object names with a period as the name separator.

#### 3.1.2 Scopes

The concept of an object *scope* relates directly to the original source ASL that describes and defines an object. An object's scope is defined as all objects that appear between the pair of open and close brackets immediately after the object. In other words, the scope of an object is the container for all of the *children* of that object.

In some of the ACPICA interfaces, it is convenient to define a scope parameter that is meant to represent this container. For example, when converting an ACPI name into an object handle, the two parameters required to resolve the name are the *name* itself, and a containing *scope* where the name can be found. When the object that matches the name is found within the scope, a handle to that object can be returned.

##### 3.1.2.1 Example Namespace Scopes, Names, and Objects

In the ASL code below, the scope of the object `_GPE` contains the objects `_L08` and `_L0A`.

```
Scope (\_GPE)
{
    Method (_L08)
    {
        Notify (\_SB.PCI0.DOCK, 1)
    }
    Method (_L0A)
    {
        Store (0, \_SB.PCI0.ISA.EC0.DCS)
    }
}
```

In this example, there are three ACPI namespace *objects*, about which we can observe the following:

The *names* of the three objects are `_GPE`, `_L08`, and `_L0A`.

The *child objects* of parent object `_GPE` are `_L08` and `_L0A`.



The absolute pathname (or fully-qualified pathname) of object `_L08` is “`\_GPE._L08`”.

The scope of object `_GPE` contains both the `_L08` and `_L0A` objects.

The scope of control methods `_L08` and `_L0A` contain executable AML code.

The containing scope of object `_L08` is the scope owned by the object `_GPE`.

The parent of both objects `_L08` and `_L0A` is object `_GPE`.

The type of both objects `_L08` and `_L0A` is **ACPI\_TYPE\_METHOD**.

The next object (or peer object) after object `_L08` is object `_L0A`. In the example `_GPE` scope, there are no additional objects after object `_L0A`.

Since `_GPE` is a namespace object at the root level (as indicated by the preceding backslash in the name), its parent is the root object, and its containing scope is the root scope.

### 3.1.3 Predefined Objects

During initialization of the internal namespace within the ACPICA Subsystem component, there are several predefined objects that are always created and installed in the namespace, regardless of whether they appear in any of the loaded ACPI tables. These objects and their associated types are shown below.


<code>"_GPE"</code>	<code>ACPI_TYPE_ANY</code>	// General Purpose Event block
<code>"_PR_"</code>	<code>ACPI_TYPE_ANY</code>	// Processor block
<code>"_SB_"</code>	<code>ACPI_TYPE_ANY</code>	// System Bus block
<code>"_SI_"</code>	<code>ACPI_TYPE_ANY</code>	// System Indicators block
<code>"_TZ_"</code>	<code>ACPI_TYPE_ANY</code>	// Thermal Zone block
<code>"_REV"</code>	<code>ACPI_TYPE_NUMBER</code>	// Supported ACPI specification revision
<code>"_OS_"</code>	<code>ACPI_TYPE_STRING</code>	// OS Name
<code>"_GL_"</code>	<code>ACPI_TYPE_MUTEX</code>	// Global Lock
<code>"_OSI"</code>	<code>ACPI_TYPE_METHOD</code>	// Query OS Interfaces

### 3.1.4 Logical Namespace Layout

The diagram below shows the logical namespace after the predefined objects and the `_GPE` scope has been entered.



**Figure 7. Internal Namespace Structure**



## 3.2 Execution Model

### 3.2.1 Initialization

The initialization of the ACPICA Subsystem must be driven entirely by the host operating system. Since it may be appropriate (depending on the requirements of the host OS) to initialize different parts of the ACPICA Subsystem at different times, this initialization is split into a multi-step process. The four main steps are outlined below.

1. Perform a global initialization of the ACPICA Subsystem – this initializes the global data and other items within the subsystem.
2. Initialize the table manager and load the ACPI tables – The FADT, FACS, DSDT, and SSDTs must be acquired and mapped before the internal namespace can be constructed. The tables may be loaded from the firmware, loaded from an input buffer, or some combination of both. The minimum set of ACPI tables includes an RSDT/XSDT, FADT, FACS, and a DSDT. Any SSDTs are optional. All other ACPI tables defined by the ACPI specification are not directly used by the ACPICA subsystem, but they are available to ACPI-related device drivers via the table manager external interfaces. These tables include the MADT, ECDT, etc.
3. Build the internal namespace – this causes ACPICA to parse the DSDT and any SSDTs and build an internal namespace from the objects found therein.
4. Enable ACPI mode of the machine. Before ACPI events can occur, the machine must be put into ACPI mode. The ACPICA Subsystem installs an interrupt handler for the System Control Interrupts (SCIs), and transitions the hardware from legacy mode to ACPI mode.



## 3.2.2 Memory Allocation

There are two models of memory allocation that can be used. In the first model, the caller to the ACPICA subsystem pre-allocates any required memory. This allows maximum flexibility for the caller since only the caller knows what is the appropriate memory pool to allocate from, whether to statically or dynamically allocate the memory, etc. In the second model, the caller can choose to have the ACPICA subsystem allocate memory via the `AcpiOsAllocate` interface. Although this model is less flexible, it is far easier to use and is sufficient for most environments.

Each memory allocation model is described below.

### 3.2.2.1 Caller Allocates All Buffers

In this model, the caller preallocates buffers of a large enough size and posts them to the ACPICA subsystem via the `ACPI_BUFFER` data type.

It is often the case that the required buffer size is not known by even the ACPICA subsystem until after the evaluation of an object or the execution of a control method has been completed. Therefore, the “get size” model of a separate interface to obtain the required buffer size is insufficient. Instead, a model that allows the caller to pre-post a buffer of a large enough size has been chosen. This model is described below.

For ACPI interfaces that use the `ACPI_BUFFER` data type as an output parameter, the following protocol can be used to determine the exact buffer size required:

1. Set the buffer length field of the `ACPI_BUFFER` structure to zero, or to the size of a local buffer that is thought to be large enough for the data.
2. Call the Acpi interface.
3. If the return exception code is **AE\_BUFFER\_OVERFLOW**, the buffer length field has been set by the interface to the buffer length that is actually required.
4. Allocate a buffer of this length and initialize the length and buffer pointer field of the `ACPI_BUFFER` structure.
5. Call the Acpi interface again with this valid buffer of the required length.

Alternately, if the caller has some idea of the buffer size required, a buffer can be posted in the original call. If this call fails, only then is a larger buffer allocated. See Section 6.2.6 – “`ACPI_BUFFER` – Input and Output Memory Buffers” for additional discussion on using the `ACPI_BUFFER` data type.

### 3.2.2.2 ACPI Allocates Return Buffers

In this model, the caller lets the ACPICA subsystem allocate return buffers. It is the responsibility of the caller to delete these returned buffers.

For the ACPI interfaces that use the `ACPI_BUFFER` data type as an output parameter, the following protocol is used to allow the ACPICA subsystem to allocate return buffers:

1. Set the buffer length field of the `ACPI_BUFFER` structure to **ACPI\_ALLOCATE\_BUFFER**.
2. Call the Acpi interface.
3. If the return exception code is **AE\_OK**, the interface completed successfully and a buffer was allocated. The length of the buffer is contained in the `ACPI_BUFFER` structure.



4. Delete the buffer by calling `AcpiOsFree` with the pointer contained in the `ACPI_BUFFER` structure (do not use **ACPI\_FREE**).

### 3.2.3 Parameter Validation

Only limited parameter validation is performed on all input parameters passed to the ACPICA Subsystem. Therefore, the host OS should perform all limit and range checks on buffer pointers, strings, and other input parameters before passing them down to the ACPICA Subsystem code.

The limited parameter validation consists of sanity checking input parameters for null pointers and out-of-range values and nothing more. Any additional parameter validation (such as buffer length validation) must occur before the host calls the ACPICA code.

### 3.2.4 Exception Handling

All exceptions that occur during the processing of a request to the ACPICA Subsystem are returned in an `ACPI_STATUS` return code and bubbled up to the original caller. Names for the ACPICA exceptions are all prefixed with “AE\_”. For example, `AE_OK` indicates successful completion of a request.

All exception handling is performed inline by the caller to the ACPICA Subsystem interfaces. There are no exception handlers associated with either the **Acpi\*** or **AcpiOs\*** calls.

### 3.2.5 Multitasking and Reentrancy

All components of the ACPICA subsystem are intended to be fully reentrant and support multiple threads of execution. To achieve this, there are several mutual exclusion OSL interfaces that must be properly implemented with the native host OS primitives to ensure that mutual exclusion and synchronization can be performed correctly. Although dependent on the correct implementation of these interfaces, the ACPICA Subsystem is otherwise fully reentrant and supports multiple threads throughout the component, with the exception of the AML interpreter, as explained below.

Because of the constraints of the ACPI specification, there is a major limitation on the concurrency that can be achieved within the AML interpreter portion of the subsystem. The specification states that at most one control method can be actually executing AML code at any given time. If a control method blocks (an event that can occur only under a few limited conditions), another method may begin execution. However, it can be said that the specification precludes the concurrent execution of control methods. Therefore, the AML interpreter itself is essentially a single-threaded component of the ACPICA subsystem. Serialization of both internal and external requests for execution of control methods is performed and managed by the front-end of the interpreter.

### 3.2.6 Event Handling

The term *Event Handling* is used somewhat loosely to describe the class of asynchronous events that can occur during the execution of the ACPICA subsystem. These events include:

- System Control Interrupts (SCIs) that are generated by both the ACPI Fixed and General Purpose Events.
- Notify events that are generated via the execution of the ASL *Notify* keyword in a control method.





- Events that are caused by accesses to an address space or operation region during the execution of a control method.

Each of these events and the support for them in the ACPICA subsystem are described in more detail below.

### 3.2.6.1 Fixed Events

Incoming Fixed Events can be handled by the default ACPICA subsystem event handlers, or individual handlers can be installed for each event. Only device drivers or system services should install such handlers.

### 3.2.6.2 General Purpose Events

Incoming General Purpose Events (GPEs) are usually handled by executing a control method that is associated with a particular GPE. According to the ACPI specification, each GPE level may have a method associated with it whose name is of the form **\_Exx** for edge-triggered or **\_Lxx** for level-triggered. **xx** is the GPE level in hexadecimal (See the ACPI specification for complete details.) This control method is never executed in the context of the SCI interrupt handler, but is instead queued for later execution by the host operating system.

In addition to this mechanism, individual handlers for GPE levels may be installed. It is not required that a handler be installed for a GPE level, and in fact, currently the only device that requires a dedicated GPE handler is the ACPI Embedded Controller. A device driver for the Embedded Controller would install a handler for the GPE that is dedicated to the EC.

If a GPE handler is installed for a given GPE, the handler takes priority and any **\_Exx/\_Lxx** method for that GPE is no longer invoked.

GPE Block Devices are also supported. These GPE blocks may be installed and removed dynamically as necessary. The ACPICA Subsystem provides centralized GPE handling and dispatch, and provides the necessary interfaces to install and remove GPE Block Devices.

### 3.2.6.3 Notify Events

An ACPI Notify Event occurs as a result of the execution of a *Notify* opcode during the execution of a control method. A notify event occurs on a particular ACPI object, and this object must be a device or thermal zone. If a handler is installed for notifications on a particular device, this handler is invoked during the execution of the *Notify* opcode, in the context of the thread that is executing the control method.

Notify handlers should be installed by device drivers and other system services that know about the particular device or thermal zone on which notifications will be received.

## 3.2.7 Address Spaces and Operation Regions

ASL source code and the corresponding AML code use the *Address Space* mechanism to access data that is out of the direct scope of the ASL. For example, Address Spaces are used to access the CMOS RAM and the ACPI Embedded Controller. There are several predefined Address Spaces that may be accessed and user-defined Address Spaces are allowed.

The Operating System software (which includes the AML Interpreter) allows access to the various address spaces via the ASL *Operation Region* (OpRegion) construct. An OpRegion is a named window into an address space. During the creation of an OpRegion, the ASL programmer defines



both the boundaries (window size) and the address space to be accessed by the OpRegion. Specific addresses within the access window can then be defined as named *fields* to simplify their use.

The AML Interpreter is responsible for translating ASL/AML references to named *Fields* into accesses to the appropriate Address Space. The interpreter resolves locations within an address space using the fields' address within an OpRegion and then the OpRegion's offset within the address space. The resolved address, address access width, and function (read or write) are then passed to the address space handler who is responsible for performing the actual physical access of the address space.

### 3.2.7.1 Installation of Address Space Handlers

At runtime, the ASL/AML code cannot access an address space until a handler has been installed for that address space. An ACPICA user can either install the default address space handlers or install user defined address space handlers using the *AcpiInstallAddressSpaceHandler* interface.

Each Address Space is “owned” by a particular device such that all references to that address space within the *scope* of the device will be handled by that device's address space handler. This mechanism allows multiple address space/operation region handlers to be installed for the same *type* of address space, each mutually exclusive by virtue of being governed by the ACPI address space scoping rules. For example, picture a platform with two SMBus devices, one an embedded controller based SMBus; the other a PCI based SMBus. Each SMBus must expose its own address space to the ASL without disrupting the function of the other. In this case, there may be two device drivers and two distinctly different address space handlers, one for each type of SMBus. This mechanism can be employed in a similar manner for the other predefined address spaces. For example, the PCI Configuration space for each PCI bus is unique to that bus. Creation of a region within the scope of a PCI bus must refer only to that bus.

Address space handlers must be installed on a named object in the ACPI namespace or on the special object ACPI\_ROOT\_OBJECT. This is required to maintain the scoping rules of address space access. Address handlers are installed for the namespace object representing the device that “owns” that address space. Per ASL rules, regions that access that address space must be declared in the ASL within the scope of that namespace object.

It is the responsibility of the ACPICA user to enumerate the namespace and install address handlers as needed.

### 3.2.7.2 ACPI-Defined Address Spaces

The ACPI specification defines address spaces for:

- System Memory
- System I/O
- PCI Configuration Space
- System Management Bus (SMBus)
- Embedded Controller
- CMOS
- PCI Bar Target
- IPMI (ACPI 4.0)
- General Purpose I/O (ACPI 5.0)
- Generic Serial Bus (ACPI 5.0)



The ACPICA subsystem implements default address space handlers for the following ACPI defined address spaces:

- System Memory
- System I/O
- PCI Configuration Space

Default address space handlers can be installed by supplying the special value `ACPI_DEFAULT_HANDLER` as the handler address when calling the *AcpiInstallAddressSpaceHandler* interface.

The other predefined address spaces (such as Embedded Controller and SMBus) have no default handlers and will not be accessible without OS provided handlers. This is typically the role of the Embedded Controller, SMBus, and other ACPI-related device drivers.

### 3.2.7.3 Sharing Resources between Device Drivers and AML

There may be situations where an ACPI-related device driver and the associated ASL/AML code must share device registers, memory locations, etc.

ACPICA provides a mechanism to allow the device driver to own these locations and registers such that all AML access is automatically forwarded to the driver. A custom address space handler can manage these shared resources.

Device drivers and OSPM code can install a custom address space handler for any particular device so that the driver has exclusive control over access to the device registers. ACPICA allows each and every device in the namespace to have a unique address space handler (for any of the ACPI address spaces). Whenever the ASL code for the device executes and accesses the registers/locations (via an Operation Region), the device driver address space handler will be invoked, thus giving the driver complete control over the shared resource.

Note: The custom address space handler will intercept only those accesses that are performed by the ASL code that is within the scope of the device where it is installed. This does not affect handling of accesses for any other devices in the namespace. For example, the default SystemIO space handler might be used for all I/O access in the entire namespace except for a particular device where a custom handler is installed because of the need to share I/O ports.



### 3.2.7.3.1 ASL Shared Resource Example

Below is a snippet of ASL code that defines and accesses an I/O Operation Region and several shared I/O registers (**COST** and **VREG**).

```
Scope (_SB)
{
    Device (PCI0)
    {
        Name (_HID, EisaId ("PNP0A08")) // _HID: Hardware ID

        Device (PS2K)
        {
            Name (_HID, EisaId ("PNP0303")) // _HID: Hardware ID

            OperationRegion (PKBS, SystemIO, 0x60, 0x05)
            Field (PKBS, WordAcc, Lock, Preserve)
            {
                COST,    16,
                VREG,    16
            }

            Method (_AC0, 0, NotSerialized)
            {
                And (COST, 0xFFFF, COST)
                Store (0x1234, VREG)
                Or (COST, 0xFFFF6, COST)

                Store (COST, Debug)
                Return (COST)
            }
        }
    }
}
```

### 3.2.7.3.2 Custom Address Space Handler Installation

In order to trap accesses to the registers defined in the example above, the device driver must obtain a handle to the device in the ACPI namespace and then install a custom address space handler for the device. Once the address space handler is installed, all ASL/AML accesses to the **PKBS** Operation Region (above) via the **COST** and **VREG** I/O ports will be forwarded to the driver for processing.

```
Status = AcpiGetHandle (NULL, "\\_SB.PCI0.PS2K", &ObjHandle);

Status = AcpiInstallAddressSpaceHandler (ObjHandle, ACPI_ADR_SPACE_SYSTEM_IO,
    RegionHandler, RegionInit, MyContext);
if (ACPI_FAILURE (Status))
{
    ACPI_EXCEPTION ((AE_INFO, Status,
        "Could not install an OpRegion handler for PS2K device (%p)",
        ObjHandle));
}
```



Using the `acpiexec` utility and executing the "handlers" command, we see that the custom handler for `\_SB_.PCI0.PS2K` has been installed:

```
- handlers

Operation Region Handlers at the namespace root:
    SystemMemory (00) : User      (00422A30) /* default acpiexec handler */
    SystemIO (01) : User      (00422A30) /* default acpiexec handler */

Operation Region Handlers for specific devices:
    SystemIO (01) : User      (00422280) Device Name: \_SB_.PCI0.PS2K
```

Executing the `_AC0` method (which accesses the I/O registers defined in the **PKBS** Operation Region), we see that the custom SystemIO handler for `\_SB_.PCI0.PS2K` is invoked multiple times:

```
- evaluate \_SB_.PCI0.PS2K._AC0

Evaluating \_SB_.PCI0.PS2K._AC0
ACPI: PCI0.PS2K SystemIO request at: 0x0000000000000060 [READ]
ACPI: PCI0.PS2K SystemIO request at: 0x0000000000000060 [WRITE]
ACPI: PCI0.PS2K SystemIO request at: 0x0000000000000062 [WRITE]
ACPI: PCI0.PS2K SystemIO request at: 0x0000000000000060 [READ]
ACPI: PCI0.PS2K SystemIO request at: 0x0000000000000060 [WRITE]
ACPI: PCI0.PS2K SystemIO request at: 0x0000000000000060 [READ]
[ACPI Debug] Integer 0x0000000000000000
ACPI: PCI0.PS2K SystemIO request at: 0x0000000000000060 [READ]
Evaluation of \_SB_.PCI0.PS2K._AC0 returned object 00323EC8, buffer length 10
[Integer] = 0000000000000000
```

## 3.3 Policies and Philosophies

This section provides insight into the policies and philosophies that were used during the design and implementation of the ACPICA Subsystem. Many of these policies are a direct interpretation of the ACPI specification. Others are a direct or indirect result of policies and procedures dictated by the ACPI specification. Still others are simply standards that have been agreed upon during the design of the subsystem.

### 3.3.1 External Interfaces

#### 3.3.1.1 Exception Codes

All external interfaces (Acpi\*) return an exception code as the function return. Any other return values are returned via pointer(s) passed as parameters. This provides a consistent and simple synchronous exception-handling model.

Since the ACPICA Subsystem is reentrant and supports multiple threads on multiple operating systems, a model where an exception code is stored in the task descriptor (such as the *errno* mechanism) was purposefully avoided to improve portability.

#### 3.3.1.2 Memory Buffers

Memory for return objects, buffers, etc. that is returned via the external interfaces is rarely allocated by the subsystem itself. The model chosen is to force the caller to always pre-allocate memory. This forces the calling software to manage both the creation and deletion of its own buffers — hopefully



minimizing memory fragmentation and avoiding memory leaks. The exception to this is the ACPI\_BUFFER type, where the caller can direct the ACPICA subsystem to allocate return buffers.

## 3.3.2 Subsystem Initialization

### 3.3.2.1 ACPI Table Validation

All ACPI tables that are examined by the ACPICA Subsystem undergo some minimal validation before they are accepted. This includes all tables found in the RSDT regardless of whether the signature is recognized, and all tables loaded from user buffers. The following validations are performed on each table. A warning is issued for tables that do not pass one or more of these tests:

1. The Table pointer must point to valid physical memory
2. The signature (in the table header) must be 4 ASCII chars, *even if the name is not recognized*.
3. The table must be readable for length specified in the header
4. The table checksum must be valid (with the exception of the FACS, which has no checksum).

Other than this validation, tables that are not recognized by their table header signature are simply ignored.

### 3.3.2.2 Required ACPI Tables

At the very minimum, the ACPICA Subsystem requires the following ACPI tables:

1. One *Fixed ACPI Description Table* (FADT — signature “FACP”). This table contains configuration information about the ACPI hardware and pointers to the FACS and DSDT tables.
2. One *Firmware ACPI Control Structure* (FACS). This table contains the OS-to-firmware interface including the firmware waking vector and the Global Lock.
3. One *Differentiated System Description Table* (DSDT). This table contains the primary AML code for the system.
4. Optional are one or more *Secondary System Description Tables* (SSDTs) that contain additional AML code. All SSDTs found in the RSDT/XSDT root table are loaded during the table/namespace initialization. Other SSDTs and OEM tables can be loaded at runtime via the *Load* or *LoadTable* AML operators.

## 3.3.3 Major Design Decisions

### 3.3.3.1 Performance versus Code/Data Size

The ACPICA subsystem is optimized to minimize code and data size at the expense of performance. The relatively static internal namespace data structure has been optimized to minimize non-paged kernel memory use, and control method execution parse trees are freed immediately upon method termination.



### **3.3.3.2 Object Management – No Garbage Collection**

Creation and deletion of all internal objects are managed such that garbage collection is never required or performed. Objects are deleted deterministically when they are no longer needed. This is achieved through the use of object reference counts and object trees.

Internal object caches allow the reuse of commonly used objects without burdening the OS free space manager. This greatly improves the performance of the entire subsystem.



## 4 Implementation Details

### 4.1 Required Host OS Initialization Sequence

This section describes a generic operating system initialization sequence that includes the ACPICA subsystem. The ACPICA subsystem must be loaded very early in the kernel initialization. In fact, ACPI support must be considered to be one of the fundamental startup modules of the kernel. The basic OS requirements of the ACPICA subsystem include memory management, synchronization primitives, and interrupt support. As soon as these services are available, ACPICA should be initialized. Only after ACPI is available can motherboard device enumeration and configuration begin.

In summary, ACPI Tables are descriptions of the hardware, therefore must be loaded into the OS very early.

#### 4.1.1 Bootload and Low Level Kernel Initialization

- OS is loaded into memory via bootloader or downloader
- Initialize OS data structures, objects and run-time environment
- Initialize low-level kernel subsystems
- Initialize ACPI Table Manager if early ACPI table access is required
- Initialize and enable free space manager
- Initialize and enable synchronization primitives
- Initialize basic interrupt mechanism and hardware
- Initialize and start system timer

#### 4.1.2 ACPICA Subsystem Initialization

- Initialize ACPICA Table Manager and Load ACPI Tables
- Initialize Namespace
- Initialize ACPI Hardware and install SCI interrupt handler
- Initialize ACPI Address Spaces (Default handlers and user handlers)
- Initialize ACPI Objects (\_STA, \_INI)
- Find PCI Root Bus(es) and install PCI config space handlers

#### 4.1.3 Other OS Initialization

- Remaining non-ACPI Kernel initialization
- Initialize and start System Resource Manager
- Determine processor configuration





#### 4.1.4 Device Enumeration, Configuration, and Initialization

- Match motherboard devices to drivers via \_HID
- Initialize PCI subsystem: Obtain \_PRT interrupt routing table and Initialize PCI routing. PCI driver enumerates PCI bus and loads appropriate drivers.
- Initialize Embedded Controller support/driver
- Initialize SM Bus support/driver
- Load and initialize drivers for any other motherboard devices

#### 4.1.5 Final OS Initialization

- Load and initialize any remaining device drivers
- Initialize upper layers of the OS
- Activate user interface

### 4.2 Required ACPICA Initialization Sequence

This section presents a detailed description of the initialization process for the ACPICA subsystem. The initialization interfaces are provided at a sufficient granularity to allow customization of the initialization sequence for each host operating system and host environment.

#### 4.2.1 Global Initialization – AcpiInitializeSubsystem

This mandatory step begins the initialization process and must be first. It initializes the ACPICA Subsystem software, including all global variables, tables, and data structures. All components of the ACPICA Subsystem are initialized, including the OSL interface layer and the OSPM layer. The interface provided is *AcpiInitializeSubsystem*.

#### 4.2.2 ACPI Table and Namespace Initialization

This required phase loads the ACPI tables from the BIOS and initializes the internal ACPI namespace.

##### 4.2.2.1 AcpiInitializeTables

This function initializes the ACPICA Table Manager. This component is independent of the rest of the ACPICA subsystem and may be initialized and executed at any time during kernel initialization, even before dynamic/virtual memory is available. This allows the ACPI tables to be acquired very early in the kernel initialization process. Some ACPI tables are required during early kernel initialization/configuration – such as the SLIT (System Locality Distance Information Table), SRAT (System Resource Affinity Table), and MADT (Multiple APIC Description Table.)

##### 4.2.2.2 AcpiGetTable, AcpiGetTableHeader, AcpiGetTableByIndex

These functions may be used by the host OS and device drivers to obtain individual ACPI tables as necessary. The only ACPI tables that are consumed by the ACPICA subsystem are the FADT, FACS, DSDT, and any SSDTs. All other ACPI tables present on the platform must be consumed by



the host OS and device drivers. For example, the ECDDT (Embedded Controller Boot Resources Table) is used by the host-dependent Embedded Controller device driver.

### 4.2.2.3 AcpiLoadTables

This interface creates the internal ACPI namespace data structure from the DSDT and SSDTs found in the RSDT/XSDT root table. All SSDTs found in the root table are loaded. Other SSDTs may be loaded by AML code at runtime via the AML Load operator. OEM tables that appear in the RSDT/XSDT can only be loaded via the AML LoadTable operator.

### 4.2.2.4 Internal ACPI Namespace Initialization

As the various ACPI tables are loaded (installed into the internal data structures of the CA subsystem), the internal ACPI Namespace (database of named ACPI objects) is constructed from those tables. As each table is loaded, the following tasks are automatically performed:

- First pass parse – Load all named ACPI objects into the internal namespace
- Second pass parse – Resolve all forward references within the ACPI table
- First pass parse of all control methods – Sanity check to ensure that the tables can be completely parsed, including the control methods. The resulting parse tree is not stored, since control methods are parsed on the fly every time they are executed. (This task represents minimal CPU overhead, and saves huge amounts of memory that would be consumed by storing parse trees.)
- Lock the namespace so that GPEs will not cause control methods to run

## 4.2.3 Hardware Initialization – AcpiEnableSubsystem

This step continues the subsystem initialization and is more hardware oriented. It first puts the system into ACPI mode, then installs the default Operation Region handlers, initializes the event manager, and installs the SCI and Global Lock handlers.

During the event manager initialization, fixed events are initialized and enabled. GPEs are initialized, but are not enabled at this time.

To summarize the actions performed by this call:

- Enter ACPI Mode.
- Install default operation region handlers for the following address spaces that must always be available: SystemMemory, SystemIO, PCI\_Config, and DataTable.
- Initialize ACPI Fixed and General Purpose events (not enabled at this time, however.)
- Install the SCI and Global Lock interrupt handlers.

### 4.2.3.1 ACPI Hardware and Event Initialization

This step puts the system into ACPI mode if necessary, sets up the ACPI hardware, initializes the ACPI Event handling, and installs the ACPI interrupt handlers. This step is optional when running in “hardware-independent” mode – when there is no access to hardware by the ACPICA subsystem (For example, the *AcpiExec* utility runs in this mode.)



The ACPI hardware must be initialized and an SCI interrupt handler must be installed before it is architecturally safe to evaluate ACPI objects and execute control methods, for the following reasons:

1. Any ACPI named object (predefined or otherwise) can be implemented as a control method and there is no way to safely make any assumptions about which objects are and are not implemented as control methods. This is dependent on the individual AML on each platform.
2. Because control methods can access the ACPI hardware, cause ACPI interrupts (SCIs), and most interesting of all, *can block while waiting for an SCI to be serviced*, it is inherently unsafe and architecturally incorrect to attempt to execute control methods without first initializing the hardware and installing the SCI interrupt handler

This step is only optional when running in “hardware-independent” mode. Otherwise it is required to setup the ACPI hardware and System Control Interrupt handling. ACPI mode is entered if the machine is in legacy mode. If the machine is already in ACPI mode (such as an IA-64 machine), no action is required.

When this step is complete, control methods may be executed because the hardware is now initialized and the subsystem is able to take ACPI-related interrupts (*System Control Interrupts or SCIs*). The execution of any control method (including the **\_REG** methods) can cause the generation of an SCI – therefore, the hardware must be initialized before control methods may be run. Additional ACPICA subsystem initialization that requires control method execution can now be completed.

## 4.2.4 Handler Installation

Once the namespace has been constructed and the hardware has been initialized, the OS should install any handlers that it may require during execution of the ACPICA subsystem. The purpose of installing these handlers at this point in the initialization process is so that the handlers are in place before execution of any control methods is allowed – thereby insuring that any custom handlers will not miss any of the events that they are intended to handle. Any handlers installed in this phase will override any default handlers.

### 4.2.4.1 Handler Types

The following handler installation interfaces are available

**Initialization Handler:** *AcpiInstallInitializationHandler*

This function is used to install a global handler for ACPICA initialization events. Currently, the handler is called after the execution of every device **\_INI** method.

**Table Event Handler:** *AcpiInstallTableHandler*

This function is used to install a global handler for ACPI table load/unload events.

**AML Exception Handler:** *AcpiInstallExceptionHandler*

This function is used to install a global handler for AML run-time exceptions.

**Address Space Handlers:** *AcpiInstallAddressSpaceHandler*

This function is used to install address space handlers to override the default address space handlers (for the predefined address spaces) or install handlers for custom address spaces. These handlers are invoked to implement Operation Region requests. Note: during the installation, any



\_REG methods associated with the SpaceID are executed. Thus, the Address Space Handlers can only be installed after the hardware has been initialized.

**Fixed Event Handlers:** *AcpiInstallFixedEventHandler*

This function is used to install handlers for ACPI Fixed Events.

**General-Purpose Event Handlers:** *AcpiInstallGpeHandler*

This function is used to install handlers for ACPI General Purpose Events (GPEs).

**Notify Handlers:** *AcpiInstallNotifyHandler*

This function is used to install handlers for ACPI device, thermal zone, and processor notifications.

## 4.2.5 Object Initialization – AcpiInitializeObjects

This step completes the initialization of all objects within the loaded namespace, then initializes and enables the runtime general-purpose events:

- Initialize all Operation Regions. This step runs all Operation Region \_REG methods for the address spaces with default handlers – SystemMemory, SystemIO, PCI\_Config, and DataTable. Note: Operation Regions that are declared within control methods are not initialized until actual execution of the method.
- Finish initialization of complex objects (Operation Regions, BufferFields, Buffers, BankFields, and Packages) that contain executable AML code within the declaration.
- Initialize all Device, Processor and Thermal objects within the namespace by executing the \_STA and \_INI methods on each of these objects.
- Initialize the FADT-defined GPE blocks.
- Execute all \_PRW methods within the namespace. These methods identify and define the GPEs that are used for wake events. These types of GPEs are never enabled at runtime, they are only enabled as the system enters a sleep state.
- Enable all runtime GPEs. The GPEs can only be enabled after the \_REG, \_STA, and \_INI methods have been run. This ensures that all Operation Regions and all Devices have been initialized and are ready.

### 4.2.5.1 ACPI Device Initialization

During this step, all Device, Processor, and Thermal objects found within the ACPI namespace are initialized. The \_INI method is executed for all devices that are present as indicated by the \_STA method. This is *not* an actual initialization of the device hardware – this is left to the actual device drivers for the hardware.

The entire namespace is traversed and the \_STA and \_INI methods are run on all ACPI objects of type *Device*, *Processor*, and *Thermal* found therein. Any operation regions accessed by these methods will be automatically initialized by the just-in-time address space initialization mechanism. The initialization is performed via the following steps:

- A namespace analysis is performed to identify all subtrees that contain devices that have a corresponding \_INI method. This greatly enhances the speed of this step and can reduce



operating system boot time. If there is no **\_INI** method for a given device, then no attempt is made to execute the **\_STA** method for the device.

- If the device has an **\_INI** method, attempt to execute the **\_STA** method for the device.
- If **\_STA** does not exist within the scope of the device, the device is assumed to be both *present* and *functional* – as per the ACPI specification.
- If the **\_STA** flags indicate the device is *not present* but *functioning*, do not run **\_INI** on the device, but continue to examine the children of the device.
- If the **\_STA** flags indicate the device is *not present* and *not functioning*, do not examine the children of this device – abort the walk of this subtree of the namespace.
- If the **\_STA** flags indicate that the device is *present*, then attempt to execute the **\_INI** method for the device.
- The global initialization handler is called after the execution of every **\_INI** method.

#### 4.2.5.2 Other ACPI Object Initialization

This step initializes the remaining AML Operation Regions and Fields that were not initialized during the device and address space initialization.

Operation Regions and CreateField ASL statements can contain executable AML code and therefore the initialization of the objects must be deferred until the CA subsystem and ACPI hardware are both initialized. Some of this initialization may have been completed during the earlier steps. This step completes that initialization.

This final pass through the loaded ACPI tables will execute all AML code outside of the control methods that has not already been executed on-demand during the previous phases. The purpose is to initialize the Field and OpRegion objects by executing all CreateField, OperationRegion code in the AML. ACPI 2.0 has additional elements that will need to be initialized this way (*Not yet implemented.*)

#### 4.2.6 Other Operating System ACPI-related Initialization

All external ACPI interfaces are available and the host OS can perform the following initialization steps:

- Enumerate devices using the **\_HID** method
- Load, configure, and install device drivers
- Device Drivers install handlers for other address spaces such as SMBus, EC, IPMI, and custom address spaces
- The PCI driver enumerates PCI devices and loads PCISConfig handlers for PCI-to-PCI-bridge devices (which causes the associated child PCI bus **\_REG** methods to run, etc.)

#### 4.2.7 Just-in-time Operation Region Initialization

This phase includes just-in-time initialization for any Operation Regions, Packages, Buffers, or Fields that are accessed by the control methods executed here. For example, if a **\_REG** method for a PCISConfig address space accesses a SystemMemory Operation Region, the definition of that



particular SystemMemory region is fully evaluated at that time. (Operation Regions and CreateField ASL statements can contain executable AML code and therefore the initialization of the objects must be deferred until the CA subsystem and ACPI hardware are both initialized).

Therefore, Address Spaces are initialized *in the order in which they are accessed*, not in the order that they are declared in the ASL source code.

When any Address Space is initialized, the associated **\_REG** method (if any) is executed as well.

#### 4.2.7.1 SystemMemory Region Initialization

For each operation region within the SystemMemory address space, a memory mapped window of maximum size **ACPI\_SYSMEM\_REGION\_WINDOW\_SIZE** is maintained, in an attempt to minimize the overhead of mapping entire operation regions if they are very large.

When a request is received that is outside of the current window, the existing mapping is deleted and a new mapping that can service the request is created.

This mapping feature is implemented in the default handler for the SystemMemory address space.

#### 4.2.7.2 PCI\_Config Region Initialization

For these operation regions, the namespace is searched upwards from the region to find the corresponding PCI Root Bridge.

If a **\_HID** or **\_CID** method under a device object indicates the presence of a PCI Root Bridge (an ID value of PNP0A03 or PNP0A08 for PCI Express), perform PCI Configuration Space initialization on the bridge. Install the PCI address space handler on the bridge (and on all descendents) and run the **\_REG** method for the device if it is present. Then execute the **\_ADR**, **\_SEG**, and **\_BBN** methods (in the bridge scope) to obtain the PCI Device, Function, Segment, and Bus numbers. Finally, run the associated **\_REG** method to indicate the availability of the region.

- The initial PCI Device and Function values are obtained from the **\_ADR** method.
- The initial PCI Segment number is obtained from the **\_SEG** method.
- The initial PCI Bus number is obtained from the **\_BBN** method.
- The final PCI ID consisting of Device, Function, Segment, and Bus is obtained by calling the *AcpiHwDerivePciId* OSL interface. This function adjusts the Bus, Device, and Function numbers based upon the PCI device tree and the PCI configuration space registers. This allows for a dynamic value for the Bus number based upon the hardware configuration and initialization.

When accessing a PCI\_Config operation region, all I/O from/to the PCI configuration space is performed via the OSL interfaces *AcpiOsReadPciConfiguration* and *AcpiOsWritePciConfiguration*.

The (internal) *AcpiHwDerivePciId* function derives a full PCI ID for a PCI device, consisting of a Segment number, a Bus number, and a Device number.

The PCI hardware dynamically configures PCI bus numbers depending on the bus topology discovered during system initialization. The *AcpiHwDerivePciId* function is invoked by the ACPICA subsystem during configuration of a *PCI\_Config* Operation Region in order to (possibly) update the Bus number in the *PciId* with the actual Bus number as determined by the hardware and operating system configuration.



The *PciId* parameter is initially populated by the ACPICA subsystem during the Operation Region initialization. ACPICA then calls *AcpiHwDerivePciId*, which makes any necessary modifications to the Segment, Bus, or Device number PCI ID subfields as appropriate for the current hardware and OS configuration.

## 4.2.8 System Shutdown – AcpiTerminate

This step frees all dynamically allocated resources back to the host operating system. The ACPICA subsystem may be re-initialized and restarted from the beginning anytime after this step completes.

## 4.3 Multithreading Support

### 4.3.1 Reentrancy

All external interfaces to the ACPICA Subsystem are fully reentrant. There are limitations to the amount of concurrency allowed during control method execution, but these limitations are transparent to the calling threads — in the sense that threads that attempt to execute control methods will simply block until the interpreter becomes available.

### 4.3.2 Mutual Exclusion and Synchronization

Three different types of synchronization objects are used by the ACPICA code:

3. **Mutex objects.** These objects are used for high-level mutual exclusion within the ACPICA Subsystem and AML interpreter and to implement the ASL Mutex operators, as well as the ACPI Global Lock. If there are no mutex primitives available in the host OS, they can be implemented with semaphore objects (binary semaphores.)
4. **Semaphore objects.** These objects are used for synchronization and to implement the ASL Event operators.
5. **Spin Locks.** These objects are only used at interrupt level (in interrupt handlers).

#### 4.3.2.1 Internal use of Mutex Objects

ACPICA defines the following mutex objects for internal use:

**Interpreter:** Lock for the entire AML interpreter

**Namespace:** Lock for the internal ACPI namespace data structure

**Tables:** Lock for the data structures for the ACPI tables received from the BIOS

**Events:** Lock for the data structures related to ACPI events (GPEs, Fixed Events, etc.)

**Caches:** General lock for internal caches

**Memory:** Lock for the debug-only memory tracking list(s)

**Debug Command Complete:** Synchronization for the AML debugger

**Debug Command Ready:** Synchronization for the AML debugger





When using these mutex objects, ACPICA obeys the following rules:

- 1) Mutex objects are always acquired in the order of the objects defined above. For example, if the Tables lock has been acquired, the Namespace or Interpreter lock will never be subsequently acquired .
- 2) However, the acquisition of a mutex does not imply or require that previous mutex objects must be acquired. In other words, the Namespace lock may be acquired without holding the Interpreter lock.
- 3) Mutex objects are never acquired recursively by ACPICA.
- 4) Mutex objects are always released in the reverse of the acquisition order.
- 5) The ACPI\_MUTEX\_DEBUG compile-time option may be specified that will enable code that checks for and enforces the rules above. This option is typically used to debug the ACPICA code and ensure that the rules above are strictly adhered to.

These rules of use are published here in order to help developers implement the mutex objects within the host OSL.

NOTE: These rules do not apply directly to the ASL/AML **Mutex** object, which has slightly different rules as defined by the ACPI specification.

In addition, there are several other miscellaneous mutex objects used internally:

**Namespace Read/Write:** Two mutex objects are used to implement a readers/writers lock that is used for namespace walks and dynamic ACPI table loading and unloading

**Global Lock:** Used to implement the AML global lock object. This is used in conjunction with a global lock semaphore and global lock spinlock.

**\_OSI Method:** Lock for the \_OSI information data structures.

#### 4.3.2.2 Internal use of Spinlock Objects

ACPICA uses several internal spinlocks for the following:

- 1) Internal object reference counting mechanism
- 2) GPE data structures and registers
- 3) Other ACPI hardware (Fixed, events, etc.) data structures and registers
- 4) Global lock pending bit





### 4.3.3 Control Method Execution

Most of the multithread support within the ACPICA subsystem is implemented using traditional locks and mutexes around critical (shared) data areas. However, the AML interpreter design is different in that the ACPI specification defines a special threading behavior for the execution of control methods. The design implements the following portion of the ACPI specification that defines a partially multithreaded AML interpreter in these four sentences:

*A control method can use other internal, or well-defined, control methods to accomplish the task at hand, which can include defined control methods provided by the operating software. Interpretation of a Control Method is not preemptive, but can block. When a control method does block, the operating software can initiate or continue the execution of a different control method. A control method can only assume that access to global objects is exclusive for any period the control method does not block.*

#### 4.3.3.1 Control Method Blocking

First of all, how can a control method block? This is a fairly exhaustive list of the possibilities:

1. Executes the **Sleep()** ASL opcode
2. Executes the **Acquire()** ASL opcode and the request cannot be immediately satisfied
3. Executes the **Wait()** ASL opcode and the request cannot be immediately satisfied
4. Attempts to acquire the **Global Lock** (via Operation Region access, etc), but must wait
5. Attempts to execute a control method that is serialized and already executing (or is blocked), or has reached its concurrency limit
6. Invokes the host debugger via a write to the debug object or executes the **BreakPoint()** ASL opcode
7. Accesses an **Operation Region** which results in a dispatch to a user-installed handler that blocks on I/O or other long-term operation
8. A **Notify** AML opcode results in a dispatch to a user-installed handler that blocks in a similar way

#### 4.3.3.2 Control Method Execution Rules

Here are some Control Method execution “rules” that the ACPICA multithread support is built upon. These rules are not always stated explicitly in the ACPI specification — some of them are inferred.

1. A Control Method will run to completion (as far as the interpreter is concerned – this doesn’t include thread preemption and interrupt handling by the OS) unless it blocks (i.e. a control method will not be arbitrarily preempted *by the interpreter*.)
2. If a Control Method blocks, the next Control Method in the queue will be executed. When the original (blocked) control method becomes ready, it will **not** preempt the executing method. Instead, it will be placed back on the execution queue (*We could place the method at the tail or the head of the execution queue, or leave this decision to the OSL implementers*).
3. Methods can be *serialized* (non-reentrant) or reentrant. A thread will block if an attempt is made to execute (either via direct invocation or indirectly via a method call) a serialized method that is already executing (or is blocked).



4. The “implicit” synchronization supported by Operation Regions and mentioned in the ACPI specification seems to depend entirely on the non-preemptive control method execution model (see above.)

### 4.3.3.3 A Simple Multithreading Model

The actual mechanisms to block a thread are simple and are already in place on the OSL side:

1. **Sleep ()** – directly implemented via *AcpiOsSleep ()*, will block the caller and free the processor.
2. **Acquire ()** – implemented via an **AcpiOsMutex**.
3. **Wait ()** – implemented via an **AcpiOsSemaphore**.
4. **Global Lock** – implemented via an **AcpiOsMutex** and the interrupt caused by the release of the lock.
5. Concurrency limit – we could put a queue at each method (high overhead), or simply re-queue the thread (perhaps in a high-priority queue if we implement one).
6. Host Debugger – These are simply **AcpiOs\*** calls that we assume will block for a long time.
7. Operation Region Handler blocks on some OS primitive
8. Notify handler blocks in the same manner as (7).

These mechanisms are sufficient to implement the blocking, but this isn’t enough to implement the execution semantics of “no preemption unless the method does something to block itself”. This requires additional support. I will take a stab at a multithread model here; please feel free to modify or comment.

1. True concurrent control method execution is not allowed. Although the interpreter is “reentrant” in the sense that more than one thread can call into the interpreter, only one thread at any given time (system wide) can be **actively** interpreting a control method. All other control methods (and the threads that are executing them) must be either blocked or awaiting execution/resumption.
2. Therefore, we can put a mutex around the entire interpreter and only allow a thread access to the interpreter when there are no other accessing threads.
3. The implication and result is that when an executing control method blocks, it is defined to have stopped accessing the interpreter, and is no longer executing within the interpreter.
4. If any interrupt handler needs interpreter services (such as the EC driver and the **\_Qxx** control methods), it must schedule a thread for execution. When it runs, this thread calls the interpreter to execute the method.



The algorithm below implements the model described above:

```
AmlExecuteControlMethod ()
  Acquire (Global Interpreter Lock)
  If <the method does anything that might block>
    Check if it will block (such as wait on a semaphore with a zero timeout, or
    grab global lock)
    If <we know or the method will block or still think that it might block>
      (such as sleep, acquire-no-units, wait-no-event, global lock not available,
      reached concurrency limit) - and perhaps before we dispatch to a user
      OpRegion or Notify handler)
      Release (Global Interpreter Lock)      (Allow another thread to execute a
      method)
      Execute the blocking call (AcpiOsSleep or AcpiOsWaitSemaphore)
      Acquire (Global Interpreter Lock)      (Must re-enter the interpreter,
      can't preempt running thread!)
  Release (Global Interpreter Lock)      (Finished with this method, free the
  interpreter)
```

#### 4.3.3.4 A More Complex Multithreading Model

This extension to the model shown above adds a mechanism to implement a “priority” system where all executing and blocked Control Methods have a higher priority than methods that are queued and have never executed yet. This allows the interpreter some control over the scheduling of threads that are executing control methods, without relying directly on an OS-defined priority mechanism. In other words, it provides an OS-dependent way to schedule threads the way we want.

Two semaphores are used, call them an “Outer Gate” and an “Inner Gate”. A thread must pass through both gates before it can begin execution. Once inside both gates, it releases the outer gate, allowing a thread in to wait at the inner gate. When the first thread completes execution of the method, it releases the inner gate, allowing the next thread to proceed. If at any time during execution a thread must block, it releases the inner gate, blocks, then re-acquires the inner gate when it resumes execution.

The maximum length of the queue at the inner gate will never exceed **<the number of blocked threads (running a method)> + 1** (the last thread allowed in through the outer gate).

In the typical (blocking) case, T1 blocks allowing T2 to run. T1 unblocks and eventually waits on the inner gate. T2 eventually completes and signals the inner gate. T1 now runs to completion. All of this happens regardless of the number of threads waiting at the outer gate – therefore, it gives priority to threads that are already running a method.

The algorithm below implements the modified model described above:

```
AmlExecuteControlMethod ()
  Acquire (Outer Lock)
  Acquire (Inner Lock) (Must acquire both locks to begin execution)
  Release (Outer Lock) (Allow one thread into the outer lock)
  If <the method does anything that might block>
    Check if it will block (such as wait on a semaphore with a zero timeout)
    If <we know or the method will block or still think that it might block>
      (such as sleep, acquire-no-units, wait-no-event, global lock not
      available, reached concurrency limit) - and perhaps before we dispatch to
      a user OpRegion or Notify handler)
      Release (Inner Lock)      (Allow another thread to begin execution of a
      method)
      Execute the blocking call (AcpiOsSleep, AcpiOsWaitSemaphore, etc.)
      Acquire (Inner Lock)      (Must re-enter the interpreter since we
      cannot preempt running thread!)
  Release (Inner Lock)      (Finished with this method, free the interpreter)
```

*Note:* It is not so important that the threads free the locks in **reverse** order as it is that they all unlock the locks **in the same order**. Since they are all executing the same code, this behavior is ensured.



While the simple multithreading model will be *sufficient*, the more complex model allows a more “fair” allocation of resources under heavy load. The outstanding question is whether there will ever be enough concurrent use of the AML interpreter to justify the complexity of the second model.

### 4.3.4 ACPI Global Lock Support

The ACPI *Global Lock* is intended to be a mutual exclusion mechanism that allows both the host operating system and the resident firmware to access common hardware and data structures. It is not intended to be a mutual exclusion mechanism between threads implemented by the host OS.

The one and **only** purpose of the Global Lock is to provide synchronization between the resident firmware (SMI BIOS, etc.) and all other software on the platform.


The ACPICA subsystem manages the global lock in the following manner:

- When the firmware owns the global lock, ACPICA queues up all requests to acquire the global lock.
- When the firmware releases the global lock, ACPICA satisfies all queued requests one at a time. A separate hardware acquire and release is performed for each thread that has requested the lock.

This algorithm prevents starvation of the global lock if many OS threads are requesting it. The BIOS has the opportunity to acquire the lock after each requesting thread releases it.

The diagram below shows the global lock in relation to the BIOS and other system software.

**Figure 8. Global Lock Architecture**





#### 4.3.4.1 Obtaining The Global Lock

```
/* Only one thread can acquire the lock at a time */

Acquire the internal global lock mutex
If (AcquireHardwareGlobalLock())
{
    GlobalLockAcquired = TRUE;
    return; /* All done! */
}

/* Must wait until the BIOS releases the lock and generates interrupt */

AmlExitInterpreter ();
AcpiOsWaitSemaphore (GlobalLockSemaphore, WAIT_FOREVER);
AmlEnterInterpreter ();
```

#### 4.3.4.2 Releasing the Global Lock

```
If global lock is not acquired
    Error, return;

ReleaseHardwareGlobalLock ();
If Pending bit set
    Write the GBL_RLS bit to the control register

GlobalLockAcquired = FALSE;
Release the internal global lock mutex
```

#### 4.3.4.3 Global Lock Interrupt Handler

```
/* We get an SCI when the firmware releases the lock */

AcquireHardwareGlobalLock ()
If (Global Lock was acquired)
{
    GlobalLockAcquired = TRUE;
    AcpiOsSignalSemaphore (GlobalLockSemaphore);
}
```

### 4.3.5 Single Thread Environments

Both the design and implementation of the ACPICA Subsystem is targeted primarily for inclusion within the kernel of a multitasking operating system. However, it is possible to generate and operate the subsystem within a single threaded environment — with either a primitive operating system or loader, or even standalone with no additional system software other than a few device drivers.

The successful operation of the ACPICA in any environment depends upon the correct implementation of the OSL layer underneath it. This requirement is no different for a single threaded environment, but some special considerations must be made:

The primary mechanisms used for mutual exclusion and multithread synchronization throughout the ACPICA subsystem are the OSL *Spinlock*, *Mutex*, and *Semaphore*. Since these mechanisms are not required in a single threaded environment, it is sufficient to implement these interfaces to simply always return an AE\_OK exception code.



When used within an OS kernel at ring 0, the ACPI debugger requires a dedicated thread to perform command line processing. Since this mechanism is not required in a single threaded environment, it can be configured out during generation of the subsystem.

## 4.4 General Purpose Event (GPE) Support

This section describes the initialization and use of the ACPI General Purpose Events.

### 4.4.1 Runtime and Wake GPEs

The original definition of a “runtime” versus a “wake” GPE was as follows:

A **runtime** GPE is a GPE that is used for signaling while the system is up and running. Examples of these types of events include the Embedded Controller, thermal zones, and notebook lid switches.

A **wake** GPE is any GPE that is capable of waking the system from sleep/suspend. Examples of these types of events include a notebook lid switch, a serial port, USB ports and a power button. These GPEs are usually identified by being referenced by one or more `_PRW` methods (Power Resources for Wake.)

There are a limited number of GPEs that are defined by the ACPI specification as being both runtime and wake. Examples of these include lid switches and control method power buttons.

Recently, however, the line between runtime and wake GPEs has been blurred by various platforms. For example, on some platforms, a wake GPE can be used at runtime to indicate state changes for individual buses such as USB.

Partly because of these changes and because ACPICA will no longer execute `_PRW` methods on behalf of the host, ACPICA itself no longer attempts to differentiate between runtime and wake GPEs. This identification is left to the host and the individual device drivers as described in the following sections.

#### 4.4.1.1 Execution of `_PRW` Methods

As of ACPICA version 20101217 (December 2010), the `_PRW` methods (Power Resources for Wake) are no longer automatically executed as part of the ACPICA initialization.

Originally (2000 – 2010), the ACPICA GPE initialization code performed a walk of the entire namespace to execute all discovered `_PRW` methods and thus detect all GPEs capable of waking the system.

As of December 2010, the `_PRW` method execution has been removed from ACPICA itself since it is actually unnecessary. The host OS must in fact execute all `_PRW` methods in order to identify the device and power-resource dependencies for its own power management subsystem. ACPICA now requires the host OS to identify the wake GPEs as part of this process and to inform ACPICA of these GPEs via the *AcpiSetWakeGpe* interface. This not only reduces the complexity of the ACPICA initialization code, but in many cases (on systems with large namespaces) it should reduce the kernel boot time as well since the `_PRW` methods are now only executed once, and an entire ACPI namespace walk/search is eliminated.

As the host executes the `_PRW` methods, it must inform ACPICA of the GPE associated with each `_PRW`, as well as the parent device associated with the `_PRW`.



#### 4.4.1.2 Implicit Notify Support

This feature provides an automatic device notification for wake devices when a wakeup GPE occurs and there is no corresponding GPE method or handler. Rather than ignoring such a GPE, an implicit AML Notify operation is performed on the parent device object.

This feature is not part of the ACPI specification and is provided for Windows compatibility only.

The behavior of this feature is summarized below:

1. A Device has a `_PRW` method that associates it with a GPE
2. There is no method for the GPE in the ACPI namespace
3. No handler is installed for the GPE
4. When the GPE fires, a `Notify(2)` is performed on the original Device. The GPE is assumed to be level-triggered and the GPE is cleared after the `Notify(2)` has been executed. `Notify(2)` is a `DEVICE_WAKE` notify.
5. Multiple devices are supported for the Implicit Notify feature. When the GPE fires, a notify is performed on all devices associated with the GPE. (See the description for the *AcpiSetupGpeForWake* interface.)

##### **Example:**

In this example, a Device named `USB0` has a `_PRW` method that associates the device with wake GPE 07. However, there is no GPE method named `_L07` in the namespace.

```
Device (USB0)
{
    Name (_PRW, Package() {
        7,
        3
    })
}
```

Since there is no GPE method named `_L07` in the ACPI namespace, ACPICA automatically executes the code below on behalf of `USB0` when GPE 7 fires:

```
Method (_L07)
{
    Notify (USB0, 2)
}
```

Note that the implicit notify feature only applies to GPEs that have a Device associated with them via a `_PRW` method.

#### 4.4.2 Using the ACPICA GPE Support Code

This section describes the use of the ACPICA GPE support code in the following areas:

- 1) GPE initialization during the host OS startup
- 2) GPE Block Devices
- 3) GPEs and dynamically loaded ACPI tables



#### 4) GPE handlers

### 4.4.2.1 Host OS Initialization

The Host operating system is expected to perform the following actions during system initialization:

The Host calls *AcpiEnableSubsystem*. During execution of this call, ACPICA initializes the FADT-defined GPE blocks 0 and 1, and finds all *\_Lxx/\_Exx* methods for the GPE 0/1 blocks (under *\\_GPE*).

Later, after the host has called *AcpiInitializeObjects*, the host then performs a namespace walk to identify and execute all *\_PRW* methods.

For each *\_PRW* method found in the ACPI namespace, the host calls *AcpiSetWakeGpe* to identify a possible wake GPE.

The host should install any GPE handlers at this time (See “GPE Handlers” below.)

After completion of the *\_PRW* method execution phase, the host calls *AcpiUpdateAllGpes*. During this call, ACPICA completes the initialization of all GPEs and enables all of the “runtime” GPEs. The only GPEs that are enabled directly by ACPICA are those GPEs that have an associated *\_Lxx/\_Exx* method. For GPEs that have handlers, the host is responsible for enabling them.

Before the system sleeps, the host calls *AcpiSetGpeWakeMask* for every GPE that is to be allowed to wake the system. The actual GPEs to be enabled for wake depends on the system configuration and the ACPI-related drivers that are loaded.

### 4.4.2.2 GPE Handlers

By default, ACPICA will enable at runtime any GPE that has an associated *\_Lxx/\_Exx* GPE method (during the execution of the *AcpiUpdateAllGpes* interface.)

The GPE handler mechanism enables host GPE processing for GPEs that do not have an associated GPE method (for example, the GPE associated with the Embedded Controller) or any other GPE. If there is a method associated with a GPE, an installed handler for the GPE takes precedence. The method is no longer executed after a handler is installed.

During host OS initialization or when a new GPE is detected via a GPE Block Device or a dynamic table load, the host may install handlers for individual GPEs via the *AcpiInstallGpeHandler* interface. Also, the host may install a single global handler that is invoked for all GPEs and Fixed Events by using the *AcpiInstallGlobalEventHandler* interface.

Once a handler is installed for a particular GPE, the host is responsible for enabling the GPE (via the *AcpiEnableGpe* interface) and disabling the GPE if necessary via *AcpiDisableGpe*.

Both *AcpiEnableGpe* and *AcpiDisableGpe* implement a reference count mechanism that allows for transparent sharing of runtime GPEs.

Any GPE handlers should be installed during the initialization phase anytime after *AcpiEnableSubsystem* has been called, but before the required call to *AcpiUpdateAllGpes*.

### 4.4.2.3 GPE Handler Execution

The basic GPE handler execution model is as follows: First, the GPE is disabled. Next, the handler is invoked, at interrupt level. At completion of the GPE handler processing, the GPE is cleared if necessary and re-enabled.





There are two types of supported GPE handlers:

1. A simple, synchronous handler that performs some GPE processing and immediately returns to the invoking ACPICA code. Note that this handler is invoked at interrupt level and thus its capabilities are limited.
2. A more complex handler that performs some asynchronous processing via a thread that is signaled from the synchronous part of the handler.

Simple Handler (synchronous): The handler should return the value **ACPI\_REENABLE\_GPE**. In response, ACPICA will immediately call the internal version of *AcpiFinishGpe* in order to clear and reenoble the GPE.

Complex Handler (with asynchronous part): The synchronous part of the handler performs some limited processing and then signals the asynchronous part via a host-dependent mechanism and returns to ACPICA. After the GPE has been completely processed by the asynchronous part of the handler (at some later time), the handler calls *AcpiFinishGpe* to clear and reenoble the GPE.

Note that in the case of the simple handler, ACPICA will automatically finish the GPE by clearing the GPE status bit (if the GPE is level-triggered) and reenabling the GPE because ACPICA knows that the GPE processing is complete. In the asynchronous/complex case, the GPE handler must tell ACPICA that the GPE processing is complete by invoking the *AcpiFinishGpe* interface.

#### 4.4.2.4 Load and LoadTable ASL/AML Operators

During execution of a control method that contains a Load or LoadTable operator, ACPICA locates the new ACPI table and installs the table into the namespace. It also finds any new *\_Lxx/\_Exx* GPE methods that may exist with the new table.

ACPICA notifies the host that a new table has been loaded by invoking the global Table Handler. The host installs this handler during system initialization via the *AcpiInstallTableHandler* interface.

From the host-installed Table Handler, the host must identify and execute any newly-loaded *\_PRW* methods, and call *AcpiSetWakeGpe* for any GPEs that are identified as possible wake GPEs.

After completion of the *\_PRW* execution, the host calls *AcpiUpdateAllGpes* to enable any GPEs that now have associated *\_Lxx/\_Exx* GPE methods that were discovered within the loaded table.

#### 4.4.2.5 GPE Block Devices

A GPE Block Device is indicated by a device object within the ACPI namespace with a PNP ID of “**ACPI0006**”. Typically, once such a device is detected, a host-specific GPE Block Device Driver will be loaded and will perform the following actions:

The Host calls *AcpiInstallGpeBlock*. During execution of this call, ACPICA installs and initializes the GPEs associated with the GPE Block Device and finds all *\_Lxx/\_Exx* methods for the block.

The Host must identify any *\_PRW* methods associated with individual GPEs within the GPE Block Device, and call *AcpiSetWakeGpe* for each possible wake GPE.

After completion of the GPE Block Device installation and *\_PRW* method execution, the host calls *AcpiUpdateAllGpes* to enable any new runtime GPEs associated with the new GPE block.

Again, before the system sleeps, the host calls *AcpiSetGpeWakeMask* for every GPE that is to be allowed to wake the system. The actual GPEs to be enabled for wake depends on the system configuration and the ACPI-related drivers that are loaded.



## 4.5 Miscellaneous ACPICA Behavior

### 4.5.1 Why ACPICA Cannot Use C Bitfields

The ACPICA code is written in ANSI C, and strives to be as portable as possible in order to support and integrate into any host operating system that requires ACPI support.

To this end, the ACPICA code and ACPICA header files purposely and explicitly avoid the use of C bitfields, for the reason summarized by the quote below:

*“Bitfields are great and easy to read, but unfortunately **the C language does not specify the layout of bitfields in memory**, which means that they are essentially useless for dealing with packed data in on-disk formats or binary wire protocols.”*

*“If you ask me, this decision was a design error in C – Ritchie could have picked an order and stuck with it”*

Quote used with permission from Norman Ramsey. For more information, see:  
<http://stackoverflow.com/a/1053662/41661>)

In addition, there are endian considerations where a compiler will change the memory layout of bitfields based on whether the target is little-endian or big-endian.

These problems with bitfields applies to ACPI tables acquired from the platform BIOS/firmware (flags fields, etc.) as well as bit-packed buffers returned from predefined ACPI names such as `_PLD`.

Therefore, in lieu of using bitfields, the ACPICA headers supply public bit/flag definitions, masks, and macros to both get and set bits as appropriate. This support is available to both the ACPICA code itself, and ACPI consumers such as ACPI-related device drivers.

### 4.5.2 Dynamically Loaded ACPI Tables

Additional ACPI tables may be loaded from ASL code via the following methods:

1. **ASL Load operator:** This operator will load an ACPI table directly from an Operation Region, Operation Region Field, or a Buffer. Although the ACPI specification states that the loaded table should be of type SSDT, ACPICA will not check the signature of the loaded table. Objects are loaded into the namespace relative to the namespace root. This is compatible with other ACPI implementations.
2. **ASL LoadTable operator:** This operator will load an ACPI table that is present in the RSDT/XSDT. Since all SSDTs within the RSDT/XSDT are loaded automatically at initialization time, this table must have a signature other than SSDT – typically OEMx.
3. **AcpiLoadTable interface:** The host can call this interface to load an SSDT from a buffer. Primarily intended for hot-plug support.

Regardless of where the table originates, the following actions are performed on behalf of the newly loaded table before the **Load** or **LoadTable** operator or *AcpiLoadTable* interface completes execution:

- Any module-level code (executable AML code not within any control method) within the table is executed.



- Any and all **\_PRW** methods within the table are executed in order to discover any GPEs that must now be marked as wakeup GPEs.
- Any new **\_Lxx/\_Exx** GPE methods within the table are registered with their corresponding GPE. If the referenced GPE is a runtime GPE and is not currently enabled, it is enabled immediately. This behavior applies to both the FADT-defined GPE blocks (0 and 1) and any GPE Block Devices.

### 4.5.3 Bus Master Arbitration (**ARB\_DIS**)

Management of bus master arbitration (via the **ARB\_DIS** bit in the optional **PM2\_CNT** ACPI register) must be implemented in the host-dependent C3 processor power state support. Note, **ARB\_DIS** is obsolete and only applies to older chipsets, both Intel and other vendors (for Intel, ICH4-M and earlier).

To disable BM arbitration, set the **ARB\_DIS** bit as follows:

```
Status = AcpiWriteBitRegister (ACPI_BITREG_ARB_DISABLE, 1);
```

To enable BM arbitration, clear the **ARB\_DIS** bit as follows:

```
Status = AcpiWriteBitRegister (ACPI_BITREG_ARB_DISABLE, 0);
```

Note: If the **PM2\_CNT** register is not supported on the platform, the **AE\_BAD\_ADDRESS** exception will be returned.



## 5 ACPICA Subsystem Features

### 5.1 ACPI 5.0 Support

The ACPI 5.0 specification was released in November, 2011. ACPICA contains a full implementation of ACPI 5.0, as summarized below.

#### 5.1.1 Reduced Hardware Platforms

Reduced hardware platforms are defined in ACPI 5.0 and refer to ACPI systems without the usual ACPI hardware. There are two ways in which the reduced hardware platforms are supported by ACPICA:

- 1) A runtime configuration feature that dynamically disables all ACPI hardware access code whenever the **HW\_REDUCED\_ACPI** flag is found to be set in the FADT.
- 2) A compile-time option to entirely remove the ACPI hardware support code from the ACPICA subsystem. This option is primarily intended for custom builds of host operating systems where the target platform is known to support ACPI in the reduced hardware mode.

##### 5.1.1.1 Runtime Reduced Hardware Support

This feature automatically supports reduced hardware platforms without any code changes. The reduced hardware support is dynamically enabled via the **HW\_REDUCED\_ACPI** flag in the revision 5 FADT. If this flag is set, ACPICA will not attempt to initialize or use any of the usual ACPI hardware. Note, when this flag is set, *all* of the following ACPI hardware is assumed to be not present and is not initialized or accessed:

- General Purpose Events (GPEs)
- Fixed Events (PM1a/PM1b and PM Control)
- Power Management Timer and Console Buttons (power/sleep)
- Real-time Clock Alarm
- Global Lock
- System Control Interrupt (SCI)
- The FACS is assumed to be non-existent

##### 5.1.1.2 Compile-Time Reduced Hardware Support

This option is used during the build/compile of the ACPICA subsystem. It disables the compilation of all code related to the hardware in the previous section. When the **ACPI\_REDUCED\_HARDWARE** option is specified during the build, all ACPI hardware-related code is omitted from the source code generation, resulting in a considerable savings of both code and data. The affected external interfaces are stubbed, however, and will return a status value of **AE\_NOT\_CONFIGURED**. The affected external interfaces are shown below:

```
AcpiInstallSciHandler
AcpiRemoveSciHandler
AcpiInstallGlobalEventHandler
AcpiInstallFixedEventHandler
AcpiRemoveFixedEventHandler
```



```
AcpiInstallGpeHandler
AcpiRemoveGpeHandler
AcpiAcquireGlobalLock
AcpiReleaseGlobalLock
AcpiEnable
AcpiDisable
AcpiEnableEvent
AcpiDisableEvent
AcpiClearEvent
AcpiGetEventStatus
AcpiUpdateAllGpes
AcpiEnableGpe
AcpiDisableGpe
AcpiSetGpe
AcpiSetupGpeForWake
AcpiSetGpeWakeMask
AcpiClearGpe
AcpiGetGpeStatus
AcpiFinishGpe
AcpiDisableAllGpes
AcpiEnableAllRuntimeGpes
AcpiInstallGpeBlock
AcpiRemoveGpeBlock
AcpiGetGpeDevice
AcpiGetTimerResolution
AcpiGetTimer
AcpiGetTimerDuration
AcpiReadBitRegister
AcpiWriteBitRegister
AcpiSetFirmwareWakingVector
AcpiSetFirmwareWakingVector64
AcpiEnterSleepStateS4bios
```

## 5.1.2 New and Existing ACPI Tables

All new tables and updates to existing tables are fully supported in the ACPICA headers (for use by device drivers), the disassembler, and the iASL Data Table Compiler. Note: ACPICA itself consumes none of these tables since they do not contain AML byte code. ACPI 5.0 defines these new tables:

BGRT	/* Boot Graphics Resource Table */
DRTM	/* Dynamic Root of Trust for Measurement table */
FPDT	/* Firmware Performance Data Table */
GTDT	/* Generic Timer Description Table */
MPST	/* Memory Power State Table */
PCCT	/* Platform Communications Channel Table */
PMTT	/* Platform Memory Topology Table */
RASF	/* RAS Feature table */

## 5.1.3 Operation Regions and Space IDs

All new operation regions are fully supported by the iASL compiler, the disassembler, and the ACPICA runtime code (for dispatch to region handlers.) The new operation region Space IDs are:

```
GeneralPurposeIo
GenericSerialBus
```



## 5.1.4 Resource Descriptors

All new ASL resource descriptors are fully supported by the iASL compiler, the ASL/AML disassembler, and the ACPICA runtime Resource Manager code (including all new predefined resource tags). The new descriptors are:

```
FixedDma
GpioIo
GpioInt
I2cSerialBus
SpiSerialBus
UartSerialBus
```

## 5.1.5 ASL/AML Support

One new operator is added, the Connection operator, which is used to associate a GeneralPurposeIo or GenericSerialBus resource descriptor with individual field objects within an operation region. Several new protocols are associated with the AccessAs operator. All are fully supported by the iASL compiler, disassembler, and runtime ACPICA AML interpreter:

```
Connection                /* Declare Field Connection attributes */
AccessAs: AttribBytes (n)  /* Read/Write N-Bytes Protocol */
AccessAs: AttribRawBytes (n) /* Raw Read/Write N-Bytes Protocol */
AccessAs: AttribRawProcessBytes (n) /* Raw Process Call Protocol */
RawDataBuffer              /* Data type for Vendor Data fields */
```

## 5.1.6 Predefined ACPI Names

All new predefined objects/control-methods are supported by the iASL compiler and the ACPICA runtime validation/repair (arguments and return values.) New predefined names include the following:

Standard Predefined Names (Objects or Control Methods): \_AEI, \_CLS, \_CPC, \_CWS, \_DEP, \_DLM, \_EVT, \_GCP, \_CRT, \_GWS, \_HRV, \_PRE, \_PSE, \_SRT, \_SUB.

Resource Tags (Names used to access individual fields within resource descriptors): \_DBT, \_DPL, \_DRS, \_END, \_FLC, \_IOR, \_LIN, \_MOD, \_PAR, \_PHA, \_PIN, \_PPI, \_POL, \_RXL, \_SLV, \_SPE, \_STB, \_TXL, \_VEN.



## 5.1.7 ACPICA External Interfaces

Some existing interfaces have been modified and several new interfaces have been defined for use by ACPI-related device drivers and other host OS services:

*AcpiAcquireMutex and AcpiReleaseMutex:* These interfaces allow the host OS to acquire and release AML mutexes that are defined in the DSDT/SSDT tables provided by the BIOS. They are intended to be used in conjunction with the ACPI 5.0 **\_DLM** (Device Lock Method) in order to provide transaction-level mutual exclusion with the AML code/interpreter. See sections 8.3.15 and 8.3.16 for the full definition of these interfaces. See the ACPI specification for more details concerning **\_DLM**.

*Operation Region Handlers:* For General Purpose IO and Generic Serial Bus operation regions, information about the Connection() object and any optional length information is passed to the region handler within the Context parameter. See section 8.8.6.4 for more information.

*AcpiGetEventResources:* New interface that returns the (formatted) resource descriptors as defined by the ACPI 5.0 **\_AEI** object (ACPI Event Information). This object provides resource descriptors associated with hardware-reduced platform events, similar to the *AcpiGetCurrentResources* interface. See section 8.9.4 for the full definition of this interface. See the ACPI specification for more details concerning **\_AEI**.

*AcpiBufferToResource:* New interface that converts a raw AML buffer containing a resource template or resource descriptor to the ACPI\_RESOURCE internal format suitable for use by device drivers. Can be used by an operation region handler to convert the Connection() buffer object into a ACPI\_RESOURCE.

## 5.1.8 Miscellaneous and Tools

Support for extended **\_HID** names (Four alpha characters instead of three).

Support for ACPI 5.0 features in the AcpiExec and AcpiHelp utilities.

Support for ACPI 5.0 features in the ASLTS test suite.

Fully updated documentation (ACPICA and iASL reference documents.)

## 5.1.9 ACPI Table Definition Language

Support for this language was implemented and released as a subsystem of the iASL compiler in 2010 (See the iASL compiler User Guide).



### 5.1.10 GPIO Event Model for ACPICA

Events that are generated via GPIO hardware represent a major departure from the standard ACPI event handling and dispatch. To support GPIO events, ACPICA has adopted this model for use by the host operating system:

#### **Host Initialization**

1. During initialization, the host performs a scan of the namespace to detect devices and **\_HIDs**.
2. When the host detects one or more GPIO **\_HIDs**, the native GPIO device driver is loaded.

#### **Native GPIO device driver initialization**

3. Call *AcpiGetEventResources* which will in turn execute the **\_AEI** object that appears under the GPIO device in the namespace. This object provides the interrupt or interrupts that are used for GPIO events via GPIO Interrupt Connection descriptors.
4. Install interrupt handler(s) for the interrupts defined by **\_AEI**.
5. Execute **\_CRS**, etc. for other required resources.

#### **Native GPIO device driver execution**

6. When the GPIO driver interrupt handler is invoked in response to a GPIO-generated event, the driver handles the interrupt according to its level/edge mode and invokes the **\_EVT** method that appears under the GPIO device. The GPIO pin number is passed to **\_EVT** to identify the source of the event.
7. The **\_EVT** method will decode the pin number and perform a *Notify()* operation on the appropriate device. This is very similar to the operation of the standard GPE control methods (**\_Lxx/\_Exx**).
8. The notify handler in the driver for the particular device then performs device-specific actions as necessary.

## 5.2 AML Interpreter Slack Mode

When enabled, this mode provides better compatibility with other existing ACPI implementation(s) by ignoring certain errors and improper AML sequences. It also enables the *Implicit Return* feature.

**Implicit Return Value:** This feature will automatically return the result of the last AML operation in a control method, in the absence of an explicit *Return()* operator. Since other ACPI implementations have implemented this feature by default, there are many existing machines whose ASL/AML depends on this behavior.

**Operation Region Range Checking:** Allow access beyond the end of of a region. The default behavior is to strictly limit access to the end of the operation region. Typically, access beyond the end of the region occurs when the access data width causes the overrun. For example, a one-byte operation region and a field with DWORD access. Normally, access to the field will cause an error. This option will allow the access to continue.

**Uninitialized Method Locals and Arguments:** Allow access to uninitialized Locals and Arguments as if they were initialized to an Integer object with a value of zero. If this feature is not enabled, an error is generated an the method is aborted.





**Source Operand Types for Store Operator:** Allow objects of any type to be the source for the ASL/AML Store operator. The ACPI specification restricts the source operand to be one of a subset of the available ACPI object types. This option overrides the ACPI specification and allows source operands of any type.

**Unresolved References within Packages:** Allow references within Package objects to go unresolved with no error or warning. A NULL package element is inserted instead. This is another compatibility issue with other AML interpreters, and there are existing machines that depend on this feature.

## 5.3 AML Interpreter Math Mode (32-bit or 64-bit)

The integer size used by the AML interpreter is variable and is dynamically set via the DSDT that is loaded. For ACPI 1.0 DSDTs with a version number of 1, the integer width used is always 32 bits for backward compatibility. For ACPI 2.0 and later DSDTs with a version number larger than 1, full 64-bit integer math is used.

## 5.4 Predefined Control Method Validation

For the predefined control methods (methods that are defined in the ACPI specification and whose names begin with a single underscore), the ACPICA subsystem performs a validation on the return value, if any. There are over 230 such predefined ACPI names.

The input number of arguments and the type of the return object is validated against the ACPI specification. If the method returns a package, the length of the package as well as the individual elements of the package are validated. A warning message is issued if there are any problems found.

This feature is useful in finding problems with objects returned by BIOS AML code immediately upon execution of the method – before the ACPI-related device drivers run into them.

## 5.5 I/O Port Protection

The ACPICA subsystem protects certain I/O ports from access via the AML code. Some ports are always illegal, and some ports are illegal based upon the strings that the BIOS has requested via the `_OSI` predefined control method. When an I/O request is made to a blocked port, the `AE_AML_ILLEGAL_ADDRESS` exception is returned.



The current list of protected ports is as follows:

```
{ "DMA",      0x0000, 0x000F, ACPI_OSI_WIN_XP},      /* DMA controller 1 */
{ "PIC0",     0x0020, 0x0021, ACPI_ALWAYS_ILLEGAL},  /* Interrupt Controller */
{ "PIT1",     0x0040, 0x0043, ACPI_OSI_WIN_XP},      /* System Timer 1 */
{ "PIT2",     0x0048, 0x004B, ACPI_OSI_WIN_XP},      /* System Timer 2 failsafe */
{ "RTC",      0x0070, 0x0071, ACPI_OSI_WIN_XP},      /* Real-time clock */
{ "CMOS",     0x0074, 0x0076, ACPI_OSI_WIN_XP},      /* Extended CMOS */
{ "DMA1",     0x0081, 0x0083, ACPI_OSI_WIN_XP},      /* DMA 1 page registers */
{ "DMA1L",    0x0087, 0x0087, ACPI_OSI_WIN_XP},      /* DMA 1 Ch 0 low page */
{ "DMA2",     0x0089, 0x008B, ACPI_OSI_WIN_XP},      /* DMA 2 Ch 2 low page */
{ "DMA2L",    0x008F, 0x008F, ACPI_OSI_WIN_XP},      /* DMA 2 low page refresh */
{ "ARBC",     0x0090, 0x0091, ACPI_OSI_WIN_XP},      /* Arbitration control */
{ "SETUP",    0x0093, 0x0094, ACPI_OSI_WIN_XP},      /* System board setup */
{ "POS",      0x0096, 0x0097, ACPI_OSI_WIN_XP},      /* POS channel select */
{ "PIC1",     0x00A0, 0x00A1, ACPI_ALWAYS_ILLEGAL},  /* Cascaded PIC */
{ "IDMA",     0x00C0, 0x00DF, ACPI_OSI_WIN_XP},      /* ISA DMA */
{ "ELCR",     0x04D0, 0x04D1, ACPI_ALWAYS_ILLEGAL},  /* PIC edge/level registers */
{ "PCI",      0x0CF8, 0x0CFF, ACPI_OSI_WIN_XP},      /* PCI configuration space */
```

**ACPI\_ALWAYS\_ILLEGAL:** These ports are always blocked.

**ACPI\_OSI\_WIN\_XP:** These ports are legal unless the BIOS AML has invoked **\_OSI** with the XP string "Windows 2001" or any Windows string representing a release of Windows later than XP. Performed for Windows compatibility, this means that these ports are illegal on most modern x86 machines.

## 5.6 Debugging Support

Two styles of debugging are supported with the debugging tools available with the ACPICA Subsystem:

1. Extraordinary amounts of trace and debug output can be generated from debug output and trace statements that are embedded in the debug version of the ACPICA subsystem. This data can be used to track down problems after the fact. So much data can be generated that the debug output can be selectively enabled on a per-subcomponent basis and even a finer granularity of the type of debug statement can be selected.
2. An AML debugger is provided that has the ability to single step control methods to examine the results of individual AML opcodes, and to change the values of local variables and method arguments if necessary.

### 5.6.1 Error and Warning Messages

There are several macros used throughout the ACPICA subsystem to format and print error and warning messages. In addition to the input message, each of these macros automatically print the module name, line number, and current ACPICA version number.

These macros are conditionally compiled and can be removed if desired by defining **ACPI\_NO\_ERROR\_MESSAGES** during subsystem compilation. However, they are used only for serious issues in order to limit their overhead.

**ACPI\_ERROR** – Displays an error message.

**ACPI\_EXCEPTION** – Displays an error message with a decoded **ACPI\_STATUS** exception.

**ACPI\_WARNING** – Displays a warning message.



**ACPI\_INFO** – Information message only.

The current statistics for the use of these macros within the ACPICA source are approximately as follows:

ACPI_ERROR	310 invocations
ACPI_EXCEPTION	80 invocations
ACPI_WARNING	40 invocations
ACPI_INFO	20 invocations

Also, if **ACPI\_NO\_ERROR\_MESSAGES** is defined, the module that formats and displays output from the AML Debug Object is configured out completely.

## 5.6.2 Execution Debug Output (ACPI\_DEBUG\_PRINT Macro)

The **ACPI\_DEBUG\_PRINT** macro is used throughout the source code of the ACPICA Subsystem to selectively print debug messages. Over 400 invocations of the **ACPI\_DEBUG\_PRINT** are scattered throughout the ACPICA subsystem source. This macro is compiled out entirely for non-debug versions of the subsystem.

Output from **ACPI\_DEBUG\_PRINT** can be enabled at two levels: on a per-subcomponent level (Namespace manager, Parser, Interpreter, etc.), and on a per-type level (informational, warnings, errors, and more.) There are two global variables that set these output levels:

1. **AcpiDbgLayer** Bit field that enables/disables debug output from entire subcomponents within the ACPICA subsystem.
2. **AcpiDbgLevel** Bit field that enables/disables the various debug output levels

The example below shows some of the debug output from a namespace search. None of the output of the function tracing is shown here, but the enter/exit traces would appear interspersed with the other debug output.

```
Nsutils-0346:  NsInternalizeName: returning [00821F30] (abs) "\BITZ"
nsaccess-0424: NsLookup: Searching from root [007F09B4]
nsaccess-0477: NsLookup: Multi Name (1 Segments, Flags=0)
nsaccess-0494: NsLookup: [BITZ/]
nssearch-0166: NsSearchOnly: Searching \/      [007F09B4]
nssearch-0168: NsSearchOnly: For BITZ (type 0)
nssearch-0239: NsSearchOnly: Name BITZ (actual type 8) found at 007FC384
nseval-0302:   NsEvaluateByName: \BITZ [007FC384] Value 007FE0C0
```

## 5.6.3 Function Tracing (ACPI\_FUNCTION\_TRACE Macro)

Most of the functions within the subsystem use the **ACPI\_FUNCTION\_TRACE** macro upon entry and the **return\_ACPI\_STATUS** macro upon exit. For the debug version of the subsystem, if the function trace debug level is enabled, the **ACPI\_FUNCTION\_TRACE** macro displays the name of the module and function and the current call nesting level. Upon exit, the **return\_ACPI\_STATUS** macro again displays the name of the function, the call nesting level, and the return status code of the call.

The next few lines show examples of the function tracing. On each invocation of the **ACPI\_FUNCTION\_TRACE** macro, we see the module name and line number, followed by the call nesting level (2 digits), followed by the name of the actual procedure entered. Some versions of the **ACPI\_FUNCTION\_TRACE** macro allow one of the function parameters to be displayed as well.



```

Executing \BITZ
nsobject-0356 [07] NsGetAttachedObject : ----Entry 004A2CC8
nsobject-0373 [07] NsGetAttachedObject : ----Exit- 004A2728
dswscope-0186 [07] DsScopeStackPush : ----Entry
    utalloc-0235 [07] UtAcquireFromCache : 004A1DC8 from State Cache
    utmisc-0711 [08] UtPushGenericState : ----Entry
    utmisc-0719 [08] UtPushGenericState : ----Exit-
dswscope-0223 [07] DsScopeStackPush : ----Exit- AE_OK
dsmthdat-0274 [07] DsMethodDataInitArgs : ----Entry 004A1438
dsmthdat-0655 [08] DsStoreObjectToLocal : ----Entry
dsmthdat-0657 [08] DsStoreObjectToLocal : Opcode=104 Idx=0 Obj=004A2F08

```

The function entry and exit macros have the ability to generate huge amounts of output data. However, this is often the best way to determine the actual execution path taken by subsystem. If the problem being debugged can be narrowed to a single control method, tracing can be enabled for that method only, thus reducing the amount of debug data generated.

## 5.6.4 ACPICA Debugger

Provided as a subcomponent of the ACPICA Subsystem, the AML Debugger provides the capability to display subsystem data structures and objects (such as the namespace and associated internal object), and to debug the execution of control methods (including single step and breakpoint support.) By using only two OSL interfaces, *AcpiOsGetLine* for input and *AcpiOsPrint* for output, the debugger can operate standalone or as an extension to a host debugger.

The debugger provides a more active debugging environment where data can be examined and altered during the execution of control methods.

## 5.7 Environmental Support Requirements

This section describes the environmental requirements of the ACPICA subsystem. This includes the external functions and header files that the subsystem uses, as well as the resources that are consumed from the host operating system.

### 5.7.1 Resource Requirements

**Static Memory – example Code and Data Size:** These are the sizes for the OS-independent *acpica.lib* produced by the Microsoft Visual C++ 9.0 32-bit compiler. The debug version of the code includes the debug output trace mechanism and has a much larger code and data size.

```

Non-Debug Version:  92.0K Code, 24.8K Data, 116.8K Total
Debug Version:      170.3K Code, 72.3K Data, 242.6K Total

```

**Dynamic Memory:** The size of the internal ACPI namespace is dependent on the size of the loaded ACPI tables – DSDT and any SSDTs – and the number of named ACPI objects they create at table load time. All resources used during control method execution are freed at control method termination.

### 5.7.2 C Library Functions

In order to make the ACPICA Subsystem as portable and truly OS-independent as possible, there is only extremely limited use of standard C library functions within the Subsystem component itself.



The calls are limited to those that can generate code in-line or link to small, independent code modules. Below is a comprehensive list of the C library functions that are used by the Subsystem code.

**Table 1. C Library Functions Used within the Subsystem**

isalpha
isdigit
isprint
isspace
isupper
isxdigit
memcmp
memcpy
memset
strcat
strcmp
strcpy
strlen
strncat
strncmp
strncpy
strstr
strtoul
strupr
tolower
toupper
va_end
va_list
va_start

If **ACPI\_USE\_SYSTEM\_CLIBRARY** is defined during the compilation of the subsystem, the subsystem must be linked to a local C library to resolve these Clib references. If **ACPI\_USE\_SYSTEM\_CLIBRARY** is not set, the subsystem will automatically link to local implementations of these functions. Note that the local implementations are written in portable ANSI C, and may not be as efficient as local assembly code implementations of the same functions. Therefore, it is recommended that the local versions of the C library functions be used if at all possible.



### 5.7.3 Source Code Organization

The ACPICA source code as released is organized as below. At the top level, there are separate directories for the ACPICA documentation, generation tools, and the actual C source code. The source code itself is organized into a separate directory for each major ACPICA component, tool, or test.

```

Acpica
  documents                // Acpica/iASL documentation
  generate                 // Source generation tools:
    lint                   // PC-lint files
    linux                  // Linux makefiles
    msvc                   // Microsoft VC++ 6.0 makefiles(obsolete)
    msvc9                  // Microsoft VC++ 9.0 makefiles
    release                // Release utilities
    unix                   // Generic Unix/gcc makefiles
  source                   // Entire ACPICA source code tree:
    common                 // Common files
    compiler               // iASL compiler
    components             // Main ACPICA components:
      debugger             // AML Debugger
      disassembler        // AML Disassembler
      dispatcher          // AML Interpreter dispatcher
      events               // ACPI Event Manager (GPES etc.)
      executer             // Main AML Interpreter
      hardware             // ACPI Hardware Manager
      namespace            // ACPI Namespace Manager
      parser               // AML Interpreter parser
      resources            // ACPI Resource Manager
      tables               // ACPI Table Manager
      utilities            // Miscellaneous utilities
    include                // Most ACPICA includes
      platform            // Platform-specific files
    os_specific            // OS-specific files
      service_layers      // Various OSLs
    tools                  // ACPICA tools/utilities:
      acpibin              // Binary file utility
      acpiexec             // ACPI user space executer
      acpihelp             // ACPI help utility
      acpinames            // Example namespace dump utility
      acpisrc              // Source translation utility
      acpixtract           // Table extraction utility
      examples             // ACPICA example code
  tests                   // ACPICA test suites:
    aapits                 // ACPICA interface tests
    aslts                  // ASL test suite
    misc                   // Miscellaneous ASL tests
    templates              // iASL table template generation tests

```



## 5.7.4 System Include Files

The following include files (header files) are useful for users of both the **Acpi\*** and **AcpiOs\*** interfaces:

- `acpi.h` Includes all of the files below.
- `acexcept.h` The ACPI\_STATUS exception codes
- `acpiosxf.h` The prototypes for all of the **AcpiOs\*** interfaces
- `acpixf.h` The prototypes for all of the **Acpi\*** interfaces
- `actypes.h` Common data types used across all interfaces

### 5.7.4.1 Customization to the Target Environment

The use of header files that are external to the ACPICA subsystem is confined to a single header file named *acenv.h*. These external include files are used only if the following symbols are defined:

- **ACPI\_USE\_SYSTEM\_LIBRARY**
- **ACPI\_USE\_STANDARD\_HEADERS**

Several of the standard C library headers are used:

- `stdarg.h`
- `stdlib.h`
- `string.h`
- `ctype.h`

When generating the ACPICA Subsystem component from source, the *acenv.h* header may be modified if the filenames above are not appropriate for generation on the target system. For example, some environments use a different set of header files for the kernel-level C library versus the user-level C library. Use of C library routines within the Subsystem component has been kept to a minimum in order to enhance portability and to ensure that the Subsystem will run as a kernel-level component in most operating systems.



## 6 Data Types and Interface Parameters

### 6.1 ACPICA Interface Parameters

#### 6.1.1 ACPI Names and Pathnames

As defined in the ACPI Specification, all ACPI object *names* (the names for all ACPI objects such as control methods, regions, buffers, packages, etc.) are exactly four ASCII characters long. The ASL compiler automatically pads names out to four characters if an input name in the ASL source is shorter. (The padding character is the underscore.) Since all ACPI names are always of a fixed length, they can be stored in a single 32-bit integer to simplify their use.

*Pathnames* are null-terminated ASCII strings that reference named objects in the ACPI namespace. A pathname can be composed of multiple 4-character ACPI names separated by a period. In addition, two special characters are defined. The backslash appearing at the start of a pathname indicates to begin the search at the root of the namespace. A carat in the pathname directs the search to traverse upwards in the namespace by one level. The ACPI namespace is defined in the ACPI specification. The ACPICA subsystem honors all of the naming conventions that are defined in the ACPI specification.

Frequently in this document, pathnames are referred to as “fully qualified pathname” or “absolute pathname” or “relative pathname”. A pathname is fully qualified if it begins with the backslash character ('\') since it defines the complete path to an object from the root of the namespace. All other pathnames are relative since they specify a path to an object from somewhere in the namespace besides the root.

The ACPI specification defines special search rules for single segment (4-character) or standalone names. These rules are intended to apply to the execution of AML control methods that reference named ACPI objects. The ACPICA Subsystem component implements these rules fully for the execution of control methods. It does not implement the so-called “parent tree” search rules for the external interfaces in order to avoid object reference ambiguities.

#### 6.1.2 Pointers

Many of the interfaces defined here pass pointers as parameters. It is the responsibility of the caller to ensure that all pointers passed to the ACPICA subsystem are valid and addressable. The interfaces only verify that pointers are non-NULL. If a pointer is any value other than NULL, it will be assumed to be a valid pointer and will be used as such.

#### 6.1.3 Buffers

It is the responsibility of the caller to ensure that all input and output buffers supplied to the ACPICA Subsystem component are at least as long as the length specified in the ACPI\_BUFFER structure, readable, and writable in the case of output buffers. The ACPICA Subsystem does not perform addressability checking on buffer pointers, nor does it perform range validity checking on the buffers themselves. In the ACPI Component Architecture, it is the responsibility of the OS Services Layer to validate all buffers passed to it by application code, create aliases if necessary to





address buffers, and ensure that all buffers that it creates locally are valid. In other words, the ACPICA Subsystem *trusts* the OS Services Layer to validate all buffers.

When the length field of `ACPI_BUFFER` is set to `ACPI_ALLOCATE_BUFFER` before a call that returns data in an output buffer, the Subsystem will allocate a return buffer on behalf of the caller. It is the responsibility of the caller to free this buffer when it is no longer needed (via `AcpiOsFree`).

## 6.2 ACPICA Basic Data Types

### 6.2.1 UINT64 and COMPILER\_DEPENDENT\_UINT64

Beginning with the ACPI version 2.0 specification, the width of integers within the AML interpreter are defined to be 64 bits on all platforms (both 32- and 64-bit). The implementation of this requirement requires the deployment of 64-bit integers across the entire ACPICA Subsystem. Since there is (currently) no standard method of defining a 64-bit integer in the C language, the `COMPILER_DEPENDENT_UINT64` macro is used to allow the `UINT64` typedef to be defined by each host compiler. The `UINT64` data type is used at the `Acpi*` interface level for both physical memory addresses and ACPI (interpreter) integers.

### 6.2.2 ACPI\_PHYSICAL\_ADDRESS

The width of all *physical* addresses is fixed at 64 bits, regardless of the platform or operating system. Logical addresses (pointers) remain the natural width of the machine (i.e. 32-bit pointers on 32-bit machines, 64-bit pointers on 64-bit machines.) This allows for a full 64-bit address space on 64-bit machines as well as “extended” physical addresses (above 4Gbytes) on 32-bit machines.

### 6.2.3 ACPI\_IO\_ADDRESS

Similar to `ACPI_PHYSICAL_ADDRESS`, except it is used for I/O addresses.

### 6.2.4 ACPI\_SIZE

This data type is 32 bits or 64 bits depending on the platform. It is used in lieu of the C library `size_t`, which cannot be guaranteed to be available.

### 6.2.5 ACPI\_STRING – ASCII String

The `ACPI_STRING` data type is a conventional “char \*” null-terminated ASCII string. It is used whenever a full ACPI pathname or other variable-length string is required. This data type was defined to strongly differentiate it from the `ACPI_NAME` data type.

### 6.2.6 ACPI\_BUFFER – Input and Output Memory Buffers

Many of the ACPICA interfaces require buffers to be passed into them and/or buffers to be returned from them. A common structure is used for all input and output buffers across the interfaces. The buffer structure below is used for both input and output buffers. The ACPICA Subsystem component only allocates memory for return buffers if requested to do so — this allows the caller



complete flexibility in where and how memory is allocated. This is especially important in kernel level code.

```
typedef struct
{
    UINT32      Length;        // Length of the buffer in bytes;
    void        *Pointer;      // pointer to buffer
} ACPI_BUFFER;
```

### 6.2.6.1 Input Buffer

An input buffer is defined to be a buffer that is filled with data by the user (caller) before it is passed in as a parameter to one of the ACPI interfaces. When passing an input buffer to one of the Subsystem interfaces, the user creates an `ACPI_BUFFER` structure and initializes it with a pointer to the actual buffer and the length of the valid data in the buffer. Since the memory for the actual `ACPI_BUFFER` structure is small, it will typically be dynamically allocated on the CPU stack. For example, a user may allocate a 4K buffer for common storage. The buffer may be reused many times with data of various lengths. Each time the number of bytes of *significant* data contained in the buffer is entered in the `Length` field of the `ACPI_BUFFER` structure before an ACPICA Subsystem interface is called.

### 6.2.6.2 Output Buffer

An output buffer is defined to be a buffer that is filled with data by an ACPI interface before it is returned to the caller. When the `ACPI_BUFFER` structure is used as an output buffer the caller must always initialize the structure by either

1. Placing a value in the `Length` field that indicates the maximum size of the buffer that is pointed to by the `Pointer` field. The length is used by the ACPI interface to ensure that there is sufficient user provided space for the return value.
2. Initializing the `Length` field to `ACPI_ALLOCATE_BUFFER` to cause the ACPICA subsystem to allocate a buffer.

If a buffer that was passed in by the caller is too small, the ACPI interfaces that require output buffers will indicate the failure by returning the error code `AE_BUFFER_OVERFLOW`. The interfaces will never attempt to put more data into the caller's buffer than is specified by the `Length` field of the `ACPI_BUFFER` structure (unless `ACPI_ALLOCATE_BUFFER` is used). The caller may recover from this failure by examining the `Length` field of the `ACPI_BUFFER` structure. The interface will place the *required* length in this field in the event that the buffer was too small.

During normal operation, the ACPI interface will copy data into the buffer. It will indicate to the caller the length of data in the buffer by setting the `Length` field of the `ACPI_BUFFER` to the actual number of bytes placed in the buffer.

Therefore, the `Length` field is both an input and output parameter. On input, it indicates either the size of the buffer or an indication to the ACPICA subsystem to allocate a return buffer on behalf of the caller. On output, it either indicates the actual amount of data that was placed in the buffer (if the buffer was large enough), or it indicates the buffer size that is required (if the buffer was too small) and the exception is set to `AE_BUFFER_OVERFLOW`.

If `ACPI_ALLOCATE_BUFFER` is used, the returned buffer should be freed by the caller by using `AcpiOsFree`.



## 6.2.7 ACPI\_STATUS – Interface Exception Return Codes

Most of the external ACPI interfaces return an exception code of type `ACPI_STATUS` as the function return value, as shown in the example below:

```
ACPI_STATUS          Status;

Status = AcpiInitializeSubsystem ();
if (ACPI_FAILURE (Status))
{
    // Exception handling code here
}
```

## 6.2.8 ACPI\_HANDLE – Object Handle

References to ACPI objects managed by the ACPICA Subsystem component are made via the `ACPI_HANDLE` data type. A handle to an object is obtained by creating an attachment to the object via the *AcpiPathnameToHandle* or *AcpiNameToHandle* primitives. The concept is similar to opening a file and receiving a connection – after the pathname has been resolved to an object handle, no additional internal searching is performed whenever additional operations are needed on the object.

References to object scopes also use the `ACPI_HANDLE` type. This allows objects and scopes to be used interchangeably as parameters to Acpi interfaces. In fact, a scope handle is actually a handle to the *first object* within the scope.

### 6.2.8.1 Predefined Handles

One predefined handle is provided in order to simplify access to the ACPI namespace:

**ACPI\_ROOT\_OBJECT:** A handle to the root object of the namespace. All objects contained within the root scope are children of the root object.



## 6.2.9 ACPI\_OBJECT\_TYPE – Object Type Codes

Each ACPI object that is managed by the ACPICA subsystem has a **type** associated with it. The valid ACPI object types are defined as follows:

**Table 2. ACPI Object Type Codes**

ACPI_TYPE_ANY
ACPI_TYPE_INTEGER
ACPI_TYPE_STRING
ACPI_TYPE_BUFFER
ACPI_TYPE_PACKAGE
ACPI_TYPE_FIELD_UNIT
ACPI_TYPE_DEVICE
ACPI_TYPE_EVENT
ACPI_TYPE_METHOD
ACPI_TYPE_MUTEX
ACPI_TYPE_REGION
ACPI_TYPE_POWER
ACPI_TYPE_PROCESSOR
ACPI_TYPE_THERMAL
ACPI_TYPE_BUFFER_FIELD
ACPI_TYPE_DDB_HANDLE
ACPI_TYPE_DEBUG_OBJECT

## 6.2.10 ACPI\_OBJECT – Method Parameters and Return Objects

The general purpose ACPI\_OBJECT is used to pass parameters to control methods, and to receive results from the evaluation of namespace objects. The point of this data structure is to provide a common object that can be used to contain multiple ACPI data types. Only a subset of the ACPI\_OBJECT\_TYPES are supported by the ACPI\_OBJECT. The types that are supported represent the types that are supported by control method arguments and return values as per the ASL/AML grammar specification.

When passing parameters to a control method, each parameter is contained in an ACPI\_OBJECT. All of the parameters are then grouped together in an ACPI\_OBJECT\_LIST.

When receiving a result from the evaluation of a namespace object, a single ACPI\_OBJECT is returned in an ACPI\_BUFFER structure. This allows variable length objects such as ACPI Packages to be returned in the buffer. The first item in the buffer is always the base ACPI\_OBJECT.

Some of the ACPI\_OBJECT types (String, Buffer, Package) contain pointers to additional data. These pointers reference additional storage within the same ACPI\_OBJECT allocation. They are guaranteed to be valid. **Note:** the entire ACPI\_OBJECT cannot be simply copied, else any pointers within the object(s) will be invalid.

- **String:** Pointer is a reference to the actual string data.
- **Buffer:** Pointer is a reference to the actual buffer data.
- **Package:** Pointer is a reference to the sub-object (elements) array of additional ACPI\_OBJECT(s)



When the device driver has completed processing of the ACPI\_OBJECT, it can be deleted with one call to free.

```
Typedef union acpi_object
{
    ACPI_OBJECT_TYPE    Type;    /* See ACPI_OBJECT_TYPE for values */
    struct
    {
        ACPI_OBJECT_TYPE    Type;        /* ACPI_TYPE_INTEGER */
        UINT64                Value;      /* The integer value */
    } Integer;

    struct
    {
        ACPI_OBJECT_TYPE    Type;        /* ACPI_TYPE_STRING */
        UINT32                Length;     /* # of bytes in string, minus null */
        char                *Pointer;    /* points to the string value */
    } String;

    struct
    {
        ACPI_OBJECT_TYPE    Type;        /* ACPI_TYPE_BUFFER */
        UINT32                Length;     /* # of bytes in buffer */
        UINT8                *Pointer;    /* points to the buffer */
    } Buffer;

    struct
    {
        ACPI_OBJECT_TYPE    Type;        /* ACPI_TYPE_PACKAGE */
        UINT32                Count;      /* # of elements in package */
        union acpi_object    *Elements;  /* Pointer to array of ACPI_OBJECTs */
    } Package;

    struct
    {
        ACPI_OBJECT_TYPE    Type;        /* ACPI_TYPE_LOCAL_REFERENCE */
        ACPI_OBJECT_TYPE    ActualType;  /* Type associated with the Handle */
        ACPI_HANDLE          Handle;     /* object reference */
    } Reference;

    struct
    {
        ACPI_OBJECT_TYPE    Type;        /* ACPI_TYPE_PROCESSOR */
        UINT32                ProcId;
        ACPI_IO_ADDRESS      PblkAddress;
        UINT32                PblkLength;
    } Processor;

    struct
    {
        ACPI_OBJECT_TYPE    Type;        /* ACPI_TYPE_POWER */
        UINT32                SystemLevel;
        UINT32                ResourceOrder;
    } PowerResource;
} ACPI_OBJECT;
```



### 6.2.10.1 Using the ACPI\_OBJECT


In this example, the `_PCT` object is evaluated via the `AcpiEvaluateObject`. `_PCT` is defined to return two buffers each containing a single Resource Template. The diagram shows the internal structure of the `ACPI_OBJECT` that is returned from `_PCT`.

The original ASL source code is shown below:

```
Name (_PCT, Package (0x02)
{
    ResourceTemplate ()
    {
        Register (SystemIO, 0x08, 0x00, 0x00000000000000B2)
    },
    ResourceTemplate ()
    {
        Register (SystemIO, 0x08, 0x00, 0x00000000000000B3)
    }
})
```

This is the evaluation of the `_PCT` object defined above, and the diagram shows the contents of the returned `ACPI_OBJECT`:

```
Status = AcpiEvaluateObject (Node, "_PCT", NULL, &ReturnObj);
```





## 6.2.11 ACPI\_OBJECT\_LIST – List of Objects

This object is used to pass parameters to control methods via the *AcpiEvaluateMethod* interface. The *Count* is the number of ACPI objects pointed to by the *Pointer* field. In other words, the *Pointer* field must point to an array that contains *Count* ACPI objects.

```
Typedef struct AcpiObjList
{
    UINT32                Count;
    ACPI_OBJECT            *Pointer;
} ACPI_OBJECT_LIST;
```

## 6.2.12 ACPI\_EVENT\_TYPE – Fixed Event Type Codes

The ACPI fixed events are defined in the ACPI specification. The event codes below are used to install handlers for the individual events.

```
ACPI_EVENT_PMTIMER        // Power Management Timer rollover
ACPI_EVENT_GLOBAL          // Global Lock released
ACPI_EVENT_POWER_BUTTON   // Power Button (pressed)
ACPI_EVENT_SLEEP_BUTTON   // Sleep Button (pressed)
ACPI_EVENT_RTC             // Real Time Clock alarm
```

## 6.2.13 ACPI\_TABLE\_HEADER – Common ACPI Table Header

This is the header used for most of the BIOS-provided ACPI tables.

```
Typedef struct /* ACPI common table header */
{
    char        Signature [4];        /* Identifies type of table */
    UINT32      Length;               /* Length of table, in bytes, */
                                         /* including header */
    UINT8       Revision;             /* Specification minor version # */
    UINT8       Checksum;             /* To make sum of entire table = 0 */
    char        OemId [6];            /* OEM identification */
    char        OemTableId [8];       /* OEM table identification */
    UINT32      OemRevision;          /* OEM revision number */
    char        AslCompilerId [4];    /* ASL compiler vendor ID */
    UINT32      AslCompilerRevision; /* ASL compiler revision number */
} ACPI_TABLE_HEADER;
```

## 6.3 ACPI Resource Data Types

These data types are used by the ACPICA resource interfaces.

### 6.3.1 PCI IRQ Routing Tables

The *AcpiGetIrqRoutingTable* interface retrieves the PCI IRQ routing tables. This interface returns the routing table in the *ACPI\_BUFFER* provided by the caller. Upon return, the *Length* field of the *ACPI\_BUFFER* will indicate the amount of the buffer used to store the PCI IRQ routing tables. If the returned status is *AE\_BUFFER\_OVERFLOW*, the *Length* indicates the size of the buffer needed to contain the routing table.



The `ACPI_BUFFER` *Pointer* points to a buffer of at least *Length* size. The buffer contains a series of `PCI_ROUTING_TABLE` entries, each of which contains both a *Length* member and a *Data* member. The *Data* member is a `PRT_ENTRY`. The *Length* member specifies the length of the `PRT_ENTRY` and can be used to walk the `PCI_ROUTING_TABLE` entries. By incrementing a buffer walking pointer by *Length* bytes, the pointer will reference each succeeding table element. The final `PCI_ROUTING_TABLE` entry will contain no data and have a *Length* member of zero.

Each `PRT_ENTRY` contains the Address, Pin, Source, and Source Index information as described in Chapter 6 of the ACPI Specification. While all structure members are `UINT32` types, the valid portion of both the *Pin* and *SourceIndex* members are only `UINT8` wide. Although the *Source* member is defined as “char Source[4]”, it can be de-referenced as a null-terminated string.

```
typedef struct acpi_pci_routing_table
{
    UINT32      Length;
    UINT32      Pin;           /* PCI Pin */
    UINT64      Address;       /* PCI Address of device */
    UINT32      SourceIndex;   /* Index of resource, allocating dev */
    char        Source[4];     /* pad to 64 bits so sizeof() works */
} ACPI_PCI_ROUTING_TABLE;
```

## 6.3.2 Device Resources

Device resources are returned by indirectly executing the `_CRS` and `_PRS` control methods via the *AcpiGetCurrentResources* and *AcpiGetPossibleResources* interfaces. These device resources are needed to properly execute the `_SRS` control method using the *AcpiSetCurrentResources* interface.

These interfaces require an `ACPI_BUFFER` parameter. If the *Length* member of the `ACPI_BUFFER` is set to zero, the **AcpiGet\*** interfaces will return an `ACPI_STATUS` of `AE_BUFFER_OVERFLOW` with *Length* set to the size buffer needed to contain the resource descriptors. If the *Length* member is non-zero and *Pointer* in non-NULL, it is assumed that *Pointer* points to a memory buffer of at least *Length* size. Upon return, the *Length* member will indicate the amount of the buffer used to store the resource descriptors.

### 6.3.2.1 ACPI\_RESOURCE\_TYPE – Resource Data Types

The following resource types are supported by the ACPICA subsystem. The resource types that follow are used in the resource definitions used in the resource handling interfaces: *AcpiGetCurrentResources*, *AcpiGetPossibleResources*, and *AcpiSetCurrentResources*.

- Irq
- Dma
- StartDependentFunctions
- EndDependentFunctions
- Io
- FixedIo
- FixedDma
- VendorSpecific
- EndTag
- Memory24
- Memory32





- FixedMemory32
- Address16
- Address32
- Address64
- ExtendedAddress64
- ExtendedIrq
- GenericRegister
- GpioIo
- GpioInt
- I2cSerialBus
- SpiSerialBus
- UartSerialBus

```
typedef union acpi_resource_data /* union of all resources */
{
    ACPI_RESOURCE_IRQ                Irq;
    ACPI_RESOURCE_DMA                Dma;
    ACPI_RESOURCE_START_DEPENDENT    StartDpf;
    ACPI_RESOURCE_IO                 Io;
    ACPI_RESOURCE_FIXED_IO           FixedIo;
    ACPI_RESOURCE_FIXED_DMA          FixedDma;
    ACPI_RESOURCE_VENDOR             Vendor;
    ACPI_RESOURCE_VENDOR_TYPER       VendorTyped;
    ACPI_RESOURCE_END_TAG             EndTag;
    ACPI_RESOURCE_MEMORY24           Memory24;
    ACPI_RESOURCE_MEMORY32           Memory32;
    ACPI_RESOURCE_FIXED_MEMORY32     FixedMemory32;
    ACPI_RESOURCE_ADDRESS16          Address16;
    ACPI_RESOURCE_ADDRESS32          Address32;
    ACPI_RESOURCE_ADDRESS64          Address64;
    ACPI_RESOURCE_EXTENDED_ADDRESS64 ExtAddress64;
    ACPI_RESOURCE_EXTENDED_IRQ       ExtendedIrq;
    ACPI_RESOURCE_GENERIC_REGISTER   GenericReg;
    ACPI_RESOURCE_GPIO               Gpio;
    ACPI_RESOURCE_I2C_SERIALBUS      I2cSerialBus;
    ACPI_RESOURCE_SPI_SERIALBUS      SpiSerialBus;
    ACPI_RESOURCE_UART_SERIALBUS     UartSerialBus;
    ACPI_RESOURCE_COMMON_SERIALBUS   CommonSerialBus;

} ACPI_RESOURCE_DATA;

typedef struct acpi_resource
{
    UINT32                Type;
    UINT32                Length;
    ACPI_RESOURCE_DATA    Data;

} ACPI_RESOURCE;
```

The `ACPI_BUFFER Pointer` points to a buffer of at least *Length* size. The buffer is filled with a series of `RESOURCE` entries, each of which begins with an *Id* that indicates the type of resource descriptor, a *Length* member and a *Data* member that is a `RESOURCE_DATA` union. The `RESOURCE_DATA` union can be any of fourteen different types of resource descriptors. The



*Length* member will allow the caller to walk the RESOURCE entries. By incrementing a buffer walking pointer by *Length* bytes, the pointer will reference each succeeding table element. The final element in the list of RESOURCE entries will have an *Id* of EndTag. An EndTag entry contains no additional data.

When walking the RESOURCE entries, the *Id* member determines how to interpret the structure. For example, if the *Id* member evaluates to StartDependentFunctions, then the *Data* member is two 32-bit values, a CompatibilityPriority value and a PerformanceRobustness value. These values are interpreted using the constant definitions that are found in actypes.h, GOOD\_CONFIGURATION, ACCEPTABLE\_CONFIGURATION or SUB\_OPTIMAL\_CONFIGURATION. The interpretation of these constant definitions is discussed in the Start Dependent Functions section of the ACPI specification, Chapter 6.

As another, more complex example, consider a RESOURCE entry with an *Id* member that evaluates to Address32, then the *Data* member is an ADDRESS32\_RESOURCE structure. The ADDRESS32\_RESOURCE structure contains fourteen members that map to the data discussed in the DWORD Address Space Descriptor section of the ACPI specification, Chapter 6. The *Data.Address32.ResourceType* member is interpreted using the constant definitions MEMORY\_RANGE, IO\_RANGE or BUS\_NUMBER\_RANGE. This value also effects the interpretation of the *Data.Address32.Attribute* structure because it contains type specific information.

The General Flags discussed in the ACPI specification are interpreted and given separate members within the ADDRESS32\_RESOURCE structure. Each of the bits in the General Flags that describe whether the maximum and minimum addresses is fixed or not, whether the address is subtractively or positively decoded and whether the resource simply consumes or both produces and consumes a resource are represented by the members *MaxAddressFixed*, *MinAddressFixed*, *Decode* and *ProducerConsumer* respectively.

The *Attribute* member is interpreted based upon the *ResourceType* member. For example, if the *ResourceType* is MEMORY\_RANGE, then the *Attribute* member contains two 16-bit values, a *Data.Address32.Attribute.Memory.CacheAttribute* value and a *ReadWriteAttribute* value.

The *Data.Address32.Granularity*, *MinAddressRange*, *MaxAddressRange*, *AddressTranslationOffset* and *AddressLength* members are simply interpreted as UINT32 numbers.

The optional *Data.Address32.ResourceSourceIndex* is valid only if the *ResourceSourceStringLength* is non-zero. Although the *ResourceSource* member is defined as UINT8 ResourceSource[1], it can be de-referenced as a null-terminated string whose length is *ResourceSourceStringLength*.

## 6.4 ACPICA Exception Codes

A common and consistent set of return codes is used throughout the ACPICA subsystem. For example, all of the public ACPI interfaces return the exception AE\_BAD\_PARAMETER when an invalid parameter is detected.

The exception codes are contained in the public acexcep.h file.

The entire list of available exception codes is given below, along with a generic description of each code. See the description of each public primitive for a list of possible exceptions, along with specific reason(s) for each exception.



Table 3. Exception Code Values

Exception Name	Typical Meaning
AE_OK	No error
<i>Environmental Exceptions</i>	
AE_ERROR	Unspecified error
AE_NO_ACPI_TABLES	ACPI tables could not be found
AE_NO_NAMESPACE	A namespace has not been loaded
AE_NO_MEMORY	Insufficient dynamic memory
AE_NOT_FOUND	The name was not found in the namespace
AE_NOT_EXIST	A required entity does not exist
AE_ALREADY_EXISTS	An entity already exists
AE_TYPE	The object type is incorrect
AE_NULL_OBJECT	A required object was missing
AE_NULL_ENTRY	The requested object does not exist
AE_BUFFER_OVERFLOW	The buffer provided is too small
AE_STACK_OVERFLOW	An internal stack overflowed
AE_STACK_UNDERFLOW	An internal stack underflowed
AE_NOT_IMPLEMENTED	The feature is not implemented
AE_SUPPORT	The feature is not supported
AE_LIMIT	A predefined limit was exceeded
AE_TIME	A time limit or timeout expired
AE_ACQUIRE_DEADLOCK	Internal error - attempt was made to acquire a mutex in improper order
AE_RELEASE_DEADLOCK	Internal error - attempt was made to release a mutex in improper order
AE_NOT_ACQUIRED	An attempt to release a mutex or the Global Lock without a previous acquire
AE_ALREADY_ACQUIRED	Internal error - attempt was made to acquire a mutex twice
AE_NO_HARDWARE_RESPONSE	Hardware did not respond after an I/O operation
AE_NO_GLOBAL_LOCK	There is no FACS Global Lock
AE_ABORT_METHOD	A control method was aborted
AE_SAME_HANDLER	Attempt was made to install the same handler that is already installed
AE_NO_HANDLER	A handler for the operation is not installed
AE_OWNER_ID_LIMIT	There are no more Owner IDs available for ACPI tables or control methods
AE_NOT_CONFIGURED	The interface is not part of the current subsystem configuration
<i>Programmer Exceptions (ACPI external interfaces)</i>	



Exception Name	Typical Meaning
AE_BAD_PARAMETER	A parameter is out of range or invalid
AE_BAD_CHARACTER	An invalid character was found in a name
AE_BAD_PATHNAME	An invalid character was found in a pathname
AE_BAD_DATA	A package or buffer contained incorrect data
AE_BAD_HEX_CONSTANT	Invalid character in a Hex constant
AE_BAD_OCTAL_CONSTANT	Invalid character in an Octal constant
AE_BAD_DECIMAL_CONSTANT	Invalid character in a Decimal constant
AE_MISSING_ARGUMENTS	Too few arguments were passed to a control method
AE_BAD_ADDRESS	A null I/O address was passed as a parameter to AcpiRead or AcpiWrite
<b>ACPI Table Exceptions</b>	
AE_BAD_SIGNATURE	An ACPI table has an invalid signature
AE_BAD_HEADER	Invalid field in an ACPI table header
AE_BAD_CHECKSUM	An ACPI table checksum is not correct
AE_BAD_VALUE	An invalid value was found in a table
AE_INVALID_TABLE_LENGTH	The FADT or FACS has improper length
<b>AML (Interpreter) Exceptions</b>	
AE_AML_BAD_OPCODE	Invalid AML opcode encountered
AE_AML_NO_OPERAND	An operand is missing (such as a method that did not return a required value)
AE_AML_OPERAND_TYPE	An operand of an incorrect type was encountered
AE_AML_OPERAND_VALUE	The operand had an inappropriate or invalid value
AE_AML_UNINITIALIZED_LOCAL	Method tried to use an uninitialized local variable
AE_AML_UNINITIALIZED_ARG	Method tried to use an uninitialized argument
AE_AML_UNINITIALIZED_ELEMENT	Method tried to use an empty package element
AE_AML_NUMERIC_OVERFLOW	Overflow during BCD conversion or other
AE_AML_REGION_LIMIT	Tried to access beyond the end of an Operation Region
AE_AML_BUFFER_LIMIT	Tried to access beyond the end of a buffer
AE_AML_PACKAGE_LIMIT	Tried to access beyond the end of a package
AE_AML_DIVIDE_BY_ZERO	During execution of AML Divide operator
AE_AML_BAD_NAME	An ACPI name contains invalid character(s)
AE_AML_NAME_NOT_FOUND	Could not resolve a named reference
AE_AML_INTERNAL	An internal error within the interpreter



Exception Name	Typical Meaning
AE_AML_INVALID_SPACE_ID	An Operation Region SpaceID is invalid
AE_AML_STRING_LIMIT	String is longer than 200 characters
AE_AML_NO_RETURN_VALUE	A method did not return a required value
AE_AML_METHOD_LIMIT	A control method reached the maximum reentrancy limit of 255
AE_AML_NOT_OWNER	A thread tried to release a mutex that it does not own
AE_AML_MUTEX_ORDER	Mutex SyncLevel release mismatch
AE_AML_MUTEX_NOT_ACQUIRED	Attempt to release a mutex that was not previously acquired
AE_AML_INVALID_RESOURCE_TYPE	Invalid resource type in resource list
AE_AML_INVALID_INDEX	Invalid Argx or Localx (x too large)
AE_AML_REGISTER_LIMIT	Bank value or Index value beyond range of register
AE_AML_NO_WHILE	Break or Continue without a While
AE_AML_ALIGNMENT	Non-aligned memory transfer on platform that does not support this
AE_AML_NO_RESOURCE_END_TAG	No End Tag in a resource list
AE_AML_BAD_RESOURCE_VALUE	Invalid value of a resource element
AE_AML_CIRCULAR_REFERENCE	Two references refer to each other
AE_AML_BAD_RESOURCE_LENGTH	The length of a Resource Descriptor in the AML is incorrect
AE_AML_ILLEGAL_ADDRESS	A memory, I/O, or PCI configuration address is invalid
AE_AML_INFINITE_LOOP	An apparent infinite AML While loop, method was aborted
<b><i>Internal Exceptions used for control</i></b>	
AE_CTRL_RETURN_VALUE	A Method returned a value
AE_CTRL_PENDING	Method is calling another method
AE_CTRL_TERMINATE	Terminate the executing method
AE_CTRL_TRUE	<b>An If or While predicate result</b>
AE_CTRL_FALSE	An If or While predicate result
AE_CTRL_DEPTH	Maximum search depth has been reached
AE_CTRL_END	An If or While predicate is false
AE_CTRL_TRANSFER	Transfer control to called method
AE_CTRL_BREAK	A Break has been executed
AE_CTRL_CONTINUE	A Continue has been executed
AE_CTRL_SKIP	Not currently used
AE_CTRL_PARSE_CONTINUE	Used to skip over bad opcodes
AE_CTRL_PARSE_PENDING	Used to implement AML While loops



## 7 Subsystem Configuration

There are several methods of configuring the OS-independent ACPICA Subsystem:

1. Selection of individual ACPICA components.
2. Configuration of platform-specific data types.
3. Per-machine configuration for machine-specific dependencies.
4. Per-compiler configuration for compiler dependencies.
5. Other compile-time configuration through the use of compiler switches.
6. Run-time global variables which are statically initialized from the configuration header file.

### 7.1 Configuration Files

The ACPICA subsystem has three types of configuration header files to allow the subsystem to be tailored to the particular machine and compiler, as well as allowing for the tuning of subsystem constants.

These three include files perform the subsystem configuration:

- An include file that is specific to the particular compiler being used to compile the ACPICA subsystem provides macros and defines that must be implemented on a per-compiler basis. These files appear in the *include/platform* directory.
- An include file that is specific to the particular machine being targeted for the ACPICA subsystem provides macros and defines that must be implemented on a per-machine basis. These files appear in the *include/platform* directory.
- A global include file, *acconfig.h* allows for the tailoring and tuning of various subsystem constants and options. This file appears in the *include* directory

### 7.2 Component Selection

#### 7.2.1 ACPI\_DISASSEMBLER

This switch enables the AML Disassembler component, which is usually used in conjunction with the ACPI Debugger.

#### 7.2.2 ACPI\_DEBUGGER

This switch enables the ACPICA Debugger component. It also enables the various object dumping routines.



## 7.2.3 ACPI\_REDUCED\_HARDWARE

This switch generates a version of ACPICA that only supports “reduced hardware” platforms as defined by ACPI 5.0. When set to TRUE, most of the hardware support component is configured out. There is no support for the following ACPI features:

- PM Event and Control registers
- SCI Interrupt (and handler)
- Fixed Events
- General Purpose Events (GPEs)
- Global Lock
- ACPI PM Timer
- FACS table (Waking vectors and Global Lock)

The following ACPICA public interfaces are configured out. They are still defined, but return the AE\_NOT\_CONFIGURED status:

### Handlers

- AcpiInstallGlobalEventHandler
- AcpiInstallFixedEventHandler
- AcpiRemoveFixedEventHandler
- AcpiInstallGpeHandler
- AcpiRemoveGpeHandler

### Global Lock

- AcpiAcquireGlobalLock
- AcpiReleaseGlobalLock

### Fixed Events

- AcpiEnable
- AcpiDisable
- AcpiEnableEvent
- AcpiDisableEvent
- AcpiClearEvent
- AcpiGetEventStatus

### General Purpose Events (GPEs)

- AcpiUpdateAllGpes
- AcpiEnableGpe
- AcpiDisableGpe
- AcpiSetGpe
- AcpiSetupGpeForWake
- AcpiSetGpeWakeMask
- AcpiClearGpe
- AcpiGetGpeStatus
- AcpiFinishGpe
- AcpiDisableAllGpes
- AcpiEnableAllRuntimeGpes
- AcpiInstallGpeBlock
- AcpiRemoveGpeBlock
- AcpiGetGpeDevice



```
PM Timer
    AcpiGetTimerResolution
    AcpiGetTimer
    AcpiGetTimerDuration

ACPI Registers
    AcpiReadBitRegister
    AcpiWriteBitRegister

Sleep/Wake
    AcpiSetFirmwareWakingVector
    AcpiSetFirmwareWakingVector64
    AcpiEnterSleepStates4bios
```

## 7.3 Configurable Data Types

The configurable data types are used to help tailor the ACPICA subsystem to a particular operation system or compiler. Any changes from the default values should be specified in a system-dependent header file under the *include/platform* directory.

### 7.3.1 ACPI\_SPINLOCK

This type is an OS-dependent handle for a spinlock. It is returned by the *AcpiOsCreateLock* interface, and passed as a parameter to the *AcpiOsAcquireLock* and *AcpiOsReleaseLock* interfaces. The default value for **ACPI\_SPINLOCK** is (void \*). It can be changed to whatever type the host OS uses for spinlocks.

### 7.3.2 ACPI\_SEMAPHORE

This type is an OS-dependent handle for a semaphore. It is returned by the *AcpiOsCreateSemaphore* interface, and passed as a parameter to the *AcpiOsWaitSemaphore* and *AcpiOsSignalSemaphore* interfaces. The default value for **ACPI\_SEMAPHORE** is (void \*). It can be changed to whatever type the host OS uses for semaphore objects.

### 7.3.3 ACPI\_MUTEX

This type is an OS-dependent handle for a mutex. It is returned by the *AcpiOsCreateMutex* interface, and passed as a parameter to the *AcpiOsAcquireMutex* and *AcpiOsReleaseMutex* interfaces. The default value for **ACPI\_MUTEX** is (void \*). It can be changed to whatever type the host OS uses for mutex objects.

If mutex objects are not supported by the host operating system, use the **ACPI\_MUTEX\_TYPE** with the **ACPI\_BINARY\_SEMAPHORE** option (described later). This option causes mutexes to be automatically implemented via **ACPI\_SEMAPHORE** objects, and the OSL mutex interfaces are not required.





### 7.3.4 ACPI\_CPU\_FLAGS

This type is used for the value returned from *AcpiOsAcquireLock*, and the value passed as a parameter to *AcpiOsReleaseLock*. It can be configured to whatever type the host OS uses for CPU flags that need to be saved and restored across the acquisition and release of a spinlock. The default value is **ACPI\_SIZE**.

### 7.3.5 ACPI\_THREAD\_ID

This type is defined as a **UINT64** and is returned by the *AcpiOsGetThreadId* interface.

There is no standard "thread\_id" across operating systems or even the various UNIX systems. Since ACPICA only needs the thread ID as a unique thread identifier, it uses a **UINT64** as the only common data type – a **UINT64** will accommodate any type of pointer or any type of integer. It is up to the host-dependent OSL to cast the native thread ID type to a **UINT64** (in *AcpiOsGetThreadId*) before returning the value to ACPICA.

### 7.3.6 ACPI\_CACHE\_T

This type is used for the value returned from *AcpiOsCreateCache*. It is used as a parameter to the various OSL cache interfaces to identify a cache object for operating systems that implement a cache manager. If the local ACPICA cache memory manager is used (configured), the value for this type is **ACPI\_MEMORY\_LIST**. Otherwise, the value is OS-dependent.

### 7.3.7 ACPI\_UINTPTR\_T

This type is introduced to assist compilation of ACPICA under a C99 compiler that implements the **uintptr\_t** type. It is used for casting of pointers to eliminate compiler warnings. The default value for the non-C99 case is (void \*).

## 7.4 Subsystem Compile-Time Options

These defines are used to customize the ACPICA Subsystem at compile time by selecting or disabling various features.

### 7.4.1 ACPI\_USE\_SYSTEM\_CLIBRARY

This switch allows the use of a system-supplied C library for the Clib functions used by the subsystem. If this switch is not set, the subsystem uses its own implementations of these functions. Use of a system C library (when available) may be more efficient in terms of reused system code and efficiency of the function implementations.

### 7.4.2 ACPI\_USE\_STANDARD\_HEADERS

This switch allows the use of standard C library headers that are provided by the host. The following C library headers are used:



```
#include <stdarg.h>
#include <stdlib.h>
#include <string.h>
#include <ctype.h>
```

### 7.4.3 ACPI\_DEBUG\_OUTPUT

This switch enables all debug facilities within ACPICA. This includes the **ACPI\_DEBUG\_PRINT** output statements, the **ACPI\_FUNCTION\_TRACE** tracing statements, and the various object dumping routines. If disabled, all of these macros evaluate to NULL and no code is produced.

### 7.4.4 ACPI\_USE\_LOCAL\_CACHE

This switch enable the local ACPICA cache manager code. The use of a cache can improve the ACPICA performance considerably, since it frequently allocations and deallocates objects of identical size. If the host OS provides a similar cache manager, the ACPICA cache manager is not needed.

### 7.4.5 ACPI\_DBG\_TRACK\_ALLOCATIONS

This switch enables the ACPICA cache statistics mechanism, and is only applicable if the local ACPICA cache manager is enabled (**ACPI\_USE\_LOCAL\_CACHE**.) When enabled, information about each cache is saved, including the total memory allocated/freed, total requests, cache hits/misses, etc. This information can be displayed via the ACPICA Debugger.

### 7.4.6 ACPI\_MUTEX\_TYPE

This macro is used to define the type of mutex support desired. Either native (host OS) mutexes may be used, or binary semaphores may be used. The default behavior is to use binary semaphores.

The **ACPI\_MUTEX\_TYPE** must be one of the two following values:

#### **ACPI\_BINARY\_SEMAPHORE** (default)

Use this value if the host OS does not support **mutex** objects. If set, this switch enables the automatic use of macros that implement the mutex interfaces via binary semaphores, and the various mutex interfaces do not need to be implemented in the OSL.

#### **ACPI\_OSL\_MUTEX**

Use this value if the host OS supports **mutex** objects. The various mutex interfaces must be implemented in the OSL:

- AcpiOsCreateMutex
- AcpiOsDeleteMutex
- AcpiOsAcquireMutex
- AcpiOsReleaseMutex



## 7.4.7 ACPI\_MUTEX\_DEBUG

Enables code that performs error checking on the use of mutex objects. It checks for possible deadlock conditions by enforcing a mutex ordering rule. Use of this option can impact performance considerably, so it should only be used for debugging.

## 7.4.8 ACPI\_SIMPLE\_RETURN\_MACROS

Enables simplified return macros. The default implementation for the return macros has extra protection so that the macro parameter is not evaluated twice. The simplified versions of these macros are smaller, but the parameter can be evaluated twice.

Protected macro:

```
#define return_ACPI_STATUS(s) \
    ACPI_DO_WHILE0 ({ \
        register ACPI_STATUS _s = (s); \
        AcpiUtStatusExit (ACPI_DEBUG_PARAMETERS, _s); \
        return (_s); })
```

Simplified macro:

```
#define return_ACPI_STATUS(s) \
    ACPI_DO_WHILE0 ({ \
        AcpiUtStatusExit (ACPI_DEBUG_PARAMETERS, (s)); \
        return((s)); })
```

## 7.4.9 ACPI\_USE\_DO\_WHILE\_0

Inserts a do ... while(0) statement around the return macros (see examples above). Prevents some compilers from issuing warnings for these macros.

Default implementation:

```
#define ACPI_DO_WHILE0(a)                do a while(0)
```

## 7.5 Per-Compiler Configuration

These macros and defines allow the ACPICA subsystem to be tailored to a particular compiler.

### 7.5.1 COMPILER\_DEPENDENT\_INT64

Defines the name of a signed 64-bit integer for this compiler. This macro is required because there is (currently) no standard method to define 64-bit integers in the C language. There is no default, this macro **must** be defined by the platform configuration file.

Examples

```
#define COMPILER_DEPENDENT_INT64    int64_t
#define COMPILER_DEPENDENT_INT64    long
#define COMPILER_DEPENDENT_INT64    __int64
#define COMPILER_DEPENDENT_INT64    long long
```



## 7.5.2 COMPILER\_DEPENDENT\_UINT64

Defines the name of an unsigned 64-bit integer on for this compiler. This macro is required because there is (currently) no standard method to define 64-bit integers in the C language. There is no default, this macro **must** be defined by the platform configuration file.

### Examples

```
#define COMPILER_DEPENDENT_UINT64    uint64_t
#define COMPILER_DEPENDENT_UINT64    unsigned long
#define COMPILER_DEPENDENT_UINT64    unsigned __int64
#define COMPILER_DEPENDENT_UINT64    unsigned long long
```

## 7.5.3 ACPI\_INLINE

Optionally defines the proper “inline” keyword for this compiler, since “inline” itself is not a standard C keyword. A few ACPICA functions use ACPI\_INLINE since they are very small. This option can be defined to the appropriate keyword for this compiler. If an inline function is not available, or if it is not needed, this function does not need to be defined, the default is “null”.

### Examples

```
#define ACPI_INLINE    inline
#define ACPI_INLINE    __inline
#define ACPI_INLINE    __inline__
```

## 7.5.4 ACPI\_USE\_NATIVE\_DIVIDE

This switch enables native 64-bit divides. It is set by default for 64-bit machine widths. It is optional for 32-bit platforms. Only use this option on a 32-bit platform if a 64-bit double-precision math library is available for use by ACPICA. If the library is not available, then do not use this option and a local ACPICA double-precision divide function is enabled instead.

## 7.5.5 ACPI\_DIV\_64\_BY\_32 (Short 64-bit Divide)

This macro performs a simple 64-bit divide with a 64-bit dividend and a 32-bit divisor. The purpose of this macro is to perform a short divide on 32-bit platforms without invoking a double-precision math library. Both the quotient and remainder must be returned. There is no default, this macro **must** be defined by the platform configuration file.

### Example 32-bit Implementation

```
#define ACPI_DIV_64_BY_32(n_hi, n_lo, d32, q32, r32) \
{ \
    __asm mov    edx, n_hi \
    __asm mov    eax, n_lo \
    __asm div    d32 \
    __asm mov    q32, eax \
    __asm mov    r32, edx \
}
```

Example 64-bit Implementation

```
#define ACPI_DIV_64_BY_32(n, n_hi, n_lo, d32, q32, r32) \
{ \
    q32 = n / d32; \
    r32 = n % d32; \
}
```

## 7.5.6 ACPI\_SHIFT\_RIGHT\_64 (64-bit Shift)

This macro performs a 64-bit right shift by one bit. The purpose of this macro is to perform a shift right on 32-bit platforms without invoking a double-precision math library. There is no default, this macro **must** be defined by the platform configuration file.

Example 32-bit Implementation

```
#define ACPI_SHIFT_RIGHT_64(n_hi, n_lo) \
{ \
    __asm shr    n_hi, 1 \
    __asm rcr    n_lo, 1 \
}
```

Example 64-bit Implementation

```
#define ACPI_SHIFT_RIGHT_64(n, n_hi, n_lo) \
{ \
    n <<= 1; \
}
```

## 7.5.7 ACPI\_EXPORT\_SYMBOL

This macro is used to define the mechanism used to export public symbols, if applicable. Within ACPICA, it is invoked for each of the public interfaces. The default value is NULL.

Example

```
#define ACPI_EXPORT_SYMBOL(Symbol)    EXPORT_SYMBOL(Symbol);
```

## 7.5.8 ACPI\_EXTERNAL\_XFACE

This macro allows the definition of an interface type prefix (such as `_cdecl`, `pascal`, etc.) to be used in the declaration of all ACPICA external interfaces (the **Acpi\*** interfaces.) The default value is NULL.

Example

```
#define ACPI_EXTERNAL_XFACE            APIENTRY
```



### 7.5.9 ACPI\_INTERNAL\_XFACE

This macro allows the definition of an interface type prefix (such as **\_cdecl**, **pascal**, etc.) to be used in the declaration of all ACPICA internal interfaces. The default value is NULL.

### 7.5.10 ACPI\_INTERNAL\_VAR\_XFACE

This macro allows the definition of an interface type prefix (such as **\_cdecl**, **pascal**, etc.) to be used in the declaration of all ACPICA variable-argument list internal interfaces. The default value is NULL.

#### Example

```
#define ACPI_INTERNAL_VAR_XFACE    __cdecl
```

### 7.5.11 ACPI\_SYSTEM\_XFACE

This macro allows the definition of an interface type prefix (such as **\_cdecl**, **pascal**, etc.) to be used in the declaration of all interfaces to the host OS. The default value is NULL.

#### Examples

```
#define ACPI_SYSTEM_XFACE    __cdecl
#define ACPI_SYSTEM_XFACE    APIENTRY
```

### 7.5.12 ACPI\_PRINTF\_LIKE

This macro defines a suffix to be used in the definitions and prototypes of internal print functions that accept a printf-like format string. Some compilers have the ability to perform additional typechecking on such functions. The default value is NULL.

#### Example

```
#define ACPI_PRINTF_LIKE(c) \
    __attribute__((__format__ (__printf__, c, c+1)))
```

### 7.5.13 ACPI\_UNUSED\_VAR

This macro defines a prefix to be used in the definition of variables that may not be used in a module (such as the **ACPI\_MODULE\_NAME**). This can prevent compiler warnings for such variables. The default value is NULL.

#### Example

```
#define ACPI_UNUSED_VAR __attribute__((unused))
```

## 7.6 Per-Machine Configuration

These macros and defines allow the ACPICA subsystem to be tailored to a particular machine or machine architecture.



## 7.6.1 ACPI\_MACHINE\_WIDTH

This macro defines the standard integer width of the target machine, either 32 or 64. There is no default, this macro **must** be defined by the platform configuration file.

### Examples

```
#define ACPI_MACHINE_WIDTH      32
#define ACPI_MACHINE_WIDTH      64
```

## 7.6.2 ACPI\_FLUSH\_CPU\_CACHE

Defines the instruction or instructions necessary to flush the CPU cache(s) on this machine.

### Examples

```
#define ACPI_FLUSH_CPU_CACHE()  __asm {WBINVD}
#define ACPI_FLUSH_CPU_CACHE()  wbinvd()
```

## 7.6.3 ACPI\_OS\_NAME

This defines the string that is returned by the predefined “\_OS\_” method in the ACPI namespace.

```
#define ACPI_OS_NAME      "Microsoft Windows NT"
```

The \_OS\_ object is essentially obsolete, but there is a large base of ASL/AML code in existing machines that check for the string above. The use of this string usually guarantees that the ASL will execute down the most tested code path. Also, there is some code that will not execute the \_OSI method unless \_OS\_ matches the string above. Therefore, change this string at your own risk.

## 7.6.4 ACPI\_ACQUIRE\_GLOBAL\_LOCK

This macro defines the code (in assembly or C) necessary to acquire the ACPI Global Lock on this machine.

**ACPI\_ACQUIRE\_GLOBAL\_LOCK (FacsPtr, Acquired)**

### Where:

FacsPtr            is a pointer to the FACS table.

Acquired           is a boolean return value. TRUE if the lock was acquired; FALSE otherwise.

**Example:**

```
#define ACPI_ACQUIRE_GLOBAL_LOCK(FacsPtr, Acq) __asm \
{
    __asm mov          eax, 0xFF          \
    __asm mov          ecx, FacsPtr       \
    __asm or           ecx, ecx           \
    __asm jz           exit_acq          \
    __asm lea          ecx, [ecx].GlobalLock \
                                           \
    __asm acq10:                          \
    __asm mov          eax, [ecx]         \
    __asm mov          edx, eax           \
    __asm and          edx, 0xFFFFFFF0    \
    __asm bts          edx, 1             \
    __asm adc          edx, 0             \
    __asm lock cmpxchg  dword ptr [ecx], edx \
    __asm jnz          acq10              \
                                           \
    __asm cmp          dl, 3              \
    __asm sbb          eax, eax           \
                                           \
    __asm exit_acq:                          \
    __asm mov          Acq, al            \
}
```

## 7.6.5 ACPI\_RELEASE\_GLOBAL\_LOCK

This macro defines the code (in assembly or C) necessary to release the ACPI Global Lock on this machine.

**ACPI\_RELEASE\_GLOBAL\_LOCK (FacsPtr, Pending)**

Where:

FacsPtr is a pointer to the FACS table.

Pending is a boolean return value. TRUE if the global lock pending bit is set; FALSE otherwise.



**Example:**

```
#define ACPI_RELEASE_GLOBAL_LOCK(FacsPtr, Pnd) __asm \  
{  
    __asm xor          eax, eax          \  
    __asm mov          ecx, FacsPtr      \  
    __asm or           ecx, ecx          \  
    __asm jz           exit_rel          \  
    __asm lea          ecx, [ecx].GlobalLock \  
    __asm Rel10:        \  
    __asm mov          eax, [ecx]        \  
    __asm mov          edx, eax          \  
    __asm and          edx, 0xFFFFFFFFC  \  
    __asm lock cmpxchg  dword ptr [ecx], edx \  
    __asm jnz          Rel10            \  
    __asm cmp          dl, 3             \  
    __asm and          eax, 1           \  
    __asm exit_rel:    \  
    __asm mov          Pnd, al          \  
}
```

## 7.7 Subsystem Runtime Configuration

This section describes features that may be enabled or disabled at run-time by setting various ACPICA global option variables.

The global option variables are found in the *include/acglobal.h* header.

### 7.7.1 Interpreter Slack Mode

Enable or disable the AML Interpreter slack mode, as described earlier. The default is disabled.

```
ACPI_INIT_GLOBAL (AcpiGbl_EnableInterpreterSlack, FALSE);
```

### 7.7.2 ACPI Register Widths

This option can be used to override the ACPI register widths that are specified in the FADT in the case where the FADT contains one or more incorrect register widths (lengths). The default value is FALSE, do not use the default register widths -- use the values as specified in the FADT.



The default register widths are as follows:

**PM1A Enable,**  
**PM1A Status,**  
**PM1A Control,**  
**PM1B Enable,**  
**PM1B Status,**  
**PM1B Control**    -- 16 bits each, = **ACPI\_PM1\_REGISTER\_WIDTH**

**PM2 Control**        -- 8 bits, = **ACPI\_PM2\_REGISTER\_WIDTH**

**PM Timer**            -- 32 bits, = **ACPI\_PM\_TIMER\_WIDTH**

```
ACPI_INIT_GLOBAL (AcpiGbl_UseDefaultRegisterWidths, FALSE);
```

### 7.7.3 Auto-Serialization of Control Methods

This feature causes ACPICA to scan all **NotSerialized** control methods at table load time. Any methods that attempt to create named ACPI objects will be dynamically changed to **Serialized**. This will prevent possible run-time exceptions such as **AE\_ALREADY\_EXISTS** which can happen if an ill-behaved method performs the following:

- 1) The method is originally **NotSerialized**.
- 2) The method creates named ACPI objects.
- 3) The method blocks after the creation of one or more named ACPI objects.
- 4) The method is subsequently reentered by a second thread during the time that the first thread is blocked.
- 5) An **AE\_ALREADY\_EXISTS** exception occurs when the second thread attempts to create the same named ACPI objects.

By automatically serializing methods that create named objects, the scenario above is avoided because only one thread at a time will be allowed to enter the method.

The default for this option is **TRUE**, but the method scan can be disabled by setting the following global variable to **FALSE**:

```
ACPI_INIT_GLOBAL (AcpiGbl_AutoSerializeMethods, TRUE);
```

### 7.7.4 Output from the AML Debug Object

This option controls whether output from the AML “Debug Object” is enabled or not. If set to **TRUE**, all system AML stores to the debug object will be formatted and printed via calls to the *AcpiOsPrintf* interface. Note: the module that formats stores to the debug object can optionally be configured out of the ACPICA build (via **ACPI\_NO\_ERROR\_MESSAGES**). In this case, this option will have no effect.

```
ACPI_INIT_GLOBAL (AcpiGbl_EnableAmlDebugObject, FALSE);
```



## 7.7.5 Copy the System DSDT to Local Memory

For memory efficiency, ACPICA does not normally copy the DSDT or any other ACPI tables from their locations as presented by the system firmware; they are simply memory mapped. This is especially important on large systems where the DSDT can be several megabytes in size.

However, on some rare systems, it has been seen that the DSDT can become corrupted or even entirely replaced by a new (and invalid) DSDT during system operation. Reasons for this are unclear, but they are assumed to be bugs in the firmware. For these systems, an option to copy the DSDT to local memory is provided. When this option is specified, the DSDT is copied during system initialization, and the original DSDT is never referenced again.

```
ACPI_INIT_GLOBAL (AcpiGbl_CopyDsdtdLocally, FALSE);
```

## 7.7.6 Creation of \_OSI Method

This option controls whether the predefined \_OSI method is created or not. The \_OSI method was defined in ACPI 2.0 and is implemented internally within the ACPICA subsystem.

```
ACPI_INIT_GLOBAL (AcpiGbl_CreateOsiMethod, TRUE);
```

## 7.7.7 I/O Address Truncation

This option will truncate I/O addresses to 16 bits. Provides compatibility with other ACPI implementations. NOTE: During ACPICA initialization, this value is set to TRUE if any Windows OSI strings have been requested by the BIOS.

```
ACPI_INIT_GLOBAL (AcpiGbl_TruncateIoAddresses, FALSE);
```

## 7.7.8 Runtime Validation/Repair of Predefined Names

This option disables runtime checking and repair of values returned by control methods. Use only if the repair is causing a problem on a particular machine.

```
ACPI_INIT_GLOBAL (AcpiGbl_DisableAutoRepair, FALSE);
```

## 7.7.9 Reduced ACPI Hardware Flag

ACPI 5.0 introduces the concept of a "reduced hardware platform", meaning that the ACPI hardware is no longer required. A flag in the FADT indicates a reduced HW machine, and that flag is duplicated here for use by drivers.

```
BOOLEAN    AcpiGbl_ReducedHardware;
```

## 7.7.10 Ignore XSDT, Use RSDT Instead

This option causes the subsystem to ignore an XSDT if present. Although the ACPI specification requires the use of an XSDT if it is present in the RSDP, the XSDT has been found to be corrupt or ill-formed on some machines. Setting this option to TRUE will use the RSDT instead of an XSDT.

```
ACPI_INIT_GLOBAL (AcpiGbl_DoNotUseXsdt, FALSE);
```



### 7.7.11 Use 32-bit FADT Addresses to Resolve Conflicts

This option causes the subsystem to prefer 32-bit ACPI register or table addresses within the FADT when there is a conflict (address mismatch) between the 32-bit and 64-bit versions of the address. Although ACPICA adheres to the ACPI specification which requires the use of the 64-bit version if it is non-zero, some machines have been found to have one or more corrupted non-zero addresses.

```
ACPI_INIT_GLOBAL (AcpiGbl_Use32BitFadtAddresses, FALSE);
```

## 7.8 Subsystem Configuration Constants

The configurable subsystem constants are specified in the *include/acconfig.h* header file. These constants may be modified at either compile time by changing the constants in *acconfig.h*, or at run-time by changing the contents of the global variables where these constants are stored.

### 7.8.1 ACPI\_CHECKSUM\_ABORT

Defines whether the table manager should abort the loading of an ACPI table if the table checksum is incorrect. Possible values are **TRUE** or **FALSE**. The default is **FALSE**.

In practice, often table checksums are found to be incorrect, not because of corruption, but because the BIOS has modified the table on the fly according to BIOS configuration options, and has inadvertently forgotten to update the checksum. Therefore, the ACPI table checksum isn't very useful and the default is to ignore checksum errors.

### 7.8.2 ACPI\_MAX\_LOOP\_ITERATIONS

This defines the number of AML While() loop executions that are permitted before the infinite loop break mechanism is invoked. The default is 64K iterations, which is a very large number of iterations for an AML loop. This mechanism prevents a catastrophic infinite loop which would block the AML interpreter forever, effectively locking up most of the ACPICA subsystem.

Infinite loops can occur in poorly written AML in a hardware polling loop. For example, if the hardware simply does not respond and the loop does not implement a timeout.

### 7.8.3 ACPI\_MAX\_STATE\_CACHE\_DEPTH

The maximum number of objects in the generic state object cache used to avoid recursive calls within the subsystem. These are small objects, but are used frequently. A larger cache will improve the performance of the entire subsystem (loading tables, parsing methods, and executing methods.)

### 7.8.4 ACPI\_MAX\_PARSE\_CACHE\_DEPTH

The maximum number of objects in the parse object cache. These are the objects used to build parse trees. A larger cache will improve the execution performance of control methods (when the parse just-in-time strategy is used) by improving the time to parse the AML.



### **7.8.5      `ACPI_MAX_OBJECT_CACHE_DEPTH`**

The maximum number of objects in the interpreter operand object cache. These objects are used during control methods to pass the operands for individual AML opcodes to the interpreter. A larger cache will improve the performance of control method execution.

### **7.8.6      `ACPI_MAX_WALK_CACHE_DEPTH`**

The maximum number of objects in the parse tree walk object cache. These are relatively large objects (about 512 bytes) that are used to contain the entire state of a control method during its execution. Each nested control method requires an additional walk object. Since only one object is required per control method, it is not necessary to cache a large number of these objects. A few cached walk objects are sufficient to increase the performance of control method execution and reduce memory fragmentation.



## 8 ACPICA Subsystem - External Interface Definition

This section contains documentation for the specific interfaces exported by the ACPICA Subsystem. The interfaces are grouped based upon their functionality. These groups are closely related to the internal modules (or sub-components) of the ACPICA Subsystem described earlier in this document. These interfaces are intended to be used by the OSL only. The host OS does not call these interfaces directly. All public/external interfaces to the ACPICA Subsystem are prefixed by the letters “**Acpi**”.

### 8.1 ACPICA Subsystem Initialization and Control

#### 8.1.1 AcpiInitializeSubsystem

**Initialize all ACPICA globals and sub-components.**

**ACPI\_STATUS**  
**AcpiInitializeSubsystem (**  
     **void)**

#### PARAMETERS

None

#### RETURN

Status	Exception code that indicates success or reason for failure.
--------	--

#### EXCEPTIONS

AE_OK	The subsystem was successfully initialized.
AE_ERROR	The system is not capable of supporting ACPI mode.
AE_NO_MEMORY	Insufficient dynamic memory to complete the ACPI initialization.

#### Functional Description:

This function initializes the entire ACPICA subsystem, including the OS Services Layer. It must be called once before any of the other **Acpi**\* interfaces are called (with the exception of the Table Manager interfaces these interfaces are independent and can be called at any time.)



## 8.1.2 AcpiInstallInitializationHandler

**Install a global handler for initialization handling.**

**ACPI\_STATUS**  
**AcpiInstallInitializationHandler (**  
    **ACPI\_INIT\_HANDLER**      **Handler,**  
    **UINT32**                    **Function)**

### PARAMETERS

Handler	A pointer to the initialization handler.
Function	Reserved.

### EXCEPTIONS

AE_OK	The ACPI namespace was successfully loaded and initialized.
AE_BAD_PARAMETER	The <i>Handler</i> parameter is invalid.
AE_ALREADY_EXISTS	A global initialization handler has already been installed.

### Functional Description:

This function installs a global initialization handler that is called during the subsystem initialization.

Currently, the handler is called after each Device object within the namespace has been initialized (The *\_INI* and *\_STA* methods have been run on the device.)

### 8.1.2.1 Interface to User Callback Function

**Interface to the user function that is installed via *AcpiInstallInitializationHandler*.**

**ACPI\_STATUS (\*ACPI\_INIT\_HANDLER) (**  
    **ACPI\_HANDLE**              **Object,**  
    **UINT32**                    **Function)**

### PARAMETERS

Object	A handle for the object that is being or has just been initialized.
Function	One of the following manifest constants:  <b>ACPI_INIT_DEVICE_INI</b> – the Object is a handle to a Device that has just been initialized.

**RETURN VALUE**

Status	AE_OK	Continue the walk.
	AE_TERMINATE	Stop the walk immediately.
	AE_DEPTH	Go no deeper into the namespace tree.
	All others	Abort the walk with this exception code.

**Functional Description:**

This function is called during subsystem initialization.

### 8.1.3 AcpiEnableSubsystem

**Complete the ACPICA Subsystem initialization and enable ACPI operations.**

**ACPI\_STATUS**

**AcpiEnableSubsystem (**  
**UINT32**

**Flags)**

**PARAMETERS**

Flags	Specifies how the subsystem should be initialized. Must be one of these manifest constants:
	<b>ACPI_FULL_INITIALIZATION</b> – Perform completed initialization. This is the normal use of this interface.
	<b>ACPI_NO_ACPI_ENABLE</b> . Do not attempt to enter ACPI mode. For hardware-independent mode only.
	<b>ACPI_NO_ADDRESS_SPACE_INIT</b> . Do not install the default address space handlers. For debug purposes only.
	<b>ACPI_NO_HANDLER_INIT</b> . Do not install the SCI and global lock handlers. For hardware-independent mode only.

**RETURN**

Status	Exception code that indicates success or reason for failure.
--------	--

**EXCEPTIONS**

AE_OK	The ACPI namespace was successfully loaded and initialized.
AE_NO_MEMORY	Insufficient memory to build the internal namespace.



**Functional Description:**

---

This function completes initialization of the ACPICA Subsystem.

## 8.1.4 AcpiInitializeObjects

<b>Initialize objects within the ACPI namespace.</b>
--

**ACPI\_STATUS**  
**AcpiInitializeObjects (**  
    **UINT32**

**Flags)**

**PARAMETERS**

Flags

Specifies how the subsystem should be initialized. Must be one of these manifest constants:

**ACPI\_FULL\_INITIALIZATION** – Perform completed initialization. This is the normal use of this interface.

**ACPI\_NO\_ADDRESS\_SPACE\_INIT.** Do not execute the operation region \_REG control methods. For debug purposes only.

**ACPI\_NO\_OBJECT\_INIT.** Do not run the final initialization pass to complete initialization of all address spaces and fields.

**ACPI\_NO\_DEVICE\_INIT.** Do not attempt to run the \_STA and \_INI methods on devices in the ACPI namespace.

**ACPI\_NO\_EVENT\_INIT.** Do not initialize the FADT-defined GPE blocks. For hardware independent mode only.

**RETURN**

Status

Exception code that indicates success or reason for failure.

**EXCEPTIONS**

AE\_OK

The ACPI namespace was successfully loaded and initialized.

AE\_NO\_MEMORY

Insufficient memory to build the internal namespace.

**Functional Description:**

---

This function completes initialization of the ACPICA Subsystem by initializing all ACPI Devices, Operation Regions, Buffer Fields, Buffers, and Packages. It must be called and it should only be called after a call to *AcpiEnableSubsystem*. The object cache is purged after these objects are initialized, in case an overly large number of cached objects were created during initialization (versus the size of the caches at runtime.)



## 8.1.5 AcpiSubsystemStatus

**Obtain initialization status of the ACPICA subsystem.**

**ACPI\_STATUS**  
**AcpiSubsystemStatus (**  
     **void)**

### PARAMETERS

None

### RETURN

Status                                      Exception code indicates success or reason for failure.

### EXCEPTIONS

AE\_OK                                      The subsystem was successfully initialized.

AE\_ERROR                                  The subsystem has not been initialized

### Functional Description:

This function allows device drivers to determine the initialization status of the ACPICA subsystem.:

## 8.1.6 AcpiTerminate

**Shutdown all ACPI Components.**

**ACPI\_STATUS**  
**AcpiTerminate (**  
     **void)**

### PARAMETERS

None

### RETURN

Status                                      Exception code indicates success or reason for failure.

### EXCEPTIONS

AE\_OK                                      The subsystem was successfully shutdown.

AE\_ERROR                                  The OS-dependent layer did not shutdown properly.

**Functional Description:**

---

This function performs a shutdown of the OS-independent portion of the ACPICA subsystem. The namespace tables are unloaded, and all resources are freed to the host operating system. This function should be called prior to unloading the ACPICA subsystem. In more detail, the terminate function performs the following:

- Free all memory associated with the ACPI tables (either allocated or mapped memory).
- Free all internal objects associated with the namespace.
- Free all objects within the object caches.
- Free all OS resources associated with mutual exclusion.

## 8.1.7 AcpInstallInterface

<b>Install an interface into the list of interfaces recognized by the _OSI predefined method.</b>
---

**ACPI\_STATUS**

**AcpInstallInterface (**  
    **ACPI\_STRING**                    **InterfaceName)**

**PARAMETERS**

InterfaceName	A pointer to a string containing the name of the interface.
---------------	---

**RETURN**

Status	Exception code that indicates success or reason for failure.
--------	--

**EXCEPTIONS**

AE_OK	The interface was successfully installed.
AE_BAD_PARAMETER	Either <i>InterfaceName</i> is NULL or it points to a NULL string.
AE_NO_MEMORY	Insufficient memory to install the interface.
AE_ALREADY_EXISTS	The interface already exists.

**Functional Description:**

---

This function installs an interface into the global list of interfaces that are recognized by the \_OSI predefined control method. Once installed, \_OSI will return TRUE for a query that matches the *InterfaceName*.



### 8.1.7.1 Default Supported \_OSI Strings

The following table lists the strings that are supported by ACPICA by default. This means that an \_OSI query on any of the default strings will return TRUE.

The *AcpiInstallInterface* function may be used to dynamically add additional strings to this list, or the *AcpiRemoveInterface* function may be used to dynamically remove strings from this list.

```
/* Operating System Vendor Strings */

"Windows 2000"           /* Windows 2000 */
"Windows 2001"           /* Windows XP */
"Windows 2001 SP1"       /* Windows XP SP1 */
"Windows 2001.1"         /* Windows Server 2003 */
"Windows 2001 SP2"       /* Windows XP SP2 */
"Windows 2001.1 SP1"     /* Windows Server 2003 SP1 - Added 03/2006 */
"Windows 2006"           /* Windows Vista - Added 03/2006 */
"Windows 2006.1"         /* Windows Server 2008 - Added 09/2009 */
"Windows 2006 SP1"       /* Windows Vista SP1 - Added 09/2009 */
"Windows 2006 SP2"       /* Windows Vista SP2 - Added 09/2010 */
"Windows 2009"           /* Windows 7 and Server 2008 R2 - Added 09/2009 */
"Windows 2012"           /* Windows 8 and Server 2012 - Added 08/2012 */
"Windows 2013"           /* Windows 8.1 and Server 2012 R2 - Added 01/2014 */

/* Feature Group Strings */

"Extended Address Space Descriptor"

/*
 * All "optional" feature group strings (features that are implemented
 * by the host) should be dynamically modified to VALID by the host via
 * AcpiInstallInterface or AcpiUpdateInterfaces. Such optional feature
 * group strings are set as INVALID by default.
 */
"Module Device"
"Processor Device"
"3.0 Thermal Model"
"3.0 _SCP Extensions"
"Processor Aggregator Device"
*/
```

### 8.1.7.2 Why ACPICA responds TRUE to \_OSI (Windows)

ACPICA responds TRUE to all known Windows strings because ACPICA attempts to be fully compatible with the Windows implementation of ACPI. On the other hand, ACPICA responds FALSE to other operating system strings (such as "Linux", "FreeBSD", or "HP-UX") because doing so has been seen to often cause serious problems. For example, on many platforms, the only path through the ASL code that has been fully tested by the manufacturer is in fact the path for "Windows". By responding TRUE to other operating system strings, the ASL may execute paths that have had only limited or even no evaluation.

An experience with the "Linux" \_OSI string as experienced by Linux developers is documented below.



### The story of \_OSI(Linux)

From pre-history through Linux-2.6.22, Linux responded TRUE upon a BIOS \_OSI(Linux) query.

Unfortunately, reference BIOS writers got wind of this and put \_OSI(Linux) in their example code, quickly exposing this string as ill-conceived and opening the door to an un-bounded number of BIOS incompatibilities.

For example, \_OSI(Linux) was used on resume to re-POST a video card on one system, because Linux at that time could not do a speedy restore in its native driver. But then upon gaining quick native restore capability, Linux has no way to tell the BIOS to skip the time-consuming POST -- putting Linux at a permanent performance disadvantage. On another system, the BIOS writer used \_OSI(Linux) to infer native OS support for IPMI! On other systems, \_OSI(Linux) simply got in the way of Linux claiming to be compatible with other operating systems, exposing BIOS issues such as skipped device initialization.

So "Linux" turned out to be a really poor choice of \_OSI string, and from Linux-2.6.23 onward we respond FALSE.

BIOS writers should NOT query \_OSI(Linux) on future systems. Linux will complain on the console when it sees it, and return FALSE. To get Linux to return TRUE for your system will require a kernel source update to add a DMI entry, or boot with "acpi\_osi=Linux"

### 8.1.7.3 ACPICA Policy for New \_OSI Strings

It is the stated policy of ACPICA that new \_OSI strings will be integrated into the \_OSI support as soon as possible after they are defined. It is strongly recommended that all ACPICA hosts mirror this policy and integrate any \_OSI changes as soon as possible. There are several historical reasons behind this policy:

- 1) New BIOSs tend to test only the case where the host responds TRUE to the latest version of Windows, which would respond to the latest/newest \_OSI string. Not responding TRUE to the latest version of Windows will risk executing untested code paths throughout the DSDT and SSDTs.
- 2) If a new \_OSI string is recognized only after a significant delay, this has the potential to cause problems on existing working machines because of the possibility that a new and different path through the ASL code will be executed.
- 3) New \_OSI strings are tending to come out about once per year. A delay in recognizing a new string for a significant amount of time risks the release of another string which only compounds the initial problem.



## 8.1.8 AcpiUpdateInterfaces

Update _OSI interface strings. Used for debugging
---

**ACPI\_STATUS**

**AcpiUpdateInterfaces (**

**UINT8**

**Action)**

### PARAMETERS

Action

Flags that specify the action to be performed. One of the following manifest constants:

**ACPI\_DISABLE\_ALL\_VENDOR\_STRINGS** – Disable all of the operating system vendor strings.

**ACPI\_DISABLE\_ALL\_FEATURE\_STRINGS** – Disable all of the feature group strings.

**ACPI\_DISABLE\_ALL\_STRINGS** – Disable all supported \_OSI strings.

**ACPI\_ENABLE\_ALL\_VENDOR\_STRINGS** – Enable all of the operating system vendor strings.

**ACPI\_ENABLE\_ALL\_FEATURE\_STRINGS** – Enable all of the feature group strings.

**ACPI\_ENABLE\_ALL\_STRINGS** – Enable all supported \_OSI strings.

### RETURN

Status

Exception code that indicates success or reason for failure.

### EXCEPTIONS

AE\_OK

The action was successfully performed.

AE\_BAD\_PARAMETER

Action is not one of the supported manifest constants.

### Functional Description:

This function globally modifies the behavior of the \_OSI function by disabling or enabling all of the vendor strings, feature strings, or both. It is typically used for debugging purposes only.



## 8.1.9 AcpiRemoveInterface

Remove an interface from the list of interfaces recognized by the \_OSI predefined method.

ACPI\_STATUS  
AcpiRemoveInterface (  
ACPI\_STRING

InterfaceName)

### PARAMETERS

InterfaceName	A pointer to a string containing the name of the interface.
---------------	---

### RETURN

Status	Exception code that indicates success or reason for failure.
--------	--

### EXCEPTIONS

AE_OK	The interface was successfully removed.
AE_BAD_PARAMETER	Either <i>InterfaceName</i> is NULL or it points to a NULL string.
AE_NOT_EXIST	The interface does not exist.

### Functional Description:

This function removes an interface from the global list of interfaces that are recognized by the \_OSI predefined control method. Once removed, an \_OSI query for the *InterfaceName* will return FALSE.

## 8.1.10 AcpiInstallInterfaceHandler

Install or remove a handler for \_OSI invocations.

ACPI\_STATUS  
AcpiInstallInterfaceHandler (  
ACPI\_INTERFACE\_HANDLER      Handler)

### PARAMETERS

Handler	Address of the handler to be installed. A NULL pointer will remove a previously installed handler.
---------	--

### RETURN

Status	Exception code that indicates success or reason for failure.
--------	--

**EXCEPTIONS**

AE_OK	The handler was successfully installed or removed.
AE_ALREADY_EXISTS	A handler has already been installed.

**Functional Description:**

This function installs or removes a global handler for all \_OSI invocations. The handler is invoked whenever an \_OSI invocation is encountered in the executing system AML.

An \_OSI handler is entirely optional and should only be installed if it is necessary for the host OS to know exactly when \_OSI is invoked and/or what interfaces are being requested by the system AML. Otherwise, the *AcpiInstallInterface* and *AcpiRemoveInterface* functions should be sufficient.

**8.1.10.1 Interface to \_OSI Interface Handlers**
**Definition of the handler interface for \_OSI handlers.**

```
typedef
UINT32 (*ACPI_INTERFACE_HANDLER) (
    ACPI_STRING      InterfaceName,
    UINT32           Supported)
```

**PARAMETERS**

InterfaceName	A pointer to a string containing the name of the interface that was requested via _OSI.
Supported	TRUE or FALSE, indicates whether the <i>InterfaceName</i> was found in the global _OSI interface table.

**RETURN VALUE**

Supported	Value of <i>Supported</i> to be returned to the AML code from the execution of _OSI. This allows the host to either accept and return the input value of <i>Supported</i> , or override it with a new value.
-----------	--

**Functional Description:**

This handler is installed via *AcpiInstallInterfaceHandler*. It is invoked whenever the \_OSI predefined control method is invoked from the system AML.





## 8.2 ACPI Table Management

### 8.2.1 AcpiInitializeTables

**Initialize the ACPICA table manager.**

#### ACPI\_STATUS

**AcpiInitializeTables (**  
    **ACPI\_TABLE\_DESC**           **\*InitialTableArray,**  
    **UINT32**                   **InitialTableCount,**  
    **BOOLEAN**                 **AllowResize)**

#### PARAMETERS

InitialTableArray	Pointer to an array of pre-allocated <b>ACPI_TABLE_DESC</b> structures. If NULL, the array is dynamically allocated.
InitialTableCount	Requested size of InitialTableArray, in number of <b>ACPI_TABLE_DESC</b> structures.
AllowResize	Flag to tell the Table Manager if a resize of the pre-allocated array is allowed. Ignored if <i>InitialTableArray</i> is NULL.

#### RETURN VALUE

Status	Exception code that indicates success or reason for failure.
--------	--

#### EXCEPTIONS

AE_OK	The table manager was successfully initialized.
AE_NOT_FOUND	A valid RSDP could not be located.
AE_NO_MEMORY	Insufficient dynamic memory to complete the operation.

#### Functional Description:

This function initializes the table manager component. A memory array is required to store information about the BIOS-provided ACPI tables. It can be pre-allocated by the caller (if dynamic memory is not available yet) or it can be allocated by this function.

Specify a static memory array for the InitialTableArray if the Table Manager is to be used early during kernel initialization, before dynamic memory is available. Otherwise, use a NULL pointer and the Table Manager will use dynamic memory to allocate the array.

### 8.2.2 AcpiReallocateRootTable

**Copy the root ACPI information table into dynamic memory.**

## ACPI\_STATUS AcpiReallocateRootTable ( void)

## PARAMETERS

None

## RETURN

Status	Exception code indicates success or reason for failure.
--------	---

## EXCEPTIONS

AE_OK	The table was successfully enlarged.
AE_NO_MEMORY	Insufficient dynamic memory to complete the operation.

### Functional Description:

This function copies the root table into dynamic memory. The root table is used to store information about the BIOS-provided ACPI tables. This function should be called after dynamic memory is available within the kernel and if *AcpiInitializeTables* was called with a pre-allocated static table array.

### 8.2.3 AcpiFindRootPointer

**Locate the RSDP via memory scan (IA-32).**

```
ACPI_STATUS
AcpiFindRootPointer (
    ACPI_SIZE      *TableAddress)
```

## PARAMETERS

TableAddress	A pointer to where the physical address of the ACPI RSDP table will be returned.
--------------	--

## RETURN VALUE

Status	Exception code that indicates success or reason for failure.
--------	--

## EXCEPTIONS

AE OK                      The RSDP was found and returned.



AE_NOT_FOUND	A valid RSDP could not be located.
AE_NO_MEMORY	Insufficient dynamic memory to complete the operation.

**Functional Description:**

This function locates and returns the ACPI Root System Description Pointer by scanning within the first megabyte of physical memory for the RSDP signature. This mechanism is only applicable to IA-32 systems.

This interface should only be called from the OSL function *AcpiOsGetRootPointer* if this memory scanning mechanism is appropriate for the current platform.

If the operation fails an appropriate status will be returned and the value of *RsdpPhysicalAddress* is undefined.

This function is always available, regardless of the initialization state of the rest of ACPICA.

## 8.2.4 AcpiInstallTable

Early installation of a single host-provided ACPI table.

**ACPI\_STATUS**

**AcpiInstallTable** (  
    **ACPI\_PHYSICAL\_ADDRESS**   **Address,**  
    **BOOLEAN**               **Physical)**

**PARAMETERS**

Address	The ACPI table to be installed. Must be a buffer containing a valid ACPI table with a valid table header.
Physical	TRUE if <i>Address</i> is a physical address. Otherwise, <i>Address</i> is a logical address.

**RETURN VALUE**

Status	Exception code that indicates success or reason for failure.
--------	--

**EXCEPTIONS**

AE_OK	The table was successfully installed.
AE_ALREADY_EXISTS	The table already exists within the ACPICA data structures.
AE_BAD_CHECKSUM	The computed table checksum does not match the checksum in the table.
AE_BAD_HEADER	The table header is invalid or is not a valid type.
AE_BAD_SIGNATURE	The table signature is invalid or is not a valid type.
AE_NO_MEMORY	Insufficient dynamic memory to complete the operation.



### Functional Description:

This function installs an ACPI table that is provided by the host in a buffer. It must be a valid ACPI table with a valid ACPI header. The table is not copied, so the caller must manage the buffer that contains the table. If the *Address* is a physical address, the table will be mapped by ACPICA via *AcpiOsMapMemory*.

This function allows tables to be installed into the ACPICA internal data structures before the namespace is actually loaded. Thus, SSDTs or any other ACPI table except for the DSDT and the FACS can be installed.

NOTE: Should only be called after *AcpiInitializeTables* and before the *AcpiLoadTables* interface.

## 8.2.5 AcpiLoadTables

**Load the BIOS-provided ACPI tables and build an internal ACPI namespace.**

**ACPI\_STATUS**  
**AcpiLoadTables** (  
     **void**)

### PARAMETERS

None

### RETURN VALUE

Status	Exception code that indicates success or reason for failure.
--------	--

### EXCEPTIONS

AE_OK	The table was successfully loaded and a handle returned.
AE_BAD_CHECKSUM	The computed table checksum does not match the checksum in the table.
AE_BAD_HEADER	The table header is invalid or is not a valid type.
AE_NO_ACPI_TABLES	The ACPI tables (RSDT, DSDT, FADT, etc.) could not be found in physical memory.
AE_NO_MEMORY	Insufficient dynamic memory to complete the operation.

### Functional Description:

This function loads ACPI tables that are pointed to by the RSDP/RSDT and installs them into the internal ACPI namespace database. The *Root System Description Pointer* (RSDP) points to the *Root System Description Table* (RSDT), and the remaining ACPI tables are found via pointers contained in RSDT.

The minimum required set of ACPI tables that will allow the ACPICA Subsystem to initialize consists of the following:

- ◆ RSDT/XSDT



- ◆ FADT
- ◆ FACS
- ◆ DSDT

Only tables that are used directly by the ACPICA subsystem are loaded. Other tables (such as the MADT, SRAT, etc.) are obtained and consumed by different kernel subsystems and/or device drivers.

All SSDTs found within the RSDT/XSDT are loaded.

If the operation fails an appropriate status will be returned.

## 8.2.6 AcpiLoadTable

**Load a single host-provided ACPI table.**

**ACPI\_STATUS**  
**AcpiLoadTable** (  
    **ACPI\_TABLE\_HEADER**    **\*Table**)

### PARAMETERS

Table	The ACPI table to be loaded into the namespace. Must be a buffer containing a valid ACPI table with a valid table header.
-------	---

### RETURN VALUE

Status	Exception code that indicates success or reason for failure.
--------	--

### EXCEPTIONS

AE_OK	The table was successfully loaded.
AE_BAD_PARAMETER	The Table parameter is NULL.
AE_BAD_CHECKSUM	The computed table checksum does not match the checksum in the table.
AE_BAD_HEADER	The table header is invalid or is not a valid type.
AE_NO_ACPI_TABLES	The standard ACPI tables (RSDT, DSDT, FADT, etc.) have not been loaded.
AE_NO_MEMORY	Insufficient dynamic memory to complete the operation.

---

### Functional Description:

This function loads an ACPI table that is provided by the host in a buffer. It must be a valid ACPI table with a valid ACPI header. The table is not copied, so the caller must manage the buffer that contains the table.



This function is primarily intended for hotplug addition of SSDTs. The *AcpiUnloadParentTable* is intended for hotplug removal of SSDTs.

NOTE: Should only be called after the namespace has been loaded and initialized via the *AcpiLoadTables* interface.

## 8.2.7 AcpiUnloadParentTable

**Unloads an ACPI table via a namespace object that is owned by the table.**

### ACPI\_STATUS

**AcpiUnloadParentTable (**  
     **ACPI\_HANDLE**                      **Object)**

### PARAMETERS

Object	An ACPI_HANDLE for any namespace object that is owned by the table to be unloaded.
--------	--

### RETURN VALUE

Status	Exception code that indicates success or reason for failure.
--------	--

### EXCEPTIONS

AE_OK	The table was successfully unloaded.
AE_BAD_PARAMETER	The Object parameter is NULL.
AE_NOT_EXIST	The table is not actually loaded at this time.
AE_TYPE	The Object is owned by the DSDT, which cannot be unloaded.

### Functional Description:

---

This function can unload an SSDT or OEMx table via any namespace object that is owned by the table. Unloading the DSDT is not allowed.

This function is primarily intending for hotplug dynamic removal of ACPI tables. It is typically used to remove a table that has been previously loaded via the *AcpiLoadTable* interface.



## 8.2.8 AcpiGetTableHeader

Get the header portion of a specific installed ACPI table.
--

### ACPI\_STATUS

AcpiGetTableHeader (

char	*Signature,
UINT32	Instance,
ACPI_TABLE_HEADER	*OutTableHeader)

### PARAMETERS

Signature	A pointer to the 4-character ACPI signature for the requested table.
Instance	For table types that support multiple tables (SSDT and UEFI), the instance of the table to be returned (one based: 1...n). For table types that support only a single table, this parameter must be set to one.
OutTableHeader	A pointer to a location where the table header is to be returned.

### RETURN VALUE

Status	Exception code that indicates success or reason for failure.
--------	--

### EXCEPTIONS

AE_OK	The table header was successfully located and returned.
AE_BAD_PARAMETER	At least one of the following is true:  The Signature pointer is NULL.  The OutTableHeader pointer is NULL.
AE_NOT_FOUND	There is no table with this <i>Signature</i> currently loaded, or the table of the specified <i>Instance</i> is not loaded.
AE_TYPE	The table <i>Signature</i> is not supported (RSDP).

### Functional Description:

---

This function obtains the header of an installed ACPI table. The header contains a length field that can be used to determine the size of the buffer needed to contain the entire table. This function is not valid for the RSDP table since it does not have a standard header and is fixed length.

For table types that support more than one table, the *Instance* parameter is used to specify which table header of the given signature should be returned. This parameter is one-based. To retrieve multiple tables, use the sequence 1...n until an exception is returned. For table types that only support single tables, the *Instance* parameter must be set to one.



If the operation fails an appropriate status will be returned and the contents of *OutTableHeader* are undefined.

## 8.2.9 AcpiGetTable

**Obtain a specific installed ACPI table.**

### ACPI\_STATUS

**AcpiGetTable** (  
     **char**                               **\*Signature,**  
     **UINT32**                           **Instance,**  
     **ACPI\_TABLE\_HEADER**           **\*\*Table)**

### PARAMETERS

Signature	A pointer to the 4-character ACPI signature for the requested table.
Instance	Which table instance, if multiple instances of the table are allowed (SSDT or UEFI). One based (1...n).
Table	A pointer to where the address of the requested ACPI table is returned.

### RETURN VALUE

Status	Exception code that indicates success or reason for failure.
--------	--

### EXCEPTIONS

AE_OK	The requested table was found and returned.
AE_BAD_PARAMETER	At least one of the following is true:  The Signature pointer is NULL.  The OutTableHeader pointer is NULL.
AE_NO_ACPI_TABLES	A valid RSDP could not be located.
AE_NOT_FOUND	There is no table with this <i>Signature</i> currently loaded, or the table of the specified <i>Instance</i> is not loaded.
AE_NO_MEMORY	Insufficient dynamic memory to complete the operation.

### Functional Description:

This function locates and returns one of the ACPI tables that are supplied by the system firmware. On IA-32 systems, this involves scanning within the first megabyte of physical memory for the RSDP signature.

This function may be called at any time after the Table Manager is initialized, even before the ACPICA subsystem has been initialized. This allows early access to ACPI tables -- even before the system virtual memory manager has been started.





For table types that support more than one table, the *Instance* parameter is used to specify which table of the given signature should be returned. This parameter is one-based. To retrieve multiple tables, use the sequence 1...n until an exception is returned. For table types that only support single tables, the *Instance* parameter must be set to one.

If the operation fails an appropriate status will be returned and the value of *Table* is undefined.

## 8.2.10 AcpiGetTableByIndex

Obtain an installed ACPI table via an index into the Root Table
---

### ACPI\_STATUS

AcpiGetTableByIndex (  
    UINT32                      **TableIndex,**  
    ACPI\_TABLE\_HEADER        **\*\*OutTable)**

### PARAMETERS

TableIndex	Index of the table within the internal Root Table list.
OutTable	A pointer to location where the table is to be returned.

### RETURN VALUE

Status	Exception code that indicates success or reason for failure.
--------	--

### EXCEPTIONS

AE_OK	The table was successfully located and returned.
AE_BAD_PARAMETER	At least one of the following is true:  The <i>OutTable</i> pointer is NULL.
AE_NOT_EXIST	There is no table of this type currently loaded, or the table of the specified <i>Instance</i> is not loaded.

### Functional Description:

---

This function obtains an installed ACPI table. It is useful for iterating through the entire set of installed ACPI tables. To obtain a specific ACPI table, use *AcpiGetTable* or *AcpiGetTableHeader*.

If the operation fails an appropriate status will be returned and the contents of *OutTable* is undefined.



## 8.2.11 AcpilInstallTableHandler

Install a global handler for ACPI table load and unload events.

```
ACPI_STATUS
AcpilInstallTableHandler (
    ACPI_TABLE_HANDLER    Handler,
    void                  *Context)
```

### PARAMETERS

Handler	Address of the handler to be installed.
Context	A context value that will be passed to the handler as a parameter.

### RETURN VALUE

Status	Exception code that indicates success or reason for failure.
--------	--

### EXCEPTIONS

AE_OK	The handler was successfully installed.
AE_BAD_PARAMETER	At least one of the following is true:  The <i>Handler</i> pointer is NULL.
AE_ALREADY_EXISTS	A global table handler is already installed.

### Functional Description:

This function installs a global handler for table load/unload events.

### 8.2.11.1 Interface to the Table Event Handler

Definition of the handler interface for Table Events.

```
typedef
ACPI_STATUS (*ACPI_TABLE_HANDLER) (
    UINT32    Event,
    void      *Table,
    void      *Context)
```

### PARAMETERS

Event	The table event that occurred. One of these manifest constants:  <b>ACPI_TABLE_EVENT_LOAD</b> – The table was just loaded.
-------	--



	<b>ACPI_TABLE_EVENT_UNLOAD</b> – The table is about to be unloaded.
Table	The table that was either just loaded or is about to be unloaded.
Context	The Context value that was passed as a parameter to the <i>AcpiInstallTableHandler</i> function.

**RETURN VALUE**

None

**Functional Description:**

---

This handler is installed via *AcpiInstallTableHandler*. It is called whenever an ACPI table is either loaded or unloaded.

This function **does not** execute in the context of an interrupt handler.

## 8.2.12 **AcpiRemoveTableHandler**

Remove a handler for ACPI table events.

**ACPI\_STATUS**

**AcpiRemoveTableHandler** (  
    **ACPI\_TABLE\_HANDLER**      **Handler**)

**PARAMETERS**

Handler	Address of the previously installed handler.
---------	--

**RETURN VALUE**

Status	Exception code that indicates success or reason for failure.
--------	--

**EXCEPTIONS**

AE_OK	The handler was successfully removed.
AE_BAD_PARAMETER	At least one of the following is true:  The Handler pointer is NULL.  The Handler address is not the same as the one that is installed.
AE_NOT_EXIST	There is no handler installed for notifications on this object.

**Functional Description:**

---

This function removes a handler for notify events that was previously installed via a call to *AcpiInstallTableHandler*.



## 8.3 ACPI Namespace Management

### 8.3.1 AcpiEvaluateObject

**Evaluate an ACPI namespace object and return the result.**

#### ACPI\_STATUS

**AcpiEvaluateObject (**  
     **ACPI\_HANDLE**                      **Object,**  
     **ACPI\_STRING**                    **Pathname,**  
     **ACPI\_OBJECT\_LIST**            **\*MethodParams,**  
     **ACPI\_BUFFER**                   **\*ReturnBuffer)**

#### PARAMETERS

Object	One of the following:  A handle to the object to be evaluated.  A handle to a parent object that is a prefix to the pathname.  A NULL handle if the pathname is fully qualified.
Pathname	Pathname of namespace object to evaluate. May be either an absolute path or a path relative to the Object.
MethodParams	If the object is a control method, this is a pointer to a list of parameters to pass to the method. This pointer may be NULL if no parameters are being passed to the method or if the object is not a method.
ReturnBuffer	A pointer to a location where the return value of the object evaluation (if any) is placed. If this pointer is NULL, no value is returned.

#### RETURN VALUE

Status	Exception code that indicates success or reason for failure.
--------	--

#### EXCEPTIONS

AE_OK	The object was successfully evaluated.
AE__LIMIT	More than the maximum number of 7 arguments were passed to a method.
AE_AML_ERROR	An unspecified error occurred during the parsing of the AML code.
AE_AML_PARSE	The control method could not be parsed due to invalid AML code.



AE_AML_BAD_OPCODE	An invalid opcode was encountered in the AML code.
AE_AML_NO_OPERAND	An required operand was missing. This could be caused by a method that does not return any object.
AE_AML_OPERAND_TYPE	An operand object is not of the required ACPI type.
AE_AML_OPERAND_VALUE	An operand object has an invalid value
AE_AML_UNINITIALIZED_LOCAL	A method attempted to access a local variable that was not initialized.
AE_AML_UNINITIALIZED_ARG	A method attempted to access an argument that was not part of the argument list, or was not passed into the method properly.
AE_AML_UNINITIALIZED_ELEMENT	A method attempted to use (dereference) a reference to an element of a package object that is empty (uninitialized).
AE_AML_NUMERIC_OVERFLOW	An overflow occurred during a numeric conversion (Such as BCD conversion.)
AE_AML_REGION_LIMIT	A method attempted to access beyond the end of an Operation Region defined boundary.
AE_AML_BUFFER_LIMIT	A method attempted to access beyond the end of a Buffer object.
AE_AML_PACKAGE_LIMIT	A method attempted to access beyond the end of a Package object.
AE_AML_DIVIDE_BY_ZERO	A method attempted to execute a divide instruction with a zero divisor.
AE_AML_BAD_NAME	A name contained within the AML code has one or more invalid characters.
AE_AML_NAME_NOT_FOUND	A name reference within the AML code could not be found and therefore could not be resolved.
AE_AML_INTERNAL	An error that is internal to the ACPICA subsystem occurred.
AE_BAD_CHARACTER	An invalid character was found in the Pathname parameter.
AE_BAD_DATA	Bad or invalid data was found in a package object.
AE_BAD_PATHNAME	The path contains at least one ACPI name that is not exactly four characters long.
AE_BAD_PARAMETER	At least one of the following is true:  Both the <i>Object</i> and <i>Pathname</i> parameters are NULL.



	The <i>Object</i> handle is NULL, but the <i>Pathname</i> is not absolute.
	The <i>Pathname</i> is relative but the <i>Object</i> is invalid.
	The <i>Length</i> field of <i>OutBuffer</i> is not ACPI_ALLOCATE_BUFFER, but the <i>Pointer</i> field of <i>OutBuffer</i> is NULL.
AE_BUFFER_OVERFLOW	The <i>Length</i> field of the <i>ReturnBuffer</i> is too small to hold the actual returned object. Upon return, the <i>Length</i> field contains the minimum required buffer length.
AE_ERROR	An unspecified error occurred.
AE_NO_MEMORY	Insufficient dynamic memory to complete the request.
AE_NOT_FOUND	The object referenced by the combination of the <i>Object</i> and <i>Pathname</i> was not found within the namespace.
AE_NULL_OBJECT	A required object was missing. This is an internal error.
AE_STACK_OVERFLOW	An internal stack overflow occurred because of an error in the AML, or because control methods or objects are nested too deep.
AE_STACK_UNDERFLOW	An internal stack underflow occurred during evaluation.
AE_TYPE	The object is of a type that cannot be evaluated.

#### Functional Description:

---

This function locates and evaluates objects in the namespace. This interface has two modes of operation, depending on the type of object that is being evaluated:

1. If the target object is a control method, the method is executed and the result (if any) is returned.
2. If the target is not a control method, the current “value” of that object is returned. The type of the returned value corresponds to the type of the object; for example, the object (and the corresponding returned result) may be a Integer, a String, or a Buffer.

**Specifying a Target Object:** The target object may be any valid named ACPI object. To specify the object, a valid *Object*, a valid *Pathname*, or both may be provided. However, at least one of these parameters must be valid.

If the *Object* is NULL, the *Pathname* must be a fully qualified (absolute) namespace path.

If the *Object* is non-NULL, the *Pathname* may be either:

1. A path relative to the *Object* handle (a *relative* pathname as defined in the ACPI specification)
2. An absolute pathname. In this case, the *Object* handle is ignored.



**Parameters to Control Methods:** If the object to be evaluated is a control method, the caller can supply zero or more parameters that will be passed to the method when it is executed.. The *MethodParams* parameter is a pointer to an *ACPI\_OBJECT\_LIST* that in turn is a counted array of *ACPI\_OBJECT*s. If *MethodParams* is NULL, then no parameters are passed to the control method. If the *Count* field of *MethodParams* is zero, then the entire parameter is treated exactly as if it is a NULL pointer. If the object to be evaluated is not a control method, the *MethodParams* field is ignored.

**Receiving Evaluation Results:** The *ReturnObject* parameter optionally receives the results of the object evaluation. If this parameter is NULL, the evaluation results are not returned and are discarded. If there is no result from the evaluation of the object and no error occurred, the *Length* field of the *ReturnObject* parameter is set to zero.

**Unsupported Object Types:** The object types that cannot be evaluated are the following: *ACPI\_TYPE\_DEVICE*. Others TBD.

**Exceptional Conditions:** Any exceptions that occur during the execution of a control method result in the immediate termination of the control methods. All nested control methods are also terminated, up to and including the parent method.

## EXAMPLES

**Example 1:** Executing the control method with an absolute path, two input parameters, with no return value expected:

```
ACPI_OBJECT_LIST    Params;
ACPI_OBJECT         Obj[2];

/* Initialize the parameter list */

Params.Count = 2;
Params.Pointer = &Obj;

/* Initialize the parameter objects */

Obj[0].Type = ACPI_TYPE_STRING;
Obj[0].String.Pointer = "ACPI User";

Obj[1].Type = ACPI_TYPE_NUMBER;
Obj[1].Number.Value = 0x0E00200A;

/* Execute the control method */

Status = AcpiEvaluateObject (NULL, "\\_SB.PCI0._TWO" , &Params, NULL);
```

**Example 2:** Before executing a control method that returns a result, we must declare and initialize an *ACPI\_BUFFER* to contain the return value:

```
ACPI_BUFFER         Results;
ACPI_OBJECT         Obj;

/* Initialize the return buffer structure */

Results.Length = sizeof (Obj);
Results.Pointer = &Obj;
```

The three examples that follow are functionally identical.



**Example 3:** Executing a control method using an absolute path. In this example, there are no input parameters, but a return value is expected.

```
Status = AcpiEvaluateObject (NULL, "\\_SB.PCI0._STA" , NULL, &Results);
```

**Example 4:** Executing a control method using a relative path. A return value is expected.

```
Status = AcpiPathnameToHandle ("\\_SB.PCI0", &Object)
Status = AcpiEvaluateObject (Object, "_STA" , NULL, &Results);
```

**Example 5:** Executing a control method using a relative path. A return value is expected.

```
Status = AcpiPathnameToHandle ("\\_SB.PCI0._STA", &Object)
Status = AcpiEvaluateObject (Object, NULL, NULL, &Results);
```

## 8.3.2 AcpiEvaluateObjectTyped

**Evaluate an ACPI namespace object and return the type-validated result.**

### ACPI\_STATUS

#### AcpiEvaluateObjectTyped (

ACPI_HANDLE	Object,
ACPI_STRING	Pathname,
ACPI_OBJECT_LIST	*MethodParams,
ACPI_BUFFER	*ReturnBuffer,
ACPI_OBJECT_TYPE	ReturnType)

### PARAMETERS

Object	One of the following:  A handle to the object to be evaluated.  A handle to a parent object that is a prefix to the pathname.  A NULL handle if the pathname is fully qualified.
Pathname	Pathname of namespace object to evaluate. May be either an absolute path or a path relative to the Object.
MethodParams	If the object is a control method, this is a pointer to a list of parameters to pass to the method. This pointer may be NULL if no parameters are being passed to the method or if the object is not a method.
ReturnBuffer	A pointer to a location where the return value of the object evaluation (if any) is placed. If this pointer is NULL, no value is returned.
ReturnType	The expected type of the returned object.

### RETURN VALUE

Status	Exception code that indicates success or reason for failure.
--------	--



**EXCEPTIONS**

AE_OK	The object was successfully evaluated and the correct object type was returned.
AE_NULL_OBJECT	No object was returned from the evaluation.
AE_TYPE	An object of the incorrect type was returned.
Others	See the definition of <code>AcpiEvaluateObject</code> .

**Functional Description:**

---

This function locates and evaluates objects in the namespace and validates that the object returned from the evaluation is of the expected type. It is a front-end to *AcpiEvaluateObject*. See the description of *AcpiEvaluateObject* for more information.

### 8.3.3 **AcpiGetObjectInfo**

<b>Get information about an ACPI namespace object.</b>
--

**ACPI\_STATUS**

**AcpiGetObjectInfo (**  
    **ACPI\_HANDLE**                    **Object,**  
    **ACPI\_DEVICE\_INFO**             **\*\*OutBuffer)**

**PARAMETERS**

Object	A handle to an ACPI object for which information is to be returned.
OutBuffer	A pointer to a location where the device info pointer is returned.

**RETURN**

Status	Exception code that indicates success or reason for failure.
--------	--

**EXCEPTIONS**

AE_OK	Device info was successfully returned. See the <code>ACPI_DEVICE_INFO</code> structure for valid returned fields.
AE_BAD_PARAMETER	At least one of the following is true:  The <i>Object</i> handle is invalid.  The <i>OutBuffer</i> pointer is NULL.
AE_NO_MEMORY	Insufficient dynamic memory to complete the operation.



### Functional Description:

---

This function obtains information about an object contained within the ACPI namespace. For all namespace objects, the following information is returned:

Type	—	The ACPI object type ( <b>ACPI_TYPE_INTEGER</b> , etc.)
Name	—	The 4-character ACPI name of the object

For Control Method objects, this additional information is returned:

ParamCount	—	The required number of input parameters
------------	---	---

For Device and Processor objects, this additional information is returned as a result of evaluating the following standard ACPI device methods and objects on behalf of the device:

_ADR	—	The address of the object (bus and device specific)
_STA	—	The current status of the object/device
_HID	—	The hardware ID of the object (string)
_UID	—	The Unique ID of the object (string)
_SUB	—	The Subsystem ID of the object (string) (ACPI 5.0)
_CID	—	The Compatibility ID list of the object (strings)
_SxW	—	Methods that return the lowest D-state values ( <b>_S0W</b> , <b>_S1W</b> , <b>_S2W</b> , <b>_S3W</b> , <b>_S4W</b> )
_SxD	—	Methods that return the highest D-state values ( <b>_S1D</b> , <b>_S2D</b> , <b>_S3D</b> , <b>_S4D</b> )

**Returned Data Format:** The device information is returned in the **ACPI\_DEVICE\_INFO** structure that is defined as follows:

```
typedef struct
{
    UINT32                InfoSize;
    UINT32                Name;
    ACPI_OBJECT_TYPE      Type;
    UINT8                 ParamCount;
    UINT8                 Valid;
    UINT8                 Flags;
    UINT8                 HighestDstates[4];
    UINT8                 LowestDstates[5];
    UINT32                CurrentStatus;
    UINT64                Address;
    ACPI_PNP_DEVICE_ID    HardwareId;
    ACPI_PNP_DEVICE_ID    UniqueId;
    ACPI_PNP_DEVICE_ID    SubsystemId;
    ACPI_PNP_DEVICE_ID_LIST CompatibleIdList;
} ACPI_DEVICE_INFO;
```

### Where:

InfoSize	Entire size of the returned structure, including all ID strings that are appended to the end of the structure.
Name	The 4-character ACPI name of the object.
Type	Is the object type code.



ParamCount	If the object is a control method, this is the number of parameters defined for the method.
Valid	A bit field that indicates which of the optional fields below contain valid values. See below.
Flags	Miscellaneous information flags. The following flags are defined:  <b>ACPI_PCI_ROOT_BRIDGE</b> : Indicates that either the <b>_HID</b> or one of the <b>_CID</b> values matched either <b>PNP0A03</b> (PCI root bridge) or <b>PNP0A08</b> (PCI Express root bridge)
HighestDstates	<b>_SxD</b> device state values. 0xFF indicates that the field is invalid.
LowestDstates	<b>_SxW</b> device wake state values. 0xFF indicates that the field is invalid.
CurrentStatus	The result of evaluating <b>_STA</b> method for this object. If a <b>_STA</b> object does not exist for this device, then this status field will indicate that the device is <i>present</i> , <i>functional</i> , and <i>enabled</i> – as per the ACPI specification.
Address	The result of evaluating <b>_ADR</b> for this object.
HardwareId	A pointer to the string obtained as a result of evaluating <b>_HID</b> for this object.
UniqueId	A pointer to the string obtained as a result of evaluating <b>_UID</b> for this object.
SubsystemId	A pointer to the string obtained as a result of evaluating <b>_SUB</b> for this object.
CompatibleIds	An array of pointers to the string(s) obtained as a result of evaluating <b>_CID</b> for this object (a list of <b>_CIDs</b> .)

The fields of the structure that are valid because the corresponding method or object has been successfully found under the device are indicated by the values of the *Valid* bitfield via the following constants:

```
ACPI_VALID_ADR
ACPI_VALID_STA
ACPI_VALID_HID
ACPI_VALID_UID
ACPI_VALID_SUB
ACPI_VALID_CID
ACPI_VALID_SXDS
ACPI_VALID_SXWS
```

Each bit should be checked before the corresponding value in the structure can be considered valid. **None** of the methods/objects that are used by this interface are *required* by the ACPI specification. Therefore, there is no guarantee that all or even any of them are available for a particular device. Even if none of the methods are found, the interface will return an AE\_OK status — but none of the bits set in the *Valid* field return structure will be set.



The sub-structures used for the variable-length PNP device ID strings are defined as follows:

```
typedef struct
{
    UINT32          Length;    /* Length of string + null */
    char            *String;

} ACPI_PNP_DEVICE_ID;

typedef struct
{
    UINT32          Count;     /* Number of IDs in Ids array */
    UINT32          ListSize; /* Size of list, including ID strings */
    ACPI_PNP_DEVICE_ID Ids[1]; /* ID array */

} ACPI_PNP_DEVICE_ID_LIST;
```

Within the original ACPI tables, the **\_HID**, **\_UID**, and **\_CID** values can be of either type **ACPI\_TYPE\_STRING** or **ACPI\_TYPE\_INTEGER**. However, in order to provide a consistent data type in the external interface, these values are always returned as NULL terminated strings, regardless of the original data type in the source ACPI table. An internal data type conversion is performed if necessary, as follows:

- 32-bit compressed **EISAIDs** within **\_HID** and **\_CID** objects are decompressed and converted to strings.
- 64-bit integer IDs within **\_UID** objects are converted to decimal string representation.

The object returned from this function should be freed via **ACPI\_FREE**.

**Note:** The string pointers for **\_HID**, **\_UID**, **SUB**, and **\_CID** simply point to a reserved area within the returned buffer after the **ACPI\_DEVICE\_INFO** structure. When the return object is freed, these pointers will become invalid.

### 8.3.4 AcpiGetNextObject

**Get a handle to the next child ACPI object of a parent object.**

#### ACPI\_STATUS

```
AcpiGetNextObject (
    ACPI_OBJECT_TYPE    Type,
    ACPI_HANDLE         Parent,
    ACPI_HANDLE         Child,
    ACPI_HANDLE         *OutHandle)
```

#### PARAMETERS

Type	The desired type of the next object.
Parent	A handle to a parent object to be searched for the next child object.
Child	A handle to a child object. The next child object of the parent object that matches the Type will be returned. Use the value of NULL to get the first child of the parent.



OutHandle	A pointer to a location where a handle to the next child object is to be returned. If this pointer is NULL, the child object handle is not returned.
-----------	--

## RETURN VALUE

Status	Exception code that indicates success or reason for failure.
--------	--

## EXCEPTIONS

AE_OK	The next object was successfully found and returned.
AE_BAD_PARAMETER	At least one of the following is true:  The <i>Parent</i> handle is invalid.  The <i>Child</i> handle is invalid.  The <i>Type</i> parameter refers to an invalid type.
AE_NOT_FOUND	The child object parameter is the last object of the given type within the parent — a next child object was not found. If Child is NULL, this exception means that the parent object has no children.

## Functional Description:

---

This function obtains the next child object of the parent object that is of type *Type*. Both the *Parent* and the *Child* parameters are optional. The behavior for the various combinations of *Parent* and *Child* is as follows:

1. If the *Child* is non-NULL, it is used as the starting point (the *current object*) for the search.
2. If the *Child* is NULL and the *Parent* is non-NULL, the search is performed starting at the beginning of the scope.
3. If both the *Parent* and the *Child* parameters are NULL, the search begins at the start of the namespace (the search begins at the *Root Object*).

If the search fails, an appropriate status will be returned and the value of *OutHandle* is undefined.

This interface is appropriate for use within a loop that looks up a group of objects within the internal namespace. However, the *AcpiWalkNamespace* primitive implements such a loop and may be simpler to use in your application; see the description of this interface for additional details.



### 8.3.5 AcpiGetParent

Get a handle to the parent object of an ACPI object.

ACPI\_STATUS

AcpiGetParent (

ACPI\_HANDLE

ACPI\_HANDLE

Child,

\*OutParent)

#### PARAMETERS

Child

A handle to an object whose parent is to be returned.

OutParent

A pointer to a location where the handle to the parent object is to be returned.

#### RETURN VALUE

Status

Exception code that indicates success or reason for failure.

#### EXCEPTIONS

AE\_OK

The parent object was successfully found and returned.

AE\_BAD\_PARAMETER

At least one of the following is true:

The *Child* handle is invalid.

The *OutParent* pointer is NULL.

AE\_NULL\_ENTRY

The referenced object has no parent. (Entries at the root level do not have a parent object.)

#### Functional Description:

This function returns a handle to the parent of the *Child* object. If an error occurs, a status code is returned and the value of *OutParent* is undefined.

### 8.3.6 AcpiGetType

Get the type of an ACPI object.

ACPI\_STATUS

AcpiGetType (

ACPI\_HANDLE

ACPI\_OBJECT\_TYPE

Object,

\*OutType)

#### PARAMETERS

Object

A handle to an object whose type is to be returned.



OutType	A pointer to a location where the object type is to be returned.
---------	--

**RETURN**

Status	Exception code that indicates success or reason for failure.
--------	--

**EXCEPTIONS**

AE_OK	The object type was successfully returned.
-------	--

AE_BAD_PARAMETER	At least one of the following is true:
------------------	--

The *Object* handle is invalid.

The *OutType* pointer is NULL.

**Functional Description:**

---

This function obtains the type of an ACPI namespace object. See the definition of the **ACPI\_OBJECT\_TYPE** for a comprehensive listing of the available object types.

### 8.3.7 AcpiGetHandle

Get the object handle associated with an ACPI name.
---

**ACPI\_STATUS**

<b>AcpiGetHandle (</b> <b>ACPI_HANDLE</b> <b>ACPI_STRING</b> <b>ACPI_HANDLE</b>	<b>Parent,</b> <b>Pathname,</b> <b>*OutHandle)</b>
--	--

**PARAMETERS**

Parent	A handle to the parent of the object specified by Pathname. In other words, the Pathname is relative to the Parent. If Parent is NULL, the pathname must be a fully qualified pathname.
--------	---

Pathname	A name or pathname to an ACPI object (a NULL terminated ASCII string). The string can be either a single segment ACPI name or a multiple segment ACPI pathname (with path separators).
----------	--

OutHandle	A pointer to a location where a handle to the object is to be returned.
-----------	---

**RETURN VALUE**

Status	Exception code that indicates success or reason for failure.
--------	--



## EXCEPTIONS

AE_OK	The pathname was successfully associated with an object and the handle was returned.
AE_BAD_CHARACTER	An invalid character was found in the pathname.
AE_BAD_PATHNAME	The path contains at least one ACPI name that is not exactly four characters long.
AE_BAD_PARAMETER	At least one of the following is true:  The <i>Pathname</i> pointer is NULL.  The <i>Pathname</i> does not begin with a backslash character.  The <i>OutHandle</i> pointer is NULL.
AE_NO_NAMESPACE	The namespace has not been successfully loaded.
AE_NOT_FOUND	One or more of the segments of the pathname refers to a non-existent object.

## Functional Description:

---

This function translates an ACPI pathname into an object handle. It locates the object in the namespace via the combination of the *Parent* and *Pathame* parameters. Only the specified *Parent* object will be searched for the name — this function will not perform a walk of the namespace tree (See *AcpiWalkNamespace*).

The pathname is relative to the *Parent*. If the parent object is NULL, the *Pathname* must be fully qualified (absolute), meaning that the path to the object must be a complete path from the root of the namespace, and the pathname must begin with a backslash ('\').

Multiple instances of the same name under a given parent (within a given scope) are not allowed by the ACPI specification. However, if more than one instance of a particular name were to appear under a single parent in the ACPI DSDT, only the first one would be successfully loaded into the internal namespace. The second attempt to load the name would collide with the first instance of the name, and the second instance would be ignored.

If the operation fails an appropriate status will be returned and the value of *OutHandle* is undefined.





### 8.3.8 AcpiGetName

Get the name of an ACPI object.
---------------------------------

ACPI\_STATUS

AcpiGetName (

ACPI\_HANDLE

UINT32

ACPI\_BUFFER

Object,

NameType,

\*OutName)

#### PARAMETERS

Object

A handle to an object whose name or pathname is to be returned.

NameType

The type of name to return; must be one of these manifest constants:

**ACPI\_FULL\_PATHNAME** – return a complete pathname (from the namespace root) to the object.

**ACPI\_SINGLE\_NAME** – return a single segment ACPI name for the object (4 characters, null terminated).

OutName

A pointer to a location where the fully qualified and NULL terminated name or pathname is to be returned.

#### RETURN VALUE

Status

Exception code that indicates success or reason for failure.

#### EXCEPTIONS

AE\_OK

The full pathname associated with the handle was successfully retrieved and returned.

AE\_BAD\_PARAMETER

At least one of the following is true:

The Parent handle is invalid.

The Object handle is invalid.

The OutName pointer is NULL.

The *Length* field of *OutName* is not **ACPI\_ALLOCATE\_BUFFER**, but the *Pointer* field of *OutName* is NULL.

AE\_BUFFER\_OVERFLOW

The *Length* field of *OutName* indicates that the buffer is too small to hold the actual pathname. Upon return, the *Length* field contains the minimum required buffer length.

AE\_NO\_NAMESPACE

The namespace has not been successfully loaded.



### Functional Description:

This function obtains the name that is associated with the *Object* parameter. The returned name can be either a full pathname (from the root, with path segment separators) or a single segment, 4-character ACPI name. This function and *AcpiGetHandle* are complementary functions, as shown in the examples below.

### EXAMPLES

Example 1: The following operations:

```
Status = AcpiGetName (Handle, ACPI_FULL_PATHNAME, &OutName)
Status = AcpiGetHandle (NULL, OutName.BufferPtr, &OutHandle))
```

Yield this result:

```
Handle == OutHandle;
```

Example 2: If Name is a 4-character ACPI name, the following operations:

```
Status = AcpiGetHandle (Parent, Name, &OutHandle))
Status = AcpiGetName (OutHandle, ACPI_SINGLE_NAME, &OutName)
```

Yield this result:

```
Name == OutName.BufferPtr
```

## 8.3.9 AcpiGetDevices

**Walk the ACPI namespace to find all objects of type Device.**

### ACPI\_STATUS

AcpiGetDevices (

char	*HID,
ACPI_WALK_CALLBACK	UserFunction,
void	*UserContext,
void	**ReturnValue)

### PARAMETERS

HID	A device Hardware ID to search for. If NULL, all objects of type Device are passed to the UserFunction.
UseFunction	A pointer to a function that is called when the namespace object is deleted:
UserContext	A value that will be passed as a parameter to the user function each time it is invoked.
ReturnValue	A pointer to a location where the (void *) return value from the UserFunction is to be placed if the walk was terminated early. Otherwise, NULL is returned.

**RETURN VALUE**

Status	Exception code that indicates success or reason for failure.
--------	--

**EXCEPTIONS**

AE_OK	The walk was successful. Termination occurred from completion of the walk or by the user function, depending on the value of the return parameter.
AE_BAD_PARAMETER	The <i>UserFunction</i> address is NULL.

**Functional Description:**

---

This function performs a modified depth-first walk of the namespace tree. The *UserFunction* is invoked whenever an object of type Device with a matching HID is found. If the user function returns a non-zero value, the search is terminated immediately and this value is returned to the caller.

If the HID parameter is NULL, all objects of type Device within the namespace are passed to the User Function.

### 8.3.10 AcpiAttachData

**Attach user data to an ACPI namespace object.**

**ACPI\_STATUS**

AcpiAttachData ( ACPI_HANDLE ACPI_OBJECT_HANDLER void	Object, Handler, *Data)
--	-------------------------------

**PARAMETERS**

Object	A handle to an object to which the data will be attached.
Handler	A pointer to a function that is called when the namespace object is deleted.
Data	A pointer to arbitrary user data. The pointer is stored in the namespace with the namespace object and can be retrieved at any time via <i>AcpiGetData</i> .

**RETURN VALUE**

Status	Exception code that indicates success or reason for failure.
--------	--

**EXCEPTIONS**

AE_OK	The data was successfully attached.
AE_BAD_PARAMETER	At least one of the following is true:



	The Object handle is invalid.
	The <i>Handler</i> pointer is NULL.
	The <i>Data</i> pointer is NULL.
AE_NO_MEMORY	Insufficient dynamic memory to complete the operation.
AE_NO_NAMESPACE	The namespace has not been successfully loaded.

---

**Functional Description:**

This function allows arbitrary data to be associated with a namespace object.

### 8.3.11 AcpiDetachData

<b>Remove a data attachment to a namespace object.</b>
--

ACPI\_STATUS  
 AcpiAttachData (  
     ACPI\_HANDLE  
     ACPI\_OBJECT\_HANDLER      Object,  
                                   Handler)

#### PARAMETERS

Object	A handle to an object to which the data will be attached.
Handler	A pointer to a function that is called when the namespace object is deleted. This must be the same pointer used when the original call to <i>AcpiAttachData</i> was used.

#### RETURN VALUE

Status	Exception code that indicates success or reason for failure.
--------	--

#### EXCEPTIONS

AE_OK	The data was successfully detached.
AE_BAD_PARAMETER	At least one of the following is true:  The Object handle is invalid.  The <i>Handler</i> pointer is NULL.
AE_NO_NAMESPACE	The namespace has not been successfully loaded.

---

**Functional Description:**

This function removes a previous association between user data and a namespace object.



### 8.3.12 AcpiGetData

Retrieve data that was associated with a namespace object.

#### ACPI\_STATUS

AcpiGetData (  
    ACPI\_HANDLE           Object,  
    ACPI\_OBJECT\_HANDLER   Handler  
    void                   \*\*Data)

#### PARAMETERS

Object	A handle to an object to from which the attached data will be returned.
Handler	A pointer to a function that is called when the namespace object is deleted: This must be the same pointer used when the original call to <i>AcpiAttachData</i> was used.
Data	A pointer to where the arbitrary user data pointer will be returned. The pointer is stored in the namespace with the namespace object.

#### RETURN VALUE

Status	Exception code that indicates success or reason for failure.
--------	--

#### EXCEPTIONS

AE_OK	The data was successfully returned.
AE_BAD_PARAMETER	At least one of the following is true:  The Object handle is invalid.  The <i>Handler</i> pointer is NULL.  The <i>Data</i> pointer is NULL.
AE_NO_MEMORY	Insufficient dynamic memory to complete the operation.
AE_NO_NAMESPACE	The namespace has not been successfully loaded.

#### Functional Description:

This function retrieves data that was previously associated with a namespace object.



### 8.3.13 AcpiInstallMethod

**Install a single control method into the namespace.**

**ACPI\_STATUS**  
**AcpiInstallMethod (**  
     **UINT8**

**\*TableBuffer)**

#### PARAMETERS

TableBuffer	A pointer to a buffer containing a DSDT or SSDT table which in turn contains a single control method.
-------------	---

#### RETURN VALUE

Status	Exception code that indicates success or reason for failure.
--------	--

#### EXCEPTIONS

AE_OK	The method was successfully installed.
AE_BAD_HEADER	The buffer does not contain a valid ACPI table, or the table is not a DSDT or SSDT.
AE_BAD_PARAMETER	At least one of the following is true:  The <i>TableBuffer</i> pointer is NULL.  The table does not contain a valid control method as the first (and only) element of the table.
AE_NO_MEMORY	Insufficient dynamic memory to complete the operation.
AE_TYPE	The name of the method already exists in the namespace, but the name is not an object of type method and cannot be overwritten.

#### Functional Description:

This function installs a single control method into the ACPI namespace. It is intended to override an existing method which may not work correctly or it can insert a completely new method in order to create a missing method such as **\_OFF**, **\_ON**, **\_STA**, **\_INI**, etc. It can also be used to insert a method for debugging purposes. For these cases, it is far simpler to dynamically install a single control method rather than override the entire DSDT with a modified DSDT.

*AcpiInstallMethod* can be used to create a new method anywhere in the namespace or to overwrite the AML for any existing control method. The name (and location) for the new method is defined within the AML contained in the ACPI table pointed to by the *TableBuffer* parameter. Either single (4 character) ACPI names may be used, or full ACPI pathnames may be used, each segment separated by periods. This function should be called only after all BIOS-defined ACPI tables have been loaded and the namespace has been created.



The method must be defined and compiled within a DSDT or SSDT. The resulting table is then passed as the parameter to *AcpiInstallMethod*. If the method needs to reference any objects that already exist within the namespace, the ASL **External** operator should be used.

### Example

The example ASL code below creates a DSDT that contains one method with the name “**\_SI\_ABCD**”. The name dictates where the method will be created within the namespace, and can be a full pathname that references any portion of the namespace.

```
DefinitionBlock ("", "DSDT", 2, "Intel", "MTHDTEST", 0x20090512)
{
    Method (\_SI_ABCD, 1, Serialized)
    {
        Store ("Example installed method", Debug)
        Store (Arg0, Debug)
        Return ()
    }
}
```

The example is compiled via the iASL compiler using the “-tc” option to create a C hex file:

```
> iasl -tc method.asl
```

This produces the following output, which is “C” code that can be included into a C source file:

```
/*
 * Intel ACPI Component Architecture
 * ASL Optimizing Compiler version 20090422 [April 22 2009]
 * Copyright (C) 2000 - 2009 Intel Corporation
 * Supports ACPI Specification Revision 3.0a
 *
 * Compilation of "method.asl" - Tue May 12 14:55:53 2009
 *
 * C source code output
 */
unsigned char AmlCode[] =
{
    0x44,0x53,0x44,0x54,0x53,0x00,0x00,0x00, /* 00000000 "DSDTS..." */
    0x02,0x12,0x49,0x6E,0x74,0x65,0x6C,0x00, /* 00000008 "..Intel." */
    0x4D,0x54,0x48,0x44,0x54,0x45,0x53,0x54, /* 00000010 "MTHDTEST" */
    0x12,0x05,0x09,0x20,0x49,0x4E,0x54,0x4C, /* 00000018 "... INTL" */
    0x22,0x04,0x09,0x20,0x14,0x2E,0x2E,0x5F, /* 00000020 "... .." */
    0x53,0x49,0x5F,0x41,0x42,0x43,0x44,0x09, /* 00000028 "SI_ABCD." */
    0x70,0x0D,0x45,0x78,0x61,0x6D,0x70,0x6C, /* 00000030 "p.Exampl" */
    0x65,0x20,0x69,0x6E,0x73,0x74,0x61,0x6C, /* 00000038 "e instal" */
    0x6C,0x65,0x64,0x20,0x6D,0x65,0x74,0x68, /* 00000040 "led meth" */
    0x6F,0x64,0x00,0x5B,0x31,0x70,0x68,0x5B, /* 00000048 "od.[lph[" */
    0x31,0xA4,0x00,
};
```

The buffer above is then used in a call to *AcpiInstallMethod*, as shown in the example code below:

```
Status = AcpiInstallMethod (AmlCode);
if (ACPI_FAILURE (Status))
{
    AcpiOsPrintf ("%s, Could not install method\n",
        AcpiFormatException (Status));
}
```



### 8.3.14 AcpiWalkNamespace

Traverse a portion of the ACPI namespace to find objects of a given type.

#### ACPI\_STATUS

<b>AcpiWalkNamespace (</b> <b>ACPI_OBJECT_TYPE</b> <b>ACPI_HANDLE</b> <b>UINT32</b> <b>ACPI_WALK_CALLBACK</b> <b>ACPI_WALK_CALLBACK</b> <b>void</b> <b>void</b>	<b>Type,</b> <b>StartObject,</b> <b>MaxDepth,</b> <b>DescendingCallback,</b> <b>AscendingCallback,</b> <b>*UserContext,</b> <b>**ReturnValue</b>
--	--

#### PARAMETERS

Type	The type of object desired.
StartObject	A handle to an object where the namespace walk is to begin. The constant <b>ACPI_ROOT_OBJECT</b> indicates to start the walk at the root of the namespace (walk the entire namespace.)
MaxDepth	The maximum number of levels to descend in the namespace during the walk.
DescendingCallback	A pointer to a user-written function that is invoked during tree descent for each matching object that is found. (See the interface specification for the user function below.)
AscendingCallback	A pointer to a user-written function that is invoked during tree ascent for each matching object that is found. (See the interface specification for the user function below.)
UserContext	A value that will be passed as a parameter to the user function each time it is invoked.
ReturnValue	A pointer to a location where the (void *) return value from the UserFunction is to be placed if the walk was terminated early. Otherwise, NULL is returned.

#### RETURN VALUE

Status	Exception code that indicates success or reason for failure.
--------	--

#### EXCEPTIONS

AE_OK	The walk was successful. Termination occurred from completion of the walk or by the user function, depending on the value of the return parameter.
AE_BAD_PARAMETER	At least one of the following is true:  The <i>MaxDepth</i> is zero.





The *UserFunction* address is NULL.

The *StartObject* handle is invalid.

The *Type* is invalid.

---

**Functional Description:**

This function performs a modified depth-first walk of the namespace tree, starting (and ending) at the object specified by the *StartObject* handle. The User Functions (*DescendingCallback* and/or *AscendingCallback*) are invoked whenever an object that matches the type parameter is found during the walk. If the user function returns a non-zero value, the search is terminated immediately and this value is returned to the caller.

The point of this procedure is to provide a generic namespace walk routine that can be called from multiple places to provide multiple services; the user function can be tailored to each task — whether it is a print function, a compare function, etc.

### 8.3.14.1 Interface to User Callback Function

<b>Interface to the user function that is invoked from AcpiWalkNamespace.</b>
---

```
ACPI_STATUS (*ACPI_WALK_CALLBACK) (  
    ACPI_HANDLE          Object,  
    UINT32               NestingLevel,  
    void                 *Context,  
    void                 **ReturnValue)
```

**PARAMETERS**

Object	A handle to an object that matches the search criteria.
Nesting Level	Depth of this object within the namespace (distance from the root.)
Context	The UserContext value that was passed as a parameter to the AcpiWalkNamespace function.
ReturnValue	A pointer to a location where the return value (if any) from the user function is to be stored.

**RETURN VALUE**

Status	AE_OK	Continue the walk.
	AE_TERMINATE	Stop the walk immediately.
	AE_DEPTH	Go no deeper into the namespace tree.
	All others	Abort the walk with this exception code.



### Functional Description:

This function is called from *AcpiWalkNamespace* whenever a object of the desired type is found. The walk can be modified by the exception code returned from this function. **AE\_TERMINATE** will abort the walk immediately, and *AcpiWalkNamespace* will return **AE\_OK** to the original caller. **AE\_DEPTH** will prevent the walk from progressing any deeper down the current branch of the namespace tree. **AE\_OK** is the normal return that allows the walk to continue normally. All other exception codes will cause the walk to terminate and the exception is returned to the original caller of *AcpiWalkNamespace*.

## 8.3.15 AcpiAcquireMutex

Acquire an AML Mutex object.

### ACPI\_STATUS

**AcpiAcquireMutex (**  
**ACPI\_HANDLE**  
**ACPI\_STRING**  
**UINT16**

**Parent,**  
**Pathname,**  
**Timeout)**

### PARAMETERS

Parent	A handle to the parent of the object specified by Pathname. In other words, the Pathname is relative to the Parent. If Parent is NULL, the pathname must be a fully qualified pathname.
Pathname	A name or pathname to an ACPI object (a NULL terminated ASCII string). The string can be either a single segment ACPI name or a multiple segment ACPI pathname (with path separators).
Timeout	Maximum time to wait for the mutex, in milliseconds. A value of 0xFFFF means “wait forever”.

### RETURN VALUE

Status	Exception code that indicates success or reason for failure.
--------	--

### EXCEPTIONS

AE_OK	The mutex was successfully acquired.
AE_BAD_CHARACTER	An invalid character was found in the pathname.
AE_BAD_PATHNAME	The path contains at least one ACPI name that is not exactly four characters long.
AE_BAD_PARAMETER	At least one of the following is true:  The <i>Pathname</i> pointer is NULL.  The <i>Pathname</i> does not begin with a backslash character.



	The <i>OutHandle</i> pointer is NULL.
AE_NO_NAMESPACE	The namespace has not been successfully loaded.
AE_NOT_FOUND	One or more of the segments of the pathname refers to a non-existent object.

---

**Functional Description:**

This function is intended to be used in conjunction with the *\_DLM (Device Lock Method)* predefined name to directly acquire a mutex object that is defined in the ACPI namespace. The purpose of this is to provide a mutual exclusion mechanism between the AML interpreter and an ACPI-related device driver, in order to support multiple-operation transactions.

From the ACPI Specification: “The *\_DLM* object appears in a device scope when AML access to the device must be synchronized with the OS environment. It is used in conjunction with a standard Mutex object. With *\_DLM*, the standard Mutex provides synchronization within the AML environment as usual, but also synchronizes with the OS environment.”

The AML mutex node is pointed to by Parent:Pathname. Either the Parent or the Pathname can be NULL, but not both.

If the operation fails an appropriate status will be returned.

## 8.3.16 AcpiReleaseMutex

<b>Release an AML Mutex object.</b>
-------------------------------------

ACPI\_STATUS  
AcpiGetHandle (  
    ACPI\_HANDLE  
    ACPI\_STRING

Parent,  
Pathname)

**PARAMETERS**

Parent	A handle to the parent of the object specified by Pathname. In other words, the Pathname is relative to the Parent. If Parent is NULL, the pathname must be a fully qualified pathname.
Pathname	A name or pathname to an ACPI object (a NULL terminated ASCII string). The string can be either a single segment ACPI name or a multiple segment ACPI pathname (with path separators).

**RETURN VALUE**

Status	Exception code that indicates success or reason for failure.
--------	--

**EXCEPTIONS**

AE_OK	The AML mutex was successfully released.
-------	--



AE_BAD_CHARACTER	An invalid character was found in the pathname.
AE_BAD_PATHNAME	The path contains at least one ACPI name that is not exactly four characters long.
AE_BAD_PARAMETER	At least one of the following is true:  The <i>Pathname</i> pointer is NULL.  The <i>Pathname</i> does not begin with a backslash character.  The <i>OutHandle</i> pointer is NULL.
AE_NO_NAMESPACE	The namespace has not been successfully loaded.
AE_NOT_FOUND	One or more of the segments of the pathname refers to a non-existent object.

---

**Functional Description:**

This function releases an AML mutex object that was previously acquired via a successful call to *AcpiAcquireMutex*.

If the operation fails an appropriate status will be returned.

## 8.4 ACPI Hardware Management

### 8.4.1 AcpiEnable

<b>Put the system into ACPI mode.</b>
---------------------------------------

**ACPI\_STATUS**

**AcpiEnable (**  
    **void)**

**PARAMETERS**

None

**RETURN VALUE**

Status	Exception code that indicates success or reason for failure.
--------	--

**EXCEPTIONS**

AE_OK	ACPI mode was successfully enabled.
AE_ERROR	Either ACPI mode is not supported by this system (legacy mode only), the SCI interrupt handler could not be installed, or the system could not be transitioned into ACPI mode.
AE_NO_ACPI_TABLES	The ACPI tables have not been successfully loaded.

**Functional Description:**

---

This function enables ACPI mode on the host computer system. It ensures that the system control interrupt (SCI) is properly configured, disables SCI event sources, installs the SCI handler, and transfers the system hardware into ACPI mode.

## 8.4.2 AcpiDisable

<b>Take the system out of ACPI mode.</b>
--

**ACPI\_STATUS**

AcpiDisable (  
void)

**PARAMETERS**

None

**RETURN VALUE**

Status	Exception code that indicates success or reason for failure.
--------	--

**EXCEPTIONS**

AE_OK	ACPI mode was successfully disabled.
AE_ERROR	The system could not be transitioned out of ACPI mode.

**Functional Description:**

---

This function disables ACPI mode on the host computer system. It returns the system hardware to original ACPI/legacy mode, disables all events, and removes the SCI interrupt handler.

## 8.4.3 AcpiReset

<b>Perform a system reset.</b>
--------------------------------

**ACPI\_STATUS**

AcpiReset (  
void)

**PARAMETERS**

None

**RETURN VALUE**

Status	Exception code that indicates success or reason for failure.
--------	--

**EXCEPTIONS**

AE_OK	The reset register was successfully written.
AE_NOT_EXIST	The FADT flags indicate that the reset register is not supported, or the reset register address is zero.

**Functional Description:**

This function performs a system reset by writing the FADT-defined *Reset Value* to the FADT-defined *Reset Register* (if the register is supported, as indicated by the FADT *Flags*).

Reset registers in both memory and I/O space are supported. A reset register in PCI configuration space is not supported by this function and must be handled by the host.

## 8.4.4 AcpiReadBitRegister

Get the contents of an ACPI-defined Bit Register.

ACPI\_STATUS  
AcpiGetRegister (  
    UINT32  
    UINT32

RegisterId,  
    \*ReturnValue)

**PARAMETERS**

RegisterId	<p>The ID of the desired bit register, one of the following manifest constants:</p> <ul style="list-style-type: none"> <li>ACPI_BITREG_TIMER_STATUS</li> <li>ACPI_BITREG_BUS_MASTER_STATUS</li> <li>ACPI_BITREG_GLOBAL_LOCK_STATUS</li> <li>ACPI_BITREG_POWER_BUTTON_STATUS</li> <li>ACPI_BITREG_SLEEP_BUTTON_STATUS</li> <li>ACPI_BITREG_RT_CLOCK_STATUS</li> <li>ACPI_BITREG_WAKE_STATUS</li> <li>ACPI_BITREG_PCIEXP_WAKE_STATUS</li> <li>ACPI_BITREG_TIMER_ENABLE</li> <li>ACPI_BITREG_GLOBAL_LOCK_ENABLE</li> <li>ACPI_BITREG_POWER_BUTTON_ENABLE</li> <li>ACPI_BITREG_SLEEP_BUTTON_ENABLE</li> <li>ACPI_BITREG_RT_CLOCK_ENABLE</li> <li>ACPI_BITREG_PCIEXP_WAKE_DISABLE</li> <li>ACPI_BITREG_SCI_ENABLE</li> <li>ACPI_BITREG_BUS_MASTER_RLD</li> <li>ACPI_BITREG_GLOBAL_LOCK_RELEASE</li> <li>ACPI_BITREG_SLEEP_TYPE</li> <li>ACPI_BITREG_SLEEP_ENABLE</li> <li>ACPI_BITREG_ARB_DISABLE</li> </ul>
ReturnValue	A pointer to a location where the data is to be returned.

**RETURN VALUE**

Status	Exception code that indicates success or reason for failure.
--------	--

**EXCEPTIONS**

AE_OK	The register was read successfully.
AE_BAD_PARAMETER	Invalid RegisterId.
Other	The function failed at the operating system level.

**Functional Description:**

---

This function reads the bit register specified in the RegisterId. The value returned is normalized to bit zero. Can be used with interrupts enabled or disabled. The hardware is not locked during the read, as it is not necessary

## 8.4.5 AcpiWriteBitRegister

**Set the contents of an ACPI-defined Bit Register.**

**ACPI\_STATUS**  
**AcpiSetRegister (**  
    **UINT32**  
    **UINT32**

**RegisterId,**  
**Value)**

**PARAMETERS**

RegisterId	The ID of the desired register, one of the following manifest constants:
------------	--

**ACPI\_BITREG\_TIMER\_STATUS**  
**ACPI\_BITREG\_BUS\_MASTER\_STATUS**  
**ACPI\_BITREG\_GLOBAL\_LOCK\_STATUS**  
**ACPI\_BITREG\_POWER\_BUTTON\_STATUS**  
**ACPI\_BITREG\_SLEEP\_BUTTON\_STATUS**  
**ACPI\_BITREG\_RT\_CLOCK\_STATUS**  
**ACPI\_BITREG\_WAKE\_STATUS**  
**ACPI\_BITREG\_PCIEXP\_WAKE\_STATUS**  
**ACPI\_BITREG\_TIMER\_ENABLE**  
**ACPI\_BITREG\_GLOBAL\_LOCK\_ENABLE**  
**ACPI\_BITREG\_POWER\_BUTTON\_ENABLE**  
**ACPI\_BITREG\_SLEEP\_BUTTON\_ENABLE**  
**ACPI\_BITREG\_RT\_CLOCK\_ENABLE**  
**ACPI\_BITREG\_PCIEXP\_WAKE\_DISABLE**  
**ACPI\_BITREG\_SCI\_ENABLE**  
**ACPI\_BITREG\_BUS\_MASTER\_RLD**  
**ACPI\_BITREG\_GLOBAL\_LOCK\_RELEASE**  
**ACPI\_BITREG\_SLEEP\_TYPE**  
**ACPI\_BITREG\_SLEEP\_ENABLE**





**Functional Description:**

---

This function reads a register defined in the generic address format. It supports reads from memory or I/O space only. Registers must have a width of either 8, 16, 32, or 64 bits.

## 8.4.7 AcpiWrite

<b>Write an ACPI Register (low-level write).</b>
--

**ACPI\_STATUS**

**AcpiWrite (**  
    **UINT64**                      **Value,**  
    **ACPI\_GENERIC\_ADDRESS**   **\*Register)**

**PARAMETERS**

Value	The data to be written.
Register	A pointer to a valid ACPI register in generic address format.

**RETURN VALUE**

Status	Exception code that indicates success or reason for failure.
--------	--

**EXCEPTIONS**

AE_OK	The register was read successfully.
AE_BAD_ADDRESS	The Address element of the register is zero.
AE_BAD_PARAMETER	The <i>Register</i> parameter is NULL.
AE_SUPPORT	The register width was not 8/16/32/64.
Other	The function failed at the operating system level.

**Functional Description:**

---

This function writes a register defined in the generic address format. It supports writes to memory or I/O space only. Registers must have a width of either 8, 16, 32, or 64 bits.



## 8.4.8 AcpiAcquireGlobalLock

**Acquire the ACPI Global Lock.**

**ACPI\_STATUS**

**AcpiAcquireGlobalLock (**

**UINT16**

**UINT32**

**Timeout,**

**\*OutHandle)**

### PARAMETERS

Timeout	The maximum time (in System Ticks) the caller is willing to wait for the global lock.
OutHandle	A pointer to where a handle to the lock is to be returned. This handle is required to release the global lock.

### RETURN VALUE

Status	Exception code that indicates success or reason for failure.
--------	--

### EXCEPTIONS

AE_OK	The global lock was successfully acquired.
AE_BAD_PARAMETER	The <i>OutHandle</i> pointer is NULL.
AE_TIME	The global lock could not be acquired within the specified time limit.

### Functional Description:

This function obtains exclusive access to the single system-wide ACPI Global Lock. The purpose of the global lock is to ensure exclusive access to resources that must be shared between the operating system and the firmware.

## 8.4.9 AcpiReleaseGlobalLock

**Release the ACPI Global Lock.**

**ACPI\_STATUS**

**AcpiReleaseGlobalLock (**

**UINT32**

**Handle)**

### PARAMETERS

Handle	The handle that was obtained when the Global Lock was acquired. This allows different threads to acquire and release the lock, as long as they share the handle.
--------	--

**RETURN VALUE**

Status	Exception code that indicates success or reason for failure.
--------	--

**EXCEPTIONS**

AE_OK	The global lock was successfully released
AE_BAD_PARAMETER	The Handle is invalid.

**Functional Description:**

---

This function releases the global lock. The releasing thread may be different from the thread that acquired the lock. However, the Handle must be the same handle that was returned by *AcpiAcquireGlobalLock*.

## 8.4.10 AcpiGetTimerResolution

**Get the resolution of the ACPI Power Management Timer.**

**ACPI\_STATUS**

**AcpiGetTimerResolution (**  
    **UINT32**                    **\*OutValue)**

**PARAMETERS**

OutValue	A pointer to where the current value of the PM Timer resolution is to be returned.
----------	--

**RETURN VALUE**

Status	Exception code that indicates success or reason for failure.
--------	--

**EXCEPTIONS**

AE_OK	The PM Timer resolution was successfully retrieved and returned.
AE_BAD_PARAMETER	The OutValue pointer is NULL.

**Functional Description:**

---

This function returns the PM Timer resolution – either 24 (for 24-bit) or 32 (for 32-bit timers).



### 8.4.11 AcpiGetTimerDuration

**Calculates the time elapsed (in microseconds) between two values of the ACPI Power Management Timer.**

**ACPI\_STATUS**

**AcpiGetTimer (**

**UINT32**

**StartTicks,**

**UINT32**

**EndTicks,**

**UINT32**

**\*OutValue)**

#### PARAMETERS

StartTicks

The value of the PM Timer at the start of a time measurement (obtained by calling AcpiGetTimer).

EndTicks

The value of the PM Timer at the end of a time measurement (obtained by calling AcpiGetTimer).

OutValue

A pointer to where the elapsed time (in microseconds) is to be returned.

#### RETURN VALUE

Status

Exception code that indicates success or reason for failure.

#### EXCEPTIONS

AE\_OK

The time elapsed was successfully calculated and returned.

AE\_BAD\_PARAMETER

The OutValue pointer is NULL.

#### Functional Description:

This function calculates and returns the time elapsed (in microseconds) between StartTicks and EndTicks, taking into consideration the PM Timer frequency, resolution, and counter rollovers.

### 8.4.12 AcpiGetTimer

**Get the current value of the ACPI Power Management Timer.**

**ACPI\_STATUS**

**AcpiGetTimer (**

**UINT32**

**\*OutValue)**

#### PARAMETERS

OutValue

A pointer to where the current value of the ACPI Timer is to be returned.

**RETURN VALUE**

Status	Exception code that indicates success or reason for failure.
--------	--

**EXCEPTIONS**

AE_OK	The current value of the timer was successfully retrieved and returned.
AE_BAD_PARAMETER	The OutValue pointer is NULL.

**Functional Description:**

---

This function returns the current value of the PM Timer (in ticks).

## 8.5 ACPI Sleep/Wake Support

### 8.5.1 AcpiSetFirmwareWakingVector

Set the 32-bit firmware wake vector.
--------------------------------------

**ACPI\_STATUS**

AcpiSetFirmwareWakingVector ( UINT32	Address32)
---	------------

**PARAMETERS**

Address32	The physical address to be stored in the waking vector.
-----------	---

**RETURN VALUE**

Status	Exception code that indicates success or reason for failure.
--------	--

**EXCEPTIONS**

AE_OK	The vector was set successfully.
AE_NO_ACPI_TABLES	The FACS is not loaded or could not be found.

**Functional Description:**

---

This function sets the 32-bit firmware (ROM BIOS) wake vector. If a 64-bit vector exists in the current FACS, it is set to zero.

If the function fails an appropriate status will be returned and the value of the waking vector will be undisturbed.





SleepTypeB	A pointer to a location where the value of <b>SLP_TYPb</b> will be returned.
------------	--

**RETURN VALUE**

Status	Exception code that indicates success or reason for failure.
--------	--

**EXCEPTIONS**

AE_OK	Both <b>SLP_TYP</b> values were returned successfully.
AE_BAD_PARAMETER	Either <i>SleepState</i> has an invalid value, or one of the <i>SleepType</i> pointers is invalid.
AE_NO_MEMORY	Insufficient dynamic memory to complete the operation.
AE_AML_NO_OPERAND	Could not locate one or more of the <b>SLP_TYP</b> values.
AE_AML_OPERAND_TYPE	One or more of the <b>SLP_TYP</b> objects was not a numeric type, or the object returned by the <b>\Sx</b> method was not a package.
AE_AML_PACKAGE_LIMIT	The package object returned by the <b>\Sx</b> method contained no objects.

**Functional Description:**

---

This function returns the **SLP\_TYP** object for the requested sleep state. This data is obtained by evaluating the **\Sx** object that corresponds to the input *SleepState* value.

Note: *AcpiGetSleepTypeData* automatically handles two types of return value from the **\Sx** object:

- 1) The returned package object contains a single encoded DWORD that contains both sleep type values. This is in accordance with the ACPI specification.
- 2) The returned package object contains two Integer objects, one for each sleep type value. Although this behavior is not in accordance with the ACPI specification, it is often found in the field.

## 8.5.4 AcpiEnterSleepStatePrep

<b>Prepare to enter a system sleep state (S1-S5).</b>
---

**ACPI\_STATUS**  
**AcpiEnterSleepStatePrep (**  
    **UINT8**                    **SleepState)**

**PARAMETERS**

SleepState	The sleep state to prepare to enter. Must be in the range 1 through 5.
------------	--

**RETURN VALUE**

Status	Exception code that indicates success or reason for failure.
--------	--

**EXCEPTIONS**

AE_OK	The _PTS and _SST methods were successfully run
Other	Exception from AcpiEvaluateObject.

**Functional Description:**

Prepare to enter a system sleep state. This function should be called before a call to *AcpiEnterSleepState*.

This function executes the **\_PTS** and **\_SST** methods.

Algorithm:

- Get the sleep type data by executing the appropriate global method (\_S0, \_S1, etc.)
- Execute the \_PTS method (Prepare To Sleep)
- Execute the \_SST method with the appropriate value for the input SleepState.

## 8.5.5 **AcpiEnterSleepState**

**Enter a system sleep state (S1-S5).**

**ACPI\_STATUS**

**AcpiEnterSleepState (**  
**UINT8** **SleepState)**

**PARAMETERS**

SleepState	The sleep state to enter. Must be in the range 1 through 5.
------------	---

**RETURN VALUE**

Status	Exception code that indicates success or reason for failure.
--------	--

**EXCEPTIONS**

AE_OK	The sleep state (S1) was successfully entered.
AE_BAD_PARAMETER	Invalid SleepState value.
Other	Hardware access exception.

**Functional Description:**

This function only returns for transitions to the S1 state or when an error occurs. Sleep states S2-S4 use the firmware waking vector during wakeup. Should only be called after a call to *AcpiEnterSleepStatePrep*.

This function must be called with interrupts disabled.





Note: works transparently with either the legacy sleep status/control bits in the ACPI PM registers, or the standalone sleep status and sleep control registers defined in the version 5 FADT.

This function does NOT execute the **\_GTS** method (Going To Sleep.) This method is untested on many platforms, is not used by major operating systems, and may result in errors and incorrect platform behavior.

Algorithm:

- Clear the WAK\_STS (wake status) bit
- Clear all fixed and general purpose events
- Enable all wakeup GPEs
- Write the SLP\_TYP value
- Flush CPU caches
- Write the SLP\_TYP and SLP\_EN values
- Wait for transition back to working state.

## 8.5.6 AcpiEnterSleepStateS4Bios

Enter S4 BIOS sleep
---------------------

**ACPI\_STATUS**

**AcpiEnterSleepStateS4bios (**  
    **void)**

### PARAMETERS

None

### RETURN VALUE

Status	Exception code that indicates success or reason for failure.
--------	--

### EXCEPTIONS

AE_OK	The sleep state (S1) was successfully entered.
Other	Hardware access exception.

---

### Functional Description:

This function performs an S4 BIOS request.

This function must be called with interrupts disabled.



## 8.5.7 AcpiLeaveSleepStatePrep

**Preparation for leaving a system sleep state (S1-S5).**

**ACPI\_STATUS**

**AcpiLeaveSleepStatePrep (**  
     **UINT8**                                      **SleepState)**

**PARAMETERS**

SleepState	The sleep state to leave.
------------	---------------------------

**RETURN VALUE**

Status	Exception code that indicates success or reason for failure.
--------	--

**EXCEPTIONS**

AE_OK	The cleanup was successful.
-------	-----------------------------

Other	Hardware access exception.
-------	----------------------------

**Functional Description:**

Begin cleanup after leaving a sleep state. This function should be called before a call to *AcpiLeaveSleepState*.

Note: works transparently with either the legacy sleep status/control bits in the ACPI PM registers, or the standalone sleep status and sleep control registers defined in the version 5 FADT.

This function does NOT execute the **\_BFS** method (Back From Sleep.) This method is untested on many platforms, is not used by major operating systems, and may result in errors and incorrect platform behavior.

Algorithm:

Set SLP\_TYP and SLP\_EN to state S0

## 8.5.8 AcpiLeaveSleepState

**Leave (cleanup) a system sleep state (S1-S5).**

**ACPI\_STATUS**

**AcpiLeaveSleepState (**  
     **UINT8**                                      **SleepState)**

**PARAMETERS**

SleepState	The sleep state to leave.
------------	---------------------------

**RETURN VALUE**

Status	Exception code that indicates success or reason for failure.
--------	--

**EXCEPTIONS**

AE_OK	The cleanup was successful.
Other	Hardware access exception.

**Functional Description:**

---

Perform cleanup after leaving a sleep state. This function should be only called after a call to *AcpiLeaveSleepStatePrep*.

Note: works transparently with either the legacy sleep status/control bits in the ACPI PM registers, or the standalone sleep status and sleep control registers defined in the version 5 FADT.

This function executes the **\_WAK** and **\_SST** methods.

Algorithm:

- Execute **\_SST** method with “waking” value
- Clear all GPEs then enable all runtime GPEs
- Execute the **\_WAK** method
- Clear the **WAK\_STS** bit
- Enable the power button
- Execute **\_SST** method with “working” value

## 8.6 ACPI Fixed Event Management

### 8.6.1 AcpiEnableEvent

**Enable an ACPI Fixed Event.**

**ACPI\_STATUS****AcpiEnableEvent (**

<b>UINT32</b>	<b>Event,</b>
<b>UINT32</b>	<b>Flags)</b>

**PARAMETERS**

Event	The fixed event to be enabled. This parameter must be one of the following manifest constants:
-------	--

**ACPI\_EVENT\_PMTIMER**  
**ACPI\_EVENT\_GLOBAL**  
**ACPI\_EVENT\_POWER\_BUTTON**  
**ACPI\_EVENT\_SLEEP\_BUTTON**  
**ACPI\_EVENT\_RTC**

Flags	Reserved, set to zero.
-------	------------------------

**RETURN VALUE**

Status	Exception code that indicates success or reason for failure.
--------	--

**EXCEPTIONS**

AE_OK	The event was successfully enabled.
AE_BAD_PARAMETER	The <i>Event</i> is invalid.
Other	Hardware access exception.

**Functional Description:**


---

This function enables a single ACPI fixed event.

## 8.6.2 AcpiDisableEvent

<b>Disable an ACPI Fixed Event.</b>
-------------------------------------

**ACPI\_STATUS****AcpiDisableEvent (****UINT32****UINT32****Event,****Flags)****PARAMETERS**

Event	The fixed event to be disabled. This parameter must be one of the following manifest constants:
-------	---

**ACPI\_EVENT\_PMTIMER**  
**ACPI\_EVENT\_GLOBAL**  
**ACPI\_EVENT\_POWER\_BUTTON**  
**ACPI\_EVENT\_SLEEP\_BUTTON**  
**ACPI\_EVENT\_RTC**

Flags	Reserved, set to zero.
-------	------------------------

**RETURN VALUE**

Status	Exception code that indicates success or reason for failure.
--------	--

**EXCEPTIONS**

AE_OK	The event was successfully disabled.
AE_BAD_PARAMETER	The <i>Event</i> is invalid.
Other	Hardware access exception.

**Functional Description:**


---

This function disables a single ACPI fixed event.



### 8.6.3 AcpiClearEvent

Clear a pending ACPI Fixed Event.

ACPI\_STATUS  
AcpiClearEvent (  
    UINT32                      Event)

#### PARAMETERS

Event                      The fixed event to be cleared. This parameter must be one of the following manifest constants:

ACPI\_EVENT\_PMTIMER  
ACPI\_EVENT\_GLOBAL  
ACPI\_EVENT\_POWER\_BUTTON  
ACPI\_EVENT\_SLEEP\_BUTTON  
ACPI\_EVENT\_RTC

#### RETURN VALUE

Status                      Exception code that indicates success or reason for failure.

#### EXCEPTIONS

AE\_OK                      The event was successfully cleared.  
AE\_BAD\_PARAMETER          The *Event* is invalid.  
Other                      Hardware access exception.

#### Functional Description:

This function clears (zeros the status bit for) a single ACPI fixed event.

### 8.6.4 AcpiGetEventStatus

Obtain the status of an ACPI Fixed Event.

ACPI\_STATUS  
AcpiGetEventStatus (  
    UINT32                      Event,  
    ACPI\_EVENT\_STATUS        \*EventStatus)

#### PARAMETERS

Event                      The fixed event for which status will be obtained. This parameter must be one of the following manifest constants:

ACPI\_EVENT\_PMTIMER  
ACPI\_EVENT\_GLOBAL



**ACPI\_EVENT\_POWER\_BUTTON**  
**ACPI\_EVENT\_SLEEP\_BUTTON**  
**ACPI\_EVENT\_RTC**

EventStatus Where the event status is returned. The following bits may be set:

**ACPI\_EVENT\_FLAG\_SET**

## RETURN VALUE

Status Exception code that indicates success or reason for failure.

## EXCEPTIONS

AE_OK	The event was successfully disabled.
AE_BAD_PARAMETER	At least one of the following is true:  The <i>Event</i> is invalid.  The <i>EventStatus</i> pointer is NULL or invalid
Other	Hardware access exception.

## Functional Description:

---

This function obtains the current status of a single ACPI fixed event.

## 8.6.5 AcpiInstallFixedEventHandler

**Install a handler for ACPI Fixed Events.**

**ACPI\_STATUS**  
**AcpiInstallFixedEventHandler (**  
     **UINT32**  
     **ACPI\_EVENT\_HANDLER**  
     **void**  
     **Event,**  
     **Handler,**  
     **\*Context)**

## PARAMETERS

Event	The fixed event to be managed by this handler.
Handler	Address of the handler to be installed.
Context	A context value that will be passed to the handler as a parameter.

## RETURN VALUE

Status Exception code that indicates success or reason for failure.

**EXCEPTIONS**

AE_OK	The handler was successfully installed.
AE_BAD_PARAMETER	At least one of the following is true:  The <i>Event</i> is invalid.  The <i>Handler</i> pointer is NULL.
AE_ERROR	The fixed event enable register could not be written.
AE_ALREADY_EXISTS	A handler for this event is already installed.

**Functional Description:**

---

This function installs a handler for a predefined fixed event.

**8.6.5.1 Interface to Fixed Event Handlers****Definition of the handler interface for Fixed Events.**

```
typedef
UINT32 (*ACPI_EVENT_HANDLER) (
    void                *Context)
```

**PARAMETERS**

Context	The Context value that was passed as a parameter to the <i>AcpiInstallFixedEventHandler</i> function.
---------	---

**RETURN VALUE**

Reserved	Handler should return zero.
----------	-----------------------------

**Functional Description:**

---

This handler is installed via *AcpiInstallFixedEventHandler*. It is called whenever the particular fixed event it was installed to handle occurs.

This function executes in the context of an interrupt handler.



## 8.6.6 AcpiRemoveFixedEventHandler

<b>Remove an ACPI Fixed Event handler.</b>
--

### ACPI\_STATUS

**AcpiRemoveFixedEventHandler (**  
     **UINT32**                      **Event,**  
     **ACPI\_EVENT\_HANDLER**    **Handler)**

### PARAMETERS

Event	The fixed event whose handler is to be removed.
Handler	Address of the previously installed handler.

### RETURN VALUE

Status	Exception code that indicates success or reason for failure.
--------	--

### EXCEPTIONS

AE_OK	The handler was successfully removed.
AE_BAD_PARAMETER	At least one of the following is true:  The <i>Event</i> is invalid.  The <i>Handler</i> pointer is NULL.  The <i>Handler</i> address is not the same as the one that is installed.
AE_ERROR	The fixed event enable register could not be written.
AE_NOT_EXIST	There is no handler installed for this event.

### Functional Description:

---

This function removes a handler for a predefined fixed event that was previously installed via a call to *AcpiInstallFixedEventHandler*.



## 8.7 ACPI General Purpose Event (GPE) Management

### 8.7.1 AcpiUpdateAllGpes

## Finish GPE initialization and enable all runtime GPEs.

**ACPI\_STATUS  
AcpiUpdateAllGpes (  
void)**

## PARAMETERS

None

## RETURN VALUE

Status	Exception code that indicates success or reason for failure.
--------	--

## EXCEPTIONS

AE_OK	All GPEs were initialized and the runtime GPEs were successfully enabled.
-------	---

### Functional Description:

This function completes the GPE initialization and enables all GPEs that have associated `_Lxx` or `_Exx` methods **and** are not referenced by any device `_PRW` methods. Any GPE that is referenced by a `_PRW` method indicates that the GPE is generally intended for system or device wakeup. Such GPEs must be enabled directly (via `AcpiEnableGpe`) when the parent device is setup for wakeup.

The host must call this function at least once after the all system **\_PRW** methods have been executed. It should also be called after any new GPEs have been added to the system, either after a GPE Block Device has been added or if any new GPE methods (**\_Lxx/\_Exx**) have been added via a dynamic ACPI table load. It is safe to simply call this function after any dynamic table load, from a global table handler.

### 8.7.2 AcpiEnableGpe

## Enable an ACPI General Purpose Event.

```
ACPI_STATUS
AcpiEnableGpe (
    ACPI_HANDLE GpeDevice,
    UINT32 GpeNumber)
```

## PARAMETERS

GpeDevice	A handle for the parent GPE Block Device of the GPE to be enabled. Specify a NULL handle to indicate that the
-----------	---



	permanent GPE blocks defined in the FADT (GPE0 and GPE1) are to be used.
GpeNumber	The GPE number to be enabled within the specified GPE Block. The GPE0 block always begins at zero. GPE1 begins at GPE1_BASE (in the FADT). Named GPE Block Devices always begin at zero.

## RETURN VALUE

Status	Exception code that indicates success or reason for failure.
--------	--

## EXCEPTIONS

AE_OK	The GPE was successfully enabled.
AE_BAD_PARAMETER	At least one of the following is true:  The <i>GpeDevice</i> is invalid or does not refer to a valid GPE Block Device.  The <i>GpeNumber</i> is out of range for the referenced <i>GpeDevice</i> .
AE_LIMIT	The specified GPE has more than 255 references.
AE_NO_HANDLER	The specified GPE has neither a handler nor an <i>_Lxx/_Exx</i> method associated with it, therefore it is useless.

## Functional Description:

---

This function enables a single General Purpose Event. Both the FADT-defined GPE blocks and GPE Block Devices are supported. The GPE blocks defined in the FADT are permanent and installed during system initialization. These permanent blocks, GPE0 and GPE1, are treated as a single logical block differentiated by non-overlapping GPE numbers. GPE Block Devices are installed via *AcpiInstallGpeBlock* during bus/device enumeration.

For shared GPEs, this function may be called multiple times, once for each device shared on the GPE. In this way, device drivers may be written such that the fact that the underlying GPE is shared is transparent. Physically, a runtime GPE is enabled on the first call to this interface. Additional calls simply increment an internal reference count..



### 8.7.3 AcpiDisableGpe

<b>Disable an ACPI General Purpose Event.</b>
---

**ACPI\_STATUS**  
**AcpiDisableGpe (**  
    **ACPI\_HANDLE**  
    **UINT32**

**GpeDevice,**  
**GpeNumber)**

#### PARAMETERS

GpeDevice	A handle for the parent GPE Block Device of the GPE to be disabled. Specify a NULL handle to indicate that the permanent GPE blocks defined in the FADT (GPE0 and GPE1) are to be used.
GpeNumber	The GPE number to be disabled within the specified GPE Block. The GPE0 block always begins at zero. GPE1 begins at GPE1_BASE (in the FADT). Named GPE Block Devices always begin at zero.

#### RETURN VALUE

Status	Exception code that indicates success or reason for failure.
--------	--

#### EXCEPTIONS

AE_OK	The GPE was successfully disabled.
AE_BAD_PARAMETER	At least one of the following is true:  The <i>GpeDevice</i> is invalid or does not refer to a valid GPE Block Device.  The <i>GpeNumber</i> is out of range for the referenced <i>GpeDevice</i> .
AE_LIMIT	There are currently no references to this GPE. This probably means that <i>AcpiEnableGpe</i> was never called for this GPE.

#### Functional Description:

This function disables a single General Purpose Event. Both the FADT-defined GPE blocks and GPE Block Devices are supported. The GPE blocks defined in the FADT are permanent and installed during system initialization. These permanent blocks, GPE0 and GPE1, are treated as a single logical block differentiated by non-overlapping GPE numbers. GPE Block Devices are installed via *AcpiInstallGpeBlock* during bus/device enumeration.

For shared GPEs, this function may be called multiple times, once for each device shared on the GPE. In this way, device drivers may be written such that the fact that the underlying GPE is shared is transparent. Physically, a runtime GPE is disabled on the last call to this interface (corresponding to the first call to *AcpiEnableGpe*.)



## 8.7.4 AcpiClearGpe

Clear a pending ACPI General Purpose Event.

ACPI\_STATUS

AcpiClearGpe (

ACPI\_HANDLE

UINT32

GpeDevice,

GpeNumber)

### PARAMETERS

GpeDevice

A handle for the parent GPE Block Device of the GPE to be cleared. Specify a NULL handle to indicate that the permanent GPE blocks defined in the FADT (GPE0 and GPE1) are to be used.

GpeNumber

The GPE number to be cleared within the specified GPE Block. The GPE0 block always begins at zero. GPE1 begins at GPE1\_BASE (in the FADT). Named GPE Block Devices always begin at zero.

### RETURN VALUE

Status

Exception code that indicates success or reason for failure.

### EXCEPTIONS

AE\_OK

The GPE was successfully cleared.

AE\_BAD\_PARAMETER

At least one of the following is true:

The *GpeDevice* is invalid or does not refer to a valid GPE Block Device.

The *GpeNumber* is out of range for the referenced *GpeDevice*.

### Functional Description:

This function clears a single General Purpose Event. Both the FADT-defined GPE blocks and GPE Block Devices are supported. The GPE blocks defined in the FADT are permanent and installed during system initialization. These permanent blocks, GPE0 and GPE1, are treated as a single logical block differentiated by non-overlapping GPE numbers. GPE Block Devices are installed via *AcpiInstallGpeBlock* during bus/device enumeration.

This function may be called from an interrupt service routine (typically a GPE handler) or a device driver.



## 8.7.5 AcpiSetGpe

Forced enable/disable for an individual ACPI General Purpose Event.

### ACPI\_STATUS

AcpiSetGpe (  
ACPI\_HANDLE  
UINT32  
UINT8

GpeDevice,  
GpeNumber,  
Action)

### PARAMETERS

GpeDevice	A handle for the parent GPE Block Device of the GPE. Specify a NULL handle to indicate that the permanent GPE blocks defined in the FADT (GPE0 and GPE1) are to be used.
GpeNumber	The GPE number within the specified GPE Block. The GPE0 block always begins at zero. GPE1 begins at GPE1_BASE (in the FADT). Named GPE Block Devices always begin at zero.
Action	<b>ACPI_GPE_ENABLE</b> – Enable this GPE. For runtime GPEs, the hardware is updated immediately. For wake GPEs, the hardware mask is updated for use when sleeping/suspending.  <b>ACPI_GPE_DISABLE</b> – Disable this GPE. For runtime GPEs, the hardware is updated immediately. For wake GPEs, the hardware mask is updated for use when sleeping/suspending.

### RETURN VALUE

Status	Exception code that indicates success or reason for failure.
--------	--

### EXCEPTIONS

AE_OK	The type of the GPE was successfully set.
AE_BAD_PARAMETER	At least one of the following is true:  The <i>GpeDevice</i> is invalid or does not refer to a valid GPE Block Device.  The <i>GpeNumber</i> is out of range for the referenced <i>GpeDevice</i> .  The <i>Action</i> is invalid.
AE_NO_HANDLER	The specified GPE has neither a handler nor an <i>_Lxx/_Exx</i> method associated with it, therefore it is useless.



### Functional Description:

This function forces the enabling or disabling of a single General Purpose Event. It bypasses the reference count mechanism implemented by *AcpiEnableGpe* and *AcpiDisableGpe* and must be used carefully and sparingly. Its primary purpose is for use in device drivers like the Embedded Controller driver where it may be necessary to disable a GPE for a short period of time.

Both the FADT-defined GPE blocks and GPE Block Devices are supported. The GPE blocks defined in the FADT are permanent and installed during system initialization. These permanent blocks, GPE0 and GPE1, are treated as a single logical block differentiated by non-overlapping GPE numbers. GPE Block Devices are installed via *AcpiInstallGpeBlock* during bus/device enumeration.

## 8.7.6 AcpiFinishGpe

**Clear and conditionally re-enable a GPE from a GPE handler.**

### ACPI\_STATUS

**AcpiFinishGpe (**  
**ACPI\_HANDLE**  
**UINT32**

**GpeDevice,**  
**GpeNumber)**

### PARAMETERS

GpeDevice	A handle for the parent GPE Block Device of the GPE to be disabled. Specify a NULL handle to indicate that the permanent GPE blocks defined in the FADT (GPE0 and GPE1) are to be used.
GpeNumber	The GPE number to be disabled within the specified GPE Block. The GPE0 block always begins at zero. GPE1 begins at GPE1_BASE (in the FADT). Named GPE Block Devices always begin at zero.

### RETURN VALUE

Status	Exception code that indicates success or reason for failure.
--------	--

### EXCEPTIONS

AE_OK	The GPE was successfully disabled.
AE_BAD_PARAMETER	At least one of the following is true:  The <i>GpeDevice</i> is invalid or does not refer to a valid GPE Block Device.  The <i>GpeNumber</i> is out of range for the referenced <i>GpeDevice</i> .

**Functional Description:**

This function simplifies the GPE completion processing for GPE handlers. If the GPE is level-triggered, the GPE status bit is cleared. If the GPE is currently logically enabled for runtime, it is then re-enabled in the hardware.

Call this function from a synchronous or asynchronous GPE handler after GPE processing is complete.

## 8.7.7 AcpiSetupGpeForWake

Identify a GPE that has the ability to wake the system.

**ACPI\_STATUS****AcpiSetupGpeForWake (****ACPI\_HANDLE****ACPI\_HANDLE****UINT32****WakeDevice,****GpeDevice,****GpeNumber)****PARAMETERS**

WakeDevice

A handle to the parent device associated with the **\_PRW** method that references this GPE. **ACPI\_ROOT\_OBJECT** may be used to take notifies on the namespace root device.

GpeDevice

A handle for the parent GPE Block Device of the GPE to be disabled. Specify a NULL handle to indicate that the permanent GPE blocks defined in the FADT (GPE0 and GPE1) are to be used.

GpeNumber

The GPE number to be disabled within the specified GPE Block. The GPE0 block always begins at zero. GPE1 begins at GPE1\_BASE (in the FADT). Named GPE Block Devices always begin at zero.

**RETURN VALUE**

Status

Exception code that indicates success or reason for failure.

**EXCEPTIONS**

AE\_OK

The GPE was successfully disabled.

AE\_ALREADY\_EXISTS

The implicit notify feature is enabled for this GPE, but this *WakeDevice* is already on the list of devices to implicitly notify.

AE\_BAD\_PARAMETER

At least one of the following is true:

The *WakeDevice* is invalid or is not of type **ACPI\_TYPE\_DEVICE**.

The *GpeDevice* is invalid or does not refer to a valid GPE Block Device.



The *GpeNumber* is out of range for the referenced *GpeDevice*.

AE\_NO\_MEMORY

Insufficient dynamic memory to complete the operation.

#### Functional Description:

This function marks an individual GPE as having the ability to wake the system. It is intended to be called as the host OS executes the system **\_PRW** methods (Power Resources for Wake) in the system ACPI tables and discovers GPEs that can wake the system.

Each **\_PRW** method appears under a Device Object (The *WakeDevice*), and contains the information for the wake GPE associated with the *WakeDevice*. The host should call this function every time such a GPE is identified.

Calling this function also enables the *Implicit Notify* feature for the input *WakeDevice*. If there neither a GPE method (**\_Lxx/\_Exx**) or a handler for the GPE, when the GPE occurs, a **Notify(DEVICE\_WAKE)** is automatically issued on the *WakeDevice*.

The *Implicit Notify* feature supports multiple *WakeDevices* for the same GPE. When the GPE occurs, a notify is issued on each of the wake devices for the GPE.

## 8.7.8 AcpiSetGpeWakeMask

**Set or clear the wakeup enable mask bit for an individual GPE.**

#### ACPI STATUS

**AcpiSetGpeWakeMask (**

**ACPI\_HANDLE**

**UINT32**

**UINT8**

**GpeDevice,**

**GpeNumber,**

**Action)**

#### PARAMETERS

GpeDevice

A handle for the parent GPE Block Device of the GPE to be disabled. Specify a NULL handle to indicate that the permanent GPE blocks defined in the FADT (GPE0 and GPE1) are to be used.

GpeNumber

The GPE number to be disabled within the specified GPE Block. The GPE0 block always begins at zero. GPE1 begins at GPE1\_BASE (in the FADT). Named GPE Block Devices always begin at zero.

Action

Action to take. This parameter must be one of the following manifest constants:

**ACPI\_GPE\_ENABLE**

**ACPI\_GPE\_DISABLE**

#### RETURN VALUE

Status

Exception code that indicates success or reason for failure.



**EXCEPTIONS**

AE_OK	The GPE was successfully disabled.
AE_BAD_PARAMETER	At least one of the following is true:  The <i>GpeDevice</i> is invalid or does not refer to a valid GPE Block Device.  The <i>GpeNumber</i> is out of range for the referenced <i>GpeDevice</i> .  The <i>Action</i> is not one of the supported values.
AE_TYPE	The GPE is not marked as a wakeup GPE.

**Functional Description:**

---

This function sets or clears the wakeup mask bit for an individual GPE. The GPE must already be marked as a wake GPE (via *AcpiSetupGpeForWake*).

Individual drivers should call this function as the system prepares to sleep when a particular device is to be allowed to wake the system.

## 8.7.9 AcpiGetGpeStatus

Obtain the status of an ACPI General Purpose Event.
---

**ACPI\_STATUS**

<b>AcpiGetGpeStatus (</b> <b>ACPI_HANDLE</b> <b>UINT32</b> <b>ACPI_EVENT_STATUS</b>	<b>GpeDevice,</b> <b>GpeNumber,</b> <b>*EventStatus)</b>
--	--

**PARAMETERS**

GpeDevice	A handle for the parent GPE Block Device of the GPE for which status is to be obtained. Specify a NULL handle to indicate that the permanent GPE blocks defined in the FADT (GPE0 and GPE1) are to be used.
GpeNumber	The GPE number to be enabled within the specified GPE Block. The GPE0 block always begins at zero. GPE1 begins at GPE1_BASE (in the FADT). Named GPE Block Devices always begin at zero.
EventStatus	Where the event status is returned. The following bits may be set:

**ACPI\_EVENT\_FLAG\_SET****RETURN VALUE**

Status	Exception code that indicates success or reason for failure.
--------	--

**EXCEPTIONS**

AE_OK	The GPE was successfully enabled.
AE_BAD_PARAMETER	At least one of the following is true:  The <i>GpeDevice</i> is invalid or does not refer to a valid GPE Block Device.  The <i>GpeNumber</i> is out of range for the referenced <i>GpeDevice</i> .

**Functional Description:**

This function obtains the status of a single General Purpose Event. Both the FADT-defined GPE blocks and GPE Block Devices are supported. The GPE blocks defined in the FADT are permanent and installed during system initialization. These permanent blocks, GPE0 and GPE1, are treated as a single logical block differentiated by non-overlapping GPE numbers. GPE Block Devices are installed via *AcpiInstallGpeBlock* during bus/device enumeration.

This function may be called from an interrupt service routine (typically a GPE handler) or a device driver.

## 8.7.10 AcpiGetGpeDevice

**Get the GPE Block Device associated with the GPE index.**

**ACPI\_STATUS**

**AcpiGetGpeDevice (**  
**UINT32**  
**ACPI\_HANDLE**

**Index,**  
**\*GpeDevice)**

**PARAMETERS**

Index	The system index of the GPE, defined to be from zero to the value of <b>AcpiCurrentGpeCount</b> .
GpeDevice	A pointer to where the handle of the GPE block device is returned. NULL indicates that the GPE is within one of the FADT-defined GPE blocks.

**RETURN VALUE**

Status	Exception code that indicates success or reason for failure.
--------	--

**EXCEPTIONS**

AE_OK	The GPE block device was successfully returned.
AE_BAD_PARAMETER	At least one of the following is true:  The <i>GpeDevice</i> pointer is invalid.



AE\_NOT\_EXIST

The Index refers to a non-existent GPE (it is larger than **AcpiCurrentGpeCount**).

**Functional Description:**

---

This function obtains the GPE block device associated with the Index parameter. A returned NULL GPE device indicates that the Index refers to a GPE that is contained in one of the FADT-defined GPE blocks.

The Index is a system index used to track all GPEs. First are the FADT GPE0 block GPEs, then the FADT GPE1 GPEs (if present), then any GPE block device GPEs. Valid values for the Index are from zero to the value of the public global variable **AcpiCurrentGpeCount**. Index values are consecutive with no 'holes'.

## 8.7.11 AcpiDisableAllGpes

<b>Disable all system GPEs</b>
--------------------------------

**ACPI\_STATUS**  
**AcpiDisableAllGpes** (  
    **void**)

**PARAMETERS**

None

**RETURN VALUE**

Status	Exception code that indicates success or reason for failure.
--------	--

**EXCEPTIONS**

AE_OK	All GPEs were successfully disabled.
Other	Hardware access exception.

**Functional Description:**

---

This function disables all GPEs currently defined in the system. This includes all runtime and wake GPEs, in both the FADT-defined GPE blocks as well as any installed GPE block devices.



## 8.7.12 AcpiEnableAllRuntimeGpes

**Enable all runtime GPEs**

**ACPI\_STATUS**  
**AcpiEnableAllRuntimeGpes (**  
     **void)**

### PARAMETERS

None

### RETURN VALUE

Status	Exception code that indicates success or reason for failure.
--------	--

### EXCEPTIONS

AE_OK	All runtime GPEs were successfully enabled.
Other	Hardware access exception.

### Functional Description:

This function enables all runtime GPEs currently defined in the system. This includes all runtime GPEs in both the FADT-defined GPE blocks as well as any installed GPE block devices. Runtime GPEs are defined to be any GPEs that are not Wake GPEs, as determined from the \_PRW methods within the system AML.

## 8.7.13 AcpiInstallGpeBlock

**Install a GPE Block Device.**

**ACPI\_STATUS**  
**AcpiInstallGpeBlock (**  
     **ACPI\_HANDLE**          **GpeDevice,**  
     **ACPI\_GENERIC\_ADDRESS**  **\*GpeBlockAddress,**  
     **UINT32**              **RegisterCount,**  
     **UINT32**              **Interrupt)**

### PARAMETERS

GpeDevice	A handle for the GPE Block Device to be installed.
GpeBlockAddress	The address and space ID for the registers that define the new GPE block.
RegisterCount	The number of status/enable GPE register pairs in this block.



Interrupt	The hardware interrupt level that this GPE block is to be associated with. Can be SCI_INT or any other system interrupt level.
-----------	--

**RETURN VALUE**

Status	Exception code that indicates success or reason for failure.
--------	--

**EXCEPTIONS**

AE_OK	The GPE was successfully enabled.
AE_BAD_PARAMETER	At least one of the following is true:  The <i>GpeDevice</i> is invalid or does not refer to a valid GPE Block Device.  The <i>GpeNumber</i> is out of range for the referenced <i>GpeDevice</i> .

**Functional Description:**

This function installs a GPE Block Device. It is intended for use by a device driver that supports the enumeration of GPE Block Devices. The caller must identify each Block Device in the ACPI namespace (each has a \_HID of **ACPI0006**) and obtain the resource requirements (\_CRS, etc.) and make this call for each device found.

Gpe Block Device handling is supported in the ACPICA Subsystem because the SCI\_INT is owned by the subsystem, and the FADT-defined GPE blocks are also owned by the subsystem. Via this interface, the ACPICA subsystem also supports GPE Block Devices and the associated interrupts, detection, dispatch, and GPE control method execution — thus centralizing all (system-wide) GPE support to the subsystem.

## 8.7.14 AcpiRemoveGpeBlock

<b>Remove a GPE Block Device.</b>
-----------------------------------

**ACPI\_STATUS**  
**AcpiRemoveGpeBlock (**  
    **ACPI\_HANDLE**                    **GpeDevice)**

**PARAMETERS**

GpeDevice	A handle for the GPE Block Device to be removed.
-----------	--

**RETURN VALUE**

Status	Exception code that indicates success or reason for failure.
--------	--

**EXCEPTIONS**

AE_OK	The GPE was successfully enabled.
-------	-----------------------------------



AE\_BAD\_PARAMETER

At least one of the following is true:

The *GpeDevice* is invalid or does not refer to a valid GPE Block Device.

The *GpeNumber* is out of range for the referenced *GpeDevice*.

**Functional Description:**

This function removed a GPE Block Device that was previously installed via *AcpiInstallGpeBlock*.

## 8.7.15 AcpiInstallGpeHandler

Install a handler for ACPI General Purpose Events.
--

ACPI\_STATUS

AcpiInstallGpeHandler (

ACPI\_HANDLE

GpeDevice,

UINT32

GpeNumber,

UINT32

Type,

ACPI\_GPE\_HANDLER

Handler,

void

\*Context)

**PARAMETERS**

GpeDevice

A handle for the parent GPE Block Device of the GPE for which the handler is to be installed. Specify a NULL handle to indicate that the permanent GPE blocks defined in the FADT (GPE0 and GPE1) are to be used.

GpeNumber

A zero based GPE number. GPE numbers start with GPE register bank zero, and continue sequentially through GPE bank one.

Type

Whether this GPE is edge or level triggered:

**ACPI\_GPE\_LEVEL\_TRIGGERED****ACPI\_GPE\_EDGE\_TRIGGERED**

Handler

Address of the handler to be installed.

Context

A context value that will be passed to the handler as a parameter.

**RETURN VALUE**

Status

Exception code that indicates success or reason for failure.

**EXCEPTIONS**

AE\_OK

The handler was successfully installed.

AE\_BAD\_PARAMETER

At least one of the following is true:

The *GpeNumber* is invalid.

The *Handler* pointer is NULL.

AE_ALREADY_EXISTS	A handler for this general-purpose event is already installed.
-------------------	--

AE_NO_MEMORY	Insufficient dynamic memory to complete the operation.
--------------	--

### Functional Description:

This function installs a handler for a general-purpose event.

### 8.7.15.1 Interface to General Purpose Event Handlers

### Definition of the handler interface for General Purpose Events.

```
typedef
UINT32 (*ACPI_GPE_HANDLER) (
    void                                *Context)
```

## PARAMETERS

Context	The Context value that was passed as a parameter to the AcpiInstallGpeHandler function.
---------	---

## RETURN VALUE

**Flags**

Return flags, defined as follows:

**ACPI\_REENABLE\_GPE:** If this flag is set, ACPICA will automatically and immediately clear and re-enable the GPE. Use this option only if the GPE has been completely processed in the handler itself and there will be no asynchronous processing. Otherwise, the handler should return zero.

### Functional Description:

This handler is installed via *AcpiInstallGpeHandler*. It is called whenever the referenced general-purpose event occurs.

This function executes in the context of an interrupt handler.

Typically, a GPE handler will simply setup and initiate some later asynchronous processing for the GPE. When the asynchronous processing is complete, the asynchronous thread should call *AcpiFinishGpe* to clear and re-enable the GPE.

If the GPE handler does not initiate an asynchronous thread to complete the GPE processing and completes the GPE processing by itself, it should return the **ACPI\_REENABLE\_GPE** flag. This will cause ACPICA to clear and re-enable the GPE immediately upon the handler return. The GPE handler should never call *AcpiFinishGpe* directly, since this interface cannot be called from interrupt level. Use **ACPI\_REENABLE\_GPE** instead.



## 8.7.16 AcpiRemoveGpeHandler

**Remove an ACPI General-Purpose Event handler.**

**ACPI\_STATUS**

**AcpiRemoveGpeHandler (**

**ACPI\_HANDLE**

**UINT32**

**ACPI\_EVENT\_HANDLER**

**GpeDevice,**

**GpeNumber,**

**Handler)**

### PARAMETERS

GpeDevice	A handle for the parent GPE Block Device of the GPE for which the handler is to be removed. Specify a NULL handle to indicate that the permanent GPE blocks defined in the FADT (GPE0 and GPE1) are to be used.
GpeNumber	A zero based GPE number. GPE numbers start with GPE register bank zero, and continue sequentially through GPE bank one.
Handler	Address of the previously installed handler.

### RETURN VALUE

Status	Exception code that indicates success or reason for failure.
--------	--

### EXCEPTIONS

AE_OK	The handler was successfully removed.
AE_BAD_PARAMETER	At least one of the following is true:  The <i>GpeNumber</i> is invalid.  The <i>Handler</i> pointer is NULL.  The <i>Handler</i> address is not the same as the one that is installed.
AE_NOT_EXIST	There is no handler installed for this general-purpose event.

### Functional Description:

This function removes a handler for a general-purpose event that was previously installed via a call to *AcpiInstallGpeHandler*.





## 8.8 Miscellaneous Handler Support

### 8.8.1 AcpiInstallSciHandler

**Install a handler for ACPI System Control Interrupts (SCIs).**

```
ACPI_STATUS  
AcpiInstallSciHandler (  
    ACPI_SCI_HANDLER    Handler,  
    void                 *Context)
```

#### PARAMETERS

Handler	Address of the handler to be installed.
Context	A context value that will be passed to the handler as a parameter.

#### RETURN VALUE

Status	Exception code that indicates success or reason for failure.
--------	--

#### EXCEPTIONS

AE_OK	The handler was successfully installed.
AE_BAD_PARAMETER	The <i>Handler</i> pointer is NULL.
AE_ALREADY_EXISTS	This handler is already installed.

#### Functional Description:

This function installs a handler for the System Control Interrupt. Certain ACPI functionality requires the host to handle raw SCIs. For example, the “SCI Doorbell” that is defined for memory power state support requires the host device driver to handle SCIs to examine if the doorbell has been activated.

#### 8.8.1.1 Interface to SCI Handlers

**Definition of the handler interface for SCIs.**

```
typedef  
UINT32 (*ACPI_SCI_HANDLER) (  
    void                 *Context)
```

#### PARAMETERS

Context	The Context value that was passed as a parameter to the <i>AcpiInstallSciHandler</i> function.
---------	--

**RETURN VALUE**

HandlerActionTaken

The handler should return one of the following manifest constants:

**ACPI\_INTERRUPT\_HANDLED****ACPI\_INTERRUPT\_NOT\_HANDLED****Functional Description:**

This handler is installed via *AcpiInstallSciHandler*. It is called for each and every SCI received on the platform.

This function executes in the context of an interrupt handler.

## 8.8.2 AcpiRemoveSciHandler

<b>Remove an ACPI SCI handler.</b>
------------------------------------

**ACPI\_STATUS**

**AcpiRemoveSciHandler (**  
**ACPI\_SCI\_HANDLER                      Handler)**

**PARAMETERS**

Handler

Address of the previously installed handler.

**RETURN VALUE**

Status

Exception code that indicates success or reason for failure.

**EXCEPTIONS**

AE\_OK

The handler was successfully removed.

AE\_BAD\_PARAMETER

The *Handler* pointer is NULL.

AE\_NOT\_EXIST

This handler is not installed for the SCI.

**Functional Description:**

This function removes a System Control Interrupt (SCI) handler that was previously installed via a call to *AcpiInstallSciHandler*.



### 8.8.3 AcpiInstallGlobalEventHandler

**Install a global handler for all ACPI General Purpose and Fixed Events.**

ACPI\_STATUS

```
AcpiInstallGlobalEventHandler (
    ACPI_GBL_EVENT_HANDLER    Handler,
    void                       *Context)
```

#### PARAMETERS

Handler	Address of the handler to be installed.
Context	A context value that will be passed to the handler as a parameter.

#### RETURN VALUE

Status	Exception code that indicates success or reason for failure.
--------	--

#### EXCEPTIONS

AE_OK	The handler was successfully installed.
AE_BAD_PARAMETER	The <i>Handler</i> pointer is NULL.
AE_ALREADY_EXISTS	A global event handler is already installed.

#### Functional Description:

This function installs a global handler for all general purpose and fixed ACPI events. The handler is invoked at interrupt level. Such a handler is intended to be used to update global data structures such as GPE and fixed event counters.

#### 8.8.3.1 Interface to the Global Event Handler

**Definition of the handler interface for the Global Event Handler.**

```
typedef
void (*ACPI_GBL_EVENT_HANDLER) (
    UINT32    EventType,
    ACPI_HANDLE Device,
    UINT32    EventNumber,
    void      *Context)
```

#### PARAMETERS

EventType	Type of this ACPI event. Currently, general purpose (GPE) and fixed events are supported. One of the following manifest constants:
-----------	--

**ACPI\_EVENT\_TYPE\_GPE**

**ACPI\_EVENT\_TYPE\_FIXED**

**Device** For GPE Block Devices, this is the parent device for the GPE. This parameter is NULL for FADT-defined GPEs and Fixed Events (**ACPI\_EVENT\_TYPE\_FIXED**).

**EventNumber** For GPEs, this is the GPE number relative to the GPE Device. For Fixed Events, this is the Fixed Event type, one of the following manifest constants:

**ACPI\_EVENT\_PMTIMER**  
**ACPI\_EVENT\_GLOBAL**  
**ACPI\_EVENT\_POWER\_BUTTON**  
**ACPI\_EVENT\_SLEEP\_BUTTON**  
**ACPI\_EVENT\_RTC**

**Context** The Context value that was passed as a parameter to the `AcpiInstallGlobalEventHandler` function.

**RETURN VALUE**

None

**Functional Description:**

This handler is installed via *AcpiInstallGlobalEventHandler*. It is called whenever a general purpose or fixed ACPI event occurs.

This function executes in the context of an interrupt handler.

## 8.8.4 **AcpiInstallNotifyHandler**

**Install a handler for notification events on an ACPI object.**

**ACPI\_STATUS**

**AcpiInstallNotifyHandler (**

<b>ACPI_HANDLE</b>	<b>Object,</b>
<b>UINT32</b>	<b>Type,</b>
<b>ACPI_NOTIFY_HANDLER</b>	<b>Handler,</b>
<b>void</b>	<b>*Context)</b>

**PARAMETERS**

**Object** A Handle to the object for which notify events will be handled. Notifies on this object will be dispatched to the handler. If **ACPI\_ROOT\_OBJECT** is specified, the handler will become a global handler that receives all (system wide) notifications of the Type specified. Otherwise, this object must be one of the following types:

**ACPI\_TYPE\_DEVICE**  
**ACPI\_TYPE\_PROCESSOR**  
**ACPI\_TYPE\_THERMAL**



Type	Specifies the type of notifications that are to be received by this handler:  <b>ACPI_SYSTEM_NOTIFY</b> – Notification values from 0x00 to 0x7F.  <b>ACPI_DEVICE_NOTIFY</b> – Notification values from 0x80 to 0xFF.
Handler	Address of the handler to be installed.
Context	A context value that will be passed to the handler as a parameter.

**RETURN VALUE**

Status	Exception code that indicates success or reason for failure.
--------	--

**EXCEPTIONS**

AE_OK	The handler was successfully installed.
AE_BAD_PARAMETER	At least one of the following is true:  The <i>Object</i> handle is invalid.  The <i>Type</i> is not a valid value.  The <i>Handler</i> pointer is NULL.
AE_ALREADY_EXISTS	This notification handler for this object is already installed.
AE_TYPE	The type of the Object is not one of the supported object types.
AE_NO_MEMORY	Insufficient dynamic memory to complete the operation.

**Functional Description:**

---

This function installs a handler for notify events on an ACPI object. According to the ACPI specification, the only objects that can receive notifications are Device, Thermal Zone, and Processor objects.

With the exception of the global notify handlers, multiple notify handlers may be installed for the same ACPI object and for the same notification type (system or device). During notification dispatch, each installed handler is invoked in turn. This can simplify the host OS notification implementation. This function may be called multiple times on the same object, as long as the handler itself is different. A different *Context* parameter may be specified for each handler for the device.

A single global handler for each notify type may be installed by using the `ACPI_ROOT_OBJECT` constant as the object handle. When a notification is received, it is first dispatched to the global handler (if there is one), and then to the device-specific notify handler (if there is one)



### 8.8.4.1 Interface to Notification Event Handlers

#### Definition of the handler interface for Notification Events.

```
typedef
void (*ACPI_NOTIFY_HANDLER) (
    ACPI_HANDLE      Device
    UINT32           Value,
    void             *Context)
```

#### PARAMETERS

Device	A handle for the device on which the notify occurred.
Value	The notify value that was passed as a parameter to the AML Notify() operation.
Context	The Context value that was passed as a parameter to the AcpiInstallNotifyHandler function.

#### RETURN VALUE

None

#### Functional Description:

This handler is installed via *AcpiInstallNotifyHandler*. It is called whenever a **notify** occurs on the target object. If the handler is installed as a global notification handler, it is called for every notify of the type specified when it was installed. If multiple handlers are installed for an object, each handler is invoked in turn during the notification dispatch.

This function **does not** execute in the context of an interrupt handler.

### 8.8.5 AcpiRemoveNotifyHandler

#### Remove a handler for ACPI notification events.

```
ACPI_STATUS
AcpiRemoveNotifyHandler (
    ACPI_HANDLE      Object,
    UINT32           Type,
    ACPI_NOTIFY_HANDLER Handler)
```

#### PARAMETERS

Object	A handle to the object for which a notify handler will be removed. If <b>ACPI_ROOT_OBJECT</b> is specified, the global handler of the <i>Type</i> specified is removed. Otherwise, this object must be one of the following types:
--------	--

**ACPI\_TYPE\_DEVICE**  
**ACPI\_TYPE\_PROCESSOR**

**ACPI\_TYPE\_THERMAL**

Type	Specifies the type of notify handler to be removed:  <b>ACPI_SYSTEM_NOTIFY</b> – Notification values from 0x00 to 0x7F.  <b>ACPI_DEVICE_NOTIFY</b> – Notification values from 0x80 to 0xFF.
Handler	Address of the previously installed handler.

**RETURN VALUE**

Status	Exception code that indicates success or reason for failure.
--------	--

**EXCEPTIONS**

AE_OK	The handler was successfully removed.
AE_BAD_PARAMETER	At least one of the following is true:  The <i>Object</i> handle is invalid.  The <i>Type</i> is not a valid value.  The <i>Handler</i> pointer is NULL.
AE_NOT_EXIST	There is no handler installed for notifications on this object.  The Handler address is not the same as the one that is installed.
AE_TYPE	The type of the Object is not one of the supported object types.

**Functional Description:**

---

This function removes a handler for notify events that was previously installed via a call to *AcpiInstallNotifyHandler*.



## 8.8.6 AcpInstallAddressSpaceHandler

Install handlers for ACPI Operation Region events.

### ACPI\_STATUS

```
AcpInstallAddressSpaceHandler (
    ACPI_HANDLE          Object,
    ACPI_ADR_SPACE_TYPE SpaceId,
    ACPI_ADR_SPACE_HANDLER Handler,
    ACPI_ADR_SPACE_SETUP Setup,
    void                  *Context)
```

### PARAMETERS

Object	A handle for the object for which a address space handler will be installed. This object may be specified as the <b>ACPI_ROOT_OBJECT</b> to request global scope. Otherwise, this object must be one of the following types:  <div style="text-align: center;"> <b>ACPI_TYPE_DEVICE</b>  <b>ACPI_TYPE_PROCESSOR</b>  <b>ACPI_TYPE_THERMAL</b> </div>
SpaceId	The ID of the Address Space or Operation Region to be managed by this handler.
Handler	Address of the handler to be installed if the special value <b>ACPI_DEFAULT_HANDLER</b> is used the handler supplied with by the ACPICA for that address space will be installed.
Setup	Address of a start/stop initialization/termination function that is called when the region first becomes available and also if and when it becomes unavailable.
Context	A context value that will be passed to the handler as a parameter.

### RETURN VALUE

Status	Exception code that indicates success or reason for failure.
--------	--

### EXCEPTIONS

AE_OK	The handler was successfully installed.
AE_BAD_PARAMETER	At least one of the following is true:  The object handle does not refer to an object of type Device, Processor, ThermalZone, or the root object.  The SpaceId is invalid.  The Handler pointer is NULL.





AE_ALREADY_EXISTS	A handler for this address space or operation region is already installed.
AE_NOT_EXIST	<b>ACPI_DEFAULT_HANDLER</b> was specified for an address space that has no default handler.
AE_NO_MEMORY	There was insufficient memory to install the handler.

---

**Functional Description:**

This function installs a handler for an Address Space.

NOTE: This function should only be called after `AcpiEnableSubsystem` has been called. This is because any `_REG` methods associated with the Space ID are executed here, and these methods can only be safely executed after the default handlers have been installed and the hardware has been initialized (via `AcpiEnableSubsystem`.)

### 8.8.6.1 Interface to Address Space Setup Handlers

<b>Definition of the setup (Address Space start/stop) handler interface for Operation Region Events.</b>
--

```
typedef
void (*ACPI_ADR_SPACE_SETUP) (
    ACPI_HANDLE      Region,
    UINT32            Function
    void             *HandlerContext)
    void             **ReturnContext)
```

**PARAMETERS**

Region	A handle to the region that is initializing or terminating.
Function	The type of function to be performed; must be one of the following manifest constants:  <b>ACPI_REGION_ACTIVATE</b> (init) <b>ACPI_REGION_DEACTIVATE</b> (terminate)
HandlerContext	An address space specific Context value. Typically this is the context that was passed as a parameter to the <code>AcpiInstallAddressSpaceHandler</code> function.
ReturnContext	An address space specific Context value. This context subsumes the <code>HandlerContext</code> , and this is the context value that is passed to the actual address space handler routine.

**RETURN VALUE**

None



### Functional Description:

This handler is installed via *AcpiInstallAddressSpaceHandler*. It is invoked to both initialize and terminate the operation region handling code. The setup handler is first invoked with a function value of **ACPI\_REGION\_ACTIVATE** upon the first access to the region from AML code. It is called again with a function value of **ACPI\_REGION\_DEACTIVATE** just before the address space handler is removed.

This function **does not** execute in the context of an interrupt handler.

## 8.8.6.2 Interface to Address Space Handlers

### Definition of the handler interface for Operation Region Events.

```
typedef
void (*ACPI_ADR_SPACE_HANDLER) (
    UINT32          Function,
    ACPI_PHYSICAL_ADDRESS Address,
    UINT32          BitWidth,
    UINT64          *Value,
    void            *HandlerContext,
    void            *RegionContext)
```

### PARAMETERS

Function	The type of function to be performed; must be one of the following manifest constants:  <b>ACPI_READ</b> <b>ACPI_WRITE</b>
Address	A space-specific address where the operation is to be performed.
BitWidth	The width of the operation, typically 8, 16, 32, or 64.
Value	A pointer to the value to be written ( <b>ACPI_WRITE</b> ), or where the value that was read should be returned ( <b>ACPI_READ</b> ).
HandlerContext	An address space specific Context value. Typically this is the context that was passed as a parameter to the <i>AcpiInstallAddressSpaceHandler</i> function.
RegionContext	An operation region specific context. Created during the region setup.

### RETURN VALUE

None

**Functional Description:**

---

This handler is installed via *AcpiInstallAddressSpaceHandler*. It is invoked whenever AML code attempts to access the target Operation Region.

This function **does not** execute in the context of an interrupt handler.

### 8.8.6.3 Context for the Default PCI Address Space Handler

**Definition of the context required for installation of the default PCI address space handler.****UINT32****PCIContext**

Where PCIContext contains the PCI bus number and the PCI segment number. The bus number is in the low 16 bits and the segment number in the high 16 bits.

**Functional Description:**

---

This data is passed via the *Context* parameter when a handler for the *PCI\_Config* address space is invoked. If a *Context* parameter is passed to the *InstallAddressSpaceHandler* interface, ACPICA will reserve and use the beginning of the context data field for the PCIContext. The caller should ensure that the area pointed to by *Context* is large enough for this data.

Locations after the PCIContext are available for use by the handler.

### 8.8.6.4 Context for the GPIO/SerialBus Address Space Handlers

**Definition of the context required for installation of GPIO/SerialBus address space handlers.**

```
typedef struct acpi_connection_info
{
    UINT8                *Connection;
    UINT16               Length;
    UINT8                AccessLength;
} ACPI_CONNECTION;
```

**Where:**

*Connection* points to a buffer that contains the raw AML ResourceTemplate associated with the Field object being accessed. This association is created via the use of the ASL/AML Connection operator.

*Length* is the length of the Connection buffer in bytes.

*AccessLength* is the value associated with an *AccessAs* operator that utilizes the ACPI 5.0 *AccessAttribute* extensions that contain a length field:

AccessAs:	AttribBytes (AccessLength)
AccessAs:	AttribRawBytes (AccessLength)
AccessAs:	AttribRawProcessBytes (AccessLength)



### Functional Description:

This data is passed via the *Context* parameter when handlers for the **GeneralPurposeIo** and **GenericSerialBus** address spaces are invoked. If a *Context* parameter is passed to the *InstallAddressSpaceHandler* interface, ACPICA will reserve and use the beginning of the context data field for the GSBUS context. The caller should ensure that the area pointed to by *Context* is large enough for this data.

Locations after the *ACPI\_CONNECTION\_INFO* structure are available for use by the handler.

The Connection buffer can be converted to an *ACPI\_RESOURCE* structure via the *AcpiBufferToResource* interface. For example:

```
ACPI_RESOURCE          *Resource;

Status = AcpiBufferToResource (Context->Connection,
                               Context->Length, &Resource);
```

## 8.8.7 AcpiRemoveAddressSpaceHandler

**Remove an ACPI Operation Region handler.**

### ACPI\_STATUS

```
AcpiRemoveAddressSpaceHandler (
    ACPI_HANDLE          Object,
    ACPI_ADR_SPACE_TYPE SpaceId,
    ACPI_ADR_SPACE_HANDLER Handler)
```

### PARAMETERS

Object	A handle for the object for which a address space handler will be installed. This object may be specified as the <i>ACPI_ROOT_OBJECT</i> to request global scope. Otherwise, this object must be one of the following types:
--------	--

```
ACPI_TYPE_DEVICE
ACPI_TYPE_PROCESSOR
ACPI_TYPE_THERMAL
```

SpaceId	The ID of the Address Space or Operation Region whose handler is to be removed.
---------	---

Handler	Address of the previously installed handler.
---------	--

### RETURN VALUE

Status	Exception code that indicates success or reason for failure.
--------	--

### EXCEPTIONS

AE_OK	The handler was successfully removed.
-------	---------------------------------------



AE_BAD_PARAMETER	At least one of the following is true:  The object handle does not refer to an object of type Device, Processor, ThermalZone, or the root object.  The SpaceId is invalid.  The Handler pointer is NULL.  The Handler address is not the same as the one that is installed.
AE_NOT_EXIST	There is no handler installed for this address space or operation region.

**Functional Description:**

---

This function removes a handler for an Address Space or Operation Region that was previously installed via a call to *AcpInstallAddressSpaceHandler*.

## 8.8.8 AcpInstallExceptionHandler

<b>Install a handler for ACPI interpreter run-time exceptions.</b>
--

**ACPI\_STATUS**  
**AcpInstallExceptionHandler (**  
    **ACPI\_EVENT\_HANDLER**    **Handler)**

**PARAMETERS**

Handler	Address of the handler to be installed.
---------	---

**RETURN VALUE**

Status	Exception code that indicates success or reason for failure.
--------	--

**EXCEPTIONS**

AE_OK	The handler was successfully installed.
AE_BAD_PARAMETER	At least one of the following is true:  The <i>Handler</i> pointer is NULL.
AE_ALREADY_EXISTS	A handler for this general-purpose event is already installed.

**Functional Description:**

---

This function installs a global handler for exceptions generated during the execution of control methods. Useful for error logging and debugging.



### 8.8.8.1 Interface to Exception Handlers

#### Definition of the handler interface for General Purpose Events.

```
typedef
ACPI_STATUS (*ACPI_EXCEPTION_HANDLER) (
    ACPI_STATUS      AmlStatus,
    ACPI_NAME        Name,
    UINT16            Opcode,
    UINT32            AmlOffset,
    void              *Context)
```

#### PARAMETERS

AmlStatus	The exception code that was raised.
Name	Name of the executing control method.
Opcode	AML opcode whose execution caused the exception.
AmlOffset	Offset of the AML opcode within the control method.
Context	Reserved for future use. Currently NULL.

#### RETURN VALUE

None

#### Functional Description:

This handler is installed via *AcpInstallExceptionHandler*. It is called whenever an exception is raised within the AML interpreter during control method execution.

The **ACPI\_STATUS** that is returned by the handler is then used by the AML interpreter instead of the original exception code.



## 8.9 ACPI Resource Management

### 8.9.1 AcpiGetCurrentResources

Get the current resource list associated with an ACPI-related device.
---

#### ACPI\_STATUS

AcpiGetCurrentResources (

ACPI\_HANDLE

ACPI\_BUFFER

Device,

\*OutBuffer)

#### PARAMETERS

Device

A handle to a device object for which the current resources are to be returned.

OutBuffer

A pointer to a location where the current resource list is to be returned.

#### RETURN VALUE

Status

Exception code that indicates success or reason for failure.

#### EXCEPTIONS

AE\_OK

The resource list was successfully returned.

AE\_BAD\_PARAMETER

At least one of the following is true:

The *Device* handle is invalid.

The *OutBuffer* pointer is NULL.

The *Length* field of *OutBuffer* is not **ACPI\_ALLOCATE\_BUFFER**, but the *Pointer* field of *OutBuffer* is NULL.

AE\_BUFFER\_OVERFLOW

The *Length* field of *OutBuffer* indicates that the buffer is too small to hold the resource list. Upon return, the *Length* field contains the minimum required buffer length.

AE\_TYPE

The *Device* handle refers to an object that is not of type **ACPI\_TYPE\_DEVICE**.

#### Functional Description:

---

This function obtains the current resources for a specific device. The caller must first acquire a handle for the desired device. The resource data is placed in the buffer pointed contained in the *OutBuffer* structure. Upon completion the *Length* field of *OutBuffer* will indicate the number of bytes copied into the *Pointer* field of the *OutBuffer* buffer. This routine will never return a partial resource structure.

If the function fails an appropriate status will be returned and the value of *OutBuffer* is undefined.



## 8.9.2 AcpiGetPossibleResources

Get the possible resource list associated with an ACPI-related device.

### ACPI\_STATUS

AcpiGetPossibleResources (

ACPI\_HANDLE

ACPI\_BUFFER

Device,  
\*OutBuffer)

### PARAMETERS

Device	A handle to a device object for which the possible resources are to be returned.
OutBuffer	A pointer to a location where the possible resource list is to be returned.

### RETURN VALUE

Status	Exception code that indicates success or reason for failure.
--------	--

### EXCEPTIONS

AE_OK	The resource list was successfully returned.
AE_BAD_PARAMETER	At least one of the following is true:  The <i>Device</i> handle is invalid.  The <i>OutBuffer</i> pointer is NULL.  The <i>Length</i> field of <i>OutBuffer</i> is not <b>ACPI_ALLOCATE_BUFFER</b> , but the <i>Pointer</i> field of <i>OutBuffer</i> is NULL.
AE_BUFFER_OVERFLOW	The <i>Length</i> field of <i>OutBuffer</i> indicates that the buffer is too small to hold the resource table. Upon return, the <i>Length</i> field contains the minimum required buffer length.
AE_TYPE	The <i>Device</i> handle refers to an object that is not of type <b>ACPI_TYPE_DEVICE</b> .

### Functional Description:

This function obtains the list of the possible resources for a specific device. The caller must first acquire a handle for the desired device. The resource data is placed in the buffer contained in the *OutBuffer* structure. Upon completion the *Length* field of *OutBuffer* will indicate the number of bytes copied into the *Pointer* field of the *OutBuffer* buffer. This routine will never return a partial resource structure.

If the function fails an appropriate status will be returned and the value of *OutBuffer* is undefined.





### 8.9.3 AcpiSetCurrentResources

Set the current resource list associated with an ACPI-related device.
---

#### ACPI\_STATUS

AcpiSetCurrentResources (  
    ACPI\_HANDLE                      Device,  
    ACPI\_BUFFER                    \*Buffer)

#### PARAMETERS

Device	A handle to a device object for which the current resource list is to be set.
Buffer	A pointer to an <b>ACPI_BUFFER</b> containing the resources to be set for the device.

#### RETURN VALUE

Status	Exception code that indicates success or reason for failure.
--------	--

#### EXCEPTIONS

AE_OK	The resources were set successfully.
AE_BAD_PARAMETER	At least one of the following is true:  The <i>Device</i> handle is invalid.  The <i>InBuffer</i> pointer is NULL.  The <i>Pointer</i> field of <i>InBuffer</i> is NULL.  The <i>Length</i> field of <i>InBuffer</i> is zero.
AE_TYPE	The Device handle refers to an object that is not of type <b>ACPI_TYPE_DEVICE</b> .

---

#### Functional Description:

This function sets the current resources for a specific device. The caller must first acquire a handle for the desired device. The resource data is passed to the routine the buffer pointed to by the *InBuffer* variable.



## 8.9.4 AcpiGetEventResources

Get the event resource information for an ACPI-related device (via _AEI method)
---

### ACPI\_STATUS

AcpiGetEventResources (

ACPI\_HANDLE

ACPI\_BUFFER

Device,  
\*OutBuffer)

### PARAMETERS

Device	A handle to a device object for which the event resource information is to be returned.
OutBuffer	A pointer to a location where the event resource information is to be returned.

### RETURN VALUE

Status	Exception code that indicates success or reason for failure.
--------	--

### EXCEPTIONS

AE_OK	The system information list was successfully returned.
AE_BAD_PARAMETER	At least one of the following is true:  The Device handle is invalid.  The OutBuffer pointer is NULL.  The <i>Length</i> field of <i>OutBuffer</i> is not <b>ACPI_ALLOCATE_BUFFER</b> , but the <i>Pointer</i> field of <i>OutBuffer</i> is NULL.
AE_BUFFER_OVERFLOW	The Length field of OutBuffer indicates that the buffer is too small to hold the event information. Upon return, the Length field contains the minimum required buffer length.
AE_TYPE	The Device handle refers to an object that is not of type <b>ACPI_TYPE_DEVICE</b> .

### Functional Description:

This function obtains the event resource information for a specific device. It does so by attempting to execute the **\_AEI** method (*ACPI Event Information*) contained in the scope of the device whose handle is passed as a parameter.

From the ACPI Specification: “The **\_AEI** object designates those GPIO interrupts that shall be handled by OSPM as ACPI events. This object appears within the scope of the GPIO controller device whose pins are to be used as GPIO-signaled events.”

If the function fails an appropriate status will be returned and the value of *OutBuffer* is undefined.



## 8.9.5 AcpiGetIRQRoutingTable

Get the ACPI Interrupt Request (IRQ) Routing Table for an ACPI-related device.
--

ACPI\_STATUS

AcpiGetIRQRoutingTable (

ACPI\_HANDLE

ACPI\_BUFFER

Device,

\*OutBuffer)

### PARAMETERS

Device

A handle to a device object for which the IRQ routing table is to be returned.

OutBuffer

A pointer to a location where the IRQ routing table is to be returned.

### RETURN VALUE

Status

Exception code that indicates success or reason for failure.

### EXCEPTIONS

AE\_OK

The system information list was successfully returned.

AE\_BAD\_PARAMETER

At least one of the following is true:

The Device handle is invalid.

The OutBuffer pointer is NULL.

The *Length* field of *OutBuffer* is not **ACPI\_ALLOCATE\_BUFFER**, but the *Pointer* field of *OutBuffer* is NULL.

AE\_BUFFER\_OVERFLOW

The Length field of OutBuffer indicates that the buffer is too small to hold the IRQ table. Upon return, the Length field contains the minimum required buffer length.

AE\_TYPE

The Device handle refers to an object that is not of type **ACPI\_TYPE\_DEVICE**.

### Functional Description:

---

This function obtains the IRQ routing table for a specific bus. It does so by attempting to execute the `_PRT` method contained in the scope of the device whose handle is passed as a parameter.

If the function fails an appropriate status will be returned and the value of *OutBuffer* is undefined.



## 8.9.6 AcpiGetVendorResource

Find a resource of type Vendor-Defined
--

### ACPI\_STATUS

AcpiGetVendorResource (

ACPI\_HANDLE

char

ACPI\_VENDOR\_UUID

ACPI\_BUFFER

Device,

\*Name,

\*Uuid,

\*OutBuffer)

### PARAMETERS

Device	A handle to the parent Device that owns the vendor resource.
Name	Name of the parent resource list ( <b>_CRS</b> or <b>_PRS</b> ).
Uuid	A pointer to the UUID to be matched. The ACPI_VENDOR_UUID structure includes both the subtype and the 16-byte UUID.
OutBuffer	Where the vendor resource is returned.

### RETURN VALUE

Status	Exception code that indicates success or reason for failure.
--------	--

### EXCEPTIONS

AE_OK	The vendor resource was successfully acquired.
AE_BAD_PARAMETER	At least one of the following is true:  The <i>DeviceHandle</i> is invalid.  The <i>Name</i> does not refer to a <b>_CRS</b> or <b>_PRS</b> control method.  The OutBuffer of UUID pointer is NULL.  The <i>Length</i> field of <i>OutBuffer</i> is not <b>ACPI_ALLOCATE_BUFFER</b> , but the <i>Pointer</i> field of <i>OutBuffer</i> is NULL.
AE_NOT_EXIST	The <i>Name</i> could not be found.

### Functional Description:

This function retrieves a resource of type *vendor-defined* that matches the supplied UUID and UUID subtype.



## 8.9.7 AcpiBufferToResource

Convert a raw AML ResourceTemplate to an ACPI_RESOURCE list
---

### ACPI\_STATUS

AcpiBufferToResource (

    UINT8

    \*AmlBuffer,

    UINT16

    AmlBufferLength,

    ACPI\_RESOURCE

    \*\*OutResource)

### PARAMETERS

AmlBuffer	Raw AML resource template to be converted.
-----------	--

AmlBufferLength	Length of the AmlBuffer in bytes.
-----------------	-----------------------------------

OutResource	Where the converted resource is returned.
-------------	---

### RETURN VALUE

Status	Exception code that indicates success or reason for failure.
--------	--

### EXCEPTIONS

AE_OK	The resource was successfully converted.
-------	--

AE_NO_MEMORY	Could not allocate memory for the OutResource buffer.
--------------	---

AE_AML_INVALID_RESOURCE_TYPE	The input buffer is not a valid resource template buffer
------------------------------	--

AE_AML_INVALID_RESOURCE_LENGTH	The input buffer is not a valid resource template buffer
--------------------------------	--

### Functional Description:

---

This utility function converts a raw AML resource template (such as a template buffer returned from a predefined ACPI method ) into an ACPI\_RESOURCE list which is easier to use.

The caller is responsible for the deletion of the \*OutResource buffer (via ACPI\_FREE.)



## 8.9.8 AcpiResourceToAddress64

Convert an address resource descriptor to 64 bits

ACPI\_STATUS

AcpiResourceToAddress64 (  
     ACPI\_RESOURCE                      \*Resource,  
     ACPI\_RESOURCE\_ADDRESS64        \*OutResource)

### PARAMETERS

Resource                      The resource descriptor to be converted. This resource must be one of the following types:

ACPI\_RESOURCE\_TYPE\_ADDRESS16  
 ACPI\_RESOURCE\_TYPE\_ADDRESS32  
 ACPI\_RESOURCE\_TYPE\_ADDRESS64

OutResource                  Where the converted resource is returned.

### RETURN VALUE

Status                      Exception code that indicates success or reason for failure.

### EXCEPTIONS

AE\_OK                      The resource was successfully converted.

AE\_BAD\_PARAMETER          The resource is not of the correct type.

### Functional Description:

This utility function converts resources of type **ADDRESS16** and **ADDRESS32** to **ADDRESS64**. This saves the caller from having to duplicate code for different-sized address descriptors. If the input descriptor is of type **ADDRESS64**, a simple copy is performed.

## 8.9.9 AcpiWalkResourceBuffer

Walk a list of ACPI Resources (Resource Template)

ACPI\_STATUS

AcpiWalkResourceBuffer (  
     ACPI\_BUFFER                      \*Buffer,  
     ACPI\_WALK\_RESOURCE\_CALLBACK    UserFunction,  
     void                              \*UserContext)

### PARAMETERS

Buffer                      A pointer to an ACPI\_BUFFER object containing an ACPI Resource Template as returned by one of the following interfaces:



*AcpiGetCurrentResources*  
*AcpiGetPossibleResources*  
*AcpiGetEventResources*  
*AcpiGetVendorResource*  
*AcpiBufferToResource*

UserFunction	A pointer to a user-written function that is invoked for each resource object within the resource list. (See the interface specification for the user function below.)
UserContext	A value that will be passed as a parameter to the user function each time it is invoked.

#### RETURN VALUE

Status	Exception code that indicates success or reason for failure.
--------	--

#### EXCEPTIONS

AE_OK	The walk was successfully completed.
AE_BAD_PARAMETER	At least one of the following is true:  The <i>Buffer</i> is invalid.  The <i>UserFunction</i> pointer is invalid.
AE_NO_MEMORY	Insufficient dynamic memory to complete the operation.

#### Functional Description:

This function walks a resource list contained in the input buffer. The User Function is called once for each resource in the list – freeing the caller from having to parse the list itself.

### 8.9.9.1 Interface to User Callback Function

**Interface to the user function that is invoked from either *AcpiWalkResourceBuffer* or *AcpiWalkResources*.**

```
ACPI_STATUS (*ACPI_WALK_RESOURCE_CALLBACK) (  
    ACPI_RESOURCE             *Resource,  
    void                      *Context)
```

#### PARAMETERS

Resource	A pointer to a single resource within the resource list.
Context	The UserContext value that was passed as a parameter to the <i>AcpiWalkResourceBuffer</i> or <i>AcpiWalkResources</i> function.

#### RETURN VALUE

Status	AE_OK	Continue the walk.
--------	-------	--------------------



AE_TERMINATE	Stop the walk immediately.
AE_DEPTH	Go no deeper into the namespace tree.
All others	Abort the walk with this exception code.

#### Functional Description:

This function is called from either *AcpiWalkResourceBuffer* or *AcpiWalkResource* for each resource object in the resource list.

## 8.9.10 AcpiWalkResources

### Create and walk a list of ACPI Resources (Resource Template)

#### ACPI\_STATUS

*AcpiWalkResources* (

ACPI\_HANDLE

char

ACPI\_WALK\_RESOURCE\_CALLBACK

void

Device,

\*Name,

UserFunction,

\*UserContext)

#### PARAMETERS

Device	A handle to the Device for which one of the resource lists will be walked:
Name	A string containing the name of a resource method (either a <b>_CRS</b> , <b>_PRS</b> , or <b>_AEI</b> method) to be invoked.
UserFunction	A pointer to a user-written function that is invoked for each resource object within the resource list. (See the interface specification for the user function for the <i>AcpiWalkResourceBuffer</i> above.)
UserContext	A value that will be passed as a parameter to the user function each time it is invoked.

#### RETURN VALUE

Status	Exception code that indicates success or reason for failure.
--------	--

#### EXCEPTIONS

AE_OK	The walk was successfully completed.
AE_BAD_PARAMETER	At least one of the following is true:  The <i>Device</i> is not a valid handle.  The <i>UserFunction</i> pointer is invalid.





The *Name* string does not refer to a **\_CRS**, **\_PRS**, or **\_AEI** control method.

**AE\_NO\_MEMORY**

Insufficient dynamic memory to complete the operation.

---

**Functional Description:**

This function retrieves the current or possible resource list for the specified device by executing either the **\_CRS**, **\_PRS**, or **\_AEI** method for the device. The User Function is called once for each resource in the list – freeing the caller from having to parse the list itself. See the description of *AcpiWalkResourceBuffer* for the definition of the user function interface.

## 8.10 Memory Management

The ACPICA Subsystem provides memory management services that are built upon the memory management services exported by the OS services layer. If enabled (in debug mode), the local ACPICA memory manager tracks and logs each allocation to detect the following conditions:

- 1) Detect attempts to release (free) an allocated memory block more than once.
- 2) Detect memory leaks by keeping a list of all outstanding allocated memory blocks. This list can be examined at any time; however, the best time to find memory leaks is after the subsystem is shutdown -- any remaining allocations represent leaked blocks.

Do not mix memory manager calls. In other words, if the ACPICA memory manager is used to allocate memory, do not free memory via the OS Services Layer (*AcpiOsFree*), via the C library (*free*), or directly call the host OS memory management primitives. The automatic buffer allocation mechanism that is used with **ACPI\_BUFFER** and **ACPI\_ALLOCATE\_BUFFER** bypasses the local memory manager, thus *AcpiOsFree* should be used to free the allocated buffer.

To summarize:

- If **ACPI\_ALLOCATE** is used to allocate memory, **ACPI\_FREE** should be used to free the memory.
- For the various ACPICA external interfaces that return data in a buffer, if **ACPI\_ALLOCATE\_BUFFER** is used to request ACPICA to allocate memory on behalf of the caller, *AcpiOsFree* should be used to free the buffer.

### 8.10.1 ACPI\_ALLOCATE

<b>Allocate memory from the dynamic memory pool.</b>
--

```
void *  
ACPI_ALLOCATE (          Size)  
    ACPI_SIZE
```

**PARAMETERS**

Size	Amount of memory to allocate.
------	-------------------------------

**RETURN VALUE**

Memory	A pointer to the allocated memory. A NULL pointer is returned on error.
--------	---

**Functional Description:**

This function dynamically allocates memory. The returned memory cannot be assumed to be initialized to any particular value or values.

## 8.10.2 ACPI\_ALLOCATE\_ZEROED

<b>Allocate and initialize memory.</b>
--

```
void *
ACPI_ALLOCATE_ZEROED (
    ACPI_SIZE          Size)
```

**PARAMETERS**

Size	Amount of memory to allocate.
------	-------------------------------

**RETURN VALUE**

Memory	A pointer to the allocated memory. A NULL pointer is returned on error.
--------	---

**Functional Description:**

This function dynamically allocates and initializes memory. The returned memory is guaranteed to be initialized to all zeros.

## 8.10.3 ACPI\_FREE

<b>Free previously allocated memory.</b>
--

```
void
ACPI_FREE (
    void          *Memory)
```

**PARAMETERS**

Memory	A pointer to the memory to be freed.
--------	--------------------------------------

**RETURN VALUE**

None	
------	--

**Functional Description:**

---

This function frees memory that was previously allocated via *ACPI\_ALLOCATE* or *ACPI\_ALLOCATE\_ZEROED*.

## 8.11 Formatted Output

### 8.11.1 AcpiInfo and ACPI\_INFO

<b>Print a formatted information/comment string.</b>
--

```
void
AcpiInfo (
    const char          *ModuleName,
    UINT32              LineNumber,
    const char          *Format,
    ...)

```

**PARAMETERS**

ModuleName	The name of the currently executing module or filename.
LineNumber	The current line number within the currently executing module.
Format	A standard printf-style format string.

**RETURN VALUE**

None

**EXCEPTIONS**

None

**Functional Description:**

---

This function prints a formatted error message using the *AcpiOsPrintf* and *AcpiOsVprintf* OSL interfaces. The format of the output string is as follows:

ACPI: (ModuleName-LineNumber): <message> [ACPICA version number]

**The ACPI\_INFO macro**

The front-end to this function is the *ACPI\_INFO* macro.

**Example:** The following invocation of the *ACPI\_INFO* macro:

```
ACPI_INFO ((AE_INFO, "ACPICA example info message"));
```

Produces this output:



#### ACPI: ACPICA example info message

The AE\_INFO macro is required and automatically injects the module name and line number into the invocation of *AcpiInfo*. Note the use of double parentheses which are required in order to pass the parameters to the printf OSL functions.

## 8.11.2 AcpiWarning and ACPI\_WARNING

Print a formatted warning string.

```
void
AcpiWarning (
    const char          *ModuleName,
    UINT32              LineNumber,
    const char          *Format,
    ...)
```

### PARAMETERS

ModuleName	The name of the currently executing module or filename.
LineNumber	The current line number within the currently executing module.
Format	A standard printf-style format string.

### RETURN VALUE

None

### EXCEPTIONS

None

### Functional Description:

This function prints a formatted error message using the *AcpiOsPrintf* and *AcpiOsVprintf* OSL interfaces. The format of the output string is as follows:

ACPI Warning (ModuleName-LineNumber): <message> [ACPICA version number]

### The ACPI\_WARNING macro

The front-end to this function is the ACPI\_WARNING macro.

**Example:** The following invocation of the ACPI\_WARNING macro:

```
ACPI_WARNING ((AE_INFO, "ACPICA example warning message"));
```

Produces this output:

```
ACPI Warning: ACPICA example warn message [20080926]
```



The `AE_INFO` macro is required and automatically injects the module name and line number into the invocation of *AcpiWarning*. Note the use of double parentheses which are required in order to pass the parameters to the `printf` OSL functions.

### 8.11.3 AcpiError and ACPI\_ERROR

Print a formatted error string.

```
void
AcpiError (
    const char          *ModuleName,
    UINT32              LineNumber,
    const char          *Format,
    ...)

```

#### PARAMETERS

ModuleName	The name of the currently executing module or filename.
LineNumber	The current line number within the currently executing module.
Format	A standard printf-style format string.

#### RETURN VALUE

None

#### EXCEPTIONS

None

#### Functional Description:

This function prints a formatted error message using the *AcpiOsPrintf* and *AcpiOsVprintf* OSL interfaces. The format of the output string is as follows:

ACPI Error (ModuleName-LineNumber): <message> [ACPICA version number]

#### The ACPI\_ERROR macro

The front-end to this function is the `ACPI_ERROR` macro.

**Example:** The following invocation of the `ACPI_ERROR` macro:

```
ACPI_ERROR ((AE_INFO, "ACPICA example error message"));
```

Produces this output:

```
ACPI Error: ACPICA example error message [20080926]
```



The `AE_INFO` macro is required and automatically injects the module name and line number into the invocation of *AcpiError*. Note the use of double parentheses which are required in order to pass the parameters to the `printf` OSL functions.

## 8.11.4 AcpiException and ACPI\_EXCEPTION

**Print a formatted error string with decoded ACPICA exception code**

```
void
AcpiException (
    const char          *ModuleName,
    UINT32              LineNumber,
    ACPI_STATUS          Status,
    const char          *Format,
    ...)

```

### PARAMETERS

ModuleName	The name of the currently executing module or filename.
LineNumber	The current line number within the currently executing module.
Status	ACPICA status to be decoded and displayed.
Format	A standard printf-style format string.

### RETURN VALUE

None

### EXCEPTIONS

None

### Functional Description:

This function prints a formatted error message using the *AcpiOsPrintf* and *AcpiOsVprintf* OSL interfaces. The format of the output string is as follows:

ACPI Exception (ModuleName-LineNumber): <message> [ACPICA version number]

### The ACPI\_EXCEPTION macro

The front-end to this function is the `ACPI_EXCEPTION` macro.

**Example:** The following invocation of the `ACPI_EXCEPTION` macro:

```
ACPI_EXCEPTION ((AE_INFO, Status, "ACPICA example error message"));

```

Produces this output:

```
ACPI Exception: AE_ERROR, ACPICA status [20080926]

```



The `AE_INFO` macro is required and automatically injects the module name and line number into the invocation of *AcpiException*. Note the use of double parentheses which are required in order to pass the parameters to the `printf` OSL functions.

### 8.11.5 AcpiBiosWarning and ACPI\_BIOS\_WARNING

Print a formatted warning string for BIOS/firmware issues.

```
void
AcpiBiosWarning (
    const char          *ModuleName,
    UINT32              LineNumber,
    const char          *Format,
    ...)
```

#### PARAMETERS

ModuleName	The name of the currently executing module or filename.
LineNumber	The current line number within the currently executing module.
Format	A standard printf-style format string.

#### RETURN VALUE

None

#### EXCEPTIONS

None

#### Functional Description:

This function prints a formatted error message using the *AcpiOsPrintf* and *AcpiOsVprintf* OSL interfaces. It is intended to be used when the host detects a problem that is specific to the platform BIOS/firmware. The format of the output string is as follows:

ACPI Firmware Warning (ModuleName-LineNumber): <message> [ACPICA version number]

#### The ACPI\_BIOS\_WARNING macro

The front-end to this function is the `ACPI_BIOS_WARNING` macro.

**Example:** The following invocation of the `ACPI_BIOS_WARNING` macro:

```
ACPI_BIOS_WARNING ((AE_INFO, "ACPICA example warning message"));
```

Produces this output:

```
ACPI BIOS Bug: Warning: ACPICA example warn message [20080926]
```



The `AE_INFO` macro is required and automatically injects the module name and line number into the invocation of *AcpiBiosWarning*. Note the use of double parentheses which are required in order to pass the parameters to the `printf` OSL functions.

## 8.11.6 AcpiBiosError and ACPI\_BIOS\_ERROR

**Print a formatted error string for BIOS/firmware issues.**

```
void
AcpiBiosError (
    const char          *ModuleName,
    UINT32              LineNumber,
    const char          *Format,
    ...)
```

### PARAMETERS

ModuleName	The name of the currently executing module or filename.
LineNumber	The current line number within the currently executing module.
Format	A standard printf-style format string.

### RETURN VALUE

None

### EXCEPTIONS

None

### Functional Description:

This function prints a formatted error message using the *AcpiOsPrintf* and *AcpiOsVprintf* OSL interfaces. It is intended to be used when the host detects a problem that is specific to the platform BIOS/firmware. The format of the output string is as follows:

ACPI Firmware Error (ModuleName-LineNumber): <message> [ACPICA version number]

### The ACPI\_BIOS\_ERROR macro

The front-end to this function is the `ACPI_BIOS_ERROR` macro.

**Example:** The following invocation of the `ACPI_BIOS_ERROR` macro:

```
ACPI_BIOS_ERROR ((AE_INFO, "ACPICA example error message"));
```

Produces this output:

```
ACPI BIOS Bug: Error: ACPICA example error message [20080926]
```





The `AE_INFO` macro is required and automatically injects the module name and line number into the invocation of `AcpiBiosError`. Note the use of double parentheses which are required in order to pass the parameters to the `printf` OSL functions.

## 8.11.7 AcpiDebugPrint and ACPI\_DEBUG\_PRINT

Print a formatted debug string.

```
void
AcpiDebugPrint (
    UINT32                RequestedDebugLevel,
    UINT32                LineNumber,
    const char             *FunctionName,
    const char             *ModuleName,
    UINT32                ComponentId,
    const char             *Format,
    ...)
```

### PARAMETERS

RequestedDebugLevel

The debug level for this statement. This value is compared to the current `AcpiDbgLevel` mask to determine if this message will be output or not. Must be one of the following:

`ACPI_DB_INIT`  
`ACPI_DB_DEBUG_OBJECT`  
`ACPI_DB_INFO`  
`ACPI_DB_ALL_EXCEPTIONS`  
`ACPI_DB_INIT_NAMES`  
`ACPI_DB_PARSE`  
`ACPI_DB_LOAD`  
`ACPI_DB_DISPATCH`  
`ACPI_DB_EXEC`  
`ACPI_DB_NAMES`  
`ACPI_DB_OPREGION`  
`ACPI_DB_BFIELD`  
`ACPI_DB_TABLES`  
`ACPI_DB_VALUES`  
`ACPI_DB_OBJECTS`  
`ACPI_DB_RESOURCES`  
`ACPI_DB_USER_REQUESTS`  
`ACPI_DB_PACKAGE`  
`ACPI_DB_ALLOCATIONS`  
`ACPI_DB_FUNCTIONS`  
`ACPI_DB_OPTIMIZATIONS`  
`ACPI_DB_MUTEX`  
`ACPI_DB_THREADS`  
`ACPI_DB_IO`  
`ACPI_DB_INTERRUPTS`  
`ACPI_DB_EVENTS`  
`ACPI_DB_ALL`



LineNumber	The current line number within the currently executing module.
FunctionName	The name of the currently executing function.
ModuleName	The name of the currently executing module or filename.
ComponentId	The ID of the executing component. Currently defined IDs are:

**ACPI\_UTILITIES**  
**ACPI\_HARDWARE**  
**ACPI\_EVENTS**  
**ACPI\_TABLES**  
**ACPI\_NAMESPACE**  
**ACPI\_PARSER**  
**ACPI\_DISPATCHER**  
**ACPI\_EXECUTER**  
**ACPI\_RESOURCES**  
**ACPI\_CA\_DEBUGGER**  
**ACPI\_OS\_SERVICES**  
**ACPI\_CA\_DISASSEMBLER**  
**ACPI\_COMPILER**  
**ACPI\_TOOLS**  
**ACPI\_EXAMPLE**  
**ACPI\_DRIVER**

Format	A standard printf-style format string.
--------	--

## RETURN VALUE

None

## EXCEPTIONS

None

## Functional Description:

---

This function prints debug messages only if the debug level and the component ID match in the global level/layer masks. This mechanism is useful to pare down the amount of debug output that is produced. In addition to the input string, the module name, the line number, and the function name are added to the output.

## The ACPI\_DEBUG\_PRINT macro

The front end to the AcpiDebugPrint interface

**Example:** The following invocation of the ACPI\_DEBUG\_PRINT macro

```
ACPI_DEBUG_PRINT ((ACPI_DB_INFO, "Example Debug output"));
```

Produces this output:

```
examples-0200 [00] Examples-main          : Example Debug output
```



## 8.11.8 AcpiDebugPrintRaw and ACPI\_DEBUG\_PRINT\_RAW

Print a formatted debug string, with no extra data.

```
void
AcpiDebugPrintRaw (
    UINT32                RequestedDebugLevel,
    UINT32                LineNumber,
    const char             *FunctionName,
    const char             *ModuleName,
    UINT32                ComponentId,
    const char             *Format,
    ...)
```

### PARAMETERS

See the definition of *AcpiDebugPrint*

### Functional Description:

This function prints debug messages only if the debug level and the component ID match in the global level/layer masks. This mechanism is useful to pare down the amount of debug output that is produced. The message produced by this function is not embellished with the line number, function name, and module name as is performed by ACPI\_DEBUG\_PRINT.

### The ACPI\_DEBUG\_PRINT\_RAW macro

The front end to the AcpiDebugPrintRaw interface.

**Example:** The following invocation of the ACPI\_DEBUG\_PRINT\_RAW macro

```
ACPI_DEBUG_PRINT_RAW ((ACPI_DB_INFO, "Example Debug output"));
```

Produces this output:

```
Example Debug output
```

## 8.12 Miscellaneous Utilities

### 8.12.1 AcpiCheckAddressRange

Check a Memory or I/O address range for conflict(s) with ACPI Operation Regions.

```
UINT32
AcpiCheckAddressRange (
    ACPI_ADR_SPACE_TYPE    SpaceId,
    ACPI_PHYSICAL_ADDRESS  Address,
    ACPI_SIZE               Length,
    BOOLEAN                EmitWarning)
```

**PARAMETERS**

SpaceId	The ACPI address space to be checked. Must be one of the following constants (Note: for values other than the two below, the request is simply ignored and zero is returned.)
---------	---

**ACPI\_ADR\_SPACE\_SYSTEM\_MEMORY****ACPI\_ADR\_SPACE\_SYSTEM\_IO**

Address	The physical address of the address range to be checked.
Length	Length of the address range to be checked.
EmitWarning	If TRUE, emit a warning string for each of the conflicts discovered. Otherwise, remain quiet and simply return the number of detected conflicts.

**RETURN VALUE**

ConflictCount	Count of the total number of conflicts detected in the SpaceId:Address:Length range. Zero is returned if no conflicts were detected or the SpaceId is not Memory or I/O.
---------------	--

**EXCEPTIONS**

None	
------	--

**Functional Description:**


---

This function checks all defined ACPI Operation Regions (in the ACPI namespace) for a conflict with the input address range. It is useful for detecting possible address conflicts between host device drivers and the ACPI namespace. An “address conflict” is defined by any overlap (partial or complete) between the input address range and an ACPI Operation Region of the same SpaceId.

## 8.12.2 **AcpiDebugTrace**

**Enable debug tracing of control method execution**
**ACPI\_STATUS****AcpiDebugTrace (**

char	*Name,
UINT32	DebugLevel,
UINT32	DebugLayer,
UINT32	Flags)

**PARAMETERS**

Name	Name of the control method to be traced. Currently, only a 4-character ACPI name is supported.
DebugLevel	The debug level used for the trace.



DebugLayer                      The debug layer used for the trace.

Flags                            Sets the type of trace:

- 1 – One shot trace
- 0 – Persistent trace

#### RETURN VALUE

Status                           Exception code that indicates success or reason for failure.

#### EXCEPTIONS

AE\_OK                           The system information list was successfully returned.

#### Functional Description:

---

This function enables debug tracing of an individual control method.

### 8.12.3 AcpiDecodePldBuffer

Decode a bit-packed buffer returned from the `_PLD` reserved name/method.

#### ACPI\_STATUS

AcpiCheckAddressRange (  
    UINT8                      \*Buffer,  
    ACPI\_SIZE                Length,  
    ACPI\_PLD\_INFO           \*\*ReturnBuffer)

#### PARAMETERS

Buffer                        A bit-packed data buffer as returned from the `_PLD` method (Physical Location of Device.)

Length                        Length of the input buffer.

ReturnBuffer                 Where the decoded buffer is returned. The caller is responsible for deallocating this buffer via the **ACPI\_FREE** macro.

#### RETURN VALUE

Status                           Exception code that indicates success or reason for failure.

#### EXCEPTIONS

AE\_OK                           The buffer was successfully decoded.

AE\_BAD\_PARAMETER            At least one of the following is true:

- The *Buffer* pointer is invalid.
- The *ReturnBuffer* pointer is invalid.



The *Length* is less than 16.

AE\_NO\_MEMORY

A return buffer could not be allocated.

---

#### Functional Description:

This function decodes the bit-packed buffer that is returned by the `_PLD` reserved method (Physical Location of Device) to a local buffer/struct that is easily accessed and thus much more useful to a host ACPI driver. The returned structure contains no fields smaller than a `UINT8`.

The definition of the **ACPI\_PLD\_INFO** struct appears in the `acbuffer.h` ACPICA header.

Note, the caller is responsible for deallocating the returned buffer via the **ACPI\_FREE** macro.

## 8.12.4 AcpiFormatException

**Return the ASCII name of an ACPI exception code.**

```
const char *
AcpiFormatException (
    ACPI_STATUS          Status)
```

#### PARAMETERS

Status	The ACPI status/exception code to be translated.
--------	--

#### RETURN VALUE

Exception String	A pointer to the formatted exception string.
------------------	--

#### EXCEPTIONS

None

---

#### Functional Description:

This function converts an ACPI exception code into a human-readable string. It returns the exception name string as the function return value. The string is a const value that does not require deletion by the caller.

## 8.12.5 AcpiGetStatistics

**Returns miscellaneous run-time statistics.**

```
ACPI_STATUS
AcpiGetStatistics (
    ACPI_STATISTICS    *OutStats)
```

## PARAMETERS

OutStats	Where the statistics are returned.
----------	------------------------------------

## RETURN

Status	Exception code indicates success or reason for failure.
--------	---

## EXCEPTIONS

AE\_OK Statistics were successfully returned.

### Functional Description:

This function returns execution statistics of the subsystem. Included are the number of GPEs, SCIs, and Fixed Events. Also, the number of control methods executed.

The returned **ACPI\_STATISTICS** structure is shown below:

```
typedef struct acpi_statistics
{
    UINT32    SciCount;
    UINT32    GpeCount;
    UINT32    FixedEventCount[ACPI_NUM_FIXED_EVENTS];
    UINT32    MethodCount;
} ACPI_STATISTICS;
```

### 8.12.6 AcpiGetSystemInfo

**Get global ACPI-related system information.**

```
ACPI_STATUS
AcpiGetSystemInfo (
    ACPI_BUFFER *OutBuffer)
```

## PARAMETERS

OutBuffer	A pointer to a location where the system information is to be returned.
-----------	---

## RETURN VALUE

Status	Exception code that indicates success or reason for failure.
--------	--

## EXCEPTIONS

AE_OK	The system information list was successfully returned.
-------	--

**AE BAD PARAMETER**                      At least one of the following is true:



The *OutBuffer* pointer is NULL.

The *Length* field of *OutBuffer* is not **ACPI\_ALLOCATE\_BUFFER**, but the *Pointer* field of *OutBuffer* is NULL.

AE\_BUFFER\_OVERFLOW

The *Length* field of *OutBuffer* indicates that the buffer is too small to hold the system information. Upon return, the *Length* field contains the minimum required buffer length.

### Functional Description:

---

This function obtains information about the current state of the ACPI system. It will return system information in the *OutBuffer* structure. Upon completion the *Length* field of *OutBuffer* will indicate the number of bytes copied into the *Pointer* field of the *OutBuffer* buffer. This routine will never return a partial resource structure.

If the function fails an appropriate status will be returned and the value of *OutBuffer* is undefined.

The structure that is returned in *OutBuffer* is defined as follows:

```
typedef struct _AcpiSysInfo
{
    UINT32                AcpiCaVersion;
    UINT32                Flags;
    UINT32                TimerResolution;
    UINT32                Reserved1;
    UINT32                Reserved2;
    UINT32                DebugLevel;
    UINT32                DebugLayer;
} ACPI_SYSTEM_INFO;
```

### Where:

AcpiCaVersion	Version number of the ACPICA Subsystem, in the form 0xYYYYMMDD.
Flags	Static information about the system: <b>ACPI_SYS_MODE_ACPI</b> ACPI mode is supported on this system. <b>ACPI_SYS_MODE_LEGACY</b> Legacy mode is supported.
TimerResolution	Resolution of the ACPI Power Management Timer. Either 24 or 32 indicating the corresponding number of bits of resolution.
DebugLevel	Current value of the global variable that controls the debug output verbosity.
DebugLayer	Current value of the global variable that controls the internal layers whose debug output is enabled.



### 8.12.7 AcpiPurgeCachedObjects

**Empty all internal object caches.**

**ACPI\_STATUS  
AcpiPurgeCachedObjects (  
void)**

## PARAMETERS

None

## RETURN

Status	Exception code indicates success or reason for failure.
--------	---

## EXCEPTIONS

```
AE_OK           The caches were successfully purged.
```

### Functional Description:

This function purges all internal object caches, freeing all memory blocks: It can be used to purge the cache after particularly large operations, or the cache can be periodically flushed to ensure that no large amounts of stagnant cache objects are present. It is implemented by calling *AcpiOsPurgeCache* for each of the object caches.

## 8.13 Global Variables

There are several global variables that are useful for ACPICA users.

### 8.13.1 AcpiDbgLevel & AcpiDbgLayer

These globals control the debug output mechanism. *AcpiDbgLevel* specifies the current debug level and *AcpiDbgLayer* specifies which ACPICA components will output debug information.

See the description of **ACPI\_DEBUG\_PRINT** for more information.

### 8.13.2 AcpiGbl\_FADT

This is a local copy of the system FADT, converted to a common internal format. ACPI-related device drivers often require information directly from the FADT. The table can be directly accessed via this symbol.

### 8.13.3 AcpiCurrentGpeCount

The current number of active (available) system GPEs. This includes the GPE blocks defined in the FADT, as well as any installed GPE block devices. This is a dynamic value that can increase or



decrease as GPE block devices are installed or removed. This value also serves as the maximum index value for the *AcpiGetGpeDevice* interface.

#### 8.13.4 **AcpiGbl\_SystemAwakeAndRunning**

This boolean is set to FALSE just before the system sleeps. It is then set to TRUE as the system wakes.

## 9 OS Services Layer - External Interface Definition

This section contains the definitions of the interfaces that must be exported by the OS Services Layer. The ACPICA Subsystem requires that all of these interfaces be present. All interfaces to the OS Services Layer *that are intended for use by the ACPICA Subsystem* are prefixed by the letters “**AcpiOs**”.

Only the external definitions of the **AcpiOs\*** interfaces are clearly defined by this document. The actual implementation of the services and interfaces is by definition OS dependent and may be very different for different operating systems.

## 9.1 Environmental and ACPI Tables

### 9.1.1 AcpiOsInitialize

**Initialize the OSL subsystem.**

**ACPI\_STATUS  
AcpiOsInitialize (  
void)**

## PARAMETERS

None

## RETURN VALUE

Status	Initialization status.
--------	------------------------

### Functional Description:

This function allows the OSL to initialize itself. It is called during initialization of the ACPICA subsystem.

**Terminate the OSL subsystem.**

### Obtain the Root ACPI table pointer (RSDP).



## 9.1.4 AcpiOsPredefinedOverride

**Allow the host OS to override a predefined ACPI object.**

ACPI\_STATUS  
AcpiOsPredefinedOverride (  
    const ACPI\_PREDEFINED\_NAMES \*PredefinedObject,  
    ACPI\_STRING \*NewValue)

### PARAMETERS

PredefinedObject	A pointer to a predefined object (name and initial value.)
NewValue	Where a new value for the predefined object is returned. NULL if there is no override for this object.

### RETURN VALUE

Status	Exception code that indicates success or reason for failure.
--------	--

### Functional Description:

This function allows the host to override the predefined objects in the ACPI namespace.

## 9.1.5 AcpiOsTableOverride

**Allow the host OS to override a firmware ACPI table via a logical address.**

ACPI\_STATUS  
AcpiOsTableOverride (  
    ACPI\_TABLE\_HEADER \*ExistingTable,  
    ACPI\_TABLE\_HEADER \*\*NewTable)

### PARAMETERS

ExistingTable	A pointer to the header of the existing ACPI table.
NewTable	Where the pointer to the replacement table is returned. The OSL returns NULL if no replacement is provided.

### RETURN VALUE

Status	Exception code that indicates success or reason for failure.
--------	--

### Functional Description:

This function allows the host to override an ACPI table that was found in the firmware via a logical address (pointer). The host OS can examine the existing table header for the table signature and version number(s) and decide to replace it if desired. Note: for the existing table, only the table header is guaranteed to be valid and accessible, not the entire table. Further, the header is only



guaranteed to be valid and accessible for the duration of the execution of this function. It may be unmapped immediately afterwards. Also see *AcpiOsPhysicalTableOverride*.

The full identification of an ACPI table includes the following header items:

- The 4-character ACPI signature
- The Revision
- The table Length
- The OEM ID string
- The OEM Table ID string
- The OEM Revision

#### ACPI Table Header Definition

```
typedef struct /* ACPI common table header */
{
    char        Signature [4];        /* Identifies type of table */
    UINT32      Length;               /* Length of table, in bytes, */
                                        /* including header */
    UINT8       Revision;             /* Specification minor version # */
    UINT8       Checksum;             /* To make sum of entire table = 0 */
    char        OemId [6];            /* OEM identification */
    char        OemTableId [8];       /* OEM table identification */
    UINT32      OemRevision;          /* OEM revision number */
    char        AslCompilerId [4];    /* ASL compiler vendor ID */
    UINT32      AslCompilerRevision; /* ASL compiler revision number */
} ACPI_TABLE_HEADER;
```

During initialization, ACPICA will invoke this interface once for each table defined in the RSDT/XSDT, and once for the DSDT (pointed to by the FADT). This includes all tables in the RSDT/XSDT, even tables that are not directly consumed by ACPICA such as ECDT, MADT, SRAT, SLIT, etc., and all of the OEMx tables.

Tables are installed and *AcpiOsTableOverride* is called in the order that they appear in the RSDT/XSDT. This may be important for tables that can have multiple instantiations such as the SSDT or UEFI tables. If the host wishes to replace an individual SSDT, it can keep track of the SSDT instantiations, or it can differentiate SSDTs based upon the full ACPI table identification described above.

ACPICA will also call this interface for each table that is dynamically loaded via the **Load** AML operator. Tables that are loaded via this mechanism are typically SSDTs and OEMx tables.

The **LoadTable** AML operator is used to load the namespace from tables that appear in the RSDT/XSDT with signatures other than SSDT, typically the OEMx tables that contain executable AML code. These tables can be replaced during the initialization phase when ACPICA traverses the RSDT/XSDT as above. *AcpiOsTableOverride* is therefore not invoked when a **LoadTable** is executed.



## 9.1.6 AcpiOsPhysicalTableOverride

Allow the host OS to override a firmware ACPI table via a physical address.

### ACPI\_STATUS

AcpiOsPhysicalTableOverride (  
    ACPI\_TABLE\_HEADER      \*ExistingTable,  
    ACPI\_PHYSICAL\_ADDRESS   \*NewAddress,  
    UINT32                   \*NewTableLength)

### PARAMETERS

ExistingTable	A pointer to the header of the existing ACPI table.
NewAddress	Where the physical address of the replacement table is returned. The OSL returns NULL if no replacement is provided.
NewLength	Where the length of the replacement table is returned.

### RETURN VALUE

Status	Exception code that indicates success or reason for failure.
--------	--

### Functional Description:

---

This function allows the host to override an ACPI table that was found in the firmware with a new table via a physical address and length. The host OS can examine the existing table header for the table signature and version number(s) and decide to replace it if desired. Note: for the existing table, only the table header is guaranteed to be valid and accessible, not the entire table. Further, the header is only guaranteed to be valid and accessible for the duration of the execution of this function. It may be unmapped immediately afterwards. When this function exits, ACPICA will create a mapping for the new table and manage it for the life of the table. Also see *AcpiOsTableOverride*.



## 9.2 Memory Management

These interfaces provide an OS-independent memory management interface.

### 9.2.1 AcpiOsCreateCache

#### Create a memory cache object

##### ACPI\_STATUS

##### AcpiOsCreateCache (

char	*CacheName,
UINT16	ObjectSize,
UINT16	MaxDepth,
ACPI_CACHE_T	**ReturnCache)

##### PARAMETERS

CacheName	An ASCII identifier for the cache. May or may not be used by the host.
ObjectSize	The size of each object in the cache.
MaxDepth	Maximum depth of the cache (max number of objects.) May or may not be used by the host.
ReturnCache	Where a pointer to the cache object is returned.

##### RETURN VALUE

Status	Exception code that indicates success or reason for failure.
--------	--

##### EXCEPTIONS

AE_OK	The cache was successfully created.
AE_BAD_PARAMETER	At least one of the following is true:  The ReturnCache pointer is NULL.  The ObjectSize is less than 16.
AE_NO_MEMORY	Insufficient dynamic memory to complete the operation.

##### Functional Description:

This function creates a cache object. Many host operating systems have a cache manager that can be used to implement the cache functions. The ACPI code uses many dynamic objects of the same size (such as the ACPI\_OPERAND\_OBJECT), and the use of a cache can improve performance considerably.





## 9.2.2 AcpiOsDeleteCache

Delete a memory cache object.

ACPI\_STATUS  
AcpiOsDeleteCache (  
    ACPI\_CACHE\_T                   \*Cache)

### PARAMETERS

Cache	The cache object to be deleted.
-------	---------------------------------

### RETURN VALUE

Status	Exception code that indicates success or reason for failure.
--------	--

### EXCEPTIONS

AE_OK	The cache was successfully created.
AE_BAD_PARAMETER	The <i>Cache</i> pointer is NULL.

### Functional Description:

This function deletes a cache object that was created via *AcpiOsCreateCache*. Any objects currently within the cache must also be deleted.

## 9.2.3 AcpiOsPurgeCache

Free all objects currently within a cache object.

ACPI\_STATUS  
AcpiOsPurgeCache (  
    ACPI\_CACHE\_T                   \*Cache)

### PARAMETERS

Cache	The cache object to be deleted.
-------	---------------------------------

### RETURN VALUE

Status	Exception code that indicates success or reason for failure.
--------	--

### EXCEPTIONS

AE_OK	The cache was successfully created.
AE_BAD_PARAMETER	The <i>Cache</i> pointer is NULL.




---

**Functional Description:**

This function deletes all objects that currently reside within a cache.

## 9.2.4 AcpiOsAcquireObject

<b>Acquire an object from a cache.</b>
--

```
void *
AcpiOsAcquireObject (
    ACPI_CACHE_T          *Cache)
```

**PARAMETERS**

Cache	The cache object from which to acquire an object.
-------	---

**RETURN VALUE**

Object	A pointer to a cache object. NULL if the object could not be acquired.
--------	--

**EXCEPTIONS**

NULL is returned if an object could not be acquired.

---

**Functional Description:**

This function acquires an object from the specified cache.

## 9.2.5 AcpiOsReleaseObject

<b>Release an object to a cache.</b>
--------------------------------------

```
ACPI_STATUS
AcpiOsReleaseObject (
    ACPI_CACHE_T          *Cache,
    void                  *Object)
```

**PARAMETERS**

Cache	The cache object to which the object will be released.
Object	The object to be released.

**RETURN VALUE**

Status	Exception code that indicates success or reason for failure.
--------	--

**EXCEPTIONS**

AE_OK	The cache was successfully created.
AE_BAD_PARAMETER	The Cache or Object pointer is NULL.

**Functional Description:**

---

This function releases an object back to the specified cache. It must have been previously acquired from the same cache via *AcpiOsAcquireObject*.

## 9.2.6 AcpiOsMapMemory

<b>Map physical memory into the caller's address space.</b>
---

```
void *  
AcpiOsMapMemory (  
    ACPI_PHYSICAL_ADDRESS  PhysicalAddress,  
    ACPI_SIZE               Length)
```

**PARAMETERS**

PhysicalAddress	A full physical address of the memory to be mapped into the caller's address space.
Length	The amount of memory to be mapped starting at the given physical address.

**RETURN VALUE**

LogicalAddress	Pointer to the mapped memory. A NULL pointer indicates failure.
----------------	---

**EXCEPTIONS**

NULL is returned if there was a mapping failure.

**Functional Description:**

---

This function maps a physical address into the caller's address space. A logical pointer is returned.



## 9.2.7 AcpiOsUnmapMemory

**Remove a physical to logical memory mapping.**

```
void
AcpiOsUnmapMemory (
    void                *LogicalAddress,
    ACPI_SIZE           Length)
```

### PARAMETERS

LogicalAddress	The logical address that was returned from a previous call to <i>AcpiOsMapMemory</i> .
Length	The amount of memory that was mapped. This value must be identical to the value used in the call to <i>AcpiOsMapMemory</i> .

### RETURN VALUE

None

### Functional Description:

This function deletes a mapping that was created by *AcpiOsMapMemory*.

## 9.2.8 AcpiOsGetPhysicalAddress

**Translate a logical address to a physical address.**

```
ACPI_STATUS
AcpiOsGetPhysicalAddress (
    void                *LogicalAddress,
    ACPI_PHYSICAL_ADDRESS *PhysicalAddress)
```

### PARAMETERS

LogicalAddress	The logical address to be translated.
PhysicalAddress	The physical memory address of the logical address.

### RETURN VALUE

AE_OK	The logical address translation was successfully.
AE_ERROR	An error occurred in the translation system call.
AE_BAD_PARAMETER	One or both of the parameters are NULL, no translation was attempted.

**Functional Description:**

---

This function translates a logical address to its physical address location.

## 9.2.9 AcpiOsAllocate

**Allocate memory from the dynamic memory pool.**

```
void *  
AcpiOsAllocate (  
    ACPI_SIZE          Size)
```

**PARAMETERS**

Size	Amount of memory to allocate.
------	-------------------------------

**RETURN VALUE**

Memory	A pointer to the allocated memory. A NULL pointer is returned on error.
--------	---

**Functional Description:**

---

This function dynamically allocates memory. The returned memory is not assumed to be initialized to any particular value or values.

## 9.2.10 AcpiOsFree

**Free previously allocated memory.**

```
void  
AcpiOsFree (  
    void          *Memory)
```

**PARAMETERS**

Memory	A pointer to the memory to be freed.
--------	--------------------------------------

**RETURN VALUE**

None
------

**Functional Description:**

---

This function frees memory that was previously allocated via *AcpiOsAllocate*.



## 9.2.11 AcpiOsReadable

Check if a memory region is readable.

**BOOLEAN**  
**AcpiOsReadable (**  
     **void**  
     **ACPI\_SIZE**

**\*Memory**  
**Length)**

### PARAMETERS

Memory	A pointer to the memory region to be checked.
Length	The length of the memory region, in bytes.

### RETURN VALUE

TRUE	If the entire memory region is readable without faults.
FALSE	If one or more bytes within the region are unreadable.

### Functional Description:

This function validates that a pointer to a memory region is valid and the entire region is readable. Used to validate input parameters to the ACPICA subsystem.

## 9.2.12 AcpiOsWritable

Check if a memory region is writable (and readable).

**BOOLEAN**  
**AcpiOsWritable (**  
     **void**  
     **ACPI\_SIZE**

**\*Memory,**  
**Length)**

### PARAMETERS

Memory	A pointer to the memory region to be checked.
Length	The length of the memory region, in bytes.

### RETURN VALUE

TRUE	If the entire memory region is both readable and writable without faults
FALSE	If one or more bytes within the region are unreadable or unwritable.

**Functional Description:**

---

This function validates that a pointer to a memory region is valid and the entire region is both writable and readable. Used to validate input parameters to the ACPICA subsystem..

## 9.3 Multithreading and Scheduling Services

### 9.3.1 AcpiOsGetThreadId

<b>Obtain the ID of the currently executing thread.</b>
---

**ACPI\_THREAD\_ID**  
**AcpiOsGetThreadId (**  
    **void)**

**PARAMETERS**

None

**RETURN VALUE**

ThreadId	A unique non-zero value that represents the ID of the currently executing thread. For single threaded implementations, a constant integer > zero is acceptable. The value 0xFFFFFFFFFFFFFFFF (-1) is reserved and must not be returned by this interface.
----------	---

**Functional Description:**

---

This function returns the ID of the currently executing thread. The value must be non-zero and must be unique to the executing thread. The ACPI\_THREAD\_ID is an unsigned, 64-bit value. It is up to the host OSL to cast the native thread ID to an ACPI\_THREAD\_ID.

A 64-bit ACPI\_THREAD\_ID is used since it is the only data type that can be used to handle all of the various native thread ID types (32-bit integer, 64-bit integer, 32-bit pointer, 64-bit pointer.)

### 9.3.2 AcpiOsExecute

<b>Schedule a procedure for deferred execution.</b>
---

**ACPI\_STATUS**  
**AcpiOsExecute (**  
    **ACPI\_EXECUTE\_TYPE**        **Type,**  
    **ACPI\_OSD\_EXEC\_CALLBACK**  **Function,**  
    **void**                      **\*Context)**

**PARAMETERS**

Type	Type of the callback function:  <b>OSL_GLOBAL_LOCK_HANDLER</b> <b>OSL_NOTIFY_HANDLER</b> <b>OSL_GPE_HANDLER</b> <b>OSL_DEBUGGER_THREAD</b> <b>OSL_EC_POLL_HANDLER</b> <b>OSL_EC_BURST_HANDLER</b>
Function	Address of the procedure to execute.
Context	A context value to be passed to the called procedure.

**RETURN VALUE**

Status	Exception code that indicates success or reason for failure.
--------	--

**EXCEPTIONS**

AE_OK	The procedure was successfully queued for execution by the host operating system. This does not indicate that the procedure has actually executed, however.
AE_BAD_PARAMETER	At least one of the following is true:  The <i>Priority</i> is invalid.  The <i>Function</i> pointer is NULL.

**Functional Description:**


---

This function queues a procedure for later scheduling and execution.

### 9.3.3 AcpiOsSleep

**Suspend the running task (course granularity).**

```
void
AcpiOsSleep (
    UINT64                      Milliseconds)
```

**PARAMETERS**

Milliseconds	The amount of time to sleep, in milliseconds.
--------------	---

**RETURN VALUE**

None



**Functional Description:**

---

This function sleeps for the specified time. Execution of the running thread is suspended for this time. The sleep granularity is one millisecond.

### 9.3.4 AcpiOsStall

**Wait for a short amount of time (fine granularity).**

```
void  
AcpiOsStall (  
    UINT32                                Microseconds)
```

**PARAMETERS**

Microseconds	The amount of time to delay, in microseconds.
--------------	---

**RETURN VALUE**

None

**Functional Description:**

---

This function waits for the specified time. Execution of the running thread is not suspended for this time. The time granularity is one microsecond.

### 9.3.5 AcpiOsWaitEventsComplete

**Wait for completion of asynchronous events.**

```
void  
AcpiOsWaitEventsComplete (  
    void)
```

**PARAMETERS**

None

**RETURN VALUE**

None

**Functional Description:**

---

This function blocks until all asynchronous events initiated by AcpiOsExecute have completed. Within ACPICA, this function is called before removal of Notify and GPE handlers. For the host, this function may be useful in related areas, such as blocking for Embedded Controller event completion.



## 9.4 Mutual Exclusion and Synchronization

Thread synchronization and locking.

These interfaces **MUST** perform parameter validation of the input handle to at least the extent of detecting a null handle and returning the appropriate exception.

### 9.4.1 AcpiOsCreateMutex

Create a mutex object.

**ACPI\_STATUS**  
**AcpiOsCreateMutex (**  
     **ACPI\_MUTEX**                      **\*OutHandle)**

#### PARAMETERS

OutHandle	A pointer to a location where a handle to the mutex is to be returned.
-----------	--

#### RETURN VALUE

Status	Exception code that indicates success or reason for failure.
--------	--

#### EXCEPTIONS

AE_OK	The mutex was successfully created.
AE_BAD_PARAMETER	The <i>OutHandle</i> pointer is NULL.
AE_NO_MEMORY	Insufficient memory to create the mutex.

#### Functional Description:

Create a mutex object. Some host operating systems have separate mutex interfaces that can be used to implement this and the other OSL mutex interfaces. If not, the the mutex interfaces can be implemented with semaphore interfaces.

### 9.4.2 AcpiOsDeleteMutex

Delete a mutex object.

**void**  
**AcpiOsDeleteMutex (**  
     **ACPI\_MUTEX**                      **Handle)**

#### PARAMETERS

Handle	The mutex to be deleted.
--------	--------------------------

**RETURN VALUE**

None.

**Functional Description:**

---

Deletes a mutex object.

### 9.4.3 AcpiOsAcquireMutex

Acquire ownership of a mutex object.
--------------------------------------

**ACPI\_STATUS****AcpiOsAcquireMutex (****ACPI\_MUTEX****UINT16****Handle,****Timeout)****PARAMETERS**

Handle

The mutex to be acquired.

Timeout

How long the caller is willing to wait for the requested units. The timeout is specified in milliseconds. A value of 0xFFFF (-1) indicates that the calling thread is willing to wait forever.

**RETURN VALUE**

Status

Exception code that indicates success or reason for failure.

**EXCEPTIONS**

AE\_OK

The mutex was successfully acquired.

AE\_BAD\_PARAMETER

The *Handle* pointer is NULL.

AE\_TIME

The mutex could not be acquired within the specified time limit.

**Functional Description:**

---

Acquire ownership of a mutex object.



## 9.4.4 AcpiOsReleaseMutex

Release ownership of a mutex object.

```
void
AcpiOsReleaseMutex (
    ACPI_MUTEX          Handle)
```

### PARAMETERS

Handle	The mutex to be released.
--------	---------------------------

### RETURN VALUE

None

### Functional Description:

Release a mutex object. The mutex must have been previously acquired via *AcpiOsAcquireMutex*.

## 9.4.5 AcpiOsCreateSemaphore

Create a semaphore.

```
ACPI_STATUS
AcpiOsCreateSemaphore (
    UINT32          MaxUnits,
    UINT32          InitialUnits,
    ACPI_SEMAPHORE *OutHandle)
```

### PARAMETERS

MaxUnits	The maximum number of units this semaphore will be required to accept.
InitialUnits	The initial number of units to be assigned to the semaphore.
OutHandle	A pointer to a location where a handle to the semaphore is to be returned.

### RETURN VALUE

Status	Exception code that indicates success or reason for failure.
--------	--

### EXCEPTIONS

AE_OK	The semaphore was successfully created.
AE_BAD_PARAMETER	At least one of the following is true: The <i>InitialUnits</i> is invalid.



The *OutHandle* pointer is NULL.

AE\_NO\_MEMORY

Insufficient memory to create the semaphore.

---

**Functional Description:**

Create a standard semaphore. The *MaxUnits* parameter allows the semaphore to be tailored to specific uses. For example, a *MaxUnits* value of one indicates that the semaphore is to be used as a *mutex*. The underlying OS object used to implement this semaphore may be different than if *MaxUnits* is greater than one (thus indicating that the semaphore will be used as a general purpose semaphore.) The ACPICA Subsystem creates semaphores of both the mutex and general-purpose variety.

## 9.4.6 AcpiOsDeleteSemaphore

Delete a semaphore.

ACPI\_STATUS

AcpiOsDeleteSemaphore (  
ACPI\_SEMAPHORE                      Handle)

**PARAMETERS**

Handle	A handle to a semaphore object that was returned by a previous call to <i>AcpiOsCreateSemaphore</i> .
--------	---

**RETURN VALUE**

Status	Exception code that indicates success or reason for failure.
--------	--

**EXCEPTIONS**

AE_OK	The semaphore was successfully deleted.
AE_BAD_PARAMETER	The <i>Handle</i> is invalid.

---

**Functional Description:**

Delete a semaphore.

## 9.4.7 AcpiOsWaitSemaphore

Wait for units from a semaphore.

ACPI\_STATUS

AcpiOsWaitSemaphore (  
ACPI\_SEMAPHORE                      Handle,  
UINT32                                  Units,  
UINT16                                  Timeout)

**PARAMETERS**

Handle	A handle to a semaphore object that was returned by a previous call to <i>AcpiOsCreateSemaphore</i> .
Units	The number of units the caller is requesting.
Timeout	How long the caller is willing to wait for the requested units. The timeout is specified in milliseconds. A value of 0xFFFF (-1) indicates that the calling thread is willing to wait forever.

**RETURN VALUE**

Status	Exception code that indicates success or reason for failure.
--------	--

**EXCEPTIONS**

AE_OK	The requested units were successfully received.
AE_BAD_PARAMETER	The <i>Handle</i> is invalid.
AE_TIME	The units could not be acquired within the specified time limit.

**Functional Description:**

Wait for the specified number of units from a semaphore.

Implementation notes:

1. The implementation of this interface must support timeout values of zero. This is frequently used to determine if a call to the interface with an actual timeout value would block. In this case, *AcpiOsWaitSemaphore* must return either an **E\_OK** if the units were obtained immediately, or an **AE\_TIME** to indicate that the requested units are not available. Single threaded OSL implementations should always return **AE\_OK** for this interface.
2. The implementation must also support arbitrary timed waits in order for ASL functions such as *Wait ()* to work properly.

## 9.4.8 AcpiOsSignalSemaphore

**Send units to a semaphore.**

**ACPI\_STATUS**

**AcpiOsSignalSemaphore (**  
**ACPI\_SEMAPHORE**  
**UINT32**

**Handle,**  
**Units)**

**PARAMETERS**

Handle	A handle to a semaphore object that was returned by a previous call to <i>AcpiOsCreateSemaphore</i> .
--------	---



Units	The number of units to send to the semaphore.
-------	---

**RETURN VALUE**

Status	Exception code that indicates success or reason for failure.
--------	--

**EXCEPTIONS**

AE_OK	The semaphore was successfully signaled.
AE_BAD_PARAMETER	The <i>Handle</i> is invalid.
AE_LIMIT	The semaphore has already been signaled MaxUnits times. No more units can be accepted.

**Functional Description:**

---

Send the requested number of units to a semaphore. Single threaded OSL implementations should always return **AE\_OK** for this interface.

## 9.4.9 AcpiOsCreateLock

Create a spin lock.

**ACPI\_STATUS**  
**AcpiOsCreateLock (**  
    **ACPI\_SPINLOCK**                    **\*OutHandle)**

**PARAMETERS**

OutHandle	A pointer to a location where a handle to the lock is to be returned.
-----------	---

**RETURN VALUE**

Status	Exception code that indicates success or reason for failure.
--------	--

**EXCEPTIONS**

AE_OK	The semaphore was successfully created.
AE_BAD_PARAMETER	The <i>OutHandle</i> pointer is NULL.
AE_NO_MEMORY	Insufficient memory to create the semaphore.

**Functional Description:**

---

Create a spin lock. Spin locks are used in the ACPICA subsystem only when there is requirement for mutual exclusion on data structures that are accessed by both interrupt handlers and normal code.



## 9.4.10 AcpiOsDeleteLock

Delete a spin lock.

```
void
AcpiOsDeleteLock (
    ACPI_HANDLE          Handle)
```

### PARAMETERS

Handle	A handle to a lock object that was returned by a previous call to <i>AcpiOsCreateLock</i> .
--------	---

### RETURN VALUE

None	Exception code that indicates success or reason for failure.
------	--

### EXCEPTIONS

AE_OK	The Lock was successfully deleted.
AE_BAD_PARAMETER	The <i>Handle</i> is invalid.

### Functional Description:

Delete a spin lock.

## 9.4.11 AcpiOsAcquireLock

Acquire a spin lock.

```
ACPI_CPU_FLAGS
AcpiOsAcquireLock (
    ACPI_SPINLOCK          Handle)
```

### PARAMETERS

Handle	A handle to a lock object that was returned by a previous call to <i>AcpiOsCreateLock</i> .
--------	---

### RETURN VALUE

Flags	Platform-dependent CPU flags. To be used when the lock is released.
-------	---

### Functional Description:

Wait for and acquire a spin lock. May be called from interrupt handlers, GPE handlers, and Fixed event handlers. Single threaded OSL implementations should always return **AE\_OK** for this interface.





## 9.4.12 AcpiOsReleaseLock

Release a spin lock.

```
void  
AcpiOsReleaseLock (  
    ACPI_SPINLOCK      Handle,  
    ACPI_CPU_FLAGS     Flags)
```

### PARAMETERS

Handle	A handle to a lock object that was returned by a previous call to <i>AcpiOsCreateLock</i> .
Flags	CPU flags that were returned from <i>AcpiOsAcquireLock</i>

### RETURN VALUE

None	Exception code that indicates success or reason for failure.
------	--

### Functional Description:

Release a previously acquired spin lock. Single threaded OSL implementations should always return **AE\_OK** for this interface.

## 9.5 Interrupt Handling

Interrupt handler installation and removal.

### 9.5.1 AcpiOsInstallInterruptHandler

Install a handler for a hardware interrupt level.

```
ACPI_STATUS  
AcpiOsInstallInterruptHandler (  
    UINT32      InterruptLevel,  
    ACPI_OSD_HANDLER Handler,  
    void        *Context)
```

### PARAMETERS

InterruptLevel	Interrupt level that the handler will service.
Handler	Address of the handler.
Context	A context value that is passed to the handler when the interrupt is dispatched.

**RETURN VALUE**

Status	Exception code that indicates success or reason for failure.
--------	--

**EXCEPTIONS**

AE_OK	The handler was successfully installed.
AE_BAD_PARAMETER	At least one of the following is true:  The <i>InterruptNumber</i> is invalid.  The <i>Handler</i> pointer is NULL.
AE_ALREADY_EXISTS	A handler for this interrupt level is already installed.

**Functional Description:**


---

This function installs an interrupt handler for a hardware interrupt level. The ACPI driver must install an interrupt handler to service the SCI (System Control Interrupt) which it owns. The interrupt level for the SCI interrupt is obtained from the ACPI tables.

### 9.5.1.1 Interface to OS-independent Interrupt Handlers

<b>Definition of the interface for OS-independent interrupt handlers.</b>
---

```
typedef
UINT32 (*ACPI_OSD_HANDLER) (
    void *Context)
```

**PARAMETERS**

Context	The Context value that was passed as a parameter to the <i>AcpiOsInstallInterruptHandler</i> function.
---------	--

**RETURN VALUE**

HandlerActionTaken	The handler should return one of the following manifest constants:
--------------------	--

**ACPI\_INTERRUPT\_HANDLED**

**ACPI\_INTERRUPT\_NOT\_HANDLED**

**Functional Description:**


---

The OS-independent interrupt handler must be called from an OSL interrupt handler “wrapper” that exists within the OS Services Layer. It is the responsibility of the OS Services Layer to manage the installed interrupt handler(s), and dispatch interrupts to the handler(s) appropriately.



## 9.5.2 AcpiOsRemoveInterruptHandler

**Remove an interrupt handler.**

ACPI\_STATUS

AcpiOsRemoveInterruptHandler (

UINT32

ACPI\_OSD\_HANDLER

InterruptNumber,  
Handler)

### PARAMETERS

InterruptNumber	Interrupt number that the handler is currently servicing.
Handler	Address of the handler that was previously installed.

### RETURN VALUE

Status	Exception code that indicates success or reason for failure.
--------	--

### EXCEPTIONS

AE_OK	The handler was successfully removed.
AE_BAD_PARAMETER	At least one of the following is true:  The <i>InterruptNumber</i> is invalid.  The <i>Handler</i> pointer is NULL.  The <i>Handler</i> address is not the same as the one that is installed.
AE_NOT_EXIST	There is no handler installed for this interrupt level.

### Functional Description:

Remove a previously installed hardware interrupt handler.

## 9.6 Memory Access and Memory Mapped I/O

These interfaces allow the OS Services Layer to implement memory access in any manner that is acceptable to the host OS. The actual hardware I/O instructions may execute within the OS Services Layer itself, or these calls may be translated into additional OS calls — such as calls to a Hardware Abstraction Component. Up to 64-bit transfers are supported by the read/write memory interfaces.

These interfaces are used by the ACPICA for small amounts of data transfer only, such as memory mapped I/O. For large transfers (such as reading the ACPI tables), the ACPICA code will call *AcpiOsMapMemory* instead.

Supports Operation Region access to the **ACPI\_ADR\_SPACE\_SYSTEM\_MEMORY** (SystemMemory) space.



## 9.6.1 AcpiOsReadMemory

**Read a value from a memory location.**

**ACPI\_STATUS**  
**AcpiOsReadMemory (**  
     **ACPI\_PHYSICAL\_ADDRESS**   **Address,**  
     **UINT64**                   **\*Value,**  
     **UINT32**                   **Width)**

### PARAMETERS

Address	Memory address to be read.
Value	A pointer to a location where the data is to be returned.
Width	The memory width in bits, either 8, 16, 32, or 64.

### RETURN VALUE

Status	Exception code that indicates success or reason for failure.
--------	--

### Functional Description:

This function is used to read a data from the specified memory location. The data is zero extended to fill the 64-bit return value even if the bit width of the location is less than 64. In other words, a full 64 bits are written to the return *Value* regardless of the number of bits that were read from the memory at *Address*. The caller must ensure that no data will be overwritten by this call.

## 9.6.2 AcpiOsWriteMemory

**Write a value to a memory location.**

**ACPI\_STATUS**  
**AcpiOsWriteMemory (**  
     **ACPI\_PHYSICAL\_ADDRESS**   **Address,**  
     **UINT64**                   **Value,**  
     **UINT32**                   **Width)**

### PARAMETERS

Address	Memory address where data is to be written.
Value	Data to be written to the memory location.
Width	The memory width in bits, either 8, 16, 32, or 64.

### RETURN VALUE

Status	Exception code that indicates success or reason for failure.
--------	--

**Functional Description:**

---

This function writes data to the specified memory location. If the bit width of the memory location is less than 64, only the lower significant bits of the *Value* parameter are written.

## 9.7 Port Input/Output

These interfaces allow the OS Services Layer to implement hardware I/O services in any manner that is acceptable to the host OS. The actual hardware I/O instructions may execute within the OS Services Layer itself, or these calls may be translated into additional OS calls — such as calls to a Hardware Abstraction Component.

Supports Operation Region access to the **ACPI\_ADR\_SPACE\_SYSTEM\_IO** (SystemIO) space.

The ACPICA subsystem checks each request against a list of protected I/O ports before calling these interfaces.

### 9.7.1 AcpiOsReadPort

<b>Read a value from an input port.</b>
---

**ACPI\_STATUS****AcpiOsReadPort (****ACPI\_IO\_ADDRESS****UINT32****UINT32****Address,****\*Value,****Width)****PARAMETERS**

Address

Hardware I/O port address to read from.

Value

A pointer to a location where the data is to be returned.

Width

The port width in bits, either 8, 16, or 32.

**RETURN VALUE**

Status

Exception code that indicates success or reason for failure.

**Functional Description:**

---

This function reads data from the specified input port. The data is zero extended to fill the 32-bit return value even if the bit width of the port is less than 32.



9.7.2      **AcpiOsWritePort**

Write a value to an output port.

**ACPI\_STATUS**  
**AcpiOsWritePort (**  
    **ACPI\_IO\_ADDRESS**            **Address,**  
    **UINT32**                    **Value,**  
    **UINT32**                    **Width)**

**PARAMETERS**

Address	Hardware I/O port address to read from.
Value	The value to be written.
Width	The port width in bits, either 8, 16, or 32.

**RETURN VALUE**

Status	Exception code that indicates success or reason for failure.
--------	--

**Functional Description:**

---

This function writes data to the specified input port. If the bit width of the port is less than 32, only the lower significant bits of the *Value* parameter are written.

9.8            **PCI Configuration Space Access**

These interfaces allow the OS Services Layer to implement PCI Configuration Space services in any manner that is acceptable to the host OS. The actual hardware I/O instructions may execute within the OS Services Layer itself, or these calls may be translated into additional OS calls — such as calls to a Hardware Abstraction Component.

Supports Operation Region access to the **ACPI\_ADR\_SPACE\_PCI\_CONFIG** (Pci\_Config) space.



## 9.8.1 AcpiOsReadPciConfiguration

**Read a value from a PCI configuration register.**

**ACPI\_STATUS**  
**AcpiOsReadPciConfiguration (**  
    **ACPI\_PCI\_ID**            **PciId,**  
    **UINT32**                **Register,**  
    **UINT64**                **\*Value,**  
    **UINT32**                **Width)**

### PARAMETERS

PciId	The full PCI configuration space address, consisting of a segment number, bus number, device number, and function number.
Register	The PCI register address to be read from.
Value	A pointer to a location where the data is to be returned.
Width	The register width in bits, either 8, 16, 32, or 64.

### RETURN VALUE

Status	Exception code that indicates success or reason for failure.
--------	--

### Functional Description:

This function reads data from the specified PCI configuration port. The data is zero extended to fill the 64-bit return value even if the bit width of the location is less than 64.

## 9.8.2 AcpiOsWritePciConfiguration

**Write a value to a PCI configuration register.**

**ACPI\_STATUS**  
**AcpiOsWritePciConfiguration (**  
    **ACPI\_PCI\_ID**            **PciId,**  
    **UINT32**                **Register,**  
    **UINT64**                **Value,**  
    **UINT32**                **Width)**

### PARAMETERS

PciId	The full PCI configuration space address, consisting of a segment number, bus number, device number, and function number.
Register	The PCI register address to be written to.
Value	Data to be written.



Width	The register width in bits, either 8, 16, 32, or 64.
-------	--

**RETURN VALUE**

Status	Exception code that indicates success or reason for failure.
--------	--

**Functional Description:**


---

This function writes data to the specified PCI configuration port. If the bit width of the register is less than 64, only the lower significant bits of the Value are written.

## 9.9 Formatted Output

These interfaces provide formatted stream output. Used mainly for debug output, these functions may be redirected to whatever output device or file is appropriate for the host operating system.

### 9.9.1 AcpiOsPrintf

<b>Formatted stream output.</b>
---------------------------------

```
void ACPI_INTERNAL_VAR_XFACE
```

```
AcpiOsPrintf (
    const char          *Format,
    ...                 <variable argument list>)
```

**PARAMETERS**

Format	A standard print format string.
...	Variable printf parameter list.

**RETURN VALUE**

None.

**Functional Description:**


---

This function provides formatted output to an open stream.





## 9.9.2 AcpiOsVprintf

Formatted stream output.

```
void  
AcpiOsVprintf (  
    const char          *Format,  
    va_list             Args)
```

### PARAMETERS

Format	A standard printf format string.
Args	A variable parameter list.

### RETURN VALUE

None

### Functional Description:

This function provides formatted output to an open stream via the va\_list argument format.

## 9.9.3 AcpiOsRedirectOutput

Redirect the debug output.

```
void  
AcpiOsRedirectOutput (  
    void                *Destination)
```

### PARAMETERS

Destination	An open file handle or pointer. Debug output will be redirected to this handle/pointer. The format of this parameter is OS-specific.
-------------	--

### RETURN VALUE

None

### Functional Description:

This function redirects the output of AcpiOsPrintf and AcpiOsVprintf to the specified destination. Usually used to redirect output to a file.



## 9.10 System ACPI Table Access

These interfaces are required only by the AcpiDump utility. They must be implemented to interface to each host OS.

### 9.10.1 AcpiOsGetTableByAddress

Obtain an ACPI table via a physical address

```

ACPI_STATUS
AcpiOsGetTableByAddress (
    ACPI_PHYSICAL_ADDRESS Address,
    ACPI_TABLE_HEADER **OutTable)
  
```

#### PARAMETERS

Address	Memory physical address of the requested ACPI table.
OutTable	A pointer to location where the table is to be returned.

#### RETURN VALUE

Status	Exception code that indicates success or reason for failure.
--------	--

#### EXCEPTIONS

AE_OK	The table was successfully located and returned.
AE_BAD_PARAMETER	The <i>OutTable</i> pointer is NULL.
AE_NO_ACPI_TABLES	The ACPI tables could not be located.
AE_NO_MEMORY	Insufficient dynamic memory to create a buffer for the ACPI table.
AE_NOT_FOUND	A valid ACPI table was not found at the specified <i>Address</i> .
AE_SUPPORT	This function is not currently supported by the host.

#### Functional Description:

This function obtains an ACPI table by specifying a physical address. It is most useful for getting a table that is dynamically loaded and is not actually present in the RSDT/XSDT. **NOTE:** It may not be possible to support this function on all hosts.

If the operation fails, an appropriate status will be returned and the contents of *OutTable* is undefined.

*AcpiOsGetTableByAddress* allocates a buffer for the ACPI table that should be freed by the caller when finished with it.



## 9.10.2 AcpiOsGetTableByIndex

Obtain an installed ACPI table via an index
---

ACPI\_STATUS

AcpiOsGetTableByIndex (

    UINT32

    ACPI\_TABLE\_HEADER

    ACPI\_PHYSICAL\_ADDRESS

    TableIndex,

    \*\*OutTable,

    \*\*OutAddress)

### PARAMETERS

TableIndex	Index of the requested table. The index does not necessarily correspond to the ordering of the RSDT/XSDT.
OutTable	A pointer to location where the table is to be returned.
OutAddress	A pointer to location where the physical address of the table is returned.

### RETURN VALUE

Status	Exception code that indicates success or reason for failure.
--------	--

### EXCEPTIONS

AE_OK	The table was successfully located and returned.
AE_BAD_PARAMETER	At least one of the following is true:  The <i>OutTable</i> pointer is NULL.  The <i>OutAddress</i> pointer is NULL.
AE_LIMIT	The last valid <i>TableIndex</i> value has been reached. There is no table that corresponds to the <i>TableIndex</i> .
AE_NO_ACPI_TABLES	The ACPI tables could not be located.
AE_NO_MEMORY	Insufficient dynamic memory to create a buffer for the ACPI table.
AE_SUPPORT	This function is not currently supported by the host.



### Functional Description:

---

This function obtains an installed ACPI table by specifying a table index value. Valid table index values are 0 through n-1, where n is the number of currently installed ACPI tables. This function is useful for iterating through the entire set of installed ACPI tables. To obtain a specific ACPI table, use *AcpiOsGetTableByName* or *AcpiOsGetTableByAddress*.

If the operation fails, an appropriate status will be returned and the contents of *OutTable* and *OutAddress* are undefined.

*AcpiOsGetTableByIndex* allocates a buffer for the ACPI table that should be freed by the caller when finished with it.

### Example:

```
/* Get and dump all available ACPI tables */

for (i = 0; i++)
{
    Status = AcpiOsGetTableByIndex (i, &Table, &Address);
    if (ACPI_FAILURE (Status))
    {
        /* AE_LIMIT means that no more tables are available */

        if (Status == AE_LIMIT)
        {
            return (0);
        }
        else if (i == 0)
        {
            fprintf (stderr, "Could not get ACPI tables, %s\n",
                AcpiFormatException (Status));
            return (-1);
        }
        else
        {
            fprintf (stderr, "Could not get ACPI table at index %u, %s\n",
                i, AcpiFormatException (Status));
            continue;
        }
    }

    if (ApDumpTableBuffer (Table, Address))
    {
        return (-1);
    }
    free (Table);
}
```



### 9.10.3 AcpiOsGetTableByName

Obtain an installed ACPI table via a specific name

```
ACPI_STATUS
AcpiOsGetTableByName (
    char                *Signature,
    UINT32              Instance,
    ACPI_TABLE_HEADER **OutTable,
    ACPI_PHYSICAL_ADDRESS **OutAddress)
```

#### PARAMETERS

Signature	The uppercase ACPI signature for the requested table. This must be a 4-character null-terminated ASCII string.
Instance	Used to obtain tables that are allowed to have multiple instances (SSDT or UEFI). For regular ACPI tables, this parameter is ignored.
OutTable	A pointer to location where the table is to be returned.
OutAddress	A pointer to location where the physical address of the table is returned.

#### RETURN VALUE

Status	Exception code that indicates success or reason for failure.
--------	--

#### EXCEPTIONS

AE_OK	The table was successfully located and returned.
AE_BAD_PARAMETER	At least one of the following is true:  The <i>OutTable</i> pointer is NULL.  The <i>OutAddress</i> pointer is NULL.
AE_LIMIT	The last valid <i>Instance</i> value has been reached. There is no table that corresponds to the <i>Instance</i> .
AE_NO_ACPI_TABLES	The ACPI tables could not be located.
AE_NO_MEMORY	Insufficient dynamic memory to create a buffer for the ACPI table.
AE_NOT_FOUND	An ACPI table with <i>Signature</i> was not found.
AE_SUPPORT	This function is not currently supported by the host.




---

**Functional Description:**

This function obtains an installed ACPI table by specifying a table signature. Tables that can have multiple instances (such as SSDT or UEFI) are also supported via the *Instance* parameter. Valid instance values are 0 through n-1, where n is the number of currently installed SSDTs.

If the operation fails, an appropriate status will be returned and the contents of *OutTable* and *OutAddress* are undefined.

The *OutAddress* parameter will be set to zero if the physical address is not available.

*AcpiOsGetTableByName* allocates a buffer for the ACPI table that should be freed by the caller when finished with it.

## 9.11 Miscellaneous

### 9.11.1 AcpiOsGetTimer

Get current value of the system timer
---------------------------------------

**UINT64**  
**AcpiOsGetTimer** (  
     **void**)

**PARAMETERS**

None.

**RETURN VALUE**

TimerValue	The current value of the system timer in 100-nanosecond units.
------------	--

---

**Functional Description:**

This function returns the current value of a fine-granularity 64-bit system timer. This interface is used to implement the Timer ASL/AML function.



## 9.11.2 AcpiOsSignal

**Break to the debugger or display a breakpoint message.**

ACPI\_STATUS  
AcpiOsSignal (  
    UINT32  
    void

Function,  
\*Info)

### PARAMETERS

Function

Signal to be sent to the host operating system – one of these manifest constants:

**ACPI\_SIGNAL\_FATAL**

**ACPI\_SIGNAL\_BREAKPOINT**

### RETURN VALUE

Status

Exception code that indicates success or reason for failure.

### Functional Description:

This function is used to pass various signals and notifications to the host operating system. The following signals are supported:

#### **ACPI\_SIGNAL\_FATAL**

This signal corresponds to the AML **Fatal** opcode. It is sent to the host OS only when this opcode is encountered in the AML stream. The host OS may or may not return control from this signal.

The definition of the Info structure for this signal is as follows:

```
typedef struct AcpiFatalInfo
{
    UINT32                Type;
    UINT32                Code;
    UINT32                Argument;
} ACPI_SIGNAL_FATAL_INFO;
```

#### **ACPI\_SIGNAL\_BREAKPOINT**

This signal corresponds to the AML **Breakpoint** opcode. The OSL implements a “Breakpoint” operation as appropriate for the host OS. If in debug mode, this interface may cause a break into the host kernel debugger.

The definition of the Info structure for this signal is as follows:

```
char                *BreakpointMessage;
```



### 9.11.3 AcpiOsGetLine

Get a input line of data.
---------------------------

**ACPI\_STATUS**  
**AcpiOsGetLine (**

<b>char</b>	<b>*Buffer,</b>
<b>UINT32</b>	<b>BufferLength,</b>
<b>UINT32</b>	<b>*BytesRead)</b>

#### PARAMETERS

Buffer	Where to return the input line.
BufferLength	Length of the Buffer (max data to return)
*BytesRead	Where the actual byte count is returned.

#### RETURN VALUE

Status	Exception code that indicates success or reason for failure.
--------	--

#### EXCEPTIONS

AE_OK	The line was successfully obtained.
AE_BUFFER_OVERFLOW	The line was too large for the input buffer.

#### Functional Description:

---

Get one line of input from the debugger command line. The purpose of this function is to support the ACPI Debugger, and it is therefore optional depending on whether ACPI debugger support is desired.





# 10 ACPICA Deployment Guide

## 10.1 Using the ACPICA Subsystem Interfaces

### 10.1.1 Initialization Sequence

In order to allow the most flexibility for the host operating system, there is no single interface that initializes the entire ACPICA subsystem. Instead, the subsystem is initialized in stages, at the times that are appropriate for the host OS. The following example shows the sequence of initialization calls that must be made; it is up to the host interface (OS Services Layer) to make these calls when they are appropriate.

1. Initialize all ACPI Code:

```
Status = AcpiInitializeSubsystem ();
```

2. Load the ACPI tables from the firmware and build the internal namespace:

```
Status = AcpiLoadTables ();
```

3. Complete initialization and put the system into ACPI mode:

```
Status = AcpiEnableSubsystem ();
```

### 10.1.2 ACPICA Initialization Examples

#### 10.1.2.1 Full ACPICA Initialization

```
ACPI_STATUS
InitializeFullAcpi (void)
{
    ACPI_STATUS          Status;

    /* Initialize the ACPICA subsystem */

    Status = AcpiInitializeSubsystem ();
    if (ACPI_FAILURE (Status))
    {
        return (Status);
    }

    /* Initialize the ACPICA Table Manager and get all ACPI tables */

    Status = AcpiInitializeTables (NULL, 16, FALSE);
    if (ACPI_FAILURE (Status))
    {
        return (Status);
    }
}
```



```

/* Create the ACPI namespace from ACPI tables */

Status = AcpiLoadTables ();
if (ACPI_FAILURE (Status))
{
    return (Status);
}

/* Note: Local handlers should be installed here */

/* Initialize the ACPI hardware */

Status = AcpiEnableSubsystem (ACPI_FULL_INITIALIZATION);
if (ACPI_FAILURE (Status))
{
    return (Status);
}

/* Complete the ACPI namespace object initialization */

Status = AcpiInitializeObjects (ACPI_FULL_INITIALIZATION);
if (ACPI_FAILURE (Status))
{
    return (Status);
}

return (AE_OK);
}

```

### 10.1.2.2 ACPICA Initialization With Early ACPI Table Access

```

#define ACPI_MAX_INIT_TABLES    16
static ACPI_TABLE_DESC          TableArray[ACPI_MAX_INIT_TABLES];

ACPI_STATUS
InitializeAcpiTables (void)
{
    ACPI_STATUS                  Status;

    /* Initialize the ACPICA Table Manager and get all ACPI tables */

    Status = AcpiInitializeTables (TableArray, ACPI_MAX_INIT_TABLES, TRUE);
    return (Status);
}

ACPI_STATUS
InitializeAcpi (void)
{
    ACPI_STATUS                  Status;

```



```
/* Initialize the ACPICA subsystem */

Status = AcpiInitializeSubsystem ();
if (ACPI_FAILURE (Status))
{
    return (Status);
}

/* Copy the root table list to dynamic memory */

Status = AcpiReallocateRootTable ();
if (ACPI_FAILURE (Status))
{
    return (Status);
}

/* Create the ACPI namespace from ACPI tables */

Status = AcpiLoadTables ();
if (ACPI_FAILURE (Status))
{
    return (Status);
}

/* Note: Local handlers should be installed here */

/* Initialize the ACPI hardware */

Status = AcpiEnableSubsystem (ACPI_FULL_INITIALIZATION);
if (ACPI_FAILURE (Status))
{
    return (Status);
}

/* Complete the ACPI namespace object initialization */

Status = AcpiInitializeObjects (ACPI_FULL_INITIALIZATION);
if (ACPI_FAILURE (Status))
{
    return (Status);
}

return (AE_OK);
}
```

### 10.1.3 Shutdown Sequence

The ACPICA Subsystem does not absolutely require a shutdown before the system terminates. It does not hold any cached data that must be flushed before shutdown. However, if the ACPICA subsystem is to be unloaded at any time during system operation, the subsystem should be shutdown so that resources that are held internally can be released back to the host OS. These resources include memory segments, an interrupt handler, and the ACPI hardware itself. To shutdown the ACPICA Subsystem, the following calls should be made:



1. Unload the namespace and free all resources:

```
Status = AcpiTerminate ();
```

## 10.1.4 Traversing the ACPI Namespace (Low Level)

This example demonstrates traversal of the ACPI namespace using the low-level *Acpi\** primitives. The code is in fact the implementation of the higher-level *AcpiWalkNamespace* interface, and therefore this example has two purposes:

1. Demonstrate how the low-level namespace interfaces are used.
2. Provide an understanding of how the namespace walk interface works.

```
ACPI_STATUS
AcpiWalkNamespace (
    ACPI_OBJECT_TYPE      Type,
    ACPI_HANDLE            StartHandle,
    UINT32                 MaxDepth,
    WALK_CALLBACK          UserFunction,
    void                   *Context,
    void                   **ReturnValue)
{
    ACPI_HANDLE            ObjHandle = 0;
    ACPI_HANDLE            Scope;
    ACPI_HANDLE            NewScope;
    void                   *UserReturnVal;
    UINT32                 Level = 1;

    /* Parameter validation */

    if ((Type > ACPI_TYPE_MAX) ||
        (!MaxDepth) ||
        (!UserFunction))
    {
        return_ACPI_STATUS (AE_BAD_PARAMETER);
    }

    /* Special case for the namespace root object */

    if (StartObject == ACPI_ROOT_OBJECT)
    {
        StartObject = Gbl_RootObject;
    }

    /* Null child means "get first object" */

    ParentHandle    = StartObject;
    ChildHandle     = 0;
    ChildType       = ACPI_TYPE_ANY;
    Level          = 1;

    /*
     * Traverse the tree of objects until we bubble back up to where we
     * started. When Level is zero, the loop is done because we have
     * bubbled up to (and passed) the original parent handle (StartHandle)
     */

    while (Level > 0)
    {
        /* Get the next typed object in this scope. Null returned if not found */

        Status = AE_OK;
```



```
if (ACPI_SUCCESS (AcpiGetObject (ACPI_TYPE_ANY, ParentHandle, ChildHandle,
                                &ChildHandle)))
{
    /* Found an object, Get the type if we are not searching for ANY */

    if (Type != ACPI_TYPE_ANY)
    {
        AcpiGetType (ChildHandle, &ChildType);
    }

    if (ChildType == Type)
    {
        /* Found a matching object, invoke the user callback function */

        Status = UserFunction (ChildHandle, Level, Context, ReturnValue);
        switch (Status)
        {
            case AE_OK:
            case AE_DEPTH:
                break;                                /* Just keep going */

            case AE_TERMINATE:
                return ACPI_STATUS (AE_OK);            /* Exit now, with OK status */
                break;

            default:
                return ACPI_STATUS (Status);            /* All others are valid exceptions */
                break;
        }
    }

    /*
     * Depth first search: Attempt to go down another
     * level in the namespace if we are allowed to. Don't go any further if we
     * have reached the caller specified maximum depth or if the user function
     * has specified that the maximum depth has been reached.
     */

    if ((Level < MaxDepth) && (Status != AE_DEPTH))
    {
        if (ACPI_SUCCESS (AcpiGetObject (ACPI_TYPE_ANY, ChildHandle,
                                         0, NULL)))
        {
            /* There is at least one child of this object, visit the object */

            Level++;
            ParentHandle = ChildHandle;
            ChildHandle = 0;
        }
    }

    else
    {
        /*
         * No more children in this object (AcpiGetObject failed),
         * go back upwards in the namespace tree to the object's parent.
         */
        Level--;
        ChildHandle = ParentHandle;
        AcpiGetParent (ParentHandle, &ParentHandle);
    }
}

return ACPI_STATUS (AE_OK); /* Complete walk, not terminated by user function */
}
```



## 10.1.5 Traversing the ACPI Namespace (High Level)

This example demonstrates the use of the *AcpiWalkNamespace* interface and other **Acpi\*** interfaces. It shows how to properly invoke *AcpiWalkNamespace* and write a callback routine.

This code searches for all device objects in the namespace under the system bus (where most, if not all devices usually reside.) The callback function always returns NULL, meaning that the walk is not terminated until the entire namespace under the system bus has been traversed.

Part 1: This is the top-level procedure that invokes *AcpiWalkNamespace*.

```
DisplaySystemDevices (void)
{
    ACPI_HANDLE          SysBusHandle;

    AcpiNameToHandle (0, NS_SYSTEM_BUS, &SysBusHandle);

    printf ("Display of all devices in the namespace:\n");

    AcpiWalkNamespace (ACPI_TYPE_DEVICE, SysBusHandle, INT_MAX,
        DisplayOneDevice, NULL, NULL);
}
```

Part 2: This is the callback routine that is repeatedly invoked from *AcpiWalkNamespace*.

```
void *
DisplayOneDevice (
    ACPI_HANDLE          ObjHandle,
    UINT32               Level,
    void                 *Context)
{
    ACPI_STATUS          Status;
    ACPI_DEVICE_INFO     Info;
    ACPI_BUFFER          Path;
    char                 Buffer[256];

    Path.Length = sizeof (Buffer);
    Path.Pointer = Buffer;

    /* Get the full path of this device and print it */

    Status = AcpiHandleToPathname (ObjHandle, &Path);
    if (ACPI_SUCCESS (Status))
    {
        printf ("%s\n", Path.Pointer);
    }

    /* Get the device info for this device and print it */

    Status = AcpiGetDeviceInfo (ObjHandle, &Info);
    if (ACPI_SUCCESS (Status))
    {
        printf ("    HID: %.8X, ADR: %.8X, Status: %x\n",
            Info.HardwareId, Info.Address, Info.CurrentStatus);
    }

    return NULL;
}
```



## 10.2 Implementing the OS Services Layer

### 10.2.1 Parameter Validation

In all implementations of the OS Services Layer, the interfaces should adhere to the descriptions in the document as far as the actual interface parameters as well as the returned exception codes. This means that the parameter validation is not optional and that the ACPICA Subsystem layer depends on correct exception codes returned from the OSL.

### 10.2.2 Memory Management

Implementation of the memory allocation functions should be straightforward. If the host operating system has several kernel-level memory pools that can be used for allocation, it may be useful to know some of the dynamic memory requirements of the ACPICA Subsystem.

During initialization, the ACPI tables are either mapped from BIOS memory or copied into local memory segments. Some of these tables (especially the DSDT) can be fairly large, up to about 64K. The namespace is built from multiple small memory segments, each of a fixed (but configurable) length. The default namespace table length is 16 entries times about 32 bytes each for a total of 512 bytes per table and per allocation.

During operation, many internal objects are created and deleted while servicing requests. The size of an internal object is about 32 bytes, and this is the primary run-time memory request size.

Several internal caches are used within the Subsystem to minimize the number of requests to the memory manager.

### 10.2.3 Scheduling Services

The intent of the *AcpiOsQueueForExecution* interface is to schedule another thread. It makes no difference whether this is a new thread created at the time this call is made, or simply a thread that is allocated out of a pool of system threads. Only the ACPICA Debugger creates a permanent thread.

### 10.2.4 Mutual Exclusion and Synchronization

In a single thread environment, the spinlock, mutex, and semaphore interfaces can simply return AE\_OK. In a multiple thread environment, these interfaces must be implemented with real blocking spinlocks, mutexes, and semaphores since the mutual exclusion support in the Subsystem relies *completely* upon the proper implementation of this mechanism and these interfaces.

### 10.2.5 Interrupt Handling

In order to support the OS-independent interrupt handler that is implemented within the ACPICA Subsystem, the OSL must provide a local interrupt handler whose interface conforms to the requirements of the host operating system. This local interrupt handler is a wrapper for the OS-independent handler; it is the actual handler that is installed for the given interrupt level. The task of this wrapper is to handle incoming interrupts and dispatch them to the OS-independent handler via the OS-independent handler interface. When the handler returns, the wrapper performs any necessary cleanup and exits the interrupt.



## 10.2.6 Stream I/O

The *AcpiOsPrintf* and *AcpiOsVprintf* functions can usually be implemented using a kernel-level debug print facility. Kernel printf functions usually output data to a serial port or some other special debug facility. If there is more than one type of debug print routine, use one that can be called from within an interrupt handler so that Fixed Events and General-Purpose events can be traced.

## 10.2.7 Hardware Abstraction (I/O, Memory, PCI Configuration)

The intent of the hardware I/O interfaces is to allow these calls to be translated into calls or macros provided by the host OS for this purpose. However, if the host does not provide a hardware abstraction service, these functions can be implemented simply and directly via I/O machine instructions.





# 11 User-Mode Tools and Utilities

## 11.1 Generating the ACPICA Tools/Utilities from Source

There are two major methods provided to generate the ACPICA tools and utilities from source code:

- 1) Makefiles are provided to generate in a unix-like environment. They can be modified to conform to other environments as needed. The tools may be generated in either 32-bit or 64-bit mode.
- 2) Project files are provided to generate with the 32-bit Microsoft Visual Studio 2008.

### 11.1.1 Generic Unix Makefiles

The generic makefiles build all of the utilities (including iASL) by default using the gcc compiler. For iASL, current versions of Flex/Bison (or Lex/Yacc) are required. See the iASL User Guide for additional iASL generation information.

The make build can be invoked from within the ACPICA source tree in one of two ways. There exists a top-level makefile within the **acpica** directory, and a similar makefile under the **acpica/generate/unix** directory.

**Examples:**

```
cd acpica
make clean
make

cd acpica/generate/unix
make clean
make
```

Individual tools can be generated by specifying the tool name on the make command line:

**Examples:**

```
make acpiexec
make acpidump
make acpixtract
make iasl
make acpihelp
make acpisrc
make acpibin
make acpinames
```

The following command line options are supported:

**OPT\_CFLAGS** – Additional flags (etc.) to be passed to the compiler can be added.

**NOOPT** – Set to TRUE in order to disable compiler optimizations and the `_FORTIFY_SOURCE` gcc option. Some older versions of gcc (such as 4.4 or earlier) may have problems compiling with optimizations enabled, and this flag is provided to workaround the problem.

**Examples:**



```
make OPT_CFLAGS=-Os
make NOOPT=TRUE
```

## 11.1.2 Visual Studio Project Files

The master Visual Studio 2008 solution file is located at:

```
acpica/generate/msvc9/AcpiComponents.sln
```

After loading this solution file, all of the ACPICA tools can be generated for Windows. The project files assume the standard ACPICA source tree.

See the Visual Studio readme file for additional instructions, located at:

```
acpica/generate/msvc9/readme.txt
```

Note: generation of the iASL compiler requires Flex and Bison for Windows. See the iASL User Guid for more information, as well as the readme file located at:

```
acpica/source/compiler/readme.txt
```

### 11.1.2.1 Visual Studio 2008 Installation Notes

The ACPICA source code is written in ANSI C for maximum portability, and is generated with all C language extensions disabled.

There are a couple of header files in Visual Studio 2008 that unfortunately contain non-ANSI “/” style comments. These will be flagged as warnings during every compile because the language extensions are disabled. The offending header files must be modified in order to eliminate these warnings.

The VC include files are under one of these directories:

```
\Program Files\Microsoft Visual Studio 9.0\VC\include
\Program Files (x86)\Microsoft Visual Studio 9.0\VC\include
```

To eliminate the warnings, the following files must must be modified:

```
sal.h
stdlib.h
```

For each file, add this statement to the start of the file:

```
#pragma warning( disable : 4001 ) /* no warning about “/” comments” */
```

And add this statement to the end of the file:

```
#pragma warning( default : 4001)
```

For stdlib.h, you may also need to disable warning 4001 again before this line, near line 774:

```
#pragma warning (disable:6540)
```

Note: you may have to change the permissions on these files in order to write to them.



### 11.1.2.2 Flex/Bison for Windows Installation Notes

In order to generate the iASL compiler, the Windows versions of the GNU Flex/Bison tools must be installed, and they must be installed in a directory that contains no embedded spaces in the pathname. This means that they cannot be installed in the default path which contains the “C:\Program Files” directory. This is a bug in Bison. The default Windows project file for iASL assumes that these tools are installed at this location:

`C:\GnuWin32`

Once the tools are installed, ensure that this path is added to the default system \$PATH environment variable:

`C:\GnuWin32\bin`

Go to: ControlPanel/System/AdvancedSystemSettings/EnvironmentVariables

Important: Now Windows must be rebooted to make the system aware of the updated \$PATH.



## 11.2 iASL Compiler

The iASL compiler is a fully-featured translator for the ACPI Source Language (ASL). As part of the Intel ACPI Component Architecture, the Intel ASL compiler implements translation for the ACPI Source Language (ASL) to the ACPI Machine Language (AML).

iASL also includes the ACPICA disassembler, and will disassemble any ACPI table, including both tables that contain AML (DSDT, SSDT, OEMx) and tables that contain data only (all other ACPI tables such as FADT, MADT, ECDT, etc.)

The compiler is fully documented in the *iASL Compiler User Reference*.

```
Intel ACPI Component Architecture
ASL Optimizing Compiler version 20131211-32 [Dec 11 2013]
Copyright (c) 2000 - 2013 Intel Corporation
```

Supports ACPI Specification Revision 5.0A

Usage: iasl [Options] [Files]

Options:

General:

```
-@ <file>          Specify command file
-I <dir>           Specify additional include directory
-T <sig>|ALL|*     Create table template file for ACPI <Sig>
-p <prefix>        Specify path/filename prefix for all output files
-v                Display compiler version
-vo               Enable optimization comments
-vs               Disable signon
```

Help:

```
-h                This message
-hc              Display operators allowed in constant expressions
-hf              Display help for output filename generation
-hr              Display ACPI reserved method names
-ht              Display currently supported ACPI table names
```

Preprocessor:

```
-D <symbol>       Define symbol for preprocessor use
-li              Create preprocessed output file (*.i)
-P              Preprocess only, create preprocessor output file (*.i)
-Pn             Disable preprocessor
```

Errors, Warnings, and Remarks:

```
-va              Disable all errors/warnings/remarks
-ve              Report only errors (ignore warnings and remarks)
-vi              Less verbose errors and warnings for use with IDEs
-vr              Disable remarks
-vw <messageid>  Disable specific warning or remark
-w1 -w2 -w3      Set warning reporting level
-we              Report warnings as errors
```

AML Code Generation (\*.aml):

```
-oa              Disable all optimizations (compatibility mode)
-of              Disable constant folding
-oi              Disable integer optimization to Zero/One/Ones
```



-on	Disable named reference string optimization
-cr	Disable Resource Descriptor error checking
-in	Ignore NoOp operators
-r <revision>	Override table header Revision (1-255)

Optional Source Code Output Files:

-sc -sa	Create source file in C or assembler (*.c or *.asm)
-ic -ia	Create include file in C or assembler (*.h or *.inc)
-tc -ta -ts	Create hex AML table in C, assembler, or ASL (*.hex)
-so	Create offset table in C (*.offset.h)

Optional Listing Files:

-l	Create mixed listing file (ASL source and AML) (*.lst)
-ln	Create namespace file (*.nsp)
-ls	Create combined source file (*.src)

Data Table Compiler:

-G	Compile custom table that contains generic operators
-vt	Create verbose template files (full disassembly)

AML Disassembler:

-d <f1 f2 ...>	Disassemble or decode binary ACPI tables to file (*.dsl)
	(Optional, file type is automatically detected)
-da <f1 f2 ...>	Disassemble multiple tables from single namespace
-db	Do not translate Buffers to Resource Templates
-dc <f1 f2 ...>	Disassemble AML and immediately compile it
	(Obtain DSDT from current system if no input file)
-e <f1 f2 ...>	Include ACPI table(s) for external symbol resolution
-fe <file>	Specify external symbol declaration file
-g	Get ACPI tables and write to files (*.dat)
-in	Ignore NoOp opcodes
-vt	Dump binary table data in hex format within output file

Debug Options:

-bf -bt	Create debug file (full or parse tree only) (*.txt)
-f	Ignore errors, force creation of AML output file(s)
-m <size>	Set internal line buffer size (in Kbytes)
-n	Parse only, no output generation
-ot	Display compile times and statistics
-x <level>	Set debug level for trace output
-z	Do not insert new compiler ID for DataTables



## 11.3 AcpiExec – User Mode ACPI Execution/Simulation

This utility can be used to load any ACPI tables from file(s), execute control methods, single step control methods, inspect the ACPI namespace, etc. When generated from source, it contains the entire ACPICA Subsystem including the ACPICA Debugger. All hardware access via the AML is simulated. All ACPICA debugger commands are available (See the ACPICA Debugger Reference later in this document.)

```
Intel ACPI Component Architecture
AML Execution/Debug Utility version 20131115-32 [Nov 15 2013]
Copyright (c) 2000 - 2013 Intel Corporation
```

```
Usage: acpiexec [options] AMLfile1 AMLfile2 ...
```

```
Options:
```

```
-b "CommandLine"  Batch mode command line execution (cmd1;cmd2;...)
-h -?            Display this help message
-m [Method]      Batch mode method execution. Default=MAIN

-da             Disable method abort on error
-di             Disable execution of STA/INI methods during init
-do             Disable Operation Region address simulation
-dr             Disable repair of method return values
-dt             Disable allocation tracking (performance)

-ef             Enable display of final memory statistics
-ei             Enable additional tests for ACPICA interfaces
-em             Enable Interpreter Serialized Mode
-es             Enable Interpreter Slack Mode
-et             Enable debug semaphore timeout

-f <Value>       Operation Region initialization fill value
-r             Use hardware-reduced FADT V5
-v             Display version information
-vi            Verbose initialization output
-vr            Verbose region handler output
-x <DebugLevel> Debug output level
```



## 11.4 AcpiHelp – Display ACPI Help Information

This utility displays information about all known ASL operators and keywords, AML opcodes, and ASL/AML predefined names.

```
Intel ACPI Component Architecture
ACPI Help Utility version 20131115-32 [Nov 15 2013]
Copyright (c) 2000 - 2013 Intel Corporation
```

```
Usage: acpihelp <options> [NamePrefix | HexValue]
```

```
Options:
```

```
-h                Display help
-v                Display version information
```

```
ACPI Names and Symbols:
```

```
-k [NamePrefix]   Find/Display ASL non-operator keyword(s)
-m [NamePrefix]   Find/Display AML opcode name(s)
-p [NamePrefix]   Find/Display ASL predefined method name(s)
-s [NamePrefix]   Find/Display ASL operator name(s)
```

```
ACPI Values:
```

```
-e [HexValue]     Decode ACPICA exception code
-i                Display known ACPI Device IDs (_HID)
-o [HexValue]     Decode hex AML opcode
```

```
NamePrefix/HexValue not specified means "Display All"
```

```
Default search with NamePrefix and no options:
```

```
Find ASL operator names - if NamePrefix does not start with underscore
Find ASL predefined method names - if NamePrefix starts with
underscore
```



## 11.5 AcpiDump – Dump System ACPI Tables

This portable utility obtains the binary system ACPI tables and dumps them to an ASCII text file suitable for input to the AcpiXtract utility.

The actual attraction of tables from the system is dependent on the host OS. To port to a new OS, a single module must be written to implement the interfaces that get ACPI tables.

```
Intel ACPI Component Architecture
ACPI Binary Table Dump Utility version 20130823-32 [Aug 23 2013]
Copyright (c) 2000 - 2013 Intel Corporation
```

Usage: acpidump [options]

Options:

-b	Dump tables to binary files
-c	Dump customized tables
-h -?	This help message
-o <File>	Redirect output to file
-r <Address>	Dump tables from specified RSDP
-s	Print table summaries only
-v	Display version information
-z	Verbose mode

Table Options:

-a <Address>	Get table via a physical address
-f <BinaryFile>	Get table via a binary file
-n <Signature>	Get table via a name/signature

## 11.6 AcpiXtract – Extract ACPI Tables

This utility is used to extract binary ACPI tables from the ASCII output of the AcpiDump utility.

```
Intel ACPI Component Architecture
ACPI Binary Table Extraction Utility version 20131115-32 [Nov 15 2013]
Copyright (c) 2000 - 2013 Intel Corporation
```

Usage: acpixtract [option] <InputFile>

Options:

-a	Extract all tables, not just DSDT/SSDT
-l	List table summaries, do not extract
-s <signature>	Extract all tables with <signature>
-v	Display version information

Extract binary ACPI tables from text acpidump output  
Default invocation extracts the DSDT and all SSDTs





## 11.7 AcpiSrc – Convert ACPICA Source Code

This utility is used to convert the ACPICA into Linux code format. It can also be used to clean the ACPICA code by removing extra trailing blanks, etc., and to generate source code statistics.

```
Intel ACPI Component Architecture
ACPI Source Code Conversion Utility version 20130823-32 [Aug 23 2013]
Copyright (c) 2000 - 2013 Intel Corporation
```

```
Usage: acpisrc [-c|l|u] [-dsvy] <SourceDir> <DestinationDir>
```

```
Options:
```

-c	Generate cleaned version of the source
-h	Insert dual-license header into all modules
-l	Generate Linux version of the source
-u	Generate Custom source translation
-d	Leave debug statements in code
-s	Generate source statistics only
-v	Display version information
-vb	Verbose mode
-y	Suppress file overwrite prompts

Example output – source code statistics for ACPICA:

```
Intel ACPI Component Architecture
ACPI Source Code Conversion Utility version 20130823-32 [Aug 23 2013]
Copyright (c) 2000 - 2013 Intel Corporation
```

```
Source code statistics only
```

```
AcpiSrc statistics:
```

```
339 Files processed
7670350 Total bytes (22.1K/file)
53 Tabs found
0 Missing if/else braces
27 Non-ANSI comments found
218962 Total Lines
113108 Lines of code
39405 Lines of non-comment whitespace
43889 Lines of comments
4810 Long lines found
2.9 Ratio of code to whitespace
2.6 Ratio of code to comments
51% code, 20% comments, 17% whitespace, 16% headers
```



## 11.8 AcpiNames – Example Namespace Dump

This utility is provided to give an example of a minimal configuration of ACPICA. It will load a DSDT from a file and simply dump the entire namespace.

The ACPICA components that are used are the Table Manager and Namespace Manager. It does not include the AML interpreter.

Functionality is a subset of the AcpiExec utility, so the purpose of AcpiNames is to show how to configure ACPICA for a subset of the various available managers.

### Example:

```
C:\acpinames dsdt.aml
```

```
Intel ACPI Component Architecture
ACPI Namespace Dump Utility version 20110413-32 [April 13 2011]
Copyright (c) 2000 - 2011 Intel Corporation
```

```
Loading Acpi table from file dsdt.aml
```

```
ACPI: RSDP 00424F04 0002C (v02 I_TEST)
ACPI: XSDT 00347150 0002C (v01          00000000          00000000)
ACPI: FACP 00424F28 000F4 (v03          00000000          00000000)
ACPI: DSDT 003470E8 00059 (v02 Intel Template 00000001 INTL 20110413)
ACPI: FACS 00425020 00040
```

```
ACPI Namespace:
```

```
0  _GPE Scope          00344E88 00
0  _PR_ Scope          00344EA8 00
0  _SB_ Device         00344EC8 00
0  _SI_ Scope          00344EE8 00
0  _TZ_ Device         00344F08 00
0  _REV Integer        00344F28 00 = 0000000000000003
0  _OS_ String         00344F80 00 Len 14 "Microsoft Windows NT"
0  _GL_ Mutex          00344FD8 00 Object 00344FF8
0  _OSI Method         00345030 00 Args 1 Len 0000 Aml 00000000
0  DUMP Method         00347558 01 Args 1 Len 0004 Aml 00347113
0  MAIN Method         00347690 01 Args 7 Len 0023 Aml 0034711E
```



## 12 ACPICA Debugger Reference

### 12.1 Overview

The ACPICA AML Debugger is an optional subcomponent of the ACPICA Subsystem. It can be operated standalone or in conjunction with (or as an extension of) a native kernel debugger. The debugger provides the ability to load ACPI tables, dump internal data structures, execute control methods, disassemble control methods, single step control methods, and set breakpoints within control methods.

### 12.2 Supported Environments

The debugger can be executed in a ring 0 (kernel) or ring 3 (application) environment. The following combinations of debugger and front-end (user-interface) are supported:

- Ring 0 Debugger, Ring 0 Front-End: In this case, the front-end is a host kernel debugger, and the Debugger operates as an extension to the host debugger.
- Ring 0 Debugger, Ring 3 Front-End: In this mode, the front-end is a ring 3 application that obtains the command lines from the user and sends them to the debugger executing in Ring 0. The actual mechanism used for this communication is dependent on the host operating system.
- Ring 3 Debugger, Ring 3 Front-End: In this mode, the entire ACPICA subsystem (including the debugger) resides in a Ring 3 application. A single thread can be used for the user interface, debugger, and AML control method execution. An example of this mode is the *AcpiExec* utility.

#### 12.2.1 The *AcpiExec* Utility

An example of the Ring3/Ring3 model of execution is the user mode *AcpiExec* utility. This application includes the entire ACPICA subsystem (including the Debugger) and allows the user to load ACPI tables from files and execute methods contained in the tables.

Of course, hardware and memory access from Ring 3 is very limited. The *AcpiExec* utility simulates hardware access.

### 12.3 Debugger Architecture

The ACPI debugger consists of the following architectural elements:

- A command line interpreter that receives entire command lines from the host, parses them into commands and parameters, and dispatches the request to the appropriate handler for the command.
- A group of modules that implement the various debugger commands.
- A group of callback routines that are invoked by the interpreter/dispatcher during the execution control methods. These callbacks enable the single stepping of control methods and the display of arguments to each executed control method.




When executing in a Ring 0 environment, the debugger initialization creates a separate thread for the debugger CLI. This threads performs the following tasks until the debugger is shut down:

1. Wait for a command line by calling the *AcpiOsGetLine* interface
2. Execute the command

All output from the debugger is via the *AcpiOsPrint* and *AcpiOsVprintf* interfaces.

The overall architecture of the ACPI Debugger is shown in the diagram below. Note how the Debugger CLI uses the *AcpiOsGetLine* interface to obtain user command lines, and how output from the entire debugger and ACPICA subsystem can be directed to the console, a file, or both via the implementation of the *AcpiOsPrint* interface within the OSL layer. Also note how the debugger and ACPICA subsystem can reside in a different protection ring than the user console support and file I/O support.

**Figure 9. ACPICA Debugger Architecture**



## 12.4 Configuration and Installation

The basic idea behind the debugger thread is that it receives a command line from *somewhere* and then asynchronously executes it. The command line can come from a ring 3 application (a debugger front-end), or it can come from the resident kernel debugger (you would install a debugger extension that forwards command lines to the debugger.)

With this in mind, there are several key components of the debugger:

1. **DbInitialize** – Initializes the debugger semaphores and creates the debugger thread, *DbExecuteThread*
2. **DbCommandDispatch** – This is the actual command execution code



3. **DbExecuteThread** – Waits for a command to become available (as indicated by the MTX\_DEBUG\_CMD\_READY mutex), executes the command, (via DbCommandDispatch), then signals command completion via the MTX\_DEBUG\_CMD\_COMPLETE mutex.
4. **DbUserCommands** – An example command loop that must execute in its own thread (this is the *caller* thread, not a thread that is part of the debugger). This loop obtains a command line via AcpiOsGetLine, puts it into the LineBuf buffer, and signals the DbExecuteThread that a command line is available. It is not necessary to use this procedure, however, if command lines become available from somewhere besides AcpiOsGetLine.
5. **DbSingleStep** – Called from the dispatcher just before an AML opcode is executed. Implements its own command loop that obtains command lines from either the MTX\_DEBUG\_CMD\_READY mutex (multi-thread mode), or by calling AcpiOsGetLine directly (single thread mode). Drops out of the loop when the control method is aborted or is allowed to continue running (perhaps just to the next opcode...)

This is the basic thread model and handshake with the outside world. To integrate the debugger into a specific environment, it is your responsibility to get command lines to the DbExecuteThread via the LineBuf and the MTX\_DEBUG\_CMD\_READY mutex. Alternatively, you can just call the DbCommandDispatch directly if you don't need an asynchronous debugger thread. Additional explanation follows.

The AcpiExec Ring3 application uses DbUserCommands to process command lines (DbUserCommands is actually called from aemain.c). However, if integrating with a kernel debugger, you will probably want to implement your own mechanism instead of using the DbUserCommands loop. I would imagine this would entail the following:

1. Install a small extension to the kernel debugger that receives command lines intended for that extension.
2. Copy the command line to the LineBuf.
3. Signal the DbExecuteThread that a command is available. (MTX\_DEBUG\_CMD\_READY).
4. Wait for the command to complete (MTX\_DEBUG\_CMD\_COMPLETE).
5. Return to the kernel debugger.

If you don't need the extra debugger thread, you can simply execute commands in the caller's context:

1. Install a small extension to the kernel debugger that receives command lines intended for that extension.
2. Copy the command line to the LineBuf.
3. Call DbCommandDispatch to execute the command directly.
4. Return to the kernel debugger.

The behavior of the debugger can be configured as follows (via the *config.h* header):

```
#define DEBUGGER_THREADING          DEBUGGER_SINGLE_THREADED
```

This sets the single thread mode of the debugger.

```
#define DEBUGGER_THREADING          DEBUGGER_MULTI_THREADED
```

This sets the multi-thread mode of the debugger.



Basically, in multithread mode, we just wait for some other thread to fill the LineBuf with a command and signal the semaphore. In single thread mode, we explicitly call AcpiOsGetLine to get a command line.

## 12.5 Command Overview

There are six classes of commands supported by the debugger:

1. The **General-Purpose** commands are available in all modes of the debugger. These commands provide the basic functionality of loading tables, dumping internal data structures, and starting the execution of control methods.
2. The **Namespace Access** commands are always available. These commands provide information about the currently loaded ACPI namespace.
3. The **Control Method Execution** commands are available only during the single-step execution of control methods. These commands allow the display and modification of method arguments and local variables, control method disassemble, and the setting of method breakpoints
4. The **Hardware-Related** commands are intended to simulate hardware events such as Fixed events, GPEs, and SCIs by invoking the dispatch code for the event. This will in turn invoke any host-installed handlers.
5. The **File I/O** commands are available only if a filesystem is available to the debugger.
6. The **Debug Test** commands provide various namespace tests.

## 12.6 Command Summary

### General-Purpose Commands:

Allocations	Display list of current memory allocations
Dump <Address> <Namepath> [Byte Word Dword Qword]	Display ACPI objects or memory
EnableAcpi	Enable ACPI (hardware) mode
Handlers	Info about global handlers
Help [Command]	This help screen or individual command
History	Display command history buffer
Level <DebugLevel>] [console	Get/Set debug level for file or console
Locks	Current status of internal mutexes
Osi [Install Remove <name>]	Display or modify global _OSI list
Quit or Exit	Exit this command
Stats <SubCommand>	Display namespace and memory statistics
Allocations	Display list of current memory allocations
Memory	Dump internal memory lists
Misc	Namespace search and mutex stats
Objects	Summary of namespace objects
Sizes	Sizes for each of the internal objects
Stack	Display CPU stack usage
Tables	Info about current ACPI table(s)
Tables	Display info about loaded ACPI tables
Unload <Namepath>	Unload an ACPI table via namespace object
! <CommandNumber>	Execute command from history buffer
!!	Execute last command again

### Namespace Access Commands:

Businfo	Display system bus info
Disassemble <Method>	Disassemble a control method



Find <AcpiName> (? is wildcard)	Find ACPI name(s) with wildcards
Integrity	Validate namespace integrity
Methods	Display list of loaded control methods
Namespace [Object] [Depth]	Display loaded namespace tree/subtree
Notify <Object> <Value>	Send a notification on Object
Objects <ObjectType>	Display all objects of the given type
Owner <OwnerId> [Depth]	Display loaded namespace by object owner
Paths	Display full pathnames of namespace objects
Predefined	Check all predefined names
Prefix [<NamePath>]	Set or Get current execution prefix
References <Addr>	Find all references to object at addr
Resources [DeviceName]	Display Device resources (no arg = all devices)
Set N <NamedObject> <Value>	Set value for named integer
Template <Object>	Format/dump a Buffer/ResourceTemplate
Terminate	Delete namespace and all internal objects
Type <Object>	Display object type

**Control Method Execution Commands:**

Arguments (or Args)	Display method arguments
Breakpoint <AmlOffset>	Set an AML execution breakpoint
Call	Run to next control method invocation
Debug <Namepath> [Arguments]	Single Step a control method
Evaluate	Synonym for Execute
Execute <Namepath> [Arguments]	Execute control method
Hex Integer	Integer method argument
"Ascii String"	String method argument
(Hex Byte List)	Buffer method argument
[Package Element List]	Package method argument
Go	Allow method to run to completion
Information	Display info about the current method
Into	Step into (not over) a method call
List [# of Aml Opcodes]	Display method ASL statements
Locals	Display method local variables
Results	Display method result stack
Set <A L> <#> <Value>	Set method data (Arguments/Locals)
Stop	Terminate control method
Thread <Threads><Loops><NamePath>	Spawn threads to execute method(s)
Trace <method name>	Trace method execution
Tree	Display control method calling tree
<Enter>	Single step next AML opcode (over calls)

**Hardware Related Commands:**

Event <F G> <Value>	Generate AcpiEvent (Fixed/GPE)
Gpe <GpeNum> <GpeBlock>	Simulate a GPE
Gpes	Display info on all GPEs
Sci	Generate an SCI
Sleep [SleepState]	Simulate sleep/wake sequence(s) (0-5)

**File I/O Commands:**

Close	Close debug output file
Load <Input Filename>	Load ACPI table from a file
Open <Output Filename>	Open a file for debug output

**Debug Test Commands:**

Test <TestName>	Invoke a debug test
Objects	Read/write/compare all namespace data objects
Predefined	Execute all ACPI predefined names (_STA, etc.)



## 12.7 General Purpose Commands

### 12.7.1 Allocations

#### Memory allocation status

##### SYNTAX

- allocations

This command dumps the current status of the dynamic memory allocations, as maintained by the ACPICA subsystem debug memory allocation tracking mechanism. Primarily used to detect memory leaks, the mechanism tracks the allocation and freeing of each memory block, and maintains statistics on the amount of memory allocated, the number of allocations, etc.

### 12.7.2 Dump

#### Display objects and memory

##### SYNTAX

- dump <Address> | <Namepath> [Byte | Word | Dword | Qword]

A generic command to dump all internal ACPI objects and memory. The operand can be a namespace name, a pointer to an ACPI object, or a pointer to random memory in the current address space. The command determines the type of ACPI object and decodes it into the appropriate fields

### 12.7.3 Exit

#### Terminate

##### SYNTAX

- exit

Terminate the ACPICA subsystem and exit the debugger.

### 12.7.4 Handlers

#### Display information about currently installed handlers

##### SYNTAX

- handlers

Displays information about all currently installed global handlers.

Example:





## Operation Region Handlers:

SystemMemory	(00)	: User	(00420420)
SystemIO	(01)	: User	(00420420)
PCI_Config	(02)	: Default	(00440F20)
EmbeddedControl	(03)	: User	(00420420)
SMBus	(04)	: User	(00420420)
SystemCMOS	(05)	: None	
PCIBARTarget	(06)	: User	(00420420)
IPMI	(07)	: User	(00420420)
GeneralPurposeIo	(08)	: User	(00420420)
GenericSerialBus	(09)	: User	(00420420)
DataTable	(7E)	: Default	(00441160)
FunctionalFixedHW	(7F)	: User	(00420420)
User-defined ID	(E4)	: User	(00420420)
User-defined ID	(80)	: User	(00420420)

## Fixed Event Handlers:

PM_Timer	(00)	: None	
GlobalLock	(01)	: User	(0041FEB0)
PowerButton	(02)	: None	
SleepButton	(03)	: None	
RealTimeClock	(04)	: User	(0041FEB0)

## Miscellaneous Global Handlers:

System Notifications	: User	(00480370)
Device Notifications	: User	(00480D30)
ACPI Table Events	: User	(00480D3C)
Control Method Exceptions	: User	(004805B0)
OSI Invocations	: User	(00480CE8)

## 12.7.5 Help

**Get help****SYNTAX**

- help

Displays a help screen with the syntax of each command and a short description of each.

## 12.7.6 History (! And !!)

**Command line recall****SYNTAX**

- history
- ! <Command Number>
- !!



last few commands. The “!” command can be used to select and re-execute a particular command from the numbered command buffer, or the “!!” command can be used to simply re-execute the immediately previous command.

## 12.7.7 Level

### Set debug output level

#### SYNTAX

```
- level [<DebugLevel>] [console]
```

Sets the global debug output level of the ACPICA subsystem for both output directed to a file and output to the console.

## 12.7.8 Locks

### Display mutex info and status

#### SYNTAX

```
- locks
```

This command displays information and current status of the various mutexes used for internal synchronization.

## 12.7.9 Osi

### Display or modify the current list of supported interfaces for the \_OSI method

#### SYNTAX

```
- osi [Install|Remove <interface name>]
```

This command displays or modifies the current contents of the global list of \_OSI interfaces that are supported.

#### SUBCOMMANDS

```
- osi
```

The standalone command will display the entire global list of \_OSI interfaces.

```
- osi install "My interface"
```

Installs an interface name into the global list.

```
- osi remove "Windows 2000"
```

Removes an interface from the global list.



## 12.7.10 Quit

### Terminate

#### SYNTAX

- quit

Terminate the current execution mode. If executing (single stepping) a control method, the method is immediately aborted with an exception and the debugger returns to the normal command line mode. If no control method is executing, the ACPICA subsystem is terminated and the debugger exits.

## 12.7.11 Stats

### Namespace statistics

#### SYNTAX

- stats [Allocations|Memory|Misc|Objects|Sizes|Stack|Tables]

Display namespace statistics that were gathered when the namespace was loaded. This includes information about the number of objects and their types, the amount of dynamic memory required, and the number of search operations performed on the namespace database.

#### SUBCOMMANDS

Allocations: Display a list of current dynamic memory allocations

Memory: Dump internal memory lists (If ACPICA memory cache is configured)

Misc: Namespace search and mutex use statistics

Objects: Summary of namespace objects

Sizes: Memory allocation sizes for each of the internal objects

Stack: Display CPU stack usage

Tables: Memory information about currently loaded ACPI tables

## 12.7.12 Tables

### Display ACPI table info

#### SYNTAX

- tables

This command displays information about each of the loaded ACPI tables. It uses the internal AcpiTbPrintTableHeader function.



## 12.7.13 Unload

### Unload table

#### SYNTAX

```
- unload <TableSignature> [Instance]
```

Unload an ACPI Table <Not implemented>

## 12.8 Namespace Access Commands

### 12.8.1 BusInfo

#### Display system bus information

#### SYNTAX

```
- businfo
```

This command displays information about all device objects that have a corresponding \_PRT method. Information includes the \_ADR, \_HID, \_UID, and \_CID.

### 12.8.2 Disassemble

#### Disassemble a control method

#### SYNTAX

```
- disassemble <Method>
```

This command will disassemble the input method to the original ASL code.

### 12.8.3 Find

#### Find names in the Namespace

#### SYNTAX

```
- find <name>
```

Find an ACPI name or names within the current ACPI namespace. All names that match the given name are displayed as they are found in the namespace. Names are up to four characters, and wildcards are supported. A '?' in the name will match any character. Thus, the wildcarded name "A???" will match all names in the namespace that begin with the letter "A".



## 12.8.4 Integrity

### Validate namespace

#### SYNTAX

- integrity

This command validates the integrity of the entire loaded namespace. It walks the entire namespace and checks each namespace node for correctness.

## 12.8.5 Methods

### List all control methods

#### SYNTAX

- methods

Displays a list of all control methods (and their full pathnames) that are contained within the current ACPI namespace. (Alias for the command “Object Methods”.)

## 12.8.6 Namespace

### Display the loaded ACPI namespace

#### SYNTAX

- namespace [<Address> | <Namepath>] [Depth]

Dump all or a portion of the current ACPI namespace. If given with no parameter, this command displays the entire namespace, one named object per line with information about each object. If given the name of an object or a pointer to an object, it displays the subtree rooted by that object.

## 12.8.7 Notify

### Generate a Notify

#### SYNTAX

- notify <Namepath> <Value>

Generates a notify on the specified device. This means that the notify handler for the device is invoked with the parameters specified.



## 12.8.8 Objects

### Display typed objects

#### SYNTAX

- objects <Object Type>

Display objects within the namespace of the requested type.

The ObjectType parameter must be one of the following:

ANY  
INTEGERS  
STRINGS  
BUFFERS  
PACKAGES  
FIELDS  
DEVICES  
EVENTS  
METHODS  
MUTEXES  
REGIONS  
POWERRESOURCES  
PROCESSORS  
THERMALZONES  
BUFFERFIELDS  
DDBHANDLES  
DEBUG  
REGIONFIELDS  
BANKFIELDS  
INDEXFIELDS  
REFERENCES  
ALIAS

## 12.8.9 Owner

### Display namespace by owner ID

#### SYNTAX

- owner <Owner ID> [Depth]

Display objects within the namespace owned by the requested Owner ID.



## 12.8.10 Paths

**Display the full pathnames of all objects in ACPI namespace**

### SYNTAX

- paths

Dumps the full pathnames and object types of all objects in the ACPI namespace. Alternative to the **namespace** command.

## 12.8.11 Predefined

**Display and check all predefined methods/objects**

### SYNTAX

- predefined

This command displays and validates all predefined methods and objects (names that start with underscore and are predefined by the ACPI specification.)

The validation checks the input argument count (if object is a control method) against the count defined in the ACPI spec.

## 12.8.12 Prefix

**Get or Set current prefix**

### SYNTAX

- prefix [<NamePath>]

Sets the pathname prefix that is prepended to namestrings entered into the debug and execute commands. This command is the equivalent of the “CD” command.

## 12.8.13 References

**Find all references to an object within the namespace**

### SYNTAX

- references <Address>

Display all references to the object at the specified address.



## 12.8.14 Resources

### Display device resources

#### SYNTAX

```
- resources <Address>
```

Display resource lists (\_PRS, \_CRS, \_AEI, etc.) for the Device object at the specified address.

## 12.8.15 Set N

### Set object value

#### SYNTAX

```
- set N <NamedObject> <Value>
```

This command sets the value of a namespace object.

## 12.8.16 Template

### Display a Resource Template (buffer)

#### SYNTAX

```
- template <Address>
```

Disassemble a ResourceTemplate at the input address. The object must be a buffer.

## 12.8.17 Terminate

### Shutdown ACPICA subsystem

#### SYNTAX

```
- terminate
```

Shutdown the ACPICA subsystem, but don't exit the debugger. This command is useful to find memory leaks in the form of objects left over after the subsystem deletes the entire namespace and all known internal objects. Any objects left over after shutdown are displayed and may be examined.





## 12.8.18 Type

### Display object type

#### SYNTAX

- type <Object>

This command displays the type of a namespace object.

## 12.9 Control Method Execution Commands

During single stepping of a control method, the following commands are available. The debugger enters a slightly different command mode (as indicated by the ‘%’ prompt) when single stepping a control method to indicate that these commands are now available

### 12.9.1 Arguments

#### Display Method arguments

#### SYNTAX

- arguments

- args

Display all arguments to the currently executing control method

### 12.9.2 Breakpoint

#### Set control method breakpoint

#### SYNTAX

- breakpoint <AML Offset>

Set a breakpoint at the AML offset given. When execution reaches this offset, execution is stopped and the debugger is entered.

### 12.9.3 Call

#### Run to next call

#### SYNTAX

- call

Step execution of the current control method until the next method invocation (call) is encountered.



## 12.9.4 Debug

### Single step a control method

#### SYNTAX

```
- debug <Namepath> [Arg0 Arg1 ...]
```

Begin execution of a control method in single step mode. Each AML opcode and its associated operand(s) is disassembled and displayed before execution. A single carriage return (Enter) single steps to the next AML opcode. The values of the arguments and the value of the return value (if any) are displayed for each opcode. See the section below, “Specifying Method Arguments” for details and syntax for Arg0...Argn.

## 12.9.5 Execute

### Execute a control method

#### SYNTAX

```
- execute <Namepath> [Arg0 Arg1 ...]
```

Execute a control method. This command begins execution of the named method and lets it run to completion without single stepping. The return result if any is displayed after execution completes.

Supported objects for method arguments are Integers, Strings, Buffers, and Packages

### 12.9.5.1 Specifying Method Arguments

For both the *Debug* and *Execute* commands, up to seven arguments (ACPI maximum) for the control method may be specified on the command line. The following data types are supported:

- Integers
- Strings
- Buffers
- Packages (nested packages are supported)

The data types and command line syntax are described below. Individual arguments should be separated by spaces.

If a method requires one or more arguments and either no or too few arguments are specified on the command line, the debugger will create default arguments for the missing arguments. The default arguments are of type *Integer*.

#### Integers

This is the simplest data type and consists of a integer hex value. The maximum data width is either 32 bits or 64 bits, depending on the version of the loaded DSDT. Version 1 or less uses 32-bit integers. Version 2 or greater allows full 64-bit integers.

#### Strings

Strings are specified by surrounding the string with quotes.



### Buffers

Buffers are specified via a list of hex byte values (separated by either commas or spaces). The list must be surrounded by parentheses.

### Packages

Packages are specified via a list of package elements (Integers, Strings, Buffers, and Packages are supported). The list must be surrounded by brackets “[ ]”.

### Example

This example shows a control method invocation with 4 arguments in this order: An integer, a string, a buffer, and a nested package. The package object contains an integer, a string, a buffer, and a nested package containing a single integer.

```
Execute TEST 1234 "abcd" (11 22 33 44) [5678 "efgh" (55 66 77 88) [9876]]
```

## 12.9.6 Go

### Run method to next breakpoint

#### SYNTAX

- go

Cease single step mode and let the control method run freely until either a breakpoint is reached or the method terminates.

## 12.9.7 Information

### Info about a control method

#### SYNTAX

- information

## 12.9.8 Into

### Step into call

#### SYNTAX

- into

Step into a control method invocation instead of over the call. The default single step behavior is to step **over** control method calls, meaning that the call is executed and single stepping resumes after the call returns. Use this command to single step the execution of a called control method.



## 12.9.9 List

### Disassemble AML code

#### SYNTAX

```
- list [<Opcode count>]
```

Disassemble the AML code of the current control method from the current AML offset for the length given. Useful for finding interesting places to set breakpoints.

## 12.9.10 Locals

### Display method local variables

#### SYNTAX

```
- locals
```

Display the current values of all of the local variables for the current control method. When stepping into a control method invocation, the locals of the newly invoked method are displayed during the time that method is single stepped.

## 12.9.11 Results

### Display method result stack

#### SYNTAX

```
- results
```

Display the current contents of the internal “Result Stack” for the control method.

## 12.9.12 Set

### Set arguments or locals

#### SYNTAX

```
- set Arg|Local <ID> <Value>
```

Set the value of any of a method’s arguments or local variables. ID is 0-7 for method locals and 0-6 for method arguments.



### 12.9.13 Stop

**Stop method****SYNTAX**

- stop

Terminate the currently executing control method

### 12.9.14 Thread

**Execute a control method with multiple threads****SYNTAX**

- thread <number of threads> <number of loops> <Pathname>

Create the specified number of threads to execute the control method at <Pathname>. Each thread will execute the method <number of loops> times. The command waits until all threads have completed before returning.

### 12.9.15 Trace

**Set a method trace****SYNTAX**

- trace <method name>

This command sets a trace command that will trace the input method if and when it is executed. Uses the AcpiDebugTrace interface.

### 12.9.16 Tree

**Display calling tree****SYNTAX**

- tree

Display the calling tree of the current method (Displays all nested control method invocations.)



## 12.10 Hardware-Related Commands

### 12.10.1 Event

#### Generate an ACPI Event

##### SYNTAX

- event <Value>

Generate an ACPI event to test event handling <NOT IMPLEMENTED>

### 12.10.2 Gpe

#### Generate a GPE

##### SYNTAX

- gpe <Block Address> <GPE number>

Generate a GPE at the GPE number within the GPE block specified at the Block Address. Use 0 for the block address to generate a GPE within the permanent FADT-defined GPE blocks (GPE0 and GPE1.).

### 12.10.3 Gpes

#### Display GPE block information

##### SYNTAX

- gpes

Display information on all GPE blocks, including the FADT-defined GPE blocks (GPE0 and GPE1) and all loaded GPE Block Devices.

### 12.10.4 Sci

#### Generate an ACPI System Control Interrupt

##### SYNTAX

- sci

Generate an ACPI SCI to test SCI handling and handler dispatch. Invokes all host-installed handlers.



## 12.10.5 Sleep

### Simulate ACPI Sleep/Wake sequences

#### SYNTAX

- sleep <SleepState>

This command simulates the sleep/wake sequence. SleepState should be an integer, 0-5. The following ACPICA interfaces are executed:

AcpiEnterSleepStatePrep  
AcpiEnterSleepState  
AcpiLeaveSleepState

If the optional SleepState is not specified (command is invoked with no arguments), then all of the possible sleep states (0-5) are executed.

## 12.11 File I/O Commands

### 12.11.1 Close

#### Close debug output file

#### SYNTAX

- close

Close the debug output file, if one is currently open. Using Exit or Quit to terminate the debugger will automatically close any open file.

### 12.11.2 Load

#### Load ACPI table

#### SYNTAX

- load <Filename>

Load an ACPI table into the namespace from a file.

### 12.11.3 Open

#### Open debug output file

#### SYNTAX

- open <Filename>



Open a file for debug output.

## 12.12 Debug Test Commands

### 12.12.1 Test Objects

**Exercise namespace data objects (read/write/compare)**

#### SYNTAX

- test objects

Perform a read/write/compare on all “data” objects in the namespace – Integers, Strings, Buffers, FieldUnits, and BufferFields. Restores the original value of each object.

### 12.12.2 Test Predefined

**Execute all predefined ACPI names in the namespace (\_STA, etc.)**

#### SYNTAX

- test predefined

Executes all predefined names in the namespace (all names that begin with an underscore). Provides arguments that are appropriate for each name, as necessary.





*This page intentionally left blank.*