

## **VS-300 Computer System**

### **PROPRIETARY INFORMATION NOTICE**

**This document contains trade secrets and other confidential information, which are the valuable property of Wang Laboratories, Inc. This document is provided in confidence for the sole purpose of facilitating the use and service of the related equipment and/or software. Neither this document nor any of its contents may be disclosed to unauthorized persons, or copied, revealed, or used in whole or in part for any other purpose without the prior written permission of Wang Laboratories, Inc.**

**Customer Engineering  
Product Maintenance Manual**

**741-1634**

**COMPANY CONFIDENTIAL**

# PUBLICATION UPDATE BULLETIN

TITLE:VS-300 Computer System

DATE: 03/21/86

This PUB affects: 741-1634  
742-1634

CLASS CODE: 6105

Previous Notice(s): None

-----  
**REASON FOR CHANGE:**

This PUB updates VS-300 IPL procedures and SCU software installation; adds Peripheral Band installation, a second dc distribution board, and diagnostics (including service log); updates the Illustrated Parts Breakdown; and makes general corrections.

-----  
**INSTRUCTIONS:**

Remove and insert attached pages and/or microfiche as follows:

	REMOVE PAGES	INSERT PAGES
1.	v thru xv	v thru xvi
2.	3-1 thru 3-10	3-1 thru 3-10
3.	3-19/20	3-19/20
4.	3-25 thru 3-31	3-25 thru 3-32
5.	4-11 thru 4-14	4-11 thru 4-14
6.	4-21 thru 4-34	4-21 thru 4-34
7.	None	4-42a/42b
8.	5-7/8	5-7/8
9.	5-17/18	5-17/18
10.	5-21 thru 5-28a	5-21 thru 5-28a
11.	5-31/32	5-31/32
12.	5-35 thru 5-38	5-35 thru 5-38
13.	5-41/42	5-41/41a
14.	None	5-41b/42
15.	None	5-50a/b/c
16.	5-55/56	5-55/56
17.	None	5-56a



LABORATORIES, INC.

ONE INDUSTRIAL AVENUE LOWELL MASSACHUSETTS 01851 TEL (617) 459 5000 TWX 710 343 6769 TELEX 94 7421

Remove and insert attached pages and/or microfiche as follows:

	REMOVE PAGES	INSERT PAGES
18.	5-57/58	5-57/58
19.	6-1 thru 6-5	6-1 thru 6-5
20.	6-9/10	6-9/10
21.	None	6/15
22.	7-1 thru 7-12	7-1 thru 7-12
23.	7-53/54	7-53/54
24.	7-57	7-57 thru 7-61

	REMOVE FICHE	INSERT FICHE
1.	1 thru 4	1 thru 4
2.		
3.		
4.		

These pages constitute a permanent record of revisions; place them directly following title page.

### COMPANY PROPRIETARY STATEMENT

This document is the property of Wang Laboratories, Inc. All information contained herein is considered Company Proprietary, and its use is restricted solely to assisting you in servicing Wang products. Neither this document nor its contents may be disclosed, copied, revealed, or used in whole or in part for any other purpose without the prior written permission of Wang Laboratories, Inc. This document must be returned upon request of Wang Laboratories, Inc.

© Copyright 1986, Wang Laboratories, Inc.

**COMPANY CONFIDENTIAL**

## PREFACE

This document is the Product Maintenance Manual (PMM) for the Wang VS-300 Computer System. The manual is organized in accordance with Customer Engineering Technical Documentation's approved PMM outline. The scope of this manual reflects the type of maintenance philosophy selected for this product.

The purpose of this manual is to provide the Wang-trained Customer Engineer (CE) with sufficient instructions to operate, troubleshoot, and repair the VS-300 Computer System. The manual will be updated on a regular schedule or as necessary. Such updates will be published either as Publication Update Bulletins (PUBs) or as full revisions.

### First Edition (September, 1985)

Use of the material in this document is authorized only for the purpose stated in the Preface, above.

© Copyright 1985, Wang Laboratories, Inc.

## WARNING

\*\*\*\*\*  
\*  
\* DO NOT OPEN THE SWITCHING POWER SUPPLY UNDER ANY \*  
\* CIRCUMSTANCE. EXTREMELY DANGEROUS VOLTAGE AND \*  
\* CURRENT LEVELS (IN EXCESS OF 300 VOLTS DC AND UN- \*  
\* LIMITED CURRENT) ARE PRESENT WITHIN THE POWER SUPPLY. \*  
\*  
\* DO NOT ATTEMPT TO REPAIR THE SWITCHING POWER \*  
\* SUPPLY; IT IS FIELD REPLACEABLE ONLY. \*  
\*  
\* AFTER POWERING THE UNIT DOWN AND DISCONNECTING THE AC \*  
\* POWER CONNECTOR FROM THE POWER SOURCE RECEPTACLE, \*  
\* ALLOW ONE MINUTE BEFORE REMOVING THE POWER SUPPLY TO \*  
\* PROVIDE ADEQUATE TIME FOR ANY RESIDUAL VOLTAGE TO \*  
\* DRAIN THROUGH THE BLEEDER RESISTORS. \*  
\*  
\*\*\*\*\*

## WARNING

\*\*\*\*\*  
\*  
\* THIS COMPUTER EQUIPMENT HAS BEEN VERIFIED AS FCC CLASS A. \*  
\*  
\*\*\*\*\*

IN ORDER TO MAINTAIN COMPLIANCE WITH FCC CLASS A  
VERIFICATION, THE FOLLOWING CONDITIONS MUST BE  
ADHERED TO DURING NORMAL OPERATION OF EQUIPMENT.

- ALL COVERS MUST BE ON SYSTEM AND SECURED IN THE PROPER MANNER.
- ALL INTERNAL CABLES MUST BE ROUTED IN THE ORIGINAL MANNER  
WITHIN THE CABLE CLAMPS PROVIDED FOR THAT PURPOSE.
- ALL EXTERNAL CABLING MUST BE SECURED AND THE PROPER  
CABLE USED TO ENSURE THAT CABLE SHIELDING IS PROPERLY  
GROUNDED TO THE CABLE CLAMPS PROVIDED.
- ALL HARDWARE MUST BE PROPERLY SECURED.

The last page before the back cover is a comment sheet.  
Please take the time to fill out the comment sheet and return it,  
via the Home Office mail pouch, addressed to:

Wang Laboratories, Inc.  
Customer Engineering Technical Documentation  
M/S 8237  
437 South Union Street  
Lawrence, Mass.  
01843-9984

## TABLE OF CONTENTS

<b>CHAPTER 1 INTRODUCTION</b>		<u>Page</u>
To be provided in the Illustrated Maintenance Manual		
<b>CHAPTER 2 THEORY OF OPERATION</b>		
To be provided in the Illustrated Maintenance Manual		
<b>CHAPTER 3 OPERATION</b>		<u>Page</u>
3.1	General .....	3-1
3.2	Controls .....	3-1
3.3	Indicators .....	3-3
3.4	Power Distribution Assembly and Controls .....	3-9
3.5	Power Supplies and Controls .....	3-9
3.6	Optional Battery Backup .....	3-14
3.7	Control Panel .....	3-17
3.7.1	On/Off Pushbuttons .....	3-17
3.7.2	System Reset Pushbutton .....	3-17
3.7.3	Operator Console Reset Pushbutton .....	3-17
3.7.4	Key Switch .....	3-17
3.8	Main Memory Size .....	3-20
3.8.1	Main Memory Size Selection .....	3-20
3.9	IOC Switches .....	3-20
3.10	Importance of Following Power Up or Down Procedures .....	3-25
3.11	Power-Up and IPL Procedures .....	3-25
3.12	Standard Power-Down Procedure .....	3-30
3.13	Power Failure Procedure .....	3-32
<b>CHAPTER 4 INSTALLATION</b>		
4.1	General .....	4-1
4.2	Installation Site Check .....	4-1
4.3	Publications .....	4-2
4.4	Tools and Test Equipment .....	4-2
4.5	Unpacking .....	4-2
4.5.1	Claims Information .....	4-3
4.5.2	Unpacking The Mainframe .....	4-4
4.5.3	Unpacking The Peripherals .....	4-10
4.6	Mainframe Inspection .....	4-12
4.6.1	Peripheral Inspection .....	4-12
4.7	Software/Diagnostic Requirements .....	4-13
4.7.1	Software .....	4-13
4.7.2	Diagnostics .....	4-13
4.8	Mainframe Power Source Check .....	4-14
4.8.1	208-240 Volt AC Domestic Power Source .....	4-14



## TABLE OF CONTENTS (Cont'd)

4.8.1.1	Using Existing VS-100 Power Service .....	4-14
4.8.1.2	Installing New Power Service For VS-300s .....	4-15
4.8.2	Initial Main Frame Power-Up .....	4-16
4.8.3	DC Voltage Checks .....	4-16
4.8.3.1	Power Supply Adjustments .....	4-16
4.8.3.2	Power Supply Controller Adjustments .....	4-18
4.9	IPL Procedures .....	4-21
4.9.1	IPLing The VS-300 .....	4-21
4.9.2	1.03 SCU Software Installation .....	4-27
4.9.3	IPL Errors .....	4-30
4.9.4	Version Checking During IPL .....	4-31
4.10	Peripheral Interconnection .....	4-33
4.10.1	I/O Connector Assembly To IOC Cabling .....	4-34
4.10.2	Serial Connectors .....	4-34
4.10.3	Cable Concentrator .....	4-36
4.10.4	Disk Cable Connectors .....	4-37
4.10.5	Telecommunications Connectors .....	4-39
4.10.6	Kennedy Tape Drive Connectors .....	4-41
4.10.7	Telex Tape Drive Connectors .....	4-42
4.10.8	P-Band Connectors .....	4-42a
4.11	Remote Link (For 1.02 SCU Software) .....	4-43
4.11.1	Remote Link Specifications .....	4-43
4.11.2	Site Preparation For Remote Link .....	4-44
4.11.3	Remote Link Installation and Verification .....	4-44

## CHAPTER 5 MAINTENANCE

5.1	General .....	5-1
5.2	Preventive Maintenance .....	5-1
5.2.1	Special Tools .....	5-1
5.2.2	Materials .....	5-1
5.2.3	Preventive Maintenance Schedule .....	5-1
5.2.4	Electrical Adjustments .....	5-2
5.2.4.1	Power Supply Adjustments .....	5-2
5.2.4.2	Power Supply Controller Adjustments .....	5-4
5.2.4.3	Battery Backup Check .....	5-7
5.2.4.4	Low Battery Voltage Dropout Adjustment .....	5-8
5.2.4.5	Battery Backup Charging Power Supply Adjustment .....	5-9
5.2.5	Peripheral Preventive Maintenance .....	5-10
5.3	Corrective Maintenance .....	5-10
5.3.1	Special Tools .....	5-10
5.3.2	Removal and Replacement .....	5-11
5.3.2.1	Top Cover Removal and Replacement .....	5-11
5.3.2.2	Left Front Panel Removal and Replacement .....	5-13
5.3.2.3	Left and Right Side Panel Removal and Replacement .....	5-15
5.3.2.4	CP Circuit Board Removal and Replacement .....	5-16
5.3.2.4.1	210-8830 Floating Point Unit Removal .....	5-17
	and Replacement	

## TABLE OF CONTENTS (Cont'd)

5.3.2.4.2	210-8831 Central Processing Unit Removal ..... and Replacement	5-18
5.3.2.4.3	210-8832 Address Generation Unit Removal ..... and Replacement	5-19
5.3.2.4.4	210-8833 Address Translation Unit Removal ..... and Replacement	5-20
5.3.2.4.5	210-8835 Support Control Unit Removal ..... and Replacement	5-21
5.3.2.4.6	210-8834 Memory Control Unit Removal and Replacement .....	5-22
5.3.2.4.7	210-8703/210-8703-1 Main Memory Removal and Replacement ...	5-23
5.3.2.4.8	210-8836 System Bus Interface Removal and Replacement .....	5-24
5.3.2.5	IOC Circuit Board Removal and Replacement .....	5-25
5.3.2.5.1	23V97 (210-8609) Serial IOC Removal and Replacement .....	5-26
5.3.2.5.2	270-0975 Serial IOC APA .....	5-27
5.3.2.5.3	6550 Gate Array TC Controller Assembly ..... Removal and Replacement	5-28
5.3.2.5.4	23V98-1/2/3/4 (210-8785) Disk Drive IOC Removal ..... and Replacement	5-30
5.3.2.5.5	23V95-1 (210-8790) Kennedy Tape IOC Removal ..... and Replacement	5-32
5.3.2.5.6	23V95-2 (210-8789) Telex Tape IOC Removal ..... and Replacement	5-33
5.3.2.5.7	23V96 (210-8491) Multiline TC IOC Removal ..... and Replacement	5-34
5.3.2.5.8	270-1003 Multiline TC Back Panel Assembly .....	5-36
5.3.2.5.9	23V79 (210-8392) CIU BLANC IOC Removal ..... and Replacement	5-37
5.3.2.5.10	210-8391 CIU CAB Board Removal and Replacement .....	5-39
5.3.2.5.11	210-8142 10 MBPS Duobinary Modem Removal ..... and Replacement	5-40
5.3.2.5.12	270-0787 Single Channel 10MBPS RF Modem Removal ..... and Replacement	5-41
5.3.2.5.13	WangNet P-Band Modem Removal and Replacement .....	5-41a
5.3.2.6	Power Supply Controller Board Removal .....	5-42
5.3.2.7	Power Supply Controller Board Replacement .....	5-43
5.3.2.8	Battery Backup Board Removal .....	5-44
5.3.2.9	Battery Backup Board Replacement .....	5-45
5.3.2.10	Battery Backup Pack Removal .....	5-46
5.3.2.11	Battery Backup Pack Replacement .....	5-46
5.3.2.12	Battery Backup Charging Power Supply Removal .....	5-47
5.3.2.13	Battery Backup Charging Power Supply Replacement .....	5-47
5.3.2.14	Power Distribution Unit and AC On/Off Circuit ..... Breaker Removal	5-48
5.3.2.15	AC On/Off Circuit Breaker Replacement .....	5-50
5.3.2.16	Power Distribution Unit Replacement .....	5-50
5.3.2.16.1	Second DC Power Distribution Board Removal .....	5-50a
5.3.2.16.2	Second DC Power Distribution Board Replacement .....	5-50a
5.3.2.17	SCU Professional Computer (PC) Removal .....	5-51
5.3.2.18	SCU Professional Computer (PC) Replacement .....	5-51

## TABLE OF CONTENTS (Cont'd)

5.3.2.19	Control Panel Pushbutton Bulb Removal .....	5-53
	and Replacement	
5.3.2.20	Control Panel Assembly Removal .....	5-54
5.3.2.21	Control Panel Board Assembly Replacement .....	5-54
5.3.2.22	Multioutput Switching Power Supply Removal .....	5-55
5.3.2.23	Multioutput Switching Power Supply Replacement .....	5-57
5.3.2.24	Booster Switching Power Supply Removal .....	5-58
5.3.2.25	Booster Switching Power Supply Replacement .....	5-60

## CHAPTER 6 ILLUSTRATED PARTS BREAKDOWN

6.1	Scope .....	6-1
-----	-------------	-----

## CHAPTER 7 TROUBLESHOOTING

7.1	General .....	7-1
7.2	Off-Line Diagnostics .....	7-1
7.2.1	Power-up Diagnostics .....	7-1
7.2.2	Accessing Off-Line Diagnostics .....	7-2
7.2.3	Running Off-Line Diagnostics .....	7-5
7.2.3.1	HELP Menu .....	7-6
7.2.3.2	DCS Test Screens .....	7-6
7.2.3.3	IOC Diagnostic Switch Settings .....	7-8
7.2.3.3.1	Multiline TC IOC Diagnostic Switch Settings .....	7-9
7.2.3.3.2	Gate Array TC Controller Loopback Test Switch Settings ....	7-9
7.2.3.3.3	CIU BLANC IOC Switch Settings .....	7-10a
7.2.4	Off-Line Diagnostics Error Management .....	7-10b
7.2.4.1	Intermittent Error Looping .....	7-10b
7.2.4.2	I/O Bit Monitor Errors .....	7-10c
7.2.4.2.1	MLTC IOC Loopback Test Error Codes .....	7-10c
7.2.4.2.2	GATC Front Panel LED BIT Error Display .....	7-11
7.2.4.3	DCS Log .....	7-11
7.3	On-Line Diagnostics .....	7-12
7.3.1	VS On-Line VSTEST Monitor .....	7-12
7.3.1.1	Main Screen .....	7-12
7.3.1.2	Log Program Output Screen .....	7-13
7.3.1.3	Device Class Selection Screen .....	7-13
7.3.1.4	System Configuration Screens .....	7-13
7.3.1.5	Message Screen .....	7-15
7.3.2	VS On-Line Workstation Exerciser (WSEX) .....	7-15
7.3.2.1	Hardware Tested .....	7-15
7.3.2.2	Running WSEX .....	7-15
7.3.2.3	WSEX Automatic Tests .....	7-16
7.3.2.4	WSEX Interactive Tests .....	7-17
7.3.2.5	WSEX Error Codes .....	7-17
7.3.2.6	WSEX Error Messages .....	7-19
7.3.3	VS On-Line Disk Exerciser (DISKEX) .....	7-19

## TABLE OF CONTENTS (Cont'd)

7.3.3.1	Hardware Tested .....	7-19
7.3.3.2	Running DISKEX .....	7-20
7.3.3.3	DISKEX Tests .....	7-20
7.3.3.4	DISKEX Error Codes .....	7-21
7.3.3.5	DISKEX Error Messages .....	7-23
7.3.4	VS On-Line Printer Exerciser (PREX) .....	7-23
7.3.4.1	Hardware Tested .....	7-24
7.3.4.2	Running PREX .....	7-24
7.3.4.3	PREX Tests .....	7-24
7.3.4.4	PREX Error Codes .....	7-26
7.3.4.5	PREX Error Messages .....	7-27
7.3.5	VS On-Line Tape Exerciser (TPEX) .....	7-27
7.3.5.1	Hardware Tested .....	7-28
7.3.5.2	Running TPEX .....	7-28
7.3.5.3	TPEX Tests .....	7-28
7.3.5.4	TPEX Error Codes .....	7-29
7.4	Memory Dump Procedures .....	7-37
7.4.1	Control Mode Dump .....	7-37
7.4.1.1	Errors Requiring Control Mode Dump .....	7-37
7.4.1.2	Control Mode Dump Procedure .....	7-39
7.4.1.3	Forcing The System Into Control Mode For Dump .....	7-44
7.4.1.4	Control Mode Dump Stops .....	7-45
7.4.2	Continuable and Snapshot Dumps .....	7-46
7.4.2.1	Requirements For Continuable and Snapshot Dumps .....	7-46
7.4.2.2	Invoking The Snapshot Dump .....	7-47
7.4.2.3	Running Continuable and Snapshot Dumps .....	7-47
7.4.2.4	Continuable Dump and Automatic IPL .....	7-48
7.5	Troubleshooting Procedures .....	7-50
7.6	Error Log .....	7-58
7.7	Service Log .....	7-60
7.7.1	Accessing the Service Log .....	7-60
7.7.2	Database Options .....	7-61

<b>APPENDIX A</b>	VS-300 Signal Mnemonics, System Errors Requiring a .....	A-1
	Control Mode Dump, System Errors Causing Continuable Dump, Version Checking Status Error Messages, I/O Controllers and Supported Devices, and VS-300 10 Megabyte Duo-binary Modem Channel Allocations	

## LIST OF ILLUSTRATIONS

<u>Figure</u>	<u>Title</u>	<u>Page</u>
3-1	Front View of Main Frame .....	3-7
3-2	Rear View of Main Frame .....	3-8
3-3	Power Distribution Assembly .....	3-10
3-4	Multioutput Power Supply .....	3-11
3-5	Booster Power Supply .....	3-11
3-6	Front View - Power Supply Controller and Battery Backup Assembly .....	3-12
3-7	Power Supply Controller Board, (Rev. 0 Version) .....	3-13
3-8	Rear View - Battery Backup Assembly .....	3-15
3-9	Battery Backup Board .....	3-16
3-10	Control Panel and Diskette Drive .....	3-18
3-11	Control Panel Controls and Indicators .....	3-19
3-12	10 MBPS Modem Back Panel Assembly .....	3-21
3-13	10 MBPS Modem Controls and Indicators .....	3-22
3-14	Multiline TC Back Panel Indicators .....	3-23
3-15	6550 Gate Array TC Back Panel Controls .....	3-24
3-16	Console Processor Screen .....	3-26
3-17	System Console Default Screen .....	3-27
3-18	System Initialization Screen .....	3-28
3-19	SYSGEN Configuration Screen .....	3-28
4-1	Unpacking the Main Frame (1 of 6) .....	4-4
4-2	Unpacking the Main Frame (2 of 6) .....	4-5
4-3	Unpacking the Main Frame (3 of 6) .....	4-6
4-4	Unpacking the Main Frame (4 of 6) .....	4-7
4-5	Unpacking the Main Frame (5 of 6) .....	4-8
4-6	Unpacking the Main Frame (6 of 6) .....	4-9
4-7	Rear View of Main Frame .....	4-11
4-8	208-240 Volt AC Power Source Requirements for VS-300 .....	4-14
	Main Frames Using Existing VS-100 Power Service	
4-9	208-240 Volt AC Power Source Requirements for .....	4-15
	New Power Service For VS-300 Main Frames.	
4-10	Multioutput Power Supply .....	4-17
4-11	Booster Power Supply .....	4-17
4-12	Power Supply Controller Board, (Rev. 0 Version) .....	4-19
4-13	Environment Test Screen .....	4-20
4-14	Console Processor Screen .....	4-22
4-14a	Modified System Console Screen in Service Mode .....	4-23
4-15	System Console Default Screen .....	4-23a
4-16	System Initialization Screen .....	4-23b
4-17	SYSGEN Configuration File Screen .....	4-24
4-18	SCU Install Utility Menu .....	4-28
4-19	SCU Install Utility Screen .....	4-29
4-20	Sample Version Warning Screen .....	4-32
4-21	VS-300 Basic I/O Panel Positions .....	4-33
4-22	Active Port Assemblies BNC/TNC Connector Assembly .....	4-35

## LIST OF ILLUSTRATIONS (Cont'd)

4-23	P-Band Modem Connections .....	4-35
4-24	VS-300 Cable Concentrator Rear Panel .....	4-36
4-25	Cable Concentrator Connections .....	4-36
4-26	270-1006 "A" and "B" Cable Connector Assembly .....	4-38
4-27	Multiline TC (MLTC) Connector Panel .....	4-39
4-28	Gate Array TC Connector Panel .....	4-40
4-29	270-1005 Kennedy Tape Drive Connector Assembly .....	4-41
4-30	270-1007 Telex Tape Drive Connector Assembly .....	4-42
4-30a	WangNet P-Band Modem Assembly .....	4-42a
4-30b	WangNet P-Band Modem Rear Panel Assembly .....	4-42b
4-31	Modem/Phone Connections and Modem Switch Settings .....	4-45
4-32	SCU Main Menu .....	4-46
4-33	SCU Console Mode Menu With Remote Link .....	4-47
4-34	SCU Console Mode Menu Without Remote Link .....	4-47
4-35	SCU Main Menu .....	4-48
4-36	SCU Maintenance Menu .....	4-48
5-1	Multioutput Power Supply .....	5-3
5-2	Booster Power Supply .....	5-3
5-3	Power Supply Controller Board. (Rev. 0 Version) .....	5-5
5-4	Environment Test Screen .....	5-6
5-5	Battery Backup Time Switch SW4 Settings .....	5-7
5-5a	Battery Backup Charging Power Supply Adjustment .....	5-9
5-6	Top Cover Removal .....	5-11
5-7	Top Cover Removal .....	5-12
5-8	Top Cover Removal .....	5-12
5-9	Left Front Panel Removal .....	5-13
5-10	Left Front Panel Removal .....	5-14
5-11	Left Front Panel Removal .....	5-14
5-12	Left and Right Side Panel Removal .....	5-15
5-13	VS-300 Card Cage .....	5-16
5-14	210-8830 Floating Point Unit .....	5-17
5-15	210-8831 Central Processing Unit .....	5-18
5-16	210-8832 Address Generation Unit .....	5-19
5-17	210-8833 Address Translation Unit .....	5-20
5-18	210-8835 Support Control Unit .....	5-21
5-19	210-8834 Memory Control Unit .....	5-22
5-20	210-8703 Main Memory .....	5-23
5-21	210-8836 System Bus Interface .....	5-24
5-22	IOC Diagnostic Switch Setting For Power Up .....	5-25
5-23	23V97 Serial IOC .....	5-26
5-24	270-0975 APA .....	5-27
5-25	Daisy Chained APA Assemblies .....	5-27
5-26	270-1016 6550 Gate Array TC Back Panel Assembly .....	5-28
5-27	210-8714 CPU/Gate Array Board .....	5-29
5-28	210-8714 CPU/Gate Array Board With Cabling .....	5-29
5-29	23V98 Disk Drive IOC .....	5-30
5-30	Disk Drive Device Type Switch Settings. ....	5-31
5-31	23V95-1 Kennedy Tape IOC .....	5-32
5-32	23V95-2 Telex Tape IOC .....	5-33

## LIST OF ILLUSTRATIONS (Cont'd)

5-33	23V96 Multiline TC (MLTC) IOC .....	5-34
5-34	270-1003 Multiline TC Back Panel Assembly .....	5-36
5-35	270-1003 Multiline TC Back Panel Assembly with Cabling ....	5-36
5-36	23V79 CIU BLANC IOC .....	5-37
5-37	BLANC IOC Functions Switch (L272) Normal Settings .....	5-38
5-38	23V79 CIU CAB Board .....	5-39
5-39	5-Channel 10 Megabit Duobinary Modem .....	5-40
5-39a	Single Channel 10 Megabit Duobinary Modem .....	5-41
5-39b	WangNet P-Band Modem Panel Assembly .....	5-41a
5-39c	WangNet P-Band Modem Removal .....	5-41b
5-40	Power Supply Controller Board .....	5-42
5-41	Battery Backup Time Switch SW4 Settings .....	5-43
5-42	210-8717 Battery Backup Board Removal .....	5-44
5-43	210-8717 Battery Backup Board Removal .....	5-45
5-44	Battery Pack Removal .....	5-46
5-45	Battery Backup Charging Power Supply Removal .....	5-47
5-46	PDU Removal .....	5-49
5-47	PDU Removal .....	5-49
5-48	AC On/Off Circuit Breaker Removal .....	5-50
5-48a	Second DC Distribution Board Removal .....	5-50b
5-48b	Second DC Distribution Board Removal .....	5-50c
5-49	SCU Professional Computer Removal and Replacement .....	5-52
5-50	Control Panel Pushbutton Bulb Removal and Replacement ....	5-53
5-51	210-8711 Control Panel Board Removal .....	5-54
5-52	Multioutput Power Supply Wiring Connections .....	5-56
	(With Original Single DC Distribution Board)	
5-52a	Multioutput Power Supply Wiring Connections .....	5-56a
	(With New Second DC Distribution Board)	
5-53	Booster Power Supply Wiring Connections .....	5-59
6-1	VS-300 Cable Interconnection Diagram .....	6-5
6-2	VS-300 Front View .....	6-7
6-3	VS-300 Rear View With Covers On .....	6-8
6-4	VS-300 Rear View With Covers Off .....	6-9
6-5	VS-300 Battery Backup Section .....	6-10
6-6	VS-300 Card Cage .....	6-11
6-7	VS-300 Multiline TC Back Panel Without Cables .....	6-12
6-8	VS-300 Multiline TC Back Panel With Cables .....	6-12
6-9	VS-300 Gate Array TC Back Panel Assembly .....	6-13
6-10	VS-300 Gate Array TC Back Panel Assembly With Cables .....	6-13
6-11	VS-300 CIU C.A.B./ Modem Back Panel Assembly .....	6-14
6-12	VS-300 Global Modem Assembly 270-1020 .....	6-15
7-1	System Console Menu .....	7-2
7-2	Workstation Emulation Menu .....	7-3
7-2a	System Console Screen in Service Mode .....	7-3a
7-3	Diagnostic Disclaimer Screen .....	7-4

## LIST OF ILLUSTRATIONS (Cont'd)

7-4	DCS Diagnostic Selection Menu .....	7-5
7-5	DCS HELP Menu Screen .....	7-6
7-6	Possible DCS Diagnostic Screen .....	7-7
7-7	VS-300 IOC 4-Position Diagnostic Switch Settings .....	7-9
7-8	Multiline TC IOC 8-Position Diagnostic Switch .....	7-10
7-8a	CIU BLANC IOC External Loopback Test Switch Settings .....	7-10b
7-9	Workstation Interrupted by HELP Screen .....	7-15
7-10	WSEX Error Message Format .....	7-19
7-11	DISKEX Error Message Format .....	7-23
7-12	PREX Error Message Format .....	7-27
7-13	Console Processor Menu .....	7-40
7-14	VS Control Mode Screen .....	7-41
7-15	Control Mode Dump Device Address Screen .....	7-42
7-16	Sample Continuable Dump Screen .....	7-47
7-17	VS-300 Power Controller Board Connectors .....	7-51
7-18	Power Interconnection Diagram .....	7-53
7-19	Power Troubleshooting Flow Chart (1 of 4) .....	7-54
7-19	Power Troubleshooting Flow Chart (2 of 4) .....	7-55
7-19	Power Troubleshooting Flow Chart (3 of 4) .....	7-56
7-19	Power Troubleshooting Flow Chart (4 of 4) .....	7-57
7-20	Error Log Screen .....	7-58
7-21	Set Error Log Defaults Screen .....	7-59
7-22	VS-300 Service Log Database Options Screen .....	7-60

## LIST OF TABLES

<u>Table</u>	<u>Title</u>	<u>Page</u>
3-1	VS-300 Controls .....	3-1
3-2	VS-300 Indicators .....	3-3
3-3	Multiline TC Back Panel Displays (RS232 Operation) .....	3-4
3-4	Multiline TC Back Panel Displays (RS366 Operation) .....	3-5
3-5	Multiline TC Back Panel Displays (X.21 Operation) .....	3-5
3-6	Multiline TC Back Panel Displays (RS449 Operation) .....	3-5
3-7	Gate Array Back Panel Displays (3270 Operation) .....	3-6
3-8	Gate Array Back Panel Displays (Remote WangNet [WSN] Point to Point and Multipoint Operation)	3-6
3-9	Gate Array Back Panel Displays (Teletex Operation) .....	3-6
4-1	VS-300 Models .....	4-3
4-2	Minimum Software Requirements .....	4-13
4-3	Built-In Test (BIT) Programs .....	4-13
4-4	Other Diagnostics .....	4-13
4-5	DVM Voltage Measurements 208-240 V AC Receptacle .....	4-15



## LIST OF TABLES (Cont'd)

4-6	Power Supply Voltage Measurements .....	4-18
4-7	DC Voltage Address Switch SW3 Settings .....	4-18
4-8	A/D Output Values At Hex Displays .....	4-20
4-9	DC Voltages On SCU Screen .....	4-21
4-10	IPL Errors .....	4-31
4-11	Version Checking Status Error Messages .....	4-32
5-1	Power Supply Voltage Measurements .....	5-4
5-2	DC Voltage Address Switch SW3 Settings .....	5-4
5-3	A/D Output Values At Hex Displays .....	5-6
5-4	DC Voltages On SCU Screen .....	5-7
5-5	Main Memory Size Selection Jumpers (L133) .....	5-22
5-6	Main Memory Jumper Configurations .....	5-23
5-7	VS-300 IOC List .....	5-25
5-8	Disk Drive Types (Formatted) .....	5-31
5-9	23V96 Multiline TC IOC Port Select L228 .....	5-35
	Switch Settings For Loopback Test	
5-10	BLANC IOC Functions Switch (L272) .....	5-38
5-11	Multioutput Power Supply Wiring Color Codes .....	5-57
5-12	Booster Power Supply Wiring Color Codes .....	5-60
6-1	VS-300 PCB Complement .....	6-2
6-2	SCU (PC) PCB Complement .....	6-2
6-3	VS-300 Power Cables .....	6-3
6-4	VS-300 Signal Cables .....	6-3
6-5	VS-300 Disk Drive Cables .....	6-4
7-1	Special Diagnostic Functions .....	7-7
7-1a	GATC Loopback Diagnostic Switch Settings .....	7-10
7-1b	MLTC IOC Loopback Test Error Codes .....	7-10c
7-2	System Configuration Screen Status Messages .....	7-13
7-3	WSEX Subtest Codes .....	7-17
7-4	WSEX Error Type Codes .....	7-18
7-5	WSEX Error Codes For All Tests .....	7-18
7-6	Additional WSEX Error Codes .....	7-19
7-7	DISKEX Subtest Codes .....	7-21
7-8	DISKEX Error Type Codes .....	7-21
7-9	DISKEX Cylinder Address Test Error Codes .....	7-21
7-10	DISKEX Data Test Error Codes .....	7-22
7-11	DISKEX Command Test Error Codes .....	7-22
7-12	DISKEX Seek Max/Min Test Error Codes .....	7-22
7-13	DISKEX System Error Codes .....	7-23
7-14	PREX Error Codes .....	7-26
7-15	TPEX Initialization Error Codes .....	7-29
7-16	Test 0 Command Test Error Codes .....	7-30
7-17	Test 1 Tape Movement Test Error Codes .....	7-34

## LIST OF TABLES (Cont'd)

7-18	Test 2 Variable Data Length Test Error Codes .....	7-35
7-19	Test 3 Tape Creep Test Error Codes .....	7-35
7-20	Test 4 Random Operations Test Error Codes .....	7-36
7-21	Test 5 Rewind Test Error Codes .....	7-36
7-22	Test 6 Density Check Test Error Codes .....	7-36
7-23	IPL Errors Requiring Control Mode Dump .....	7-38
7-24	VS-300 Machine Check Error Codes .....	7-39
7-25	Control Mode Stops .....	7-45

**CHAPTER**

**1**

**INTRO-  
DUCTION**

# CHAPTER 1

## INTRODUCTION

Chapter 1 information is not provided as part of this Product Maintenance Manual, but will appear in the Illustrated Maintenance Manual.

**CHAPTER**

**2**

**THEORY**

## CHAPTER 2

# THEORY OF OPERATION

Chapter 2 information is not provided as part of this Product Maintenance Manual, but will appear in the Illustrated Maintenance Manual.

**CHAPTER**

**3**

**OPERA-**

**TION**

## TABLE OF CONTENTS

<b>CHAPTER 3 OPERATION</b>	<b>Page</b>
3.1 General .....	3-1
3.2 Controls .....	3-1
3.3 Indicators .....	3-3
3.4 Power Distribution Assembly and Controls .....	3-9
3.5 Power Supplies and Controls .....	3-9
3.6 Optional Battery Backup .....	3-14
3.7 Control Panel .....	3-17
3.7.1 On/Off Pushbuttons .....	3-17
3.7.2 System Reset Pushbutton .....	3-17
3.7.3 Operator Console Reset Pushbutton .....	3-17
3.7.4 Key Switch .....	3-17
3.8 Main Memory Size .....	3-20
3.8.1 Main Memory Size Selection .....	3-20
3.9 IOC Switches .....	3-20
3.10 Importance of Following Power Up or Down Procedures .....	3-25
3.11 Power-Up and IPL Procedures .....	3-25
3.12 Standard Power-Down Procedure .....	3-30
3.13 Power Failure Procedure .....	3-32

## LIST OF ILLUSTRATIONS

<b>Figure</b>	<b>Title</b>	<b>Page</b>
3-1	Front View of Main Frame .....	3-7
3-2	Rear View of Main Frame .....	3-8
3-3	Power Distribution Assembly .....	3-10
3-4	Multioutput Power Supply .....	3-11
3-5	Booster Power Supply .....	3-11
3-6	Front View - Power Supply Controller and Battery Backup Assembly .....	3-12
3-7	Power Supply Controller Board. (Rev. 0 Version) .....	3-13
3-8	Rear View - Battery Backup Assembly .....	3-15
3-9	Battery Backup Board .....	3-16
3-10	Control Panel and Diskette Drive .....	3-18
3-11	Control Panel Controls and Indicators .....	3-19
3-12	10 MBPS Modem Back Panel Assembly .....	3-21
3-13	10 MBPS Modem Controls and Indicators .....	3-22
3-14	Multiline TC Back Panel Indicators .....	3-23
3-15	6550 Gate Array TC Back Panel .....	3-24
3-16	Console Processor Screen .....	3-26
3-17	System Console Default Screen .....	3-27
3-18	System Initialization Screen .....	3-28
3-19	SYSGEN Configuration Screen .....	3-28



## LIST OF TABLES

<u>Table</u>	<u>Title</u>	<u>Page</u>
3-1	VS-300 Controls .....	3-1
3-2	VS-300 Indicators .....	3-3
3-3	Multiline TC Back Panel Displays (RS232 Operation) .....	3-4
3-4	Multiline TC Back Panel Displays (RS366 Operation) .....	3-5
3-5	Multiline TC Back Panel Displays (X.21 Operation) .....	3-5
3-6	Multiline TC Back Panel Displays (RS449 Operation) .....	3-5
3-7	Gate Array Back Panel Displays (3270 Operation) .....	3-6
3-8	Gate Array Back Panel Displays (Remote WangNet [WSN] .....	3-6
	Point to Point and Multipoint Operation)	
3-9	Gate Array Back Panel Displays (Teletex Operation) .....	3-6

# CHAPTER 3

## OPERATION

### 3.1 GENERAL

This chapter provides tables listing all VS-300 mainframe controls and indicators, power control and battery backup description, main memory size selection, power-on, IPL, and power-off procedures.

### 3.2 CONTROLS

Table 3-1 lists the controls found on the VS-300 followed by a brief description of their purpose. Locations of the controls are shown in figures 3-1 through 3-15.

**Table 3-1. VS-300 Controls**

<u>Control Name And Type</u>	<u>Location</u>	<u>Purpose</u>	<u>Normal Position</u>
Ac On/Off (Circuit breaker)	Power Distribution Assembl y	Provides ac power to power supplies, Power Supply Controller board, and mainframe fans.	On
Power On (Lighted pushbutton)	Control Panel	Turns dc power on.	Open (not active)
Power Off (Lighted pushbutton)	Control Panel	Turns dc power off.	Open (not active)
System Reset (Pushbutton)	Control Panel	Resets system, clears main memory, enters control mode.	Open (not active)
Operator Console Reset (Pushbutton)	Control Panel	Resets SCU (PC) only.	Open (not active)
1. Remote Service 2. Remote Admin. 3. Normal Control	Control Panel	Remote diagnostics. RSAF operation. All Cntrl Panel controls function when power on.	Normal Control
4. Control Lock (Key switch)		Disables power on.	

# OPERATION

Table 3-1. VS-300 Controls (Cont'd)

Control Name And Type	Location	Purpose	Normal Position
V1 (+5A), V2 (+12) V3 (-5) V4 (-12) 5V (+5B) (Adjustment pots)	Multioutput SPS " " " SPS Booster SPS	Adjusts power supply voltages up or down as needed.	Various (Chapters 4 and 5)
SW1 (Power On) (Pushbutton)	Power Supply Controller	Turns dc power on. Parallel to Control Panel On pushbutton.	Open (not active)
SW2 (Power Off) (Pushbutton)	Power Supply Controller	Turns dc power off. Parallel to Control Panel Off pushbutton.	Open (not active)
SW3 - Voltage Address (DIP switch)	Power Supply Controller	Addresses hex displays that are used to zero A/D converter.	Various
SW4 - Battery Backup Time (DIP switch)	Power Supply Controller	Set length of time backup batteries supply power to power supplies after ac input line failure.	100 seconds (Rev. 0) 96 seconds (Rev.1) (Currently)
R11, R12 (Adjustment pots) (Rev. 0 only)	Power Supply Controller	Calibrates Power Supply Controller.	Various
R18 through R22 (Five adjustment pots)	Power Supply Controller	Calibrate A/D (Analog/ Digital) converter for individual dc voltages.	Various (Chapters 4 and 5)
R70A (adjustment pot)	Power Supply Controller	Low Battery Voltage Dropout adjustment.	Various (Chapter 5)
R23 (adjustment pot)	Battery Backup Charging P/S	Sets proper battery charging voltage.	Various (Chapter 5)
Local/Remote (Toggle switch)	SCU (PC) Local Comm Data Link board	Selects PC IPL operation (Local) or workstation operation (Remote)	Local
Main Memory Size (Jumpers)	MCU board	Selects maximum main memory size.	Various (Chapter 5)
Main Memory DRAM loading (Jumpers)	Main Memory board	Selects half or fully loaded MM boards.	Various (Chapter 5)
IOC Diagnostic Switch (DIP switch)	All IOCs	Permits IOC diagnostic functions.	All Off (open) (Chapter 5)

Table 3-1. VS-300 Controls (Cont'd)

Control Name And Type	Location	Purpose	Normal Position
Disk Drive Device Type (DIP switch)	Disk Drive IOC	Selects disk drive types connected to system.	Various (Chapter 5)
Port Select (DIP switch)	Multiline TC (MLTC) IOC	Selects TC ports on MLTC for loopback test.	All Closed (On)
Gate Array Clear (Pushbutton)	Gate Array TC Connector Assembly	ReIPL CPU/Gate Array (210-8714 board)	Open (not active)
Gate Array Switch (DIP switch)	CPU/Gate Array (210-8714) board	Memory configuration and loopback test selection.	5,6 closed, rest open
CIU IOC Functions (DIP switch)	BLANC IOC	Selects configuration, diagnostics, and re- pair functions.	All Open (Off) (Chapter 5)
5-Channel CIU 10MBPS Modem Reset (Pushbutton)	5-Channel CIU 10MBPS Duo- binary Modem	Clears transmit fault.	Open (not active)

### 3.3 INDICATORS

Tables 3-2 through 3-9 lists the indicators found on the VS-300 followed by a brief description of their purpose. Locations of the indicators are shown in figures 3-1 through 3-15. There are no indicators on any of the circuit boards comprising the VS-300 mainframe PCB chassis. Any errors are displayed on the SCU screen.

Table 3-2. VS-300 Indicators

Indicator Name And Type	Location	Purpose	Normal Indication
Power On lamp (Power On pushbutton)	Control Panel	Shows dc power is on.	On
Power Off lamp (Power Off pushbutton)	Control Panel	Shows dc power is off.	Off
LED1 - LED5 (Five voltage sensing LEDs)	Power Supply Controller	Shows dc voltages are on. Does not show accuracy.	On

OPERATION

Table 3-2. VS-300 Indicators (Cont'd)

Indicator Name And Type	Location	Purpose	Normal Indication
L3, L4 (Two Hex displays)	Power Supply Controller	Used to zero A/D converters.	Hex 7E (Minus) Hex 80 (Zero) Hex 82 (Plus)
LED1	Battery Backup Board	Indicates +240 V dc battery voltage is on line.	On
Diskette Activity LED	Front of SCU minidiskette drive	Shows drive in use (head loaded)/ not in use.	On (in use) Off (not in use)
TC Displays (Up to 4 LED displays)	MLTC Connect- or Assembly	Shows interchange signals between mo- dem and controller.	Refer to Tables 3-3 thru 3-6.
TC Display (One display with 8 LEDs)	Gate Array TC Back Panel	Shows interchange signals between mo- dem and controller.	Refer to Tables 3-7 thru 3-9.
5-Channel CIU 10MBPS Modem Display (4 LEDs)	5-Channel CIU 10MBPS Duo- binary Modem	1. Channel Select. 2. Fault.	3 LEDs - Various 1 LED - Off

NOTES

1. Tables 3-3 to 3-5 show EIA (Electronic Industries Association) interchange signals between the modem and the MLTC controller.
2. For the MLTC, all LEDs are normally on or blinking during the BIT (Built In Test). If the BIT fails, the software controlled LED will go off.

Table 3-3. Multiline TC Back Panel Displays (RS232 Operation)

Indicator Name And Type	Purpose
LED1	Data Set Ready
LED2	Data Terminal Ready
LED3	Carrier Detect
LED4	Software Controlled
LED5	Transmitted Data
LED6	Request-to-Send
LED7	Clear-to-Send
LED8	Received Data

**Table 3-4. Multiline TC Back Panel Displays (RS366 Operation)**

Indicator Name And Type	Purpose
LED1	Data Line Occupied
LED2	Call Origination Status
LED3	Present Next Digit
LED4	Abandon Call and Retry
LED5	Digit Present
LED6	Call Request Present
LED7	Software Controlled

**Table 3-5. Multiline TC Back Panel Displays (X.21 Operation)**

Indicator Name And Type	Purpose
LED1	Transmitted data
LED2	Data Terminal Ready
LED3	Received Data
LED4	Indication
LED5	Software Controlled

**Table 3-6. Multiline TC Back Panel Displays (RS449 Operation)**

Indicator Name And Type	Purpose
LED1	Carrier Detect
LED2	Clear-to-Send

**NOTE**

Tables 3-7 to 3-9 show EIA (Electronic Industries Association) interchange signals between the modem and the Gate Array controller. Read the Gate Array LEDs from left to right.

## OPERATION

**Table 3-7. Gate Array Back Panel Displays (3270 Operation)**

<u>Indicator Name And Type</u>	<u>Purpose</u>
LED1	Received Data
LED2	Transmitted Data
LED3	Clear-to-Send
LED4	Request-to-Send
LED5	Data Carrier Detect
LED6	Data Terminal Detected
LED7	Data Set Ready
LED8	Power Indicator

**Table 3-8. Gate Array Back Panel Displays  
(Remote WangNet [WSN] Point to Point and Multipoint Operation)**

<u>Indicator Name And Type</u>	<u>Purpose</u>
LED1	System Activity
LED2	Received Valid Data
LED3	Transmitter Active
LED4	Data Carrier Detected
LED5	Virtual Circuit Active
LED6	Activity to VS
LED7	TC Controller Refusing New Traffic
LED8	Diagnostic Mode

**Table 3-9. Gate Array Back Panel Displays  
(Teletex Operation)**

<u>Indicator Name And Type</u>	<u>Purpose</u>
LED1	Document Received
LED2	Receive Memory Full
LED5	Transmitting Document
LED6	Receiving Document
LED7 (Note 1)	O.S. Code Active
LED8 (Note 2)	Normal Operation

### NOTES

1. Blinks at a 3-second rate when Operating System code is active.
2. On for normal operation. Blinks for a hardware problem or fatal software error.




Figure 3-1. Front View of Mainframe



OPERATION




Figure 3-2. Rear View of Mainframe

## OPERATION

### 3.4 POWER DISTRIBUTION ASSEMBLY AND CONTROLS

Ac input power to the VS-300 is 208-240 volts ac, split (single) phase. Ac neutral is not used in domestic mainframes. (Refer to Chapter 4.) The ac is supplied to the mainframe through the Power Distribution assembly, figure 3-3. The assembly is mounted on the lower right rear of the mainframe and contains a 30 amp mainframe ac On/Off circuit breaker, the ac line filter, and the ac and dc voltage distribution terminal boards.

To handle the increased dc voltage load requirements of the Active Port Assemblies and other back panel assemblies, a second DC Distribution board has been added to the system. The board is mounted on the left rear side of the card cage assembly, to the upper right of the Power Supply Controller board. (Figure 3-2.)

Moving the ac On/Off circuit breaker up turns on 16 card cage fans and two back panel fans and supplies ac to the Power Supply Controller board and to the dc switching power supplies. However, the power supplies are not activated.

Ac power is removed from the mainframe by moving the ac On/Off circuit breaker down.

### 3.5 POWER SUPPLIES AND CONTROLS

The VS-300 contains two switching power supplies, figures 3-4 and 3-5. The primary supply is a multioutput 1600 watt supply generating +5 V (+5A) at 200 amps, -5 V at 10 amps, +12 V at 20 amps, and -12 V at 10 amps. The secondary supply is a 1500 watt booster supply and the output is +5 V (+5B). The booster supplies the added power needed to share the heavy load that would have been placed on the +5 volt section of the multioutput supply. Each voltage is adjusted and regulated at the individual power supply (Figures 3-6 and 3-7.)

OPERATION




Figure 3-3. Power Distribution Assembly




Figure 3-4. Multioutput Power Supply

PHOTO NOT AVAILABLE

Figure 3-5. Booster Power Supply





Figure 3-6. Front View - Power Supply Controller and Battery Backup Assembly

OPERATION



B-02080-FY85-14

Figure 3-7. Power Supply Controller Board. (Rev. 0 Version)

## OPERATION

### 3.6 OPTIONAL BATTERY BACKUP

In the event of an input ac power failure, five rechargable lead acid battery packs, figure 3-8, supply sufficient dc power to the power supplies to permit an orderly shut down of the mainframe. (Presently, the batteries do not supply power to any peripheral devices except the Support Control Unit (SCU) which is powered by the mainframe power supplies.) The length of time that the batteries provide power to the power supplies is preset by Switch 4 on the Power Supply Controller board. Currently, the time is set for 100 seconds for the Rev. 0 board, and 96 seconds for the Rev. 1 board, which represents approximately 90 percent of all expected power failures.

When the power fails, an alarm sounds at the SCU to alert the operator that a power outage is being experienced and the battery backup unit is providing power. The message "<Power Supply Failure>" appears on the SCU screen as well. The Battery Backup board, figure 3-9, notifies the SCU to start a software shutdown of the system.

Each battery pack weighs 22 pounds and is rated at 48 V dc, 5.5 amp. hours. The expected operating life span is between 18 and 24 months, with a shelf life of 5 years when stored at 40° F. When one pack becomes defective, all five packs must be replaced at the same time.

The packs are mounted below the Power Supply Controller board behind the left mainframe cabinet panel. They are connected in series to supply an average of 240 V dc and can be fully charged to 264-270 V dc. The packs are constantly being trickle charged by a modified Professional Computer switching power supply located beneath the Power Supply Controller board.

Normally, the power supplies rectify the 208-240 volts input ac line voltage to dc. When the Power Supply Controller senses an input line voltage of less than 195 volts ac, it signals the Battery Backup board to connect the batteries to the mainframe power supplies. The power supplies can regulate input voltages of between 180 and 325 volts.

Should the battery output drop below 192 V dc, the Power Supply Controller senses this and will power down the mainframe.

A LED, mounted on the Battery Backup board, indicates that the dc battery voltage is applied to the power supplies from the Battery Backup board. When the power supplies have been turned off, the battery voltage output from the Battery Backup board will turn off and the LED should go out. If the LED remains on when the power is turned off, there is a fault on the Battery Backup board.

### WARNING

Even when the LED is off, battery voltage remains present on the input connectors from the batteries and other locations on the Battery Backup board.




Figure 3-8. Rear View - Battery Backup Assembly






Figure 3-9. Battery Backup Board

### 3.7 CONTROL PANEL

Located in the top right corner of the front cover, the Control Panel, figures 3-10 and 3-11, contains four buttons and one key switch as follows: Power On pushbutton; Power Off pushbutton; System Reset pushbutton; Operator Console Reset pushbutton, and Remote Service/Remote Admin./Normal Control/-Control Lock switch.

#### 3.7.1 POWER ON/OFF PUSHBUTTONS

Pressing the Power On pushbutton causes the Power Supply Controller to energize the switching power supplies. Pressing the Power Off pushbutton causes the Power Supply Controller to deenergize the switching power supplies.

#### 3.7.2 SYSTEM RESET PUSHBUTTON

The System Reset pushbutton, when pressed, resets the system, clearing main memory and entering Control Mode.

#### 3.7.3 OPERATOR CONSOLE RESET PUSHBUTTON

The Operator Console Reset pushbutton, when pressed, resets only the SCU, clearing SCU memory. It does not affect the CPU mainframe. It also resets the Z80 on the Local Comm. Processor. The Z80 then starts executing from memory location 0000.

#### 3.7.4 KEY SWITCH

The 4-position Control Panel key switch controls the following functions:

- a. Remote Service position permits running Remote diagnostics, and viewing the system error log.
- b. Remote Admin. position permits the Remote System Administrator Facility features to be run. Other users can log on and run any available VS functions.
- c. Normal Control permits all Control Panel controls to function once power is applied. All SCU functions can be run, as well as all Operator Console functions. Users can log on and run any available VS functions. Power Fail/Auto Restart functions are disabled.
- d. Control Lock disables Power On when the system is powered off. Power Fail/Auto Restart functions are enabled. No SCU tasks can be run from the Operator's Console, but system activity can be monitored. Other workstation users can log on and run any available VS functions. The key can be inserted and removed in this position only.




Figure 3-10. Control Panel And Diskette Drive




Figure 3-11. Control Panel Controls and Indicators

## OPERATION

### 3.8 MAIN MEMORY SIZE

Memory can range in size from a minimum of 4 megabytes to a maximum of 16 megabytes, using 256K byte x 1 bit RAM chips. Each main memory board contains either 4 megabytes half-loaded (210-8703), or 8-megabytes fully loaded (210-8703-1).

#### 3.8.1 MAIN MEMORY SIZE SELECTION

The Memory Control Unit (MCU) board has an 8-position jumper block, of which five positions are used to determine the maximum size of main memory. Refer to Chapter 5 for the jumper locations and configurations. Incorrect altering of the jumpers, or altering of the jumpers without adding the correct number of memory boards, can result in CP hangups and loss of data. Adding a board without altering the jumpers results in no change in apparent memory size to the CP.

Each main memory board also contains a 10-position jumper block used to determine whether the board is half-loaded or fully loaded with 256K byte x 1 bit RAM chips. Refer to Chapter 5 for the jumper locations and configurations.

### 3.9 IOC SWITCHES

The IOCs do not have the Bus Adapter and I/O slot selection DIP switches that are used on the VS-85/VS-100. Each IOC has an Identification (ID) Register that is set by the position of the IOC in the backplane. The CPU reads the ID Register to determine the type and position of the IOC.

The only switch common to each IOC is a 4-position diagnostic DIP switch. Refer to Chapter 5 for the normal switch settings and Chapter 7 for the switch functions and test positions.

The 23V98 Disk Drive IOC does have two 8-position disk device type DIP switches; the 23V96 Multiline TC IOC has an 8-position port select DIP switch for loopback tests; and the 23V79 CIU BLANC IOC has an 8-position CIU Functions DIP switch. Refer to Chapter 5 for the switch settings.




Figure 3-12. 10 MBPS Modem Back Panel Assembly

OPERATION




Figure 3-13. 10 MBPS Modem Controls and Indicators




Figure 3-14. Multiline TC Back Panel Indicators



OPERATION




Figure 3-15. 6550 Gate Array TC Back Panel Indicators

### 3.10 IMPORTANCE OF FOLLOWING POWER UP OR DOWN PROCEDURES

The following summary describes general rules that must be followed when powering a VS-300 system up or down:

- When powering down, the system must be in Control Mode.
- Always power the mainframe up before powering up disk drives and tape drives. Always power the mainframe down after powering down the disk drives and tape drives. Failure to follow this procedure can result in disk or tape VTOC damage or data loss.

The Volume Table of Contents (VTOC) resides at the beginning of each disk pack. If the VTOC is damaged, two conditions may occur: I/O errors occur upon IPL and the VS Workstation Emulation - Initialization In Progress screen remains displayed. Although many of the original files may remain intact, the VTOC is inaccessible.

#### NOTE

Crash-tolerant or media-tolerant volumes can help protect VTOC integrity.

In addition to this VTOC integrity problem, other conditions may cause the writing of random blocks of data to the disk. These conditions include power failures, surges, or fluctuations, or a possible hardware malfunction.

### 3.11 POWER-UP AND IPL PROCEDURES

This section describes standard power-up and IPL procedures for the VS-300.

1. Power up all workstations and printers.
2. Turn ON the mainframe ac On/Off circuit breaker.
3. Make sure the Front Panel key switch is in Normal Control position.
4. Power up the mainframe and the SCU by pressing the Control Panel On pushbutton, located above the diskette drive door.
5. Power up the disk drives.
6. Press the System Reset pushbutton and then press the Operator Console Reset pushbutton.
7. After a pause, the SCU start-up sequence is invoked and start-up messages appear on the SCU screen:

```
"WANG SUPPORT CONTROL UNIT REV. X.XX"  
"01 Start From Winchester"
```

## OPERATION

8. Followed by:

"Wang Support Control Unit - BIOS X.XX"  
"MS-DOS Version X.XX"

```
SYSCON X.X.X  
Copyright Wang Laboratories, Inc. 1985
```

9. The Console Processor screen then appears.

```
    <<< System in Control Mode >>>  
    *** Wang VS System Console ***  
SYSCON Version X.XX      11:06 AM      Monday, January 6, 1986  
  
    Press (HELP) for online system console information.  
  
    Use the function keys to select a command:  
  
    (1) ENTER Workstation Emulation      (8) RESET System  
    (2) ENTER Control Mode              (9) RESET Console  
  
    (5) AUTO IPL                        (12) SET Console Defaults  
    (13) SET Time and Date
```

Figure 3-16. Console Processor Screen

### NOTE

The functions that the key switch allows in any one of the four key switch positions are highlighted on the Console Processor screen.

10. If necessary, press HELP for an explanation of the PF key functions.

11. a. Press PF5 (AUTO IPL). This message appears:  
**"WARNING: This function resets the system, RETURN to proceed or PF16 to abort"**
  - b. Press RETURN. (If the console defaults need modifying, or if the CPU code has not been loaded, a CPU or IPL error may appear. Go to step 12. If there are no changes necessary, or no CPU or IPL errors appear, go to step 13.)
12. a. Press PF12 (SET Console Defaults). The System Console Default screen appears.

```

<<< System in Control Mode >>>

*** System Console Defaults ***

IPL Device Address: R 0100

CPU Microcode File: /SCU/OBJVSE.CP8
FPU Microcode File:

WS Emulator Options: -PC

Give Console Date/Time to VSOS: N
Warning message before a reset: Y

(9) Modify Defaults      (10) Load System Microcode      (16) Exit
```

**Figure 3-17. System Console Default Screen**

- 1) If defaults are incorrect, press PF9 (Modify Defaults), make corrections as shown in figure 3-17, press RETURN, and/or:
  - 2) Whether defaults were corrected or not, press PF10 (Load System Microcode).
- b. Press PF16 (Exit). and the Console Processor screen (figure 3-16) reappears.
- c. Press PF5 (AUTO IPL). This message appears:  
**"WARNING: This function resets the system, RETURN to proceed or PF16 to abort"**
  - d. Press RETURN.

## OPERATION

13. The Workstation Initialization Screen, figure 3-18, appears.

```
Wang
VS
Workstation Emulation
Version X.XX

Initialization in Progress - Please Wait
```

Figure 3-18. Workstation Initialization Screen

14. The SYSGEN Configuration Screen appears.

```
***MESSAGE M001 BY SYSGEN

INFORMATION REQUIRED BY PROGRAM

ACTIVE SUBPROGRAM IS @SYSGEN@

Specify the name of the system configuration file and press (ENTER)
-or-
Press (1) to use one workstation and one disk.

SYSFILE = @CONFIG@
SYSLIB = @SYSTEM@

Specify the communications configuration file to be use, if any

COMMFILE = *****
COMMLIB = @SYSTEM@

Inhibit logons at all workstations?          LOGONS = NO■
Load Micro Code to all devices?              LMCODE = NO■
Inhibit dumping continuable halts?          CMDUMP = NO■
```

Figure 3-19. SYSGEN Configuration File Screen

## NOTE

If the IPL was unsuccessful and an "IPL failed" message is received, refer to paragraph 4.9.3, IPL Errors

15. a. On the SYSGEN Configuration File screen, enter the names of the configuration files and the system library to be used. The field for the communications configuration file is blank. Fill in the communications configuration file field only if communications are going to be used. To change one of these values, move the cursor to the appropriate field and enter in the new information. Then, press RETURN.

## NOTE

If the system is being IPLed for the first time, the default values of @CONFIG@ and @SYSTEM@ are used for the configuration file and system library, respectively. After IPLing for the first time, configuration files can be created using GENEDIT. Refer to the VS Software Bulletin Release 7.06.

- b. After the values have been entered, the VS-300 stores them in a start-up file. At the next IPL the system displays the stored values and allows them to be changed.
- c. The prompt "Inhibit logons at all workstations?" allows workstation logons to be inhibited. If "YES" is entered, only the SCU user can log on. The default value is "NO", which allows logons at all workstations, which were enabled before this IPL.
- d. The prompt "Load Micro Code to all devices" lets microcode be loaded to each workstation (including remote workstations) as part of the IPL procedure. If "Yes" is entered, microcode is loaded to each workstation and the IPL process is significantly slower. This option is used when a workstation is hung up or when the workstation configuration has been changed. The default value is "No".
- e. The prompt "Inhibit dumping continuable halts" allows disabling of the Continuable Dump for errors that do not require reIPL. If "Yes" is entered, Continuable Dumps which do not reIPL the system are not performed and system processing continues with the system error in effect. If "No" is entered, all Continuable Dumps occur. The default value is No. Refer to Chapter 7 for more information on the Continuable Dump.

## OPERATION

16. Press RETURN when finished with the SYSGEN Configuration File screen. (Or, to bring up a minimum configuration of one workstation [W/S0] and one disk, without changing the default values, just press PF1.)

### NOTE

The IPL procedure automatically activates any remote workstations that have been configured via the remote workstation parameters in the GENEDIT procedure.

17. After pressing RETURN from the SYSGEN Configuration File screen, the VS-300 checks to determine if any of the critical operating system components are obsolete or incompatible. If no problems are detected, the IPL continues and the message "System Generation in Progress" appears on the SCU.
  - a. If incompatibilities exist that can cause problems, the IPL is stopped and a warning message is displayed by @SYSGEN@.
18. The message "I/O Subsystem Load in Progress" appears on the SCU screen.
19.
  - a. If the SCU real time clock is not usable, the date and time screen appears. Enter the correct date and time, and press RETURN.
  - b. This screen also allows changing the amount of memory available for use. The default value is the total amount of physical memory for the system. To change the value, move the cursor to the field, enter the new value, and press RETURN.
20. The message "System Initialization in Progress" appears on the SCU screen.

The VS-300 is now initialized and ready for operation. VS workstation emulation is running on the SCU and the Operator's screen is displayed. To log on from the SCU;

1. Press PF1 and the VS Logon screen appears.
2. Enter the User ID and Password. (As this is the first time that the system has been IPLed and logged onto, use "CSG" for the User ID and leave the Password field blank.)
3. Press RETURN. The User screen is displayed.

### 3.12 STANDARD POWER-DOWN PROCEDURE

The VS-300 can be either partially or completely powered down.

## CAUTION

It is essential to power the mainframe up before powering up disk drives and tape drives, and to power the mainframe down after powering down disk drives and tape drives. Failure to power the system up and down correctly may result in disk and tape information loss.

## NOTE

Always power down all workstations before powering down the mainframe. The 4200 Series workstations cause Error 7203 (read and test data error) if they are not powered down before the mainframe. Power down the workstations and continue with the system power-down procedure.

To completely power down the system, perform the following from Workstation 0, the SCU:

1. Inhibit further logons by pressing PF6 (INTERACTIVE Tasks) or PF13 (WORKSTATIONS) from the Operator's Console menu.
2. Notify all users to log off the system by pressing PF14 (SYSTEM Options - Broadcast SYSTEM MESSAGE). Use PF6 from the Operator's Console to verify that all users have done so.
3. Inhibit the execution of any pending background procedures by pressing PF3 (PROCEDURE Queue) on the Operator's Console menu.
4. Press PF9 (PRINTERS) on the Operator's Console menu to idle all printers by changing their status.
5. Press PF7 to deactivate the background task through the Control Proc Initiation command (NON-INTERACTIVE Tasks) on the Operator's Console menu.
6. Log off from the SCU.
7. Press CONTROL, then press SHIFT and CANCEL simultaneously to exit workstation emulation. The Workstation Emulation menu appears. Use the space bar to select Suspend Emulation and press EXEC.
8. The Console Processor screen appears. Press PF2, ENTER Control Mode.
9. Power down all workstations.
10. Unload the cartridge tape drive, if any, by pressing the Online push-button on the front of the drive.



## OPERATION

11. Unload the nine-track tape drives, if any, by pressing the Online and then the Rewind pushbuttons. When the nine-track tape drive has reached its load point, press the Rewind pushbutton again and wait until it is rewound. Once rewound, finish powering down tape drives by pressing the Power pushbutton on each drive.
12. Power down all disk drives.
13. Power down the mainframe and SCU by pressing the Power Off pushbutton.

If a partial power-down procedure is being performed, the system can be left in Control mode without powering down every device. For a partial power-down of the system, perform steps 7 and 8, and 10 through 13.

To bring a system up from a complete power-down state, follow the complete standard procedure in paragraph 3.11 for powering up the system. To bring a system up from a partial power-down state, follow the power-up procedure described in paragraph 3.11, starting with step 4.

### **3.13 POWER FAILURE PROCEDURE (WITHOUT OPTIONAL BATTERY BACKUP)**

Once power is restored, bring the VS-300 back up by pressing the On pushbutton and reIPL. Follow the IPL procedure in paragraph 3.11, starting with step 4.

**CHAPTER**

**4**

**INSTAL-**

**LATION**

## TABLE OF CONTENTS

CHAPTER 4 INSTALLATION		Page
4.1	General .....	4-1
4.2	Installation Site Check .....	4-1
4.3	Publications .....	4-2
4.4	Tools and Test Equipment .....	4-2
4.5	Unpacking .....	4-2
4.5.1	Claims Information .....	4-3
4.5.2	Unpacking The Mainframe .....	4-4
4.5.3	Unpacking The Peripherals .....	4-10
4.6	Mainframe Inspection .....	4-12
4.6.1	Peripheral Inspection .....	4-12
4.7	Software/Diagnostic Requirements .....	4-13
4.7.1	Software .....	4-13
4.7.2	Diagnostics .....	4-13
4.8	Mainframe Power Source Check .....	4-14
4.8.1	208-240 Volt AC Domestic Power Source .....	4-14
4.8.1.1	Using Existing VS-100 Power Service .....	4-14
4.8.1.2	Installing New Power Service For VS-300s .....	4-15
4.8.2	Initial Mainframe Power-Up .....	4-16
4.8.3	DC Voltage Checks .....	4-16
4.8.3.1	Power Supply Adjustments .....	4-16
4.8.3.2	Power Supply Controller Adjustments .....	4-18
4.9	IPL Procedures .....	4-21
4.9.1	IPLing The VS-300 .....	4-21
4.9.2	1.03 SCU Software Installation .....	4-27
4.9.3	IPL Errors .....	4-30
4.9.4	Version Checking During IPL .....	4-31
4.10	Peripheral Interconnection .....	4-33
4.10.1	I/O Connector Assembly To IOC Cabling .....	4-34
4.10.2	Serial Connectors .....	4-34
4.10.3	Cable Concentrator .....	4-36
4.10.4	Disk Cable Connectors .....	4-37
4.10.5	Telecommunications Connectors .....	4-39
4.10.6	Kennedy Tape Drive Connectors .....	4-41
4.10.7	Telex Tape Drive Connectors .....	4-42
4.10.8	P-Band Connectors .....	4-42a
4.11	Remote Link (For 1.02 SCU Software) .....	4-43
4.11.1	Remote Link Specifications .....	4-43
4.11.2	Site Preparation For Remote Link .....	4-44
4.11.3	Remote Link Installation and Verification .....	4-44

## LIST OF ILLUSTRATIONS

<u>Figure</u>	<u>Title</u>	<u>Page</u>
4-1	Unpacking the Main Frame (1 of 6) .....	4-4
4-2	Unpacking the Main Frame (2 of 6) .....	4-5
4-3	Unpacking the Main Frame (3 of 6) .....	4-6
4-4	Unpacking the Main Frame (4 of 6) .....	4-7
4-5	Unpacking the Main Frame (5 of 6) .....	4-8
4-6	Unpacking the Main Frame (6 of 6) .....	4-9
4-7	Rear View of Main Frame .....	4-11
4-8	208-240 Volt AC Power Source Requirements for VS-300 .....	4-14
	Main Frames Using Existing VS-100 Power Service	
4-9	208-240 Volt AC Power Source Requirements for .....	4-15
	New Power Service For VS-300 Main Frames.	
4-10	Multioutput Power Supply .....	4-17
4-11	Booster Power Supply .....	4-17
4-12	Power Supply Controller Board. (Rev. 0 Version) .....	4-19
4-13	Environment Test Screen .....	4-20
4-14	Console Processor Screen .....	4-23
4-14a	Modified System Console Screen in Service Mode .....	4-23
4-15	System Console Default Screen .....	4-23a
4-16	System Initialization Screen .....	4-23b
4-17	SYSGEN Configuration File Screen .....	4-24
4-18	SCU Install Utility Menu .....	4-28
4-19	SCU Install Utility Screen .....	4-29
4-20	Sample Version Warning Screen .....	4-32
4-21	VS-300 Basic I/O Panel Positions .....	4-33
4-22	Active Port Assemblies BNC/TNC Connector Assembly .....	4-35
4-23	P-Band Modem Connections .....	4-35
4-24	VS-300 Cable Concentrator Rear Panel .....	4-36
4-25	Cable Concentrator Connections .....	4-36
4-26	270-1006 "A" and "B" Cable Connector Assembly .....	4-38
4-27	Multiline TC (MLTC) Connector Panel .....	4-39
4-28	Gate Array TC Connector Panel .....	4-40
4-29	270-1005 Kennedy Tape Drive Connector Assembly .....	4-41
4-30	270-1007 Telex Tape Drive Connector Assembly .....	4-42
4-30a	WangNet P-Band Modem Assembly .....	4-42a
4-30b	WangNet P-Band Modem Rear Panel Assembly .....	4-42b
4-31	Modem/Phone Connections and Modem Switch Settings .....	4-45
4-32	SCU Main Menu .....	4-46
4-33	SCU Console Mode Menu With ACCESS .....	4-47
4-34	SCU Console Mode Menu Without ACCESS .....	4-47
4-35	SCU Main Menu .....	4-48
4-36	SCU Maintenance Menu .....	4-48

## LIST OF TABLES

<u>Table</u>	<u>Title</u>	<u>Page</u>
4-1	VS-300 Models .....	4-3
4-2	Minimum Software Requirements .....	4-13
4-3	Built-In Test (BIT) Programs .....	4-13
4-4	Other Diagnostics .....	4-13
4-5	DVM Voltage Measurements 208-240 V AC Receptacle .....	4-15
4-6	Power Supply Voltage Measurements .....	4-18
4-7	DC Voltage Address Switch SW3 Settings .....	4-18
4-8	A?D Output Values At Hex Displays .....	4-20
4-9	DC Voltages On SCU Screen .....	4-21
4-10	IPL Errors .....	4-31
4-11	Version Checking Status Error Messages .....	4-32

# CHAPTER 4

## INSTALLATION

### 4.1 GENERAL

This chapter describes the procedures for unpacking, inspecting, and installing the VS-300 mainframe. Included in this chapter are instructions for system interconnection and initial power-up. Refer to Chapter 3, Operation; Chapter 5, Preventive and Corrective Maintenance and Removal/Replacement; and Chapter 7, Troubleshooting, of this manual for more information needed to complete installation. Actual installation should not begin until the site requirements have been met. Refer to the following two sources for publications concerning site requirements.

<u>Publication Title</u>	<u>WLI P/N</u>
Customer Site Planning Guide	700-5978
Technical Documentation Catalog/Index	741-0000
Wang Customer Resource Catalog	700-7647

### 4.2 INSTALLATION SITE CHECK

Prior to installation, the following conditions must have been met:

1. All site plans should have been approved by both the customer and a Customer Service Representative.
2. All building alterations must have been completed and inspected.
3. All electrical wiring, air conditioning, and telecommunications (TC) modifications must have been installed and tested. (The following TC equipment should have been ordered for remote maintenance support:)
  - a. Telephone line. (A dedicated line is not required.)
  - b. Telephone.
  - c. Either of the following modular connecting blocks for the telephone:
    - 1) RJ11C jack for desk top telephones
    - 2) RF11W jack for flush mounted wall telephones

## INSTALLATION

### NOTE

RF11W flush mount wall phone jack can be used with the "T" connector and a desk top phone, but a wall mounted phone cannot be used.

4. The preinstallation inspection is to be performed two weeks prior to delivery. At this time, the service representative will check the site for compliance with VS site specifications. The service representative will bring any unsatisfactory conditions noted to the attention of the customer for correction.

### NOTE

Before installation of a VS-300 can take place, the minimum specifications as described in publications listed in the Customer Site Planning Guide (700-5978), the Technical Documentation Catalog/Index (741-0000), and the Customer Resource Catalog (700-7647) should be met. Failure to meet these requirements can be cause for the service representative to deem a site as unsuitable for the proper functioning of a VS-300 system.

### 4.3 PUBLICATIONS

Refer to the following source for publications containing information that will be helpful in installing the VS-300.

Publication Title	WLI P/N
Technical Documentation Catalog/Index	741-0000

### 4.4 TOOLS AND TEST EQUIPMENT

1. No special tools or test equipment are required.

### 4.5 UNPACKING

Before unpacking the VS-300, check all packing slips to make sure that the proper equipment has been delivered. Refer to the model number information below. After checking packing slips, inspect all shipping containers for damage (crushed corners, punctures, etc.).

#### 4.5.1 CLAIMS INFORMATION

If damage is discovered during inspection, the customer should file an appropriate claim promptly with the carrier involved, and notify your service manager.

**Table 4-1. VS-300 Models**

<u>Model Number</u>	<u>WLI/P/N</u>	<u>Description</u>
VS300-4	157/177-7301	4096KB Main Memory
VS300-8	157/177-7302	8192KB Main Memory
VS300-12	157/177-7303	12,288KB Main Memory
VS300-16	157/177-7304	16,384KB Main Memory

#### NOTES


1. Part number prefix 157 = 50Hz. ac line frequency mainframes.
2. Part number prefix 177 = 60Hz. ac line frequency mainframes.



## INSTALLATION

### 4.5.2 UNPACKING THE MAIN FRAME

1. Cut and remove the strapping that secures the top cover and outside tube to the shipping pallet. (If the strapping is metal be careful that it does not spring out and away from the shipping container.)
2. Remove the top cover and the outside tube.




B-02191-FY85-1

Figure 4-1. Unpacking the Main Frame (1 of 6)

## INSTALLATION

3. Remove the top cushion pad and plastic wrap covering the mainframe cabinet.
4. Remove the shipping bolts securing the mainframe cabinet and the support assembly to the pallet.



B-02191-FY85-2

Figure 4-2. Unpacking the Main Frame (2 of 6)

## INSTALLATION


### WARNING

The mainframe cabinet weighs between 750 and 850 pounds (340-385kg). Be careful when performing the following steps.

5. Push the mainframe 1" or 2", enough to position the casters on the wheel blocks.

### NOTE

An alternate method is to pry up each corner of the mainframe cabinet at a time with a piece of 2"x4" lumber (if available) and swivel each caster up onto the wheel blocks.




B-02191-FY85-3

Figure 4-3. Unpacking the Main Frame (3 of 6)

## INSTALLATION

6. Pull out and remove the support assembly.



B-02191-FY85-4


Figure 4-4. Unpacking the Main Frame (4 of 6)

## INSTALLATION

### WARNING

The mainframe cabinet will begin to tilt down when the cushion assembly is pulled out from under the pallet.


7. Pull the cushion assembly out from under the pallet.



B-02191-FY85-5

Figure 4-5. Unpacking the Main Frame (5 of 6)

- Carefully push the cabinet off the pallet.



B-02191-FY85-6

Figure 4-6. Unpacking the Main Frame (6 of 6)

## INSTALLATION

9. Move the cabinet to its permanent location.
10. Once the cabinet is in place, check the service clearances as listed below.

<u>Service Clearances</u>	<u>Inches</u>	<u>Centimeters</u>
Front	36	91.4
Rear	36	91.4
Left	24	60.9
Right	24	60.9
Top	36	91.4

### 4.5.3 UNPACKING THE PERIPHERALS

Before proceeding, carefully unpack all peripherals according to procedures outlined in applicable maintenance manuals. As each unit is unpacked, check it for any obvious shipping damage. Refer to paragraph 4.5.1 if any damage is seen.

## CAUTION

```
*****
*
* THIS COMPUTER EQUIPMENT HAS BEEN VERIFIED AS FCC CLASS A. *
*
*****
```

IN ORDER TO MAINTAIN COMPLIANCE WITH FCC CLASS A VERIFICATION, THE FOLLOWING CONDITIONS MUST BE ADHERED TO DURING NORMAL OPERATION OF EQUIPMENT.

- ALL COVERS MUST BE ON SYSTEM AND SECURED IN THE PROPER MANNER.
- ALL INTERNAL CABLES MUST BE ROUTED IN THE ORIGINAL MANNER WITHIN THE CABLE CLAMPS PROVIDED FOR THAT PURPOSE.
- ALL EXTERNAL CABLING MUST BE SECURED AND THE PROPER CABLE USED TO ENSURE THAT CABLE SHIELDING IS PROPERLY GROUNDED TO THE CABLE CLAMPS PROVIDED.
- ALL HARDWARE MUST BE PROPERLY SECURED.




Figure 4-7. Rear View of Mainframe



## INSTALLATION

### 4.6 MAINFRAME INSPECTION

#### NOTE

Quality assurance procedures and tests have shown that VS mainframes arriving on the customer's premises require only visual inspection, voltage checks, software loading, and cabling. Therefore, the following inspection and installation procedures for all VS mainframe products are in effect.

#### DO NOT REMOVE PRINTED CIRCUIT BOARDS FOR INSPECTION

#### DO NOT CLEAN PRINTED CIRCUIT BOARD CONTACTS WITH AN ERASER

#### INSPECT CPU MAINFRAME VISUALLY

#### REPORT INSTALLATION PROBLEMS ON THE INSTALLATION REPORT AND STATE SPECIFIC CAUSES OF FAILURE

1. Remove the top and front covers from the VS-300 cabinet. (Refer to paragraph 5.3.2.1)
2. Remove the shipping protector from the SCU floppy diskette drive.
3. Inspect the interior of the mainframe for packing material or such shipping damage as broken connectors and loose fastening hardware.
4. Refer to the shipping list to make sure that the correct circuit boards have been shipped.
5. Make sure all circuit boards are properly seated in the backplane.
6. Carefully inspect the backplane and the power supply and Support Control Unit (SCU) fans for obvious damage.
7. Inspect the power supply assemblies for damage and loose connections. At this time, make sure that all power supply connections are tight.
8. If necessary, vacuum clean the unit.
9. Do not reassemble the mainframe at this time.
10. If damage is discovered at any time during the inspection, follow the reporting procedure in paragraph 4.5.1

#### 4.6.1 PERIPHERAL INSPECTION

After inspecting the mainframe, carefully inspect each peripheral according to procedures outlined in the applicable maintenance manuals. If damage is discovered at any time during the peripheral inspection, follow the reporting procedure in paragraph 4.5.1.

4.7 SOFTWARE/DIAGNOSTIC REQUIREMENTS

4.7.1 SOFTWARE

Table 4-2. Minimum Software Requirements

<u>Software</u>	<u>Version</u>	<u>Comments</u>	<u>WLI P/N</u>
VS-300 SCU	1.02.00	Has CP8 CPU ucode & DCS package	195-4682-9
	1.03.XX	" " " " " " " " " " (Includes FPU ucode)	195-XXXX-X
Operating System	7.06.46		195-4681-7

NOTE

Use of SCU Software versions 1.03.XX and above requires installation of FCO #1189, Real Time Clock function reliability.

4.7.2 DIAGNOSTICS

Table 4-3. Built-In Test (BIT) Programs

<u>Diagnostic Name</u>	<u>PROM Rev.</u>	<u>Package P/N</u>
928 Serial IOC	5560	195-4721-D
SMD Disk IOC	5570	195-4724-D
Kennedy Tape IOC	5560	195-4730-D
Telex Tape IOC	5560	195-4731-D
Multiline TC IOC	5590	195-4729-D

Table 4-4. Other Diagnostics

<u>Diagnostic Name</u>	<u>Version</u>	<u>Package P/N</u>
Uniboot (Boot Loader)	846C	195-2479-3
FTU Off-line	6385	195-2759-3
VOLCOPY	8181	702-0122-A

NOTES

1. Complete 195 package part numbers include diskette and documentation.
2. Diskette only part numbers (702) are shown if no package part numbers are available.

# INSTALLATION

## 4.8 MAINFRAME POWER SOURCE CHECK

### 4.8.1 208-240VAC DOMESTIC POWER SOURCE

There are two options for VS-300 input power service; using existing VS-100 service or installing a new service. Both are discussed below. Before completing the mainframe reassembly and peripheral equipment installation, use a Digital Voltmeter (DMV) to check the mainframe power source receptacle for proper wiring and service as shown in figures 4-8 and 4-9, and table 4-5. Make sure that the receptacle meets all specified requirements before proceeding with the installation.


#### CAUTION

Failure to verify the input power service can result in serious damage to mainframe circuits and to connected peripherals.

#### 4.8.1.1 Using Existing VS-100 Power Service

#### NOTE

Even though ac neutral is not used in domestic VS-300 mainframes, previously properly installed VS-100 mainframe power service can be used without modifications.



NEMA Configuration  
Hubbel Part Number

RECEPTACLE BODY  
L14-30R  
2710


MATCHING CONNECTOR  
L14-30P  
2711

Figure 4-8. 208-240 Volt AC Power Source Requirements for VS-300 Mainframes Using Existing VS-100 Power Service.

4.8.1.2 Installing New Power Service For VS-300s

**NOTE**

New power service for VS-300s can be installed as shown in either figure 4-8 or 4-9, whichever is more convenient. However, if the service shown in figure 4-9 (without a neutral line) is installed, it cannot be reused for a VS-100 mainframe.



	<u>RECEPTACLE BODY</u>	<u>MATCHING CONNECTOR</u>
NEMA Configuration	L14-30R	L14-30P
Hubbel Part Number	2710	2711

Figure 4-9. 208-240 Volt AC Power Source Requirements for New Power Service For VS-300 Mainframes.

Table 4-5. DVM Voltage Measurements 208-240VAC Receptacle

<u>Measure From</u>	<u>Acceptable DMV Readings</u>
Ac Hot (L1) to Ground	120 V ac (+/- 10%)
Ac Hot (L2) to Ground	120 V ac (+/- 10%)
Ac Hot (L1) to Ac Hot (L2)	208-240 V ac (+/-10%)

## INSTALLATION

### 4.8.2 INITIAL MAINFRAME POWER-UP

1. After making sure that the ac On/Off circuit breaker is OFF, plug the mainframe power connector into the power source receptacle.
2. Perform the following:
  - a. Turn ON the mainframe ac On/Off circuit breaker.

### 4.8.3 DC VOLTAGE CHECKS

#### 4.8.3.1 Power Supply Adjustments

1. Remove the left front panel (paragraph 5.3.2.2)
2. Remove the screws from the rear fan panel, disconnect the two fans and set aside the panel.
3. Press the Control Panel On button or SW1 (On) on the Power Supply Controller. Make sure the On lamp on the Control Panel and the voltage sensing LEDs 1 - 5 on the Power Supply Controller are lit. If the LEDs are not lit or go out after a few seconds, there is a problem with either of the power supplies, or the Power Supply Controller board. No adjustments can be done until the problem is corrected. Do the following:
  - a. Remove the 4-pin connector from either J5 (multioutput power supply control) or J4 (booster power supply control) of the Power Supply Controller board. (Figure 4-12.)

#### WARNING

Inserting the test jumper as described in step b (below) will immediately turn on the switching power supplies if the ac On/Off circuit breaker is on.

- b. Insert the Power Supply Test Plug (WLI P/N 220-2342) into P5 (cable to the multioutput p/s) or P4 (cable to the booster p/s).
  - c. If the power supply comes up and stays up, the power supply is good. (Refer to Chapter 7 for troubleshooting procedures for the 210-8709 Power Supply Controller board.) If the power supply still does not come up, replace the supply. (Paragraph 5.3.2.22 or 5.3.2.24.)
  - d. Disconnect the test jumper and reconnect the cable to J4 or J5 on the Power Supply Controller.
4. The following power supply voltages should be measured at the test points on the Power Supply Controller. Adjust the voltages to the readings listed below using the potentiometers on the front of the particular switching power supply at the rear of the mainframe (figures 4-10 and 4-11).




Figure 4-10. Multioutput Power Supply

PHOTO NOT AVAILABLE

Figure 4-11. Booster Power Supply

## INSTALLATION

**Table 4-6. Power Supply Voltage Measurements**

<u>Test Point</u>	<u>Adjust (P/S)</u>	<u>Volts</u>	<u>Minimum</u>	<u>Maximum</u>	<u>AC Ripple Limits</u>
TP+5VA	V1 (P/S 1)	+5.0A	+4.96	+5.04	35mV RMS or 50mV Pk-to-Pk
TP+5VB	5V (P/S 2)	+5.0B	+4.96	+5.04	35mV RMS or 50mV Pk-to-Pk
TP+12V	V2 (P/S 1)	+12.0	+11.96	+12.04	35mV RMS or 50mV Pk-to-Pk
TP-5V	V3 (P/S 1)	-5.0	-4.96	-5.04	35mV RMS or 50mV Pk-to-Pk
TP-12V	V4 (P/S 1)	-12.0	-11.96	-12.04	35mV RMS or 50mV Pk-to-Pk
TPGROUND		+/-0	+/-0	+/-0	

### NOTE

1. P/S 1 is the multioutput supply.
2. P/S 2 is the booster supply.
3. It is better to have the +5 V adjusted more toward the maximum than toward the minimum.

#### 4.8.3.2 Power Supply Controller Adjustments

1. On the Power Supply Controller board (figure 4-12), measure/adjust the calibration voltages at:
  - a. TP 8 for 8 volts. On Rev. 0 boards, adjust R11. (There is no TP 8 or adjustment on Rev. 1 boards.)
  - b. TP 2.5 for 2.5 volts. On Rev. 0 boards, adjust R12. (There is no TP 2.5 or adjustment on Rev. 1 boards.)
2. Set the 4-bit Voltage Address switch SW3 (table 4-7) on the Power Supply Controller board to the A/D input be adjusted.


**Table 4-7. DC Voltage Address Switch SW3 Settings**

<u>Voltage</u>	<u>Bit 1</u>	<u>Bit 2</u>	<u>Bit 3</u>	<u>Bit 4</u>
-5.0	On	Off	Off	X
-12.0	Off	On	Off	X
+12.0	On	On	Off	X
+5.0B	Off	Off	On	X
+5.0A	On	Off	On	X

### NOTES

1. X = don't care (position 4 not used)

# INSTALLATION



B-02080-FY85-14

Figure 4-12. Power Supply Controller Board. (Rev. 0 Version)



# INSTALLATION

- Look at the two hex displays on the Power Supply Controller board. Using the potentiometers on the Power Supply Controller board, adjust the A/D outputs to the hex display values as shown in table 4-8. Change the Voltage Address switch for each voltage to be measured/adjusted.

**Table 4-8. A/D Output Values At Hex Displays**

<u>Voltage</u>	<u>Adjust</u>	<u>Minimum Hex Value</u>	<u>Exact Hex Value</u>	<u>Maximum Hex Value</u>
-5.0	R21	7E	80	82
-12.0	R22	7E	80	82
+12.0	R18	7E	80	82
+5.0B	R20	7E	80	82
+5.0A	R19	7E	80	82

- From the SCU DCS Test Selection Menu, select the VS XXX Environment.

```

mm/dd/yy           Wang VS Diagnostic Control System           hh/mm/ss
                    prerelease 5.03.14p
                    □□□□ □□□□ □□□□ □□□□

Sequence: 1                               Error Cnt: 0
Diagnostic: R1530 VSXXX Environment
Test: Display

| DCS Status: Diagnostic Executing |

Voltage Readings = +5.000 +5.000 -5.000 +12.00 -12.00 Air Flow = 01
SCU Control Registers = 4700 ACFF           SCU Registers = C804 5000
CPU SCR = 4400      FPU SCR = EEEE      MCU SCR = 0000      SBI SCR = 0000

Control Panel Key switch is set to NORMAL

System Reset has been pressed

AC power has been cycled
    
```

**Figure 4-13. Environment Test Screen**

5. Look at the Environment Test Screen on the Support Control Unit (SCU) screen. (Figure 4-13.) The voltages shown in table 4-9 will appear on the screen.

**NOTE**

Do not use the Environment Test Screen on the SCU to adjust the voltages. It is strictly a monitor and will not respond quickly enough to do a reliable voltage adjustment. Adjust the A/D outputs while viewing the hex display.

**Table 4-9. DC Voltages On SCU Screen**

<u>Voltage</u>	<u>Minimum</u>	<u>Maximum</u>
+5.0(A)	+4.96	+5.04
+5.0(B)	+4.96	+5.04
-5.0	-4.96	-5.04
+12.0	+11.96	+12.04
-12.0	-11.96	-12.04

**4.9 IPL PROCEDURES**

If the voltage checks are correct, the system can be IPLed. If the system fails to IPL, the software may have to be installed on the SCU. Refer to paragraph 4.9.2. Make sure that the following have been connected to the system.

1. The SCU must be connected to J9 and J10 of the rear panel labeled "Cable Concentrator". J9 and J10 connect to Port 0 of the APA panel for the first SIO IOC. (Figures 4-22 and 4-24.)
2. The "B" cable of the system disk is attached to the top left "B" cable connector, labeled "0", of the disk connector assembly in the rear panel for the first disk IOC. (Figure 4-26.) The "B" cable from this connector assembly must be connected to J4 of the 23V98 Disk IOC in card cage slot 17.

**4.9.1 IPLING THE VS-300**

Follow this procedure to perform an IPL.

1. Make sure the Front Panel key switch is in Normal Control position.
2. Power up the system disk drive.
3. Press the System Reset pushbutton and then press the Operator Console Reset pushbutton.

## INSTALLATION

4. After a pause, the SCU start-up sequence is invoked and start-up messages appear on the SCU screen:

```
"WANG SUPPORT CONTROL UNIT REV. X.XX"  
"01 Start From Winchester"
```

5. Followed by:

```
"Wang Support Control Unit - BIOS X.XX"  
"MS-DOS Version X.XX"
```

```
SYSCON X.X.X  
  
Copyright Wang Laboratories, Inc. 1985
```

6. The Console Processor screen then appears.

```
      <<< System in Control Mode >>>  
  
      *** Wang VS System Console ***  
  
SYSCON Version X.XX      11:06 AM      Monday, January 6, 1986  
  
      Press (HELP) for online system console information.  
  
      Use the function keys to select a command:  
  
(1) ENTER Workstation Emulation      (8) RESET System  
(2) ENTER Control Mode                (9) RESET Console  
  
                                         (12) SET Console Defaults  
(5) AUTO IPL                          (13) SET Time and Date
```

Figure 4-14. Console Processor Screen

### NOTE

The functions that the key switch allows in any one of the four key switch positions are highlighted on the Console Processor screen.

Certain elements of the System Console Menu are password-protected to prevent unauthorized use of some SYSCON facilities. These elements are not immediately displayed.

7. If it is necessary to load any SCU software, do step 7. If no software is to be loaded, go to step 8.
  - a. Place the Front Panel key switch in the "Remote Service" position.
  - b. Type in the following password:

CSG, plus the current four digit time as displayed on the System Console screen. Example: If time is 9:30 (am or pm), enter 0930.

**NOTE**

The password will not appear on the screen. Also, while entering the password, the keyboard beeper will sound as each key is pressed. This is normal. It is intended to keep unauthorized personnel from enabling the Full System Console menu.

- c. A modified Console Processor screen in service mode, figure 4-14a, will appear.

```

*** WANG VS System Console ***

SYSCON Version X.X.X           2:44 PM           Monday February 11, 1986

Press (HELP) for on-line system console information.

Use the function keys to select a command:

(1) ENTER Workstation Emulation      (8) RESET System
(2) ENTER Control Mode                (9) RESET Console
(3) ENTER Service Log Mode           (10) Terminate Service Mode
(4) ENTER Off-line Diagnostics       (11) Show Error Log
                                       (12) SET Console Defaults
(5) AUTO IPL                          (13) Set Time and Date
(29) Install Software                (32) Wang PC Emulation

```

Figure 4-14a. Modified System Console Screen in Service Mode

## INSTALLATION

- d. Insert the diskette to be loaded in the diskette drive and close the door.
  - e. Press PF29 (Shift + Command), for Install Software. The diskette will begin loading onto the SCU disk drive.
  - f. Upon a successful load, a "Diskette installed" message will appear and the system will return to the modified Console Processor screen in service mode.
  - g. If no more software is to be loaded, press PF10, Terminate Service Mode, and return the key switch to the "Normal Control".
8. a. Press PF5 (AUTO IPL). This message appears:
- "WARNING: This function resets the system, RETURN to proceed or PF16 to abort"**
- b. Press RETURN. (If the console defaults need modifying, or if the CPU code has not been loaded, a CPU or IPL error may appear. Go to step 9. If there are no changes necessary, or no CPU or IPL errors appear, go to step 10.)
9. a. Press PF12 (SET Console Defaults). The System Console Default screen appears.

```
          <<< System in Control Mode >>>

          *** System Console Defaults ***

IPL Device Address: R 0100

CPU Microcode File: /SCU/OBJVSE.CP8
FPU Microcode File:

WS Emulator Options: -PC


Give Console Date/Time to VSOS: N
Warning message before a reset: Y

(9) Modify Defaults      (10) Load System Microcode      (16) Exit
```

Figure 4-15. System Console Default Screen

## INSTALLATION

- 1) If defaults are incorrect, press PF9 (Modify Defaults), make corrections as shown in figure 4-15, press RETURN, and/or:
  - 2) Whether defaults were corrected or not, press PF10 (Load System Microcode).
- b. Press PF16 (Exit). and the Console Processor screen (figure 4-14) reappears.
  - c. Press PF5 (AUTO IPL). This message appears:  
  
"WARNING: This function resets the system, RETURN to proceed or PF16 to abort"
  - d. Press RETURN.
10. The Workstation Initialization Screen, figure 4-16, appears.



**Figure 4-16. Workstation Initialization Screen**

11. The SYSGEN Configuration Screen (figure 4-17) appears.

## INSTALLATION

```
***MESSAGE M001 BY SYSGEN

      INFORMATION REQUIRED BY PROGRAM

      ACTIVE SUBPROGRAM IS @SYSGEN@

Specify the name of the system configuration file and press (ENTER)
      -or-
      Press (1) to use one workstation and one disk.

      SYSFILE = @CONFIG@
      SYSLIB  = @SYSTEM@

Specify the communications configuration file to be use, if any

      COMMFIL = *****
      COMMLIB = @SYSTEM@

Inhibit logons at all workstations?          LOGONS = NO■
Load Micro Code to all devices?             LMCODE = NO■
Inhibit dumping continuable halts?         CMDUMP = NO■
```

Figure 4-17. SYSGEN Configuration File Screen

### NOTE

If the IPL was unsuccessful and an "IPL failed" message is received, refer to paragraph 4.9.3, IPL Errors

12. a. On the SYSGEN Configuration File screen, enter the names of the configuration files and the system library to be used. The field for the communications configuration file is blank. Fill in the communications configuration file field only if communications are going to be used. To change one of these values, move the cursor to the appropriate field and enter in the new information. Then, press RETURN.

## NOTE

If the system is being IPLed for the first time, the default values of @CONFIG@ and @SYSTEM@ are used for the configuration file and system library, respectively. After IPLing for the first time, configuration files can be created using GENEDIT. Refer to the VS Software Bulletin Release 7.06.

- b. After the values have been entered, the VS-300 stores them in a start-up file. At the next IPL, the system displays the stored values and allows them to be changed.
  - c. The prompt "Inhibit logons at all workstations?" allows workstation logons to be inhibited. If "YES" is entered, only the SCU user can log on. The default value is "NO", which allows logons at all workstations, which were enabled before this IPL.
  - d. The prompt "Load Micro Code to all devices" lets microcode be loaded to each workstation (including remote workstations) as part of the IPL procedure. If "Yes" is entered, microcode is loaded to each workstation and the IPL process is significantly slower. This option is used when a workstation is hung up or when the workstation configuration has been changed. The default value is "No".
  - e. The prompt "Inhibit dumping continuable halts" allows disabling of the Continuable Dump for errors that do not require reIPL. If "Yes" is entered, Continuable Dumps which do not reIPL the system are not performed and system processing continues with the system error in effect. If "No" is entered, all Continuable Dumps occur. The default value is No. Refer to Chapter 7 for more information on the Continuable Dump.
13. Press RETURN when finished with the SYSGEN Configuration File screen. (Or, to bring up a minimum configuration of one workstation [W/S0] and one disk, without changing the default values, just press PF1.)

## NOTE

The IPL procedure automatically activates any remote workstations that have been configured via the remote workstation parameters in the GENEDIT procedure.

14. After pressing RETURN from the SYSGEN Configuration File screen, the VS-300 checks to determine if any of the critical operating system components are obsolete or incompatible. If no problems are detected, the IPL continues and the message "System Generation in Progress" appears on the SCU.



## INSTALLATION

- a. If incompatibilities exist that can cause problems, the IPL is stopped and a warning message is displayed.
15. The message "I/O Subsystem Load in Progress" appears on the SCU screen.
16. a. If the SCU real time clock is not usable, the date and time screen appears. Enter the correct date and time, and press RETURN.  
b. This screen also allows changing the amount of memory available for use. The default value is the total amount of physical memory for the system. To change the value, move the cursor to the field, enter the new value, and press RETURN.
17. The message "System Initialization in Progress" appears on the SCU screen.

The VS-300 is now initialized and ready for operation. VS workstation emulation is running on the SCU and the Operator's screen is displayed. To log on from the SCU;

1. Press PF1 and the VS Logon screen appears.
2. Enter the User ID and Password. (As this is the first time that the system has been IPLed and logged onto, use "CSG" for the User ID and leave the Password field blank.)
3. Press RETURN. The User screen is displayed.

Usually, the SCU is Workstation 0; while workstation emulation is running, perform all Workstation 0 tasks from the SCU. See Chapter 3 of the VS-300 Processor Handbook for information on running the SCU; see Chapter 4 for procedures for running Operator's tasks.

Once workstation emulation is running on the SCU, it is interrupted when one of several conditions occur. When workstation emulation is suspended, Workstation 0 functions are maintained by the SCU; however, they are not displayed on the screen. The conditions interrupting workstation emulation are:

1. Exiting workstation emulation (press CONTROL, then press SHIFT and CANCEL simultaneously, then select Suspend Emulation and press EXEC). (Returns to figure 4-14, the Console Processor Screen.)
2. The VS-300 enters Control mode automatically.

If a system element, such as an IOC, fails, the VS-300 does not automatically enter Control mode. Rather, it displays the problem on the screen and continues operation.

After Control mode is manually invoked and then exited, workstation emulation has to be selected from the Console Mode menu to reenter Operator's mode.

## 4.9.2 1.03 SCU SOFTWARE INSTALLATION

The SCU and SCU Installation utility software are stored on the floppy diskettes that are auto-enclosed with the VS-300. Generally, SCU software need only be installed if the system failed to IPL, or if the SCU fixed drive (the SCU Winchester) is damaged (e.g., during a power outage).

1. If the system is not already powered up:
  - a. Make sure that the key switch on the Control Panel is turned to the Normal Control position.
  - b. Power up the mainframe and W/S 0 (SCU) by pressing the Power On pushbutton on the Control Panel. Don't power on external disk drives.
2. If the system is already powered up, enter Control Mode, power off any external disk drives, and exit Control Mode. Then, press the Operator Console Reset pushbutton.
3. Watch the SCU keyboard. As soon as the keyboard lights go out and the beep signal sounds, press the HELP key.
4. When the Options menu appears on the SCU screen:
  - a. Insert the Install diskette in the diskette drive and close the door.
  - b. Press D. (Re-direct Start)
  - c. Press A.
  - d. Press Return.
5. The start-up message appears on the SCU screen:  
**"01 Start From Drive A"**
6. Followed by:  
**"Wang Support Control Unit - BIOS X.XX"**  
**"MS-DOS Version X.XX"**  
**"Loading Menu"**
7. The SCU Install Utility menu appears. (See figure 4-18.)

## INSTALLATION

```
mm/dd/yy           Wang Laboratories, Inc.           hh:mm:ss
                   Support Control Unit Install Utility
                   Version. XX.XX.XX

Select an Item and Proceed

                   ■ Analyze Winchester Disk
                   _ Format Winchester Disk
                   _ Realign and Format Winchester
                   _ Install SCU Software

                   SPACE BAR - Item Select
                   EXECUTE   - Proceed
                   CANCEL    - Previous Menu
```

Figure 4-18. SCU Install Utility Menu

This menu presents four choices:

- a. Analyze Winchester Disk - This utility checks the Winchester disk; it corrects inconsistencies in the File Allocation Table (FAT) and reports the number of extents.
  - b. Format Winchester Disk - This utility erases all existing files and prepares the Winchester to accept new files. It takes about 6 minutes.
  - c. Realign and Format Winchester - This utility does a complete reformatting of the Winchester, including several passes across the disk to erase current files and file information. It takes about 1 hour and 40 minutes to complete.
  - d. Install SCU software - This utility loads the SCU software onto the Winchester.
8. a. Press the space bar (or press "F") to select Format Winchester Disk. (Formatting takes about six minutes.)
- b. Press EXEC. The following message appears on the screen:
- ```
"Format version X.X.XX"
"Type 'Winchester' to begin formatting C:"
```
- c. Enter Winchester and press RETURN. The following messages appear on the screen during formatting:
- ```
"Formatting..."
"Writing Winchester"
"Building Winchester FAT table..."
```

d. When formatting is complete, this request appears on the screen:

"Volume label (11 characters, RETURN for none)?"

Either label the volume or press RETURN for no label.

e. The following message appears on the screen:

"Format Completed..."  
 "----- bytes total disk space"  
 "----- bytes available on disk"

f. Figure 4-18, the SCU Install Utility Menu, reappears.

9. Select the Install SCU Software option from the Support Control Unit Install Utility menu and press EXEC. The "Setting Up Winchester" message appears, followed by the SCU Install Utility screen, figure 4-19.




Figure 4-19. SCU Install Utility Screen

10. Remove the Install diskette from the diskette drive. Insert any one of the other SCU software diskettes in the diskette drive. It does not matter which one is used first, or if the same diskette is accidentally inserted twice. Close the diskette drive door.

**NOTE**

Once the Install has been used to start up the Install utility, do not copy it. If it is accidentally copied, terminate the Install utility (step 15) and repeat the installation procedure.

## INSTALLATION

11. Press any key to initiate the installation. The message "Copying ....." with the list of files as they are being copied appear on the screen.

- a. If this error message appears:

**"Not ready reading drive A  
Abort, Retry, Ignore?"**

- 1). Check the arrows on the diskette to make sure that the diskette has been inserted properly in the drive.
- 2). Make sure that the diskette door is completely closed.
- 3). Restart the Install utility by pressing "R".

- b. If this error message appears:

**"Write protect error writing drive A  
Abort, Retry, Ignore?"**

- 1). Remove the diskette from the drive, remove the write-protect tab, and insert the diskette into the drive. Close the door.
- 2). Restart the Install utility by pressing "R".

12. After the files from the diskette are copied to the Winchester, the following message appears:

**"Disk installed.  
Please remove floppy from drive.  
Strike a key when ready."**

13. Remove the diskette from the drive and press any key. The Install utility screen, figure 4-19, reappears. Insert another diskette and press any key. Repeat this step until the files from all the diskettes have been copied.
14. After the files from the last diskette have been copied, remove any diskette from the diskette drive and leave the diskette drive door open. Terminate the Install utility.
15. Press the Operator Console Reset pushbutton on the Control Panel. The SCU start-up messages appear, followed by the Command Processor screen.

### 4.9.3 IPL ERRORS

There are four major errors that can be encountered in an unsuccessful IPL. Table 4-10 lists the errors and the action necessary to correct them.

Table 4-10. IPL Errors

Error	Description	What To Do
IPL Failed, No SQB (Status Qualifier Byte) received from IOC	The request to the IOC was made, but not acknowledged.	Check the second digit of the 4-digit hexadecimal IPL device number; it may reference an invalid IOC. Change the number and re-IPL. Press System Reset pushbutton.
IPL failed, no interrupt received from IOC	This indicates a system bus problem.	Check all four digits of the hexadecimal IPL device number to see if the number is valid. Change the number and reIPL. Press the System Reset pushbutton.
IPL failed, invalid SQB (Status Qualifier Byte)	The IOC may be experiencing a problem.	IPL from another device; change the 4-digit hexadecimal IPL device number for the new device and reIPL. Press the System Reset pushbutton.
IPL failed: Intervention required.	The IPL drive is not powered on, the disk be damaged, or the drive may be defective.	Power on the drive, change the disk, or change the IPL drive. If changing the IPL drive, change the 4-digit hexadecimal IPL device number. ReIPL the system. Press the System Reset pushbutton.

#### 4.9.4 VERSION CHECKING DURING IPL

If any operating system component cannot be found or has no version number or too low a version number, the system displays the Version Warning screen (figure 4-20) on the SCU.

The Version Warning screen lists all the operating system and bus processor components checked, up to and including the component that causes the "Fatal Error" message to appear on the screen. The sample Version Warning screen (figure 4-20) lists the entire set of operating system and bus processor components to be checked. The entry for any component causing a version number problem is blinking. The current version of the NUCLEUS file is listed at the top of the screen. This screen also lists component information, such as component name, the minimal (oldest) version that will run with the current NUCLEUS file, and the current version number for that component and its status.

# INSTALLATION

WARNING			
Some components of the WANG VS OPERATING SYSTEM could not be identified as the latest versions for the current NUCLEUS file (rel X.XX.XX)			
<u>Component</u>	<u>Minimal Version</u>	<u>Current Version</u>	<u>Status</u>
@SYSGEN@	07.06.02	07.06.03	
@SYSSVC@	07.06.06	07.06.06	
@SYSTSK@	07.06.06	06.30.57	FATAL ERROR
@TSKMGR@	07.06.03	07.06.03	
@OPER@	07.06.05	07.06.05	
@SYSCPR@	07.06.02	07.06.02	
@SHARER@	07.06.03	07.06.03	
@PRTTSK@	07.06.02	07.06.02	
@MCBP@	07.06.03	07.06.03	
DEVLST	07.06.30	07.06.25	WARNING

You may continue by pressing ENTER

**Figure 4-20. Sample Version Warning Screen**

The Status field located on the Version Warning screen indicates a status error message if the component is in error. The status error messages are listed in table 4-11.

**Table 4-11. Version Checking Status Error Messages**

<u>Message</u>	<u>Definition</u>	<u>Components</u>
(blank)	No problems are detected.	
WARNING	A version problem exists with this component, though it is not critical enough to halt system initialization.	@PRTTSK@ @SHARER@ DEVLST
FATAL ERROR	IPL procedures cannot continue. Obtain a current, compatible version of the component and then reIPL.	@SYSGEN@ @SYSTSK@ @OPER@ @SYSCPR@ @TSKMGR@

If the VS-300 cannot determine a component's version number, the Current Version field displays UNKNOWN as the version number. This error usually occurs if the file does not exist. If no fatal problems exist (i.e., "NonFatal Error"), continue the IPL procedure by pressing RETURN. If, when pressing RETURN, there is a "Fatal Error", the VS-300 enters Control mode.

If the system detects a version number problem with the @SYSSVC@ component, it may not display the Version Warning screen and it may enter Control mode. Depending on the version numbers of @SYS000@ and @SYSSVC@, the following message is displayed on the workstation screen:

**CURRENT @SYS000@ CANNOT SUPPORT CURRENT @SYSSVC@**

When the system enters Control mode, the Control Mode Dump procedure may have to be performed, as described in Chapter 7.

**4.10 PERIPHERAL INTERCONNECTION**

After the system has been IPLed and GENEDIT has been run, power down the mainframe and connect all peripheral devices according to the configuration created during GENEDIT. See figures 4-21 through 4-30, the following paragraphs, and appropriate documents for cabling procedures.

<u>PANEL #</u>				<u>PANEL #</u>
1	OPTIONAL	(e)	OPTIONAL	11
2	OPTIONAL	(e)	OPTIONAL	12
3	OPTIONAL	(e)	OPTIONAL	13
4	OPTIONAL	(e)	OPTIONAL	14
5	WS24 SIOC1	(a)	CIU	15
6	WS16 SIOC1	(a)	OPTIONAL	16
7	WS8 SIOC1	(a)	OPTIONAL	17
8	WS0 SIOC1	(a)	OPTIONAL	18
9	BLANK	(f)	DIOC1	19
10	BLANK	(f)	PERIPHERAL BAND	20

Figure 4-21. VS-300 I/O Panel Basic Positions



## INSTALLATION

### NOTES

- a. Panel position 8 reserved for W/S0. Panel positions 5 through 7 used for remaining daisy chained Active Port Assembly (APAs) on first SIOC. Cable Concentrator(s) (CC) configured with next eight SIO panels (second & third SIOCs) for total of 64 ports per CC. CCs will be shipped with all cables necessary to fully populate the CC. Additional SIO panels, over the 64-port mainframe limit, will require additional CCs be ordered.
- b. Panel position 19 allocated to first 4-port disk IOC panel.
- c. Panel position 15 allocated for Cable Interface Unit (CIU) modem & CAB (Contention Access Board).
- d. Panel position 20 allocated for WangNet Peripheral Band (P-Band) modem, if physically possible.
- e. Remaining panel positions may be used for remaining disk, tape, SIO IOC panels, and WangNet P-Band modems. MLTC panels should be mounted on the right side only.
- f. Panel positions 9 & 10 will normally be blank panels. This will permit access to the +5V(B) booster power supply for adjustment or replacement.

#### 4.10.1 I/O CONNECTOR ASSEMBLY TO IOC CABLING

Before installing cables in the connector assemblies at the rear of the mainframe, check all cables between the assemblies and associated IOCs. The SCU must be connected to J9 and J10 of the rear panel labeled "Cable Concentrator". J9 and J10 connect to Port 0 of the APA panel for the first SIO IOC.

Make sure that the "B" cable of the system disk is attached to the top left "B" cable connector, labeled "0", of the disk connector assembly in the rear panel for the first disk IOC. The "B" cable from this connector assembly must be connected to J4 of the 23V98 Disk IOC in card cage slot 17.

#### 4.10.2 SERIAL CONNECTORS

Serial I/O devices (workstations, printers, etc.) connect to the mainframe by means of standard BNC/TNC connectors mounted on 16-connector (8-port) Active Port Assembly (APA), WLI P/N 270-0975. Maximum cable length for these devices is 2000 feet. The APAs connect to J2 of the 23V97 Serial IOCs through a 34-pin ribbon cable. Four APAs are supported by each 23V97 IOC. See figure 4-22.

The APAs can also be mounted in the free standing Cable Concentrator unit.

The 23V97 IOC also supports the 6550 Gate Array TC controller (paragraph 4.10.5), and the existing WangNet P-Band 19-channel Global modem and the new 28-channel Global modem (paragraph 4.10.8). Connector J1 on the IOC is always reserved for P-Band. No other type of devices should be connected to J1.

The 6550 Gate Array TC controller, and the WangNet P-Band Global modems can also be housed in the Cable Concentrator unit. (See figures 4-23, 4-24 and 4-25.)





Figure 4-22. First Active Port Assembly BNC/TNC Connector Assembly




B-02442-FY85-3

Figure 4-23. P-Band Modem Connections

# INSTALLATION


## 4.10.3 CABLE CONCENTRATOR

The Cable Concentrator is a free standing unit used to house APA and Gate Array TC connector panels, and WangNet P-Band modems.



B-02442-FY85-2

Figure 4-24. VS-300 Cable Concentrator Rear Panel



B-02442-FY85-1


Figure 4-25. Cable Concentrator Connections

#### 4.10.4 DISK CABLE CONNECTORS

Two types of disk cable connectors are located on the disk connector assembly, WLI P/N 270-1006. The four narrow connectors are 26-pin sockets for the "B" cable connections; the wide connector is a 60-pin socket for the "A" cable connection.

Before connecting an external disk cable, prepare it as follows, if necessary:

1. Remove the cover plate from the disk connector assembly.
2. Remove 4 inches of plastic sheathing from one end of the cable.
3. Disassemble the cable clamps on the cover plate by removing the Phillips screws on either side of the clamp. (Figure 4-26.)
4. Lay the shielded section of the external "A" disk cable against the face of the clamp at the right side of the plate. Leave 1/4 inch of foil exposed.
5. Lay the shielded section of the external "B" disk cable(s) against the face of the clamp at the left side of the plate. Group all four "B" cables on the left side. Leave 1/4 inch of foil exposed.
6. Reassemble the cable clamps by installing the two Phillips screws removed in step 3. Make sure that pin 1 of the cables are oriented properly and tighten the clamp screws until solid contact with the shield is made. DO NOT overtighten the Phillips screws, as this could damage the disk cables.
7. Plug the cables into the cable connectors on the disk connector assembly. The top left "B" cable connector attaches to Port 0 of the associated 23V98 Disk IOC, the bottom left "B" cable connector attaches to Port 1, and so forth. The extreme left connector on the assembly attaches the "A" cable daisy-chained through each drive to the VS-300 mainframe.
8. Reinstall the disk connector assembly cover plate.



B-02442-FY85-7

Figure 4-26. 270-1006 "A" and "B" Cable Connector Assembly

#### 4.10.5 TELECOMMUNICATION CONNECTORS

If either the Multiline TC (MLTC) or the Gate Array option is to be installed, the TC cables must be attached to a MLTC connector assembly, WLI P/N 270-1003, or Gate Array connector assembly, WLI P/N 270-1016, at the rear of the mainframe (or on the Cable Concentrator).

Each MLTC assembly provides 16 ports in support of only one type of TC protocol at a time. If the customer's TC requirement calls for support of Automatic Calling Units (ACU), each ACU requires one RS232C port link and one RS366 port link. Currently, each VS-300 supports two MLTC options for a total of 32 ports.

The Gate Array supports only one type of TC protocol at a time. Support of two types of protocols requires a second Gate Array assembly. A single Gate Array assembly must be reinitialized (reIPL'ed) to support another type of protocol.




Figure 4-27. Multiline TC (MLTC) Connector Panel

INSTALLATION





Figure 4-28. Gate Array TC Connector Panel

4.10.6 KENNEDY TAPE DRIVE CONNECTORS

The Kennedy tape connector assembly (WLI P/N 270-1005) is used when one or more Kennedy tape drives are connected to the mainframe. Two 50-pin sockets (labeled Control #1 and Data #2) are located on the assembly for connection to the drives. Note the orientation of the cable plugs when inserting them into the 50-pin sockets.



B-02442-FY85-6

Figure 4-29. 270-1005 Kennedy Tape Drive Connector Assembly



## INSTALLATION

### 4.10.7 TELEX TAPE DRIVE CONNECTORS

The Telex tape connector assembly (WLI P/N 270-1007) is used when one or more Telex tape drives are connected to the mainframe. Three 50-pin sockets (labeled 0, 1, and 2) are located on the assembly for connection to the drives. Note the orientation of the cable plugs when inserting them into the 50-pin sockets.





Figure 4-30. 270-1007 Telex Tape Drive Connector Assembly

4.10.8 P-BAND CONNECTORS

The WangNet Peripheral Band (P-Band) is supported by the 23V97 Serial IOC. Connector J1 on the IOC is always reserved for the P-Band. P-Band supports Ergo Workstations and Netmux.


The complete Peripheral Band assembly model number is 23V67W-19, which includes the Serial IOC, Global Modem assembly, all interconnecting cables, and hardware.



B-02983-FY86-1

Figure 4-30a. WangNet P-Band Modem Assembly

# INSTALLATION



B-02983-FY86-4

Figure 4-30b. WangNet P-Band Modem Rear Panel Assembly

**4.11 REMOTE LINK (FOR 1.02 SCU SOFTWARE)**

Remote Link will be used on initial VS-300 systems for remote maintenance support. The following provides installation and remote link verification information for version 1.02 of the SCU software.

**4.11.1 REMOTE LINK SPECIFICATIONS**

1. Capabilities:
  - a. Remote operator console and workstation 0 emulation.
  - b. Access to error log and all online diagnostics.
2. Restrictions:
  - a. Can't use Control Mode or run offline diagnostics. System must be running to use Remote Link.
3. Remote Site Requirements:
  - a. Hardware.
    - 1) Phone line - supplied by customer for remote hookup.
    - 2) VS-300 Support Control Unit (SCU) - supplied with the VS-300.
    - 3) Wang WA3451 modem - supplied with the VS-300.
    - 4) "T" connector - supplied with the modem.
  - b. Software.
    - 1) Modified console menu - Remote Link selection added.
    - 2) Remote Link Home Interface program - installed on SCU disk drive.

## INSTALLATION

### 4.11.2 SITE PREPARATION FOR REMOTE LINK


1. During the site installation check, verify that the following order has been placed with the local telephone company by the customer:
  - a. Telephone line for remote maintenance support. (A dedicated line is not required.)
  - b. Telephone for remote maintenance support
  - c. Either of the following modular connecting blocks for the telephone:
    - 1) RJ11C jack for desk top telephones
    - 2) RF11W jack for flush mounted wall telephones

#### NOTE

RF11W flush mount wall phone jack can be used with the "T" connector and a desk top phone, but a wall mounted phone cannot be used.

### 4.11.3 REMOTE LINK INSTALLATION AND VERIFICATION

1. Connect the modem to the phone line, supplied by the customer, through the "T" connector. (Figure 4-31.) (If the phone line is not available, indicate this on the call report. If the installation is among the first 50 systems, the Technical Assistance Center [TAC] should also be notified when status is reported.)
2. Connect the modem to the SCU RS232 connector located on the rear of the mainframe, on the bulkhead below the monitor arm, using the RS232 cable that is supplied with the VS-300.
3. Make sure that the modem switches are set as shown in figure 4-31.



B-02875-FY86-9

Figure 4-31. Modem/Phone Connections and Modem Switch Settings

## INSTALLATION

4. After the system is powered up and IPLed, press the space bar until Console Mode on the SCU screen is highlighted. (Figure 4-32.)




Figure 4-32. SCU Main Menu

5. Press execute.
6. Check the menu for the Remote Link choice. (Figure 4-33.) If Remote Link has not been installed, there will be only two menu choices. (Figure 4-34). If Remote Link has not been installed, go to step 7. If Remote Link has been installed, go to step 11.




Figure 4-33. SCU Console Mode Menu With Remote Link




Figure 4-34. SCU Console Mode Menu Without Remote Link

7. If Remote Link has not been loaded onto the SCU disk drive, press Cancel and select Maintenance Mode on the SCU Main Menu.



# INSTALLATION




Figure 4-35. SCU Main Menu

8. Press Execute. The SCU Maintenance Menu will appear.




Figure 4-36. SCU Maintenance Menu

9. Select Install SCU Software on the SCU Maintenance Menu and press Execute.

## INSTALLATION

10. Copy the Remote Link software to the SCU disk from the Remote Link diskette, SCU diskette number six. Upon completion of this step the SCU Console Menu will have Remote Link for a third menu choice. (Figure 4-33.)
11. When the installation is complete, notify the Technical Assistance Center (TAC) that the system is ready for remote maintenance certification. Supply TAC with the modem phone number and a backup phone number for voice communication. Place the modem offline to allow conformation of the system status.
12. Place the Control Panel key switch in the Remote Service position.
13. A TAC engineer will call back using the modem phone number. The system should be IPLed and running. Workstation 0 must be logged on, or TAC must be provided with a valid logon. Workstation emulation on workstation 0 must be suspended or terminated and Remote Link selected. (Figure 4-33.) The modem is now put into data position and the link verification started.
14. Upon completion of the link verification, TAC will disconnect the Remote Link link and release workstation 0. To exit Remote Link, press the 2ND key and select TERMINATE. The workstation will return to the Console Menu.

**CHAPTER**

**5**

**MAINT-  
ENANCE**

## TABLE OF CONTENTS

CHAPTER 5 MAINTENANCE		Page
5.1	General .....	5-1
5.2	Preventive Maintenance .....	5-1
5.2.1	Special Tools .....	5-1
5.2.2	Materials .....	5-1
5.2.3	Preventive Maintenance Schedule .....	5-1
5.2.4	Electrical Adjustments .....	5-2
5.2.4.1	Power Supply Adjustments .....	5-2
5.2.4.2	Power Supply Controller Adjustments .....	5-4
5.2.4.3	Battery Backup Check .....	5-7
5.2.4.4	Low Battery Voltage Dropout Adjustment .....	5-8
5.2.4.5	Battery Backup Charging Power Supply Adjustment .....	5-9
5.2.5	Peripheral Preventive Maintenance .....	5-10
5.3	Corrective Maintenance .....	5-10
5.3.1	Special Tools .....	5-10
5.3.2	Removal and Replacement .....	5-11
5.3.2.1	Top Cover Removal and Replacement .....	5-11
5.3.2.2	Left Front Panel Removal and Replacement .....	5-13
5.3.2.3	Left and Right Side Panel Removal and Replacement .....	5-15
5.3.2.4	CP Circuit Board Removal and Replacement .....	5-16
5.3.2.4.1	210-8830 Floating Point Unit Removal .....	5-17
	and Replacement	
5.3.2.4.2	210-8831 Central Processing Unit Removal .....	5-18
	and Replacement	
5.3.2.4.3	210-8832 Address Generation Unit Removal .....	5-19
	and Replacement	
5.3.2.4.4	210-8833 Address Translation Unit Removal .....	5-20
	and Replacement	
5.3.2.4.5	210-8835 Support Control Unit Removal .....	5-21
	and Replacement	
5.3.2.4.6	210-8834 Memory Control Unit Removal and Replacement .....	5-22
5.3.2.4.7	210-8703/210-8703-1 Main Memory Removal and Replacement ...	5-23
5.3.2.4.8	210-8836 System Bus Interface Removal and Replacement .....	5-24
5.3.2.5	IOC Circuit Board Removal and Replacement .....	5-25
5.3.2.5.1	23V97 (210-8609) Serial IOC Removal and Replacement .....	5-26
5.3.2.5.2	270-0975 Serial IOC APA .....	5-27
5.3.2.5.3	6550 Gate Array TC Controller Assembly .....	5-28
	Removal and Replacement	
5.3.2.5.4	23V98-1/2/3/4 (210-8785) Disk Drive IOC Removal .....	5-30
	and Replacement	
5.3.2.5.5	23V95-1 (210-8790) Kennedy Tape IOC Removal .....	5-32
	and Replacement	
5.3.2.5.6	23V95-2 (210-8789) Telex Tape IOC Removal .....	5-33
	and Replacement	
5.3.2.5.7	23V96 (210-8491) Multiline TC IOC Removal .....	5-34
	and Replacement	
5.3.2.5.8	270-1003 Multiline TC Back Panel Assembly .....	5-36
5.3.2.5.9	23V79 (210-8392) CIU BLANC IOC Removal .....	5-37
	and Replacement	

## TABLE OF CONTENTS (Cont'd)

5.3.2.5.10	210-8391 CIU CAB Board Removal and Replacement .....	5-39
5.3.2.5.11	210-8142 10 MBPS Duobinary Modem Removal .....	5-40
	and Replacement	
5.3.2.5.12	270-0787 Single Channel 10MBPS RF Modem Removal .....	5-41
	and Replacement	
5.3.2.5.13	WangNet P-Band Modem Removal and Replacement .....	5-41a
5.3.2.6	Power Supply Controller Board Removal .....	5-42
5.3.2.7	Power Supply Controller Board Replacement .....	5-43
5.3.2.8	Battery Backup Board Removal .....	5-44
5.3.2.9	Battery Backup Board Replacement .....	5-45
5.3.2.10	Battery Backup Pack Removal .....	5-46
5.3.2.11	Battery Backup Pack Replacement .....	5-46
5.3.2.12	Battery Backup Charging Power Supply Removal .....	5-47
5.3.2.13	Battery Backup Charging Power Supply Replacement .....	5-47
5.3.2.14	Power Distribution Unit and AC On/Off Circuit .....	5-48
	Breaker Removal	
5.3.2.15	AC On/Off Circuit Breaker Replacement .....	5-50
5.3.2.16	Power Distribution Unit Replacement .....	5-50
5.3.2.16.1	Second DC Power Distribution Board Removal .....	5-50a
5.3.2.16.2	Second DC Power Distribution Board Replacement .....	5-50a
5.3.2.17	SCU Professional Computer (PC) Removal .....	5-51
5.3.2.18	SCU Professional Computer (PC) Replacement .....	5-51
5.3.2.19	Control Panel Pushbutton Bulb Removal .....	5-53
	and Replacement	
5.3.2.20	Control Panel Assembly Removal .....	5-54
5.3.2.21	Control Panel Board Assembly Replacement .....	5-54
5.3.2.22	Multioutput Switching Power Supply Removal .....	5-55
5.3.2.23	Multioutput Switching Power Supply Replacement .....	5-57
5.3.2.24	Booster Switching Power Supply Removal .....	5-58
5.3.2.25	Booster Switching Power Supply Replacement .....	5-60

## LIST OF ILLUSTRATIONS

<u>Figure</u>	<u>Title</u>	<u>Page</u>
5-1	Multioutput Power Supply .....	5-3
5-2	Booster Power Supply .....	5-3
5-3	Power Supply Controller Board. (Rev. 0 Version) .....	5-5
5-4	Environment Test Screen .....	5-6
5-5	Battery Backup Time Switch SW4 Settings .....	5-7
5-5a	Battery Backup Charging Power Supply Adjustment .....	5-9
5-6	Top Cover Removal .....	5-11
5-7	Top Cover Removal .....	5-12
5-8	Top Cover Removal .....	5-12
5-9	Left Front Panel Removal .....	5-13
5-10	Left Front Panel Removal .....	5-14
5-11	Left Front Panel Removal .....	5-14
5-12	Left and Right Side Panel Removal .....	5-15

## LIST OF ILLUSTRATIONS (Cont'd)

5-13	VS-300 Card Cage .....	5-16
5-14	210-8830 Floating Point Unit .....	5-17
5-15	210-8831 Central Processing Unit .....	5-18
5-16	210-8832 Address Generation Unit .....	5-19
5-17	210-8833 Address Translation Unit .....	5-20
5-18	210-8835 Support Control Unit .....	5-21
5-19	210-8834 Memory Control Unit .....	5-22
5-20	210-8703 Main Memory .....	5-23
5-21	210-8836 System Bus Interface .....	5-24
5-22	IOC Diagnostic Switch Setting For Power Up .....	5-25
5-23	23V97 Serial IOC .....	5-26
5-24	270-0975 APA .....	5-27
5-25	Daisy Chained APA Assemblies .....	5-27
5-26	270-1016 6550 Gate Array TC Back Panel Assembly .....	5-28
5-27	210-8714 CPU/Gate Array Board .....	5-29
5-28	210-8714 CPU/Gate Array Board With Cabling .....	5-29
5-29	23V98 Disk Drive IOC .....	5-30
5-30	Disk Drive Device Type Switch Settings. ....	5-31
5-31	23V95-1 Kennedy Tape IOC .....	5-32
5-32	23V95-2 Telex Tape IOC .....	5-33
5-33	23V96 Multiline TC (MLTC) IOC .....	5-34
5-34	270-1003 Multiline TC Back Panel Assembly .....	5-36
5-35	270-1003 Multiline TC Back Panel Assembly with Cabling ....	5-36
5-36	23V79 CIU BLANC IOC .....	5-37
5-37	BLANC IOC Functions Switch (L272) Normal Settings .....	5-38
5-38	23V79 CIU CAB Board .....	5-39
5-39	5-Channel 10 Megabit Duobinary Modem .....	5-40
5-39a	Single Channel 10 Megabit Duobinary Modem .....	5-41
5-39b	Wangnet P-Band Modem Panel Assembly .....	5-41a
5-39c	Wangnet P-Band Modem Removal .....	5-41b
5-40	Power Supply Controller Board. (Rev. 0 Version) .....	5-42
5-41	Battery Backup Time Switch SW4 Settings .....	5-43
5-42	210-8717 Battery Backup Board Removal .....	5-44
5-43	210-8717 Battery Backup Board Removal .....	5-45
5-44	Battery Pack Removal .....	5-46
5-45	Battery Backup Charging Power Supply Removal .....	5-47
5-46	PDU Removal .....	5-49
5-47	PDU Removal .....	5-49
5-48	AC On/Off Circuit Breaker Removal .....	5-50
5-48a	Second DC Distribution Board Removal .....	5-50b
5-48b	Second DC Distribution Board Removal .....	5-50c
5-49	SCU Professional Computer Removal and Replacement .....	5-52
5-50	Control Panel Pushbutton Bulb Removal and Replacement .....	5-53
5-51	210-8711 Control Panel Board Removal .....	5-54
5-52	Multioutput Power Supply Wiring Connections .....	5-56
	(With Original Single DC Distribution Board)	
5-52a	Multioutput Power Supply Wiring Connections .....	5-56a
	(With New Second DC Distribution Board)	
5-53	Booster Power Supply Wiring Connections .....	5-59

## LIST OF TABLES

<u>Table</u>	<u>Title</u>	<u>Page</u>
5-1	Power Supply Voltage Measurements .....	5-4
5-2	DC Voltage Address Switch SW3 Settings .....	5-4
5-3	A/D Output Values At Hex Displays .....	5-6
5-4	DC Voltages On SCU Screen .....	5-7
5-5	Main Memory Size Selection Jumpers (L133) .....	5-22
5-6	Main Memory Jumper Configurations .....	5-23
5-7	VS-300 IOC List .....	5-25
5-8	Disk Drive Types (Formatted) .....	5-31
5-9	23V96 Multiline TC IOC Port Select L228 .....	5-35
	Switch Settings For Loopback Test	
5-10	BLANC IOC Functions Switch (L272) .....	5-38
5-11	Multioutput Power Supply Wiring Color Codes .....	5-57
5-12	Booster Power Supply Wiring Color Codes .....	5-60

# CHAPTER 5

## MAINTENANCE

### 5.1 GENERAL

This chapter consists of preventive maintenance (PM), adjustments, and removal and replacement procedures for field-replaceable components in the VS-300 mainframe.

### 5.2 PREVENTIVE MAINTENANCE

Periodic maintenance is essential to the proper operation of the VS-300 mainframe and associated peripherals. Because of its design, the mainframe requires a minimum amount of maintenance to ensure efficient operation.

#### 5.2.1 SPECIAL TOOLS

Description	WLI P/N
Low Battery Voltage Dropout Jumper	220-2341
Power Supply Test Jumper	220-2342

#### 5.2.2 MATERIALS

No special materials are necessary to perform mainframe PM.

#### 5.2.3 PREVENTIVE MAINTENANCE SCHEDULE

PM for the mainframe should be performed at six month intervals, (in conjunction with a service call if no PM has been performed within six months), and is as follows:

Procedure	Item	Notes
Inspect	Mainframe interior	Look for dust & loose hardware. Clean.
Inspect/clean	SCU (PC) diskette read/write heads	Refer to Professional Computer Manual
Inspect	Power supply(s) fan(s) (3) & SCU (PC) fan	Replace power supply. Replace SCU (PC) fan
Check/adjust	Power supply voltages	Paragraph 5.2.4.1
Check (Note)	Backup batteries	Paragraph 5.2.4.3
Run diagnostics	Mainframe & peripherals	Refer to Chapter 7 or applicable maintenance manuals.



## MAINTENANCE

### NOTE

The backup batteries should be replaced every 18 months. Replace all five battery packs at the same time. (Paragraph 5.3.2.10.)

### 5.2.4 ELECTRICAL ADJUSTMENTS

#### 5.2.4.1 Power Supply Adjustments

1. Remove the left front panel (paragraph 5.3.2.2)
2. Remove the screws from the rear fan panel, disconnect the two fans and set aside the panel.
3. Press the Control Panel On button or SW1 (On) on the Power Supply Controller. Make sure the On lamp on the Control Panel and the voltage sensing LEDs 1 → 5 on the Power Supply Controller are lit. If the LEDs are not lit or go out after a few seconds, there is a problem with either of the power supplies, or the Power Supply Controller board. No adjustments can be done until the problem is corrected. Do the following:
  - a. Remove the 4-pin connector from either J5 (multioutput power supply control) or J4 (booster power supply control) of the Power Supply Controller board. (Figure 5-3.)

### WARNING

Inserting the test jumper as described in step b (below) will immediately turn on the switching power supplies if the ac On/Off circuit breaker is on.

- b. Insert the Power Supply Test Plug (WLI P/N 220-2342) into P5 (cable to the multioutput p/s) or P4 (cable to the booster p/s).
  - c. If the power supply comes up and stays up, the power supply is good. (Refer to Chapter 7 for troubleshooting procedures for the 210-8709 Power Supply Controller board.) If the power supply still does not come up, replace the supply. (Paragraph 5.3.2.22 or 5.3.2.24.)
  - d. Disconnect the test jumper and reconnect the cable to J4 or J5.
4. The following power supply voltages should be measured at the test points on the Power Supply Controller. Adjust the voltages to the readings listed below using the potentiometers on the front of the particular switching power supply at the rear of the mainframe (figures 5-1 and 5-2).




Figure 5-1. Multioutput Power Supply

PHOTO NOT AVAILABLE

Figure 5-2. Booster Power Supply

**MAINTENANCE**

**Table 5-1. Power Supply Voltage Measurements**

Test Point	Adjust (P/S)	Volts	Minimum	Maximum	AC Ripple Limits
TP+5VA	V1 (P/S 1)	+5.0A	+4.96	+5.04	35mV RMS or 50mV Pk-to-Pk
TP+5VB	5V (P/S 2)	+5.0B	+4.96	+5.04	35mV RMS or 50mV Pk-to-Pk
TP+12V	V2 (P/S 1)	+12.0	+11.96	+12.04	35mV RMS or 50mV Pk-to-Pk
TP-5V	V3 (P/S 1)	-5.0	-4.96	-5.04	35mV RMS or 50mV Pk-to-Pk
TP-12V	V4 (P/S 1)	-12.0	-11.96	-12.04	35mV RMS or 50mV Pk-to-Pk
TPGROUND		+/-0	+/-0	+/-0	

**NOTE**

1. P/S 1 is the multioutput supply.
2. P/S 2 is the booster supply.
3. It is better to have the +5 V adjusted more toward the maximum than toward the minimum.

**5.2.4.2 Power Supply Controller Adjustments**

1. On the Power Supply Controller board (figure 5-3), measure/adjust the calibration voltages at:
  - a. TP 8 for 8 volts. On Rev. 0 boards, adjust R11. (There is no TP 8 or adjustment on Rev. 1 boards.)
  - b. TP 2.5 for 2.5 volts. On Rev. 0 boards, adjust R12. (There is no TP 2.5 or adjustment on Rev. 1 boards.)
2. Set the 4-bit Voltage Address switch SW3 (table 5-2) on the Power Supply Controller board to the A/D input to be calibrated.


**Table 5-2. DC Voltage Address Switch SW3 Settings**

Voltage	Bit 1	Bit 2	Bit 3	Bit 4
-5.0	On	Off	Off	X
-12.0	Off	On	Off	X
+12.0	On	On	Off	X
+5.0B	Off	Off	On	X
+5.0A	On	Off	On	X

**NOTES**

1. On = 1
2. Off = 0
3. X = don't care (position 4 not used)

MAINTENANCE



B-02080-FY85-14

Figure 5-3. Power Supply Controller Board. (Rev. 0 Version)

**MAINTENANCE**

- Look at the two hex displays on the Power Supply Controller board. Using the potentiometers on the Power Supply Controller board, adjust the A/D outputs to the hex display values as shown in table 5-3. Change the Voltage Address switch for each voltage to be calibrated.

**Table 5-3. A/D Output Values At Hex Displays**

Voltage	Adjust	Minimum Hex Value	Exact Hex Value	Maximum Hex Value
-5.0	R21	7E	80	82
-12.0	R22	7E	80	82
+12.0	R18	7E	80	82
+5.0B	R20	7E	80	82
+5.0A	R19	7E	80	82

- From the SCU DCS Test Selection Menu, select the VS XXX Environment.

```

mm/dd/yy           Wang VS Diagnostic Control System           hh/mm/ss
                    prerelease 5.03.14p
                    □□□□ □□□□ □□□□ □□□□

Sequence: 1
Diagnostic: R1530 VSXXX Environment
Test: Display
Error Cnt: 0

-----
DCS Status: Diagnostic Executing
-----

Voltage Readings = +5.000 +5.000 -5.000 +12.00 -12.00 Air Flow = 01
SCU Control Registers = 4700 ACFF           SCU Registers = C804 5000
CPU SCR = 4400      FPU SCR = EEEE      MCU SCR = 0000      SBI SCR = 0000

Control Panel Key switch is set to NORMAL

System Reset has been pressed

AC power has been cycled
    
```

**Figure 5-4. Environment Test Screen**

- Look at the Environment Test Screen on the Support Control Unit (SCU) screen. (Figure 5-4.) The voltages shown in table 5-4 will appear on the screen.

NOTE

Do not rely on the Environment Test Screen on the SCU to adjust the voltages. It is strictly a monitor and will not respond quickly enough to do a reliable voltage adjustment. Adjust the A/D outputs while viewing the hex display.

Table 5-4. DC Voltages On SCU Screen

Voltage	Minimum	Maximum
+5.0(A)	+4.96	+5.04
+5.0(B)	+4.96	+5.04
-5.0	-4.96	-5.04
+12.0	+11.96	+12.04
-12.0	-11.96	-12.04

5.2.4.3 Battery Backup Check

To check the length of time and the capacity of the backup batteries to provide power for the mainframe, perform the following:

1. Make sure that all operators have logged off the system, inhibit further logons from the Operator's Console menu, and enter Control Mode.
2. Power down the disk drives. Also power down all workstations and other peripheral devices, if possible.
3. Leave the ac On/Off circuit breaker (located on the Power Distribution Unit) in the On position and disconnect the ac power input connector from the power source receptacle.
4. The mainframe should stay powered up for 100 seconds. If the mainframe drops power before 100 seconds time has expired, check the setting of Switch 4 on the Power Supply Controller board. Switch 4 should be set for 100 seconds of backup time for Rev. 0 boards, and (currently) 96 seconds for for Rev. 1 boards.

Switch 4 Settings (Rev. 0 Board)		Switch 4 Settings (Rev. 1 Board)	
	<p><u>Designations</u></p> <p>1</p> <p>2</p> <p>4 Battery</p> <p>8 Backup</p> <p>16 Time</p> <p>32 (Seconds)</p> <p>64</p> <p>128</p>		<p><u>Designations</u></p> <p>16 Battery</p> <p>32 Backup</p> <p>64 Time</p> <p>128 (Seconds)</p> <p>32 Minor</p> <p>64 Voltage</p> <p>128 Time</p> <p>256 (Seconds)</p>

Figure 5-5. Battery Backup Time Switch SW4 Settings

B-02675-FY86-8

## MAINTENANCE

5. If Switch 4 is set correctly, the batteries may not be properly charged (refer to paragraph 5.2.4.5, charging p/s adjustment); or the Power Supply Controller board may be defective (refer to paragraph 7.5.1, Power Supply Controller board fault isolation).

### 5.2.4.4 Low Battery Voltage Dropout Adjustment

1. Turn OFF the mainframe ac On/Off circuit breaker.

#### WARNING

120 V ac remains on J3 if the mainframe ac On/Off circuit breaker is not turned OFF.

2. On the Battery Backup Charging Power Supply, disconnect the 3-pin ac input power cable connector from J3. (Figure 5-5a.)

#### CAUTION

If the mainframe ac On/Off circuit breaker is not turned OFF and J3 is not disconnected before inserting the jumper described below in step 3, the charging p/s will be damaged.

3. On the Battery Backup board disconnect J7, one of the 2-pin battery input cables. Insert the 2-pin Low Battery Voltage Dropout jumper (WLI P/N 220-2341) into J7 of the board.
4. Turn ON the mainframe ac On/Off circuit breaker and press the Control Panel On button or SW1 (On) on the Power Supply Controller. Observe one of the following:
  - a. If the system powers up, carefully adjust R70A on the Power Supply Controller counterclockwise until the system just powers down. Leave R70A in this position.
  - b. If the system does not power up, adjust R70A on the Power Supply Controller clockwise, while pressing the Control Panel On button or SW1 (On), until the system just powers up. Carefully adjust R70A counterclockwise until the system just powers down. Leave R70A in this position.
5. Turn OFF the mainframe ac On/Off circuit breaker.
6. On the Battery Backup board remove the jumper from the battery input cable connector J7 and reconnect this connector and also reconnect the 3-pin connector on J3 on the Battery Backup Charging Power Supply.
7. Turn ON the mainframe ac On/Off circuit breaker and press the Control Panel On button or SW1 (On) on the Power Supply Controller. The system should power up and stay powered up.

#### 5.2.4.5 Battery Backup Charging Power Supply Adjustment

The battery backup charging power supply is adjusted as follows:

1. Set the dc voltage scale on a digital voltmeter for 200 volts.
2. Measure across the two top wires (the black wire, pin 1, and the brown wire, pin 2) of the 6-pin cable connector (J4) on the power supply. (Figure 5-5a.)
3. Turn the power supply adjustment pot, R23, until the meter reads +53.5 volts, +/-1.0 volt.
4. Measure between the other wires of J4 connector as follows:
  - a. Brown (pin 2) and red (pin 3).
  - b. Red (pin 3) and orange (pin 4).
  - c. Orange (pin 4) and yellow (pin 5).
  - d. Yellow (pin 5) and blue (pin 6).
5. If the voltage reading(s) deviate greater than +/-1.0V from 53.5 volts, either the power supply or one of the batteries is defective. (Replace all five battery packs at the same time.)




Figure 5-5a. Battery Backup Charging Power Supply Adjustment



# MAINTENANCE

## 5.2.5 PERIPHERAL PREVENTIVE MAINTENANCE

Refer to the appropriate documents for PM procedures for all VS-300 associated peripherals.

## 5.3 CORRECTIVE MAINTENANCE

### 5.3.1 SPECIAL TOOLS

Description	Part Number
RS232 Loopback Plug	421-0025
RS232/366 Loopback Plug	420-1041
RS449 Loopback Plug	270-3193
X.21 Loopback Plug	421-0010
Low Battery Voltage Dropout Jumper	220-2341
Power Supply Test Jumper	220-2342

## CAUTION

\*\*\*\*\*  
\*  
\* THIS COMPUTER EQUIPMENT HAS BEEN VERIFIED AS FCC CLASS A. \*  
\*  
\*\*\*\*\*

IN ORDER TO MAINTAIN COMPLIANCE WITH FCC CLASS A VERIFICATION, THE FOLLOWING CONDITIONS MUST BE ADHERED TO DURING NORMAL OPERATION OF EQUIPMENT.

- ALL COVERS MUST BE ON SYSTEM AND SECURED IN THE PROPER MANNER.
- ALL INTERNAL CABLES MUST BE ROUTED IN THE ORIGINAL MANNER WITHIN THE CABLE CLAMPS PROVIDED FOR THAT PURPOSE.
- ALL EXTERNAL CABLING MUST BE SECURED AND THE PROPER CABLE USED TO ENSURE THAT CABLE SHIELDING IS PROPERLY GROUNDED TO THE CABLE CLAMPS PROVIDED.
- ALL HARDWARE MUST BE PROPERLY SECURED.

## 5.3.2 REMOVAL AND REPLACEMENT

These paragraphs describe the steps involved in removing and replacing or reinstalling all major field-replaceable components in the VS-300 mainframe.

### 5.3.2.1 Top Cover Removal and Replacement

Remove the top cover as follows: (See figures 5-6, 5-7, and 5-8.)

#### WARNING

The top cover is heavy. Be careful when performing the following steps.

1. At the rear of the cabinet, three Phillips head bolts secure the top cover to the mainframe. Loosen and remove the bolts.
2. Push on the cover until the cover starts to move forward. (Don't pry the cover with a screwdriver and don't let the cover become cocked.)




Figure 5-6. Top Cover Removal

## MAINTENANCE

3. From the front of the mainframe, grasp the front and rear of the cover and pull it forward about 6".




Figure 5-7. Top Cover Removal

4. As the cover moves forward, it will rise in the left and right cam brackets. When the cover is free of the cam brackets, tip it up, and carefully lift it off the mainframe.




Figure 5-8. Top Cover Removal

Reinstall the top cover as follows:

1. Reinstall the top cover by reversing the removal procedure.
2. Carefully slide the top cover back into the cover cam brackets.
3. Alternately tighten the bolts. Don't let the cover become cocked.

### 5.3.2.2 Left Front Panel Removal and Replacement

Remove the left front panel as follows: (See figures 5-9, 5-10, 5-11.)

1. Open the front hinged door by turning the top and bottom keyed latches counterclockwise, then unlock the slam latch.




Figure 5-9. Left Front Panel Removal

## MAINTENANCE

2. Remove the two Phillips head screws (top and bottom) that secure the left front panel to the vertical frame.




Figure 5-10. Left Front Panel Removal

3. The panel rests on three latch buttons. Slide the panel to the left, off the latch buttons, and off the mainframe.




Figure 5-11. Left Front Panel Removal

Reinstall the left front panel as follows:

1. Reinstall the left front panel by reversing the removal procedure.

### 5.3.2.3 Left and Right Side Panel Removal and Replacement

Remove the left or right side panel as follows: (See figure 5-12.)

1. Remove the top cover as described in paragraph 5.3.2.1.
2. Each side panel rests on four latch buttons. Slide the panel(s) up, off the latch buttons, and off the mainframe.




Figure 5-12. Left and Right Side Panel Removal

Reinstall the side panels as follows:

1. Reinstall the side panels by reversing the removal procedure.
2. The panels must be reinstalled with the "L" shaped lip edge toward the rear of the mainframe.

## MAINTENANCE

### 5.3.2.4 CP Circuit Board Removal and Replacement

There are eight different CP boards found in the VS-300. The removal and replacement procedures for the different boards are given in the order in which they are found in the backplane (figure 5-13). A board locator label is mounted on the front of the card cage.

#### CAUTION

Be careful when replacing the large, flexible VS-300 boards. Make sure that all boards are seated properly in the correct backplane slots. Don't damage the sockets when inserting the boards. Make sure all boards have their component sides facing to the left when viewed from the chassis front.




Figure 5-13. VS-300 Card Cage

### 5.3.2.4.1 210-8830 Floating Point Unit Removal and Replacement

1. Enter Control Mode from the Support Control Unit (SCU) Console Mode Menu, and power down the disk drives.
2. Power down the mainframe by pressing the Control Panel Power Off pushbutton (or SW2, Off, on the Power Supply Controller).
3. Open the front hinged door by turning the top and bottom keyed latches (figure 5-9) counterclockwise, unlock the slam latch, and remove the black card cage cover by turning the 1/2 turn fasteners.
4. Each circuit board is held in place by two snap locks. One snap lock tab fits under the edge of the top board guide plate and the second snap lock fits under the edge of the bottom board guide plate.
5. Remove the Floating Point Unit (FPU) (figure 5-14) from backplane slot #1 by lifting the snap locks to free the board from the card cage connectors. Once the board is free of the connectors, ease it forward in the board guides and out of the board cage.
6. Insert the new Floating Point Unit in the board guides and slide it back to the backplane.
7. Make sure the board edge connectors are lined up with the backplane connector slots and the snap lock tabs are under the guide plates.
8. Push back on the snap locks to seat the board in the backplane.




Figure 5-14. 210-8830 Floating Point Unit



## MAINTENANCE

### 5.3.2.4.2 210-8831 Central Processing Unit Removal and Replacement

1. Before removing the Central Processing Unit (CPU), figure 5-15, from backplane slot #2 disconnect the 50-pin cable from J1.
2. Remove the CPU in the manner described in 5.3.2.4.1.
3. After checking the CPU System Address ID jumpers at L50 of the board, install the new CPU.
4. Reconnect the 50-pin cable to J1.




Figure 5-15. 210-8831 Central Processing Unit

### 5.3.2.4.3 210-8832 Address Generation Unit Removal and Replacement

1. Before removing the Address Generation Unit (AGU), figure 5-16, from backplane slot #3 disconnect the 50-pin cables from J1 and J2.
2. Remove the AGU in the manner described in 5.3.2.4.1.
3. Install the new AGU board.
4. Reconnect the 50-pin cables to J1 and J2.




Figure 5-16. 210-8832 Address Generation Unit

## MAINTENANCE

### 5.3.2.4.4 210-8833 Address Translation Unit Removal and Replacement

1. Before removing the Address Translation Unit (ATU), figure 5-17, from backplane slot #4 disconnect the 50-pin cable from J1.
2. Remove the ATU in the manner described in 5.3.2.4.1.
3. After checking the IPC Destination Processor jumpers at L364 or SW1 as shown in figure 5-17, install the new ATU.
4. Reconnect the 50-pin cable to J1.




Figure 5-17. 210-8833 Address Translation Unit

## 5.3.2.4.5 210-8835 Support Control Unit Removal and Replacement

## NOTE

The diagnostics refer to this board as the Support Control Unit Interface (SCUI).

1. Remove the Support Control Unit (SCU) (figure 5-18) from backplane slot #5 in the manner described in 5.3.2.4.1. There are no cables, switches, or jumpers on the SCU.
2. Install the new SCU.





Figure 5-18. 210-8835 Support Control Unit

**MAINTENANCE**

**5.3.2.4.6 210-8834 Memory Control Unit Removal and Replacement**

1. Remove the Memory Control Unit (MCU) (figure 5-19) from backplane slot #6 in the manner described in 5.3.2.4.1. No cables are on the MCU.
2. After checking the MCU System Address ID jumpers at L67, MCU Support Packet Bus ID jumpers at L133, and Main Memory Size Selection jumpers at L133 (figure 5-19 and table 5-5), install the new MCU.



**Figure 5-19. 210-8834 Memory Control Unit**

**Table 5-5. Main Memory Size Selection Jumpers (L133)**

Memory Size		4	8	12	16	20	24	28	32	36	40	44	48	52	56	60	64
	MEG	MEG	MEG	MEG	MEG	MEG	MEG	MEG	MEG	MEG	MEG	MEG	MEG	MEG	MEG	MEG	MEG
Jumper W4		■		■		■		■		■		■		■		■	
Jumper W5			■	■			■	■			■	■			■	■	
Jumper W6					■	■	■	■					■	■	■	■	
Jumper W7									■	■	■	■	■	■	■	■	
Jumper W8																	■

5.3.2.4.7 210-8703/210-8703-1 Main Memory Removal and Replacement

1. Remove the Main Memory board(s) (figure 5-20) from backplane slot(s) #7 through 14 in the manner described in 5.3.2.4.1.
2. After checking the Memory Module DRAM Loading (table 5-6), install the new Main Memory board. (A 210-8703 board is half-loaded and contains 4 megabytes, while a 210-8703-1 is fully loaded and contains 8 megabytes.)
3. If installing a new board means the main memory capacity will change, refer to paragraph 5.3.2.4.6 for Main Memory Size Selection Jumpers.




Figure 5-20. 210-8703 Main Memory

Table 5-6. Main Memory Jumper Configurations

Memory Module DRAM Loading	W1	W2	W3	W4	W5	W6	W7	W8
256K Full Load (8 Meg.)		■				■		■
256K Half Load (4 Meg.)			■	■	■			■

NOTE

■ = Jumper in.

## MAINTENANCE

### 5.3.2.4.8 210-8836 System Bus Interface Removal and Replacement

1. Remove the System Bus Interface(s) (SBI) (figure 5-21) from SBI backplane slot(s) #0 or #1 in the manner described in 5.3.2.4.1.
2. After checking the I/O Clock Speed jumpers at L125, I/O Data Speed jumpers at L182, SBI Identification jumpers at L74, and the SPB (Support Packet Bus) Target ID jumpers at L113 (figure 5-21), install the new SBI.




Figure 5-21. 210-8836 System Bus Interface

**5.3.2.5 IOC Circuit Board Removal and Replacement**


There are six different IOC assemblies used in the VS-300. The removal and replacement procedures for the different assemblies are given in the order in which they are found in the backplane, table 5-7.

**NOTE**

In the VS-300, the Operating System (OS) requires that I/O slot #1 be reserved for a 23V98 Disk Drive IOC, and I/O slot #3 be reserved for a 23V97 Serial IOC.

**Table 5-7. VS-300 IOC List**

<u>IOC Type</u>	<u>WLI Part Number</u>	<u>IOC Priority</u>	<u>Physical Backplane Slot Number</u>
System Bus Interface	210-8836		SBI #0 (SBI #1 for 2nd SBI)
SMD (23V98-1/2/3/4)	210-8785	1	I/O #1
32-Port Serial (23V97)	210-8609	3	I/O #3
Kennedy Tape (23V95-1)	210-8790		
Telex Tape (23V95-2)	210-8789		
Multiline TC (23V86/96)	210-8491A		
CIU BLANC (23V79)	210-8392A		



▨ = switch position

B-02675-FY86-11

**NOTE**

This switch is set the same for all IOCs except the 23V79 CIU BLANC IOC. See each IOC for the location of the switch.

**Figure 5-22. IOC Diagnostic Switch Setting For Power Up (Except 23V79 [210-8392] CIU BLANC IOC)**



## MAINTENANCE

### 5.3.2.5.1 23V97 (210-8609) Serial IOC Removal and Replacement

1. The 23V97 drives up to four Active Port Assemblies mounted on the rear panel or in the Cable Concentrator unit. Each APA drives up to eight serial device ports. The IOC also supports the 6550 Gate Array TC controller and the P-Band WangNet modems, via the Cable Concentrator. Connector J1 on the IOC is always reserved for P-Band. No other type of devices should be connected to J1.
2. Disconnect all cables from the top of the 23V97 Serial IOC (figure 5-23). Note the position of all cables for later reassembly.
3. Remove the IOC in the manner described in 5.3.2.4.1.
4. After checking the Diagnostic switch setting at L194 as shown in figure 5-22, install the new 23V97.
5. Reconnect all cables.




Figure 5-23. 23V97 Serial IOC

5.3.2.5.2 270-0975 Serial IOC APA

1. The 270-0975 Serial Active Port assembly (APA) consists of the 210-8504 APA board and the 210-8509 BNC/TNC board. The assembly is daisy chained to include up to four APA back panels.
2. Figure 5-24 shows one assembly and figure 5-25 shows four assemblies daisy chained. The last APA must be terminated at J2 with a 210-8503 terminator board.




Figure 5-24. 270-0975 APA Assembly




Figure 5-25. Daisy Chained APA Assemblies

## MAINTENANCE

### 5.3.2.5.3 6550 Gate Array TC Controller Assembly Removal and Replacement

1. The 6550 Gate Array TC assembly consists of one 210-8714 CPU/Gate Array board, one 210-8713 Receiver/Driver board, and one 210-8712 Connector board. Order and replace the entire 6550 Gate Array assembly (WLI P/N 270-1016). Do not replace individual PC boards.
2. Figure 5-26 shows the Gate Array TC back panel assembly, figure 5-27 shows the 210-8714 CPU/Gate Array board, and figure 5-28 shows one CPU/Gate Array board with cabling. Power cabling is not daisy-chained to a second Gate Array back panel assembly.
3. Before installing the new 6550 Gate Array TC back panel assembly, check the 8-position DIP switch at SW1, and the jumpers at J5 and J6 as shown in figure 5-27. (Switches 5 and 6 are On for support of 128K byte Gate Array without X.21 protocol; switches 5, 6, and 7 are On for support of 128K byte Gate Array with X.21 protocol; all other switches should be off.)




Figure 5-26. 270-1016 6550 Gate Array TC Back Panel Assembly

## NOTE


Revisions are being made to the 210-8714 CPU/Gate Array board for RS232 E.I.A. interface compatibility, as follows:

## 1. Operational

- a. Existing 210-8714 E0/R0 board now provides a clock on RS232 non-standard interface pin 11. This board is compatible only with existing Wang 2228N Null Modems.
- b. New 210-8714 E1/R0 board will provide a clock on RS232 standard interface pin 24. This board will be compatible only with the new Null Modem, WLI P/N XXX-XXXX.
- c. Future 210-8714 E1/R1 board will have a jumper to allow selection of either a clock on RS232 interface pin 24, or on both pin 11 and pin 24. This board will be compatible with existing 2228N Null Modems and the new Null Modem.


## 2. Test Fixtures

- a. Existing 210-8714 E0/R0 board is supported by the existing RS232/366 Loopback Plug, WLI P/N 420-1041.
- b. New 210-8714 E1/R0 board will not be supported by any Loopback Plug. However, the EIA Interface Test Set (breakout box), WLI P/N 727-0122, may be used. (The breakout box is required because the Loopback Plug - WLI P/N 420-1041 - cannot support clock on RS232 pin 24.) This requires the following pins on the breakout box to be strapped together, as follows:
  - 1) Pins 2 and 3.
  - 2) Pins 4, 5, and 8.
  - 3) Pins 11, 15, 17, and 24
  - 4) Pins 6 and 20
- c. Future 210-8714 E1/R1 board will be supported by the existing RS232/366 Loopback Plug. To use the RS232/366 Loopback Plug, DTE clock on pin 11 must be enabled. However, when this board is used with a modem that has internal clock selected, DTE clock must be disabled.



B-02875-FY86-6

Figure 5-27. 210-8714 CPU/Gate Array Board



B-02875-FY86-7

Figure 5-28. 210-8714 CPU/Gate Array Board with Cabling

## MAINTENANCE

### 5.3.2.5.4 23V98-1/2/3/4 (210-8785) Disk Drive IOC Removal and Replacement

1. Disconnect all cables from the top of the 23V98 Disk Drive IOC (figure 5-29). Note the position of all cables for later reassembly.
2. Remove the IOC in the manner described in 5.3.2.4.1.
3. Check the device type switches (figures 5-29 and 5-30, and table 5-8). The two 8-position disk device type switches, SW1 (L76) and SW2 (L51), define the type of drive connected to the 23V98 IOC, ports 0-3. Set the switches for the type of drive(s) connected to the IOC.
4. After checking the Diagnostic switch setting at L247 as shown in figure 5-22, install the new 23V98.
5. Reconnect all cables.




Figure 5-29. 23V98 Disk Drive IOC

	Open (Off)	Closed (On)
Bit 1	1	
Bit 2	2	Port
Bit 3	3	0
Bit 4	4	
Bit 1	5	
Bit 2	6	Port
Bit 3	7	1
Bit 4	8	

SW2 (L51)

	Open (Off)	Closed (On)
Bit 1	1	
Bit 2	2	Port
Bit 3	3	2
Bit 4	4	
Bit 1	5	
Bit 2	6	Port
Bit 3	7	3
Bit 4	8	

SW1 (L76)

Figure 5-30. Disk Drive Device Type Switch Settings.

Table 5-8. Disk Drive Types (Formatted)

Drive Type	Bit 1	Bit 2	Bit 3	Bit 4	Hex Code
75Meg SMD/76Meg RSD	Closed	Closed	Closed	Closed	0
288Meg SMD	Open	Closed	Closed	Closed	1
30Meg CMD	Closed	Closed	Open	Closed	4
60Meg CMD	Open	Closed	Open	Closed	5
90Meg CMD	Closed	Open	Open	Closed	6
76Meg NEC	Open	Closed	Closed	Open	9
147Meg NEC	Closed	Open	Closed	Open	A
600Meg FMD	Open	Open	Closed	Open	B
454Meg CDC/FSD	Closed	Closed	Open	Open	C
No Drive	Open	Open	Open	Open	F

## MAINTENANCE

### 5.3.2.5.5 23V95-1 (210-8790) Kennedy Tape IOC Removal and Replacement

1. Disconnect all cables from the top of the 23V95-1 Kennedy Tape IOC (figure 5-31). Note the position of all cables for later reassembly.
2. Remove the IOC in the manner described in 5.3.2.4.1.
3. After checking the Diagnostic switch setting at L130 as shown in figure 5-22, install the new 23V95-1.
4. Reconnect all cables.




Figure 5-31. 23V95-1 Kennedy Tape IOC



5.3.2.5.6 23V95-2 (210-8789) Telex Tape IOC Removal and Replacement

1. Disconnect all cables from the top of the 23V95-2 Telex Tape IOC (figure 5-32). Note the position of all cables for later reassembly.
2. Remove the IOC in the manner described in 5.3.2.4.1.
3. After checking the Diagnostic switch setting at SW1 as shown in figure 5-22, install the new 23V95-2.
4. Reconnect all cables.




Figure 5-32. 23V95-2 Telex Tape IOC

## MAINTENANCE

### 5.3.2.5.7 23V96 (210-8491) Multiline TC IOC Removal and Replacement

1. The 23V96 drives up to four Multiline TC (MLTC) back panels. Each back panel drives up to four TC lines.
2. Disconnect all cables from the top of the 23V96 Multiline TC IOC (figure 5-33). Note the position of all cables for later reassembly.
4. Remove the IOC in the manner described in 5.3.2.4.1.
5. Check the 8-position port select loop back test switch at L228. (Figure 5-33, and table 5-9.) For normal power up, all switches are on.
6. After checking the Diagnostic switch setting at L202 as shown in figure 5-22, install the new 23V96.
7. Reconnect all cables.




Figure 5-33. 23V96 Multiline TC (MLTC) IOC

Table 5-9. 23V96 Multiline TC IOC Port Select  
Switch Settings For Loopback Test

S8	S7	S6	S5	S4	S3	S2	S1	
				Closed	Closed	Closed	Closed	Select Port 0 (If 5 Open)
				Closed	Closed	Closed	Open	Select Port 1 ( " )
				Closed	Closed	Open	Closed	Select Port 2 ( " )
				Closed	Closed	Open	Open	Select Port 3 ( " )
				Closed	Open	Closed	Closed	Select Port 4 ( " )
				Closed	Open	Closed	Open	Select Port 5 ( " )
				Closed	Open	Open	Closed	Select Port 6 ( " )
				Closed	Open	Open	Open	Select Port 7 ( " )
				Open	Closed	Closed	Closed	Select Port 8 ( " )
				Open	Closed	Closed	Open	Select Port 9 ( " )
				Open	Closed	Open	Closed	Select Port 10 ( " )
				Open	Closed	Open	Open	Select Port 11 ( " )
				Open	Open	Closed	Closed	Select Port 12 ( " )
				Open	Open	Closed	Open	Select Port 13 ( " )
				Open	Open	Open	Closed	Select Port 14 ( " )
				Open	Open	Open	Open	Select Port 15 ( " )
				Closed	-----			Deselects single channel mode.
				Open	-----			Selects single chan. mode (Sws. 1 → 4 select chan.)
					-----			Not used
				Closed	-----			Deselects burn-in
				Open	-----			Selects burn-in

NOTES

1. Location of switch is L228.
2. For normal operation, all L202 Diagnostic switches must be as shown in figure 5-22, and all L228 switches must be Closed (on).
3. To select burn-in, switch 8 Open (off), all others Closed (on).

# MAINTENANCE

## 5.3.2.5.8 270-1003 Multiline TC Back Panel Assembly

1. The 270-1003 Multiline TC back panel assembly consists of one 210-8496 Serial Communications Link (SCL) board, two 210-8497 Block Connector boards, and up to four interface boards with displays. Replace individual PC boards. Do not order or replace the entire assembly.
2. Figure 5-34 shows the Multiline TC back panel assembly, and figure 5-35 shows one assembly with cabling. Power cabling is daisy-chained to a second MLTC back panel assembly.




Figure 5-34. 270-1003 Multiline TC Back Panel Assembly




Figure 5-35. 270-1003 Multiline TC Back Panel Assembly with Cabling

NOTE

Revisions are being made to the dc power cabling between the DC PDU and the 270-1003 Multiline TC back panel assembly, as follows:

1. Current DC Power Cabling

- a. From the DC PDU (210-8716 - J1/J10) to the 5-pin to 4-pin MLTC adapter cable (220-2372) using the 5-pin dc power cable 220-2343. (Figure 5-35.)
- b. The 5-pin to 4-pin MLTC adapter cable connects to the dc power input connector J2 of the 210-8496 Serial Communications Link (SCL) board on the first 270-1003 Multiline TC back panel assembly.
- c. The dc power output connector J3 of the SCL board on the first Multiline TC back panel assembly connects to the dc power input connector J2 of the SCL board on the second Multiline TC back panel assembly, using 4-pin daisy cable, 220-2373.
- d. Up to four back panel assemblies could be powered this way.

2. Revised DC Power Cabling

- a. From the DC PDU (210-8716 - J1/J10) to the 5-pin to 4-pin MLTC "Y" adapter dc power cable (WLI P/N 220-2400) using the 5-pin dc power cable 220-2343.
- b. One leg of the 5-pin to 4-pin "Y" adapter cable (220-2400) connects to the dc power input connector J2 of the 210-8496 Serial Communications Link (SCL) board on the first 270-1003 Multiline TC back panel assembly. The second leg of the 5-pin to 4-pin "Y" adapter cable connects to the dc power input connector J2 of the SCL board on the second Multiline TC back panel assembly.
- c. A second 5-pin to 4-pin "Y" adapter cable (220-2400) and a second 5-pin dc power cable (220-2343) are needed to power the third and fourth Multiline TC back panel assembly as described above.


3. Test Fixtures

- a. For loopback testing, use Loopback Plug WLI P/N 421-0025 only. The pin-out of this connector is as follows:

From Pin	To/From Pin	To/From Pin	To/From Pin
2	..... 3		
4	..... 5	..... 22	
6	..... 8	..... 20	
11	..... 15	..... 17	..... 24
12	..... 13	..... 19	
14	..... 16		

5.3.2.5.9 23V79 (210-8392) CIU BLANC IOC Removal and Replacement

1. Disconnect the cable from the top of the 23V79 CIU BLANC IOC (figure 5-36). Note the position of all cables for later reassembly.
2. Remove the IOC in the manner described in 5.3.2.5.1.
3. After checking the 8-position CIU Functions switch setting at L272 as shown in figures 5-36 and 5-37, install the new 23V79.
4. Reconnect the cable.



▨ = switch position

B-02675-FY86-12

Figure 5-36. 23V79 CIU BLANC IOC


Table 5-10. BLANC ICC Functions Switch (L272)

SW#	Function
SW1	Not used
SW2	Not used
SW3	
Open	CAB/modem present
Closed	CAB/modem not present
SW4	Not used
SW5	
Open	Don't loop on BIT test
Closed	Loop on BIT test
SW6	
Open	CIU installed in VS
Closed	CIU installed in testbed
SW7	Not used
SW8	
Open	All other switches not valid
Closed	All other switches valid

**CAUTION**

Do not run the External Loopback test with live WangNet cables connected to the modem. The test will cause the WangNet contention fields to drop out of synchronization. To run the test, connect either a 40db. loopback test pad or a Cable Simulator to the transmit and receive connectors of the modem. (Refer to Chapter 7, Troubleshooting.)

B-02675-FY86-10



∞ = switch position

Figure 5-37. BLANC IOC Functions Switch (L272) Normal Settings

5.3.2.5.10 210-8391 CIU CAB Board Removal and Replacement

1. The 210-8391 CIU CAB board is part of the 279-0687 CAB/Modem assembly. Do not order or replace the entire assembly.
2. Remove the top cover as described in paragraph 5.3.2.1 and the left side panel as described in paragraph 5.3.2.3.
3. The CIU CAB board (figure 5-38) is mounted on top of the 10 megabit per second (MBPS) duobinary modem. The modem and the CAB board are located behind the CIU connector panel at the rear of the mainframe. Refer to figure 3-12. Disconnect all cables from the CAB board. It may be necessary to remove the CIU connector panel from the back panel to allow access to the rear power cable on the CAB board.
4. Remove the six Phillips head screws securing the CAB board to the modem and remove the CAB board.
5. After checking the 3-position jumper shown in figure 5-38, install the new CAB board.
6. Reconnect all cables.




Figure 5-38. 23V79 CIU CAB Board



# MAINTENANCE

## 5.3.2.5.11 210-8142 5-Channel 10MBPS Modem Removal and Replacement

1. The 210-8142 5-channel 10MBPS Duobinary Modem is part of the 279-0687 CAB/Modem assembly. Do not order or replace the entire assembly.
2. Remove the top cover as described in paragraph 5.3.2.1 and the left side panel as described in paragraph 5.3.2.3.
3. The 10 megabit per second (MBPS) duobinary modem (figure 5-39) has the 210-8391 CIU CAB board (figure 5-38) mounted on top. The modem and the CAB board are located behind the CIU connector panel at the rear of the mainframe. Refer to figure 3-12. Disconnect all cables from the modem. It may be necessary to remove the CIU connector panel from the back panel to allow access to the CAB and modem.
4. Remove the CAB board as described in paragraph 5.3.2.5.10.
5. Remove the modem (with the front panel).
6. After checking the four 3-position jumpers shown in figure 5-39, install the new modem. (Refer to Appendix A for 10MBPS modem channel allocations and device types that should not be used on the same channels or frequencies.)
7. Remount the CAB board.
8. Reconnect all cables.





Figure 5-39. 5-Channel 10 Megabit Duobinary Modem

**5.3.2.5.12 270-0787 Single Channel 10MBPS RF Modem Removal and Replacement**

1. The 270-0787 single channel 10 MBPS RF Modem is also supported on the VS-300. It is part of the 279-0687 CAB/Modem assembly. Replace either the modem or the CAB board.
2. Remove six screws securing the modem to the modem mounting plate.
3. Remove the CAB board from the modem by removing six Phillips head screws and stand-offs.
4. Remove the 11" shielded ribbon cable (WLI P/N 220-3529) that is routed between the CAB board and the modem.
5. There are no jumpers on the single channel modem.




**Figure 5-39a. Single Channel 10 Megabit Duobinary Modem**

## MAINTENANCE


### 5.3.2.5.13 WangNet P-Band Modem Removal and Replacement

1. Remove the top cover as described in paragraph 5.3.2.1 and the left side panel as described in paragraph 5.3.2.3.
2. Disconnect the cables from the transmit (gold) and the receive (silver) connectors on the front of the P-Band modem panel assembly. (Figure 5-39b.)
3. Disconnect the power cable from J2 on the P-Band modem panel assembly. (Figure 5-39c.)
4. Disconnect the 32-pin ribbon cable from P1 on the P-Band modem panel assembly.
5. Remove the modem panel assembly.
6. Remove the two Phillips head screws that secure the P-Band modem to the rear panel of the VS-300. (Figure 5-39b.)
7. Do not replace the entire assembly; only the modem. Remove the six screws that secure the modem to the mounting plate and remove the plate. Remove the four screws that secure the modem to the mounting panel and remove the panel. (Figure 5-39c.)
8. Remount the modem.
9. Reinstall all cables.



B 02903 FY86 4

Figure 5-39b. Wangnet P-Band Modem Panel Assembly



B-02983-FY86-1

Figure 5-39c. Wangnet P-Band Modem Removal

## MAINTENANCE

### 5.3.2.6 Power Supply Controller Board Removal

Remove the 210-8709 Power Controller board as follows:

1. Enter Control Mode from the SCU Console Mode Menu.
2. Power down the mainframe by pressing the Control Panel Power Off pushbutton (or SW2, Off, on the Power Supply Controller).
3. Turn off the ac On/Off circuit breaker located on the Power Distribution Unit at the right rear of the mainframe.
4. Remove the left front cover.
5. Disconnect the 9-pin cable connector from J1 of the Power Controller board.
6. Disconnect the 3-pin cable connector from J2.
7. Disconnect the 4-pin cable connectors from J4 and J5.
8. Disconnect the 60-pin cable connector from J6.
9. Disconnect the 20-pin cable connector from J7.
10. Disconnect the 12-pin cable connector from J8.
11. Disconnect the 5-pin cable connector from J9.
12. Disconnect the 2-pin cable connector from J10.
13. Remove the six Phillips head screws from the Power Controller board plastic cover standoffs and remove the plastic cover.
14. Remove the six standoffs.
15. Remove the three Phillips head screws from the Power Controller board.
16. Remove the board.






















Figure 5-40. Power Supply Controller Board. (Rev. 0 Version)

5.3.2.7 Power Supply Controller Board Replacement

1. To reinstall the Power Controller board, reverse the removal procedure.
2. Set the Battery Backup Time switch (SW4) for 100 seconds for the Rev. 0 board, or 96 seconds (currently) for the Rev. 1. board. (Figure 5-41.)

Switch 4 Settings (Rev. 0 Board)		Switch 4 Settings (Rev. 1 Board)	
 = SWITCH POSITION	Designations	 = SWITCH POSITION	Designations
 1	1	 1	16 Battery
 2	2	 2	32 Backup
 3	4 Battery	 3	64 Time
 4	8 Backup	 4	128 (Seconds)
 5	16 Time	 5	32 Minor
 6	32 (Seconds)	 6	64 Voltage
 7	64	 7	128 Time
 8	128	 8	256 (Seconds)

B-02675-FY86-3

Figure 5-41. Battery Backup Time Switch SW4 Settings.

3. Make sure that all cable connectors are reconnected correctly.
4. Power up the system and check and adjust the Power Supply, paragraph 5.2.4.1, and the Power Supply Controller, paragraph 5.2.4.2. Also check the Low Battery Voltage Dropout adjustment, paragraph 5.2.4.4.

## MAINTENANCE

### 5.3.2.8 Battery Backup Board Removal

The Battery Backup board (figures 5-42 and 5-43) is mounted on the rear of the battery pack assembly. Remove the Battery Backup board:

#### WARNING

Battery voltage is on the battery input connectors (J3 through J7) to the board at all times.

1. Enter Control Mode from the SCU Console Mode Menu.
2. Power down the mainframe by pressing the Control Panel Power Off pushbutton (or SW2, Off, on the Power Supply Controller).
3. Turn off the ac On/Off circuit breaker located on the Power Distribution Unit at the right rear of the mainframe.
4. Remove the top cover and left side panel.
5. Remove the four Phillips head screws that secure the sheet metal safety cover over the Battery Backup board and remove the cover.




Figure 5-42. 210-8717 Battery Backup Board Removal

## MAINTENANCE

6. Disconnect the 6-pin power cable connectors from J1 and J2.
7. Disconnect the 2-pin battery input cable(s) connectors J3 through J7 of the board.
8. Disconnect the yellow 3-pin battery power cable connector from J8.

### CAUTION

If it is necessary to reconnect the yellow 3-wire battery power cable to J8, wait several seconds for the power supply capacitors to discharge or the Battery Backup board will be damaged. The red LED on the Battery Backup board must be out.

9. Remove the six Phillips head screws from the board standoffs and remove the board.




Figure 5-43. 210-8717 Battery Backup Board Removal

### 5.3.2.9 Battery Backup Board Replacement

1. To reinstall the Battery Backup board, reverse the removal procedure.



## MAINTENANCE

### 5.3.2.10 Battery Backup Pack Removal

The five optional battery backup packs are located behind the left front panel. This procedure describes removing a single battery pack, WLI P/N 666-1011. All packs are removed in the same manner.

#### NOTE

When one pack becomes defective, all five packs must be replaced at the same time.

1. Enter Control Mode from the SCU Console Mode Menu.
2. Power down the mainframe by pressing the Control Panel Power Off pushbutton (or SW2, Off, on the Power Supply Controller).
3. Turn off the ac On/Off circuit breaker on the Power Distribution Unit.
4. Remove the top cover, the left front cover, and the left side cover.
5. Disconnect the 2-pin battery cable(s) connector(s) from J3 through J7 of the Battery Backup board.
6. At the front of the battery pack, remove the two Phillips head screws securing the battery pack baseplate to the battery pack housing.
7. Carefully remove the battery pack while guiding the 2-wire battery cable(s) out. (Make sure the pack stays in the baseplate guides.)
8. Once the battery pack is out, remove the battery cable from the battery pack (red is plus [+] and black is minus [-].), and remove the four screws (two on each side) securing the battery pack hold down clamp to the battery pack mounting shelf baseplate.
9. Remove the battery pack.




Figure 5-44. Battery Pack Removal

### 5.3.2.11 Battery Backup Pack Replacement

1. To reinstall the battery pack(s), reverse the removal procedure.
2. Make sure that all cable(s) are reconnected.

### 5.3.2.12 Battery Backup Charging Power Supply Removal

Remove the battery backup charging power supply as follows:

1. Enter Control Mode from the SCU Console Mode Menu.
2. Power down the mainframe by pressing the Control Panel Power Off pushbutton (or SW2, Off, on the Power Supply Controller).
3. Turn off the ac On/Off circuit breaker located on the Power Distribution Unit at the right rear of the mainframe.
4. Remove the left front cover.
5. Disconnect the 3-pin ac power input cable connector (J3) and the 6-pin cable connector (J4) from from the power supply.
6. Remove the two Phillips head screws securing the power supply to the battery mounting shelf base and remove the power supply.




Figure 5-45. Battery Backup Charging Power Supply Removal

### 5.3.2.13 Battery Backup Charging Power Supply Replacement

1. To reinstall the power supply, reverse the removal procedure.
2. Make sure that all cables are reconnected.
3. Power up the system and adjust the power supply as described in paragraph 5.2.4.5.

## MAINTENANCE

### 5.3.2.14 Power Distribution Unit and AC On/Off Circuit Breaker Removal

The Power Distribution Unit (PDU) is mounted on the right rear of the mainframe, below the SCU. (See figures 5-46 and 5-47.)

The ac On/Off circuit breaker is mounted inside the PDU (figure 5-48) and can be replaced without replacing the entire PDU.

#### WARNING

Because of the high operating voltages passing through the PDU, power down the mainframe and disconnect the mainframe power connector from the power source receptacle before performing the following removal/replacement procedures.

Remove the PDU as follows:

1. Enter Control Mode from the SCU Console Mode Menu.
2. Power down the mainframe by pressing the Control Panel Power Off pushbutton (or SW2, Off, on the Power Supply Controller).
3. Turn off the ac On/Off circuit breaker located on the Power Distribution Unit at the right rear of the mainframe.
4. Disconnect the ac power input connector from the power source receptacle.
5. Remove the top cover, rear fan panel, and right side panel.

#### NOTE

Note the orientation of the dc power supply wiring of TBl before proceeding with step 6.

6. Remove the dc power supply wiring from TBl on the DC Distribution board on top of the PDU.
7. Disconnect all dc distribution cable(s) connectors from the DC Distribution board on top of the PDU.
8. Disconnect all ac distribution cable(s) connectors from the AC Distribution board at the rear of the PDU. Note the 5-wire cable connected to J1 (the standalone connector) of the AC Distribution board. This cable must be reconnected to J1 only.
9. Remove the 14 hex head screws securing the PDU to the mainframe and remove the PDU and ac input power cable.

Remove the circuit breaker as follows: (See figure 5-48.)

1. Remove the hex head screws securing the PDU cover and remove the cover.
2. Disconnect the power input cable wiring to the circuit breaker. Make sure to note the orientation and color coding of the power wiring to the circuit breaker for reinstallation of the new circuit breaker.
3. Remove the four Phillips head screws securing the circuit breaker to the front of the PDU and remove the circuit breaker.




Figure 5-46. PDU Removal




Figure 5-47. PDU Removal




Figure 5-48. AC On/Off Circuit Breaker Removal

**5.3.2.15 AC On/Off Circuit Breaker Replacement**

1. To reinstall the circuit breaker, reverse the removal procedure.
2. Make sure the power input cable wiring to the circuit breaker is rewired correctly.
3. Make sure the circuit breaker is ON when pushed up and OFF when pushed down.

**5.3.2.16 Power Distribution Unit Replacement**

1. To reinstall the PDU, reverse the removal procedure.
2. Make sure that the 5-wire cable is reconnected to J1 of the AC Distribution board.

### 5.3.2.16.1 Second DC Power Distribution Board Removal

The second (new) DC Power Distribution board is mounted on the left rear side of the card cage assembly, to the upper right of the Power Supply Controller board. (See figure 5-48a.)

Remove the DC Distribution board as follows:

1. Enter Control Mode from the SCU Console Mode Menu.
2. Power down the mainframe by pressing the Control Panel Power Off pushbutton (or SW2, Off, on the Power Supply Controller).
3. Turn off the ac On/Off circuit breaker located on the Power Distribution Unit at the right rear of the mainframe.
4. Remove the top cover and left side panel.
5. Disconnect the yellow 3-pin battery power cable connector from J8 of the Battery Backup board.

#### CAUTION

If it is necessary to reconnect the yellow 3-wire battery power cable to J8, wait several seconds for the power supply capacitors to discharge or the Battery Backup board will be damaged. The red LED on the Battery Backup board must be out.

6. Disconnect all cable connectors from the DC Distribution board.
7. Disconnect all wires from the 7-connector terminal strip at the bottom of the board.
8. Remove the four locknuts securing the board cover and remove the cover.
9. Remove the six Phillips screws from the board standoffs, (figure 5-48b) and remove the board.

### 5.3.2.16.2 Second DC Power Distribution Board Replacement

1. To reinstall the DC Distribution board, reverse the removal procedure.
2. Make sure that all cables and wires are correctly reconnected to the DC Distribution board, and the yellow 3-pin battery power cable is reconnected to J8 of the Battery Backup board.




Figure 5-48a. Second DC Distribution Board Removal




Figure 5-48b. Second DC Distribution Board Removal



### 5.3.2.17 SCU Professional Computer (PC) Removal

The SCU (PC) is mounted internally at the right side of the mainframe, behind the Control Panel. Remove the SCU as follows: (See figures 5-49.)

1. Enter Control Mode from the SCU Console Mode Menu.
2. Power down the mainframe by pressing the Control Panel Power Off pushbutton (or SW2, Off, on the Power Supply Controller).
3. Turn off the ac On/Off circuit breaker located on the Power Distribution Unit at the right rear of the mainframe.
4. Remove the screws from the rear fan panel, disconnect the two fans and set aside the panel.
5. Disconnect the 4-pin keyboard cable connector from J3 of the SCU CPU board.
6. Disconnect the 25-pin remote diagnostic cable connector from J4 (RS232 connector) of the SCU CPU board.
7. Disconnect the 8-pin monitor video cable connector from J1 of the SCU Monochrome Monitor board.
8. Disconnect the 5-pin monitor power cable connector from J2 of the SCU Monochrome Monitor board.
9. Disconnect the coax cable from the BNC/TNC connectors of the Local Comm. Data Link board.
10. Disconnect the 60-pin signal cable connector from the SCU Professional Computer Interface (PCI) option board.
11. Disconnect the 15-pin power cable connector mounted on a bracket to the left of the SCU fan.
12. Remove the four black anodized Phillips head screws (two top and two bottom) securing the SCU to the case.
13. Carefully slide the SCU toward the rear of the mainframe and out of the case.
14. Refer to the Professional Computer Product Maintenance Manual for disassembly/reassembly procedures and replacement parts.

### 5.3.2.18 SCU Professional Computer (PC) Replacement

1. To reinstall the SCU, reverse the removal procedure.
2. Reach through the Control Panel cutout (at the front of the mainframe) for the SCU's floppy drive and try to guide the front of the SCU into it's final position. Be careful of the RF gaskets surrounding all four sides of the floppy drive cutout.
3. Make sure that all cable connectors are reconnected correctly.
4. Make sure that the Local/Remote switch on the Local Comm. Data Link board is in the Local position.




Figure 5-49. SCU Professional Computer Removal and Replacement

**5.3.2.19 Control Panel Pushbutton Bulb Removal and Replacement**

Each of the Control Panel pushbuttons contains an incandescent bulb. Remove and replace the bulbs as follows: (Figure 5-50)

1. Enter Control Mode from the SCU Console Mode Menu.
2. Power down the mainframe by pressing the Control Panel Power Off pushbutton (or SW2, Off, on the Power Supply Controller).
3. Turn off the ac On/Off circuit breaker located on the Power Distribution Unit at the right rear of the mainframe.
4. With a small screwdriver, pry (top and bottom) the lens cap out of the pushbutton.
5. Pull the small silver lever on the bottom of the pushbutton forward until the bulb pops out.
6. Replace the bulb by pushing it into the pushbutton.
7. Replace the lens cap.




Figure 5-50. Control Panel Pushbutton Bulb Removal and Replacement

## MAINTENANCE

### 5.3.2.20 Control Panel Assembly Removal

The Control Panel assembly is mounted inside the right front panel. Remove the 272-0044 Control Panel assembly as follows: (Figure 5-51)

1. Enter Control Mode from the SCU Console Mode Menu.
2. Power down the mainframe by pressing the Control Panel Power Off pushbutton (or SW2, Off, on the Power Supply Controller).
3. Turn off the ac On/Off circuit breaker located on the Power Distribution Unit at the right rear of the mainframe.
4. Remove the top cover.
5. Disconnect the 20-pin signal cable from the Control Panel assembly.
6. Remove the four hex nuts securing the Control Panel assembly to the right front panel and remove the assembly.

### 5.3.2.21 Control Panel Board Assembly Replacement

1. To reinstall the Control Panel assembly, reverse the removal procedure.
2. Make sure that the 20-pin signal cable is reconnected correctly.




Figure 5-51. 210-8711 Control Panel Board Removal

**5.3.2.22 Multioutput Switching Power Supply Removal**

Remove the multioutput switching power supply as follows:

**WARNING**

```

*****
*
* DO NOT OPEN THE SWITCHING POWER SUPPLY UNDER ANY
* CIRCUMSTANCE. EXTREMELY DANGEROUS VOLTAGE AND
* CURRENT LEVELS (IN EXCESS OF 300 VOLTS DC AND UN-
* LIMITED CURRENT) ARE PRESENT WITHIN THE POWER SUPPLY.
*
* DO NOT ATTEMPT TO REPAIR THE SWITCHING POWER
* SUPPLY; IT IS FIELD REPLACEABLE ONLY.
*
* AFTER POWERING THE UNIT DOWN AND DISCONNECTING THE AC
* POWER CONNECTOR FROM THE POWER SOURCE RECEPTACLE,
* ALLOW ONE MINUTE BEFORE REMOVING THE POWER SUPPLY TO
* PROVIDE ADEQUATE TIME FOR ANY RESIDUAL VOLTAGE TO
* DRAIN THROUGH THE BLEEDER RESISTORS.
*
*****
    
```

1. Enter Control Mode from the SCU Console Mode Menu.
2. Power down the mainframe by pressing the Front Panel Power Off push-button (or SW2, Off, on the Power Supply Controller).
3. Turn off the ac On/Off circuit breaker.
4. Remove the top cover and left side panel.
5. Open the front hinged door.
6. Remove the screws from the rear fan panel, disconnect the two fans and set aside the panel.

**CAUTION**

If it is necessary to reconnect the yellow 3-wire battery power cable to J8 (below), wait several seconds after the LED on the Battery Backup board goes out or the Battery Backup board will be damaged.

7. Disconnect the yellow 3-pin battery power cable connector from J8 of the 210-8717 Battery Backup Board.
8. All wiring is color coded as listed in table 5-11. Using figures 5-52 (for systems with only the original single DC Distribution board) or 5-52a (for systems with both the original and the new second DC Distribution board), and table 5-11, disconnect the bus bars and wiring from the power supply terminals.





Figure 3-52. Multioverpower Supply Wiring Connections  
(With Original Single DC Distribution Board)

- |                 |  |             |              |  |                 |
|-----------------|--|-------------|--------------|--|-----------------|
| A - +5V BUS BAR | 1 - GREEN                                | 5 - RED (3) | 8 - BLUE (4) | 12 - WHITE                               | 15 - VIOLET (2) |
| B - +0V BUS BAR | 2 - WHITE                                | 6 - BLACK   | 9 - RED      | 13 - GREEN                               | 16 - VIOLET (2) |
|                 | 3 - BLACK                                | 7 - BLACK   | 10 - BLACK   | 14 - YELLOW SHIELD<br>(CONTAINS 12 & 13) | 17 - WHITE (2)  |
|                 | 4 - BLACK SHIELD<br>(CONTAINS 1, 2, & 3) |             | 11 - BLUE    |  | 18 - WHITE (2)  |

Figure 5-52a. Multioutput Power Supply Wiring Connections  
(With New Second DC Distribution Board)



A- +5V BUS BAR  
B- ±0V BUS BAR

1-GREEN  
2-WHITE  
3-BLACK  
4-BLACK SHIELD  
(CONTAINS 1, 2, & 3)

5-RED (5)  
6-BLACK (2)  
7-BLACK (2)

8-BLUE (3)  
9-RED  
10-BLUE

11-WHITE  
12-GREEN  
13-YELLOW SHIELD  
(CONTAINS 11 & 12)

14-VIOLET (1)  
\*15-VIOLET (1)  
16-WHITE (1)  
\*17-WHITE (1)

\* FINAL VERSION SHOULD BE (1)  
BUT FCO'D VERSION MAY BE (2).

**Table 5-11. Multioutput Power Supply  
Wiring Color Codes**

<u>Voltage</u>	<u>Color Code</u>
240 dc	Yellow shield
220 ac	Black shield
+5	Red
-5	White
+12	Blue
-12	Violet
+/- 0	Black

9. Loosen the two hex head screws securing the base clamping plate at the rear (connection side) of the power supply.
10. Remove the two hex head screws securing the power supply assembly to the mainframe base at the front of the cabinet.
11. Pull the assembly forward and out of the mainframe.

#### **5.3.2.23 Multioutput Switching Power Supply Replacement**

1. To reinstall the multioutput power supply, reverse the removal procedure.
2. Reinstall all of the power supply wiring as shown in figures 5-52 or 5-52a, and table 5-11.
3. Reconnect the yellow 3-pin battery power cable connector to J8 of the 210-8717 Battery Backup board.
4. Power up the system and check and adjust the power supply voltages as described in paragraph 5.2.4.1.
5. Reinstall all covers and panels.



## MAINTENANCE

### 5.3.2.24 Booster Switching Power Supply Removal

Remove the booster switching power supply as follows:

## WARNING

```
*****
*
* DO NOT OPEN THE SWITCHING POWER SUPPLY UNDER ANY
* CIRCUMSTANCE. EXTREMELY DANGEROUS VOLTAGE AND
* CURRENT LEVELS (IN EXCESS OF 300 VOLTS DC AND UN-
* LIMITED CURRENT) ARE PRESENT WITHIN THE POWER SUPPLY.
*
* DO NOT ATTEMPT TO REPAIR THE SWITCHING POWER
* SUPPLY; IT IS FIELD REPLACEABLE ONLY.
*
* AFTER POWERING THE UNIT DOWN AND DISCONNECTING THE AC
* POWER CONNECTOR FROM THE POWER SOURCE RECEPTACLE,
* ALLOW ONE MINUTE BEFORE REMOVING THE POWER SUPPLY TO
* PROVIDE ADEQUATE TIME FOR ANY RESIDUAL VOLTAGE TO
* DRAIN THROUGH THE BLEEDER RESISTORS.
*
*****
```


1. Enter Control Mode from the SCU Console Mode Menu.
2. Power down the mainframe by pressing the Front Panel Power Off push-button (or SW2, Off, on the Power Supply Controller).
3. Turn off the ac On/Off circuit breaker.
4. Remove the top cover and left side panel.
5. Open the front hinged door.
6. Remove the screws from the rear fan panel, disconnect the two fans and set aside the panel.
7. Remove the two bottom left blank I/O panels on the rear of the main frame.

## CAUTION

If it is necessary to reconnect the yellow 3-wire battery power cable to J8 (below), wait several seconds after the LED on the Battery Backup Board goes out or the Battery Backup board will be damaged.

8. Disconnect the yellow 3-pin battery power cable connector from J8 of the 210-8717 Battery Backup Board.
9. All wiring is color coded as listed in table 5-12. Using figure 5-53 and table 5-12, disconnect the bus bars, the wiring from the power supply terminals, and the 6-pin connector on the front of the supply.

Figure 5-53. Booster Power Supply Wiring Connections



A - +5V BUS BAR  
 B - +0V BUS BAR

1 - GREEN  
 2 - WHITE  
 3 - BLACK  
 4 - BLACK SHIELD  
 (CONTAINS 1, 2, & 3)  
 5 - BLACK  
 6 - BLUE

7 - RED  
 8 - BLACK  
 9 - YELLOW SHIELD  
 (CONTAINS 7 & 8)  
 10 - BLACK (2)  
 11 - RED (2)

## MAINTENANCE

**Table 5-12. Booster Power Supply  
Wiring Color Codes**

<u>Voltage</u>	<u>Color Code</u>
240 dc	Yellow shield
220 ac	Black shield
+5	Red
-12 (fan)	Blue
+/- 0	Black

10. Loosen the two hex head screws securing the base clamping plate at the rear (connection side) of the power supply.
11. Remove the two hex head screws securing the power supply assembly to the mainframe base at the front of the cabinet.
12. Pull the assembly forward and out of the mainframe.

### **5.3.2.25 Booster Switching Power Supply Replacement**

1. To reinstall the booster power supply, reverse the removal procedure.
2. Reinstall all of the power supply wiring as shown in figure 5-53 and table 5-12.
3. Reconnect the yellow 3-pin battery power cable connector to J8 of the 210-8717 Battery Backup Board.
4. Power up the system and check and adjust, if necessary, the power supply voltages as described in paragraph 5.2.4.1.
5. Reinstall all covers and panels.

**CHAPTER**

**6**

**ILLUSTRATED**

**PARTS**

**BREAKDOWN**

## TABLE OF CONTENTS

<b>CHAPTER 6</b>	<b>ILLUSTRATED PARTS BREAKDOWN</b>	<u>Page</u>
6.1	Scope .....	6-1

### LIST OF ILLUSTRATIONS

<u>Figure</u>	<u>Title</u>	<u>Page</u>
6-1	VS-300 Cable Interconnection Diagram .....	6-5
6-2	VS-300 Front View .....	6-7
6-3	VS-300 Rear View With Covers On .....	6-8
6-4	VS-300 Rear View With Covers Off .....	6-9
6-5	VS-300 Battery Backup Section .....	6-10
6-6	VS-300 Card Cage .....	6-11
6-7	VS-300 Multiline TC Back Panel Without Cables .....	6-12
6-8	VS-300 Multiline TC Back Panel With Cables .....	6-12
6-9	VS-300 Gate Array TC Back Panel Assembly .....	6-13
6-10	VS-300 Gate Array TC Back Panel Assembly With Cables .....	6-13
6-11	VS-300 CIU C.A.B./ Modem Back Panel Assembly .....	6-14
6-12	VS-300 Global Modem Assembly 270-1020 .....	6-15

### LIST OF TABLES

<u>Table</u>	<u>Title</u>	<u>Page</u>
6-1	VS-300 PCB Complement .....	6-2
6-2	SCU (PC) PCB Complement .....	6-2
6-3	VS-300 Power Cables .....	6-3
6-4	VS-300 Signal Cables .....	6-3
6-5	VS-300 Disk Drive Cables .....	6-4

# CHAPTER 6

## IPB

### 6.1 SCOPE

This chapter contains the illustrated parts breakdown and power and signal cable part numbers for the VS-300 Computer System. Use this IPB for part number identification when ordering field-replaceable components.

Table 6-1. VS-300 PCB Complement

Board Description	WLI P/N
5-Channel, Duo-Binary RF Modem (10MBPS)	210-8142-A
AC Distribution	210-8715
APA (Active Port Assembly)	210-8504
APA Terminator	210-8503
Address Generation Unit	210-8832
Address Translation Unit	210-8833
BNC/TNC (APA)	210-8509
Backplane (Motherboard) (Note)	210-8837
Battery Backup	210-8717
Block Connector (MLTC)	210-8497
CIU BLANC IOC (23V79)	210-8392-A
CIU CAB IOC (23V79)	210-8391
Central Processing Unit	210-8831
Control Panel	210-8711
DC Distribution (2 boards)	210-8716
Floating Point Unit	210-8830
Kennedy Tape IOC (23V95-1)	210-8790
Main Memory (4 megabytes)	210-8703
Main Memory (8 megabytes)	210-8703-1
Memory Control Unit	210-8834
Multiline TC Controller IOC (23V96)	210-8491-A
Power Supply Controller	210-8709
RS232A Interface (MLTC)	210-8494
RS366 Interface (MLTC)	210-8495-A
RS449 Interface (MLTC)	210-8730
SMD IOC (23V98-1/2/3/4)	210-8785
Serial IOC (23V97)	210-8609
Serial Communications Link (MLTC)	210-8496
Support Control Unit	210-8835
System Bus Interface	210-8836-A
Telex Tape IOC (23V95-2)	210-8789
X.21 Interface (MLTC)	210-8493

## NOTE

Order motherboard assembly WLI P/N 270-5017.

Table 6-2. SCU (PC) PCB Complement

Board Description	WLI P/N
CPU (256KB) (P/N is unique to VS-300)	210-9521-1B
Local Comm. Data Link (2-board Local Comm. option)	210-9245-A
Local Comm. Processor (2-board Local Comm. option)	210-9246-A
Monochrome Monitor	210-9343-A
PCI (PC to SCU Interface) (P/N is unique to VS-300)	210-8377
Single Board Local Comm. Option	210-8310
Winchester Controller	210-9225

Table 6-3. VS-300 Power Cables

Source	Destination	Description	P/N
220-2343 APA cable	APA (J3)	3-pin	220-2339
220-2343 MLTC cable	SCL (MLTC) (J2)	5-pin → 4-pin	220-2372
220-2343 MLTC cable	SCL (MLTC) (J2) (new type)	"Y" cable	220-2400
220-2343 P-Band	P-Band modem (J2)	5-pin	220-2402
220-2375 G/A cable	CPU/Gate Array (J1)	6-pin	220-2374
220-2383 fan cable	Bottom card cage fans	3-pin	220-2386
220-2383 fan cable	Top card cage fans	3-pin	220-2385
APA (J3)	APA (J4) (2nd APA)	3-pin	220-2346
Ac Dist.	Battery charging p/s (ac in)	3-pin	220-2293
Ac Dist.	Booster p/s (ac in)	3-pin	220-2297
Ac Dist.	Card cage fan cable	3-pin	220-2383
Ac Dist.	Multioutput p/s (ac in)	3-pin	220-2296
Ac Dist.	Rear panel fan assy.	3-pin	220-2384
Ac Dist. (J1)	P/S Controller (J9)	5-pin	220-2294
Bat. Backup (J1)	Battery charging p/s	6-pin	220-2302
Bat. Backup (J3-J7)	Battery pack (5 cables)	2-pin	220-2301
Bat. Backup (J8)	Multioutput & booster p/s	2-pin	220-2292
Cable Concen. p/s	APAs (Cable Concentrator)	3-pin	220-2345
Dc Dist. (J1)	Booster p/s	2-pin	220-2299
Dc Dist. (J1-J10)	APA cable	5 pin	220-2343
Dc Dist. (J1-J10)	CIU CAB and CIU Modem	"Y" cable	270-3380
Dc Dist. (J1-J10)	G/A cable	6-pin	220-2375
Dc Dist. (J1-J10)	MLTC cable	5-pin	220-2343
Dc Dist. (J1-J10)	P-Band modem cable	5-pin	220-2343
Dc Dist. (J11)	SCU (PC)	15-pin	220-2298
Dc Dist. (J2)	P/S Controller (J1)	6-pin	220-2300
Dc Dist. (second)	Backplane (J32 & J33)	Dc power out	270-3359
Multioutput p/s	Dc Dist. (first) (TB1)	Dc power out	270-3376
Multioutput p/s	Dc Dist. (second) (TB1)	Dc power out	270-3350
P/S Controller (J2)	P/S Controller (J2)	2-pin jumper	220-2344
Power receptacle	Cable Concentrator unit	Ac power in	420-2040
Power receptacle	VS-300 PDU	Ac power in	220-0503
SCL (MLTC) (J3)	SCL (MLTC) (J2) (2nd SCL)	4-pin daisy	220-2373

Table 6-4. VS-300 Signal Cables

Source	Destination	Description	P/N
AGU (J2)	ATU (J2)	50-pin	220-3472
APA (J2) (1st APA)	APA (J1) (2nd APA)	36-pin daisy	220-3319
APA (J5)	BNC/TNC (J1) (APA)	40-pin jumper	220-3344
APA Port 0	C.C. J9&J10 (panel)	Coax	220-0216
Bat. Backup (J2)	P/S Controller (J8)	6-pin	220-2303
Bat. Backup (J7)	Bat. Backup (J7) (low bat.)	Test jumper	220-2341
Booster p/s	P/S Controller (J4)	3-pin	220-2306
Bulkhead	Remote diagnostic modem	25-pin	220-0332
C.C (panel)	Cable Concentrator	34-pin (25')	220-0510
C.C. J9&J10 (panel)	SCU Local Comm.	Coax	220-0522



Table 6-4. VS-300 Signal Cables (Cont'd)

Source	Destination	Description	P/N
CIU BLANC IOC (J1)	CIU CAB (J2)	40-pin	220-3463
CIU CAB (J1)	CIU Modem (J1) (5-channel)	34-pin (2")	220-3456
CIU CAB (J1)	CIU Modem (J1) (1-channel)	34-pin (11")	220-3529
CPU (J1)	AGU (J1)	50-pin	220-3472
Cable Concentrator	Global modems (P-Band)	36-pin	220-3471
Control Panel	Control Panel (internal)	26-pin	220-3465
Control Panel (J1)	P/S Cont. (J7)	20-pin → 26-pin	220-3464
Kennedy (J1,2)	Tape panel (Kennedy)	50-pin	220-3462
MLTC IOC (J1 → J4)	SCL (MLTC) (J1)	50-pin	220-3484
Multioutput p/s	P/S Controller (J5)	3-pin	220-2449
P/S Cont. (J6)	SCU (backplane) → SCU (PCI)	60-pin	220-3450
P/S Cont. (P4/P5)	P/S Cont. (P4/P5) (p/s test)	Test jumper	220-2342
SCU CPU (J3)	Bulkhead	4-pin	220-0498
SCU CPU (J4)	Bulkhead (Remote Diag.)	25-pin	220-3448
SCU Monochrome (J1)	Bulkhead	8-pin	220-0499
SCU Monochrome (J2)	Bulkhead	5-pin	220-0499
SMD IOC (J1)	Disk panel B-cable (drive 0)	26-pin B-cable	220-3457
SMD IOC (J2)	Disk panel B-cable (drive 1)	26-pin B-cable	220-3458
SMD IOC (J3)	Disk panel B-cable (drive 2)	26-pin B-cable	220-3459
SMD IOC (J4)	Disk panel B-cable (drive 3)	26-pin B-cable	220-3460
SMD IOC (J5)	Disk panel A-cable	60-pin A-cable	220-3390
Serial IOC (J1)	C.C (panel)	36-pin	220-3470
Serial IOC (J2)	APA (J1)	36-pin	220-3455
Telex IOC (J1,2,3)	Tape panel (Telex)	50-pin	220-3462

## NOTES

1. C.C. (panel) is the Cable Concentrator output connector panel on the top rear of the VS-300 main frame.
2. Cable Concentrator is the actual free standing Cable Concentrator unit.

Table 6-5. VS-300 Disk Drive Cables

Source	Destination	Description	Length	P/N
I/O panel	Any drive	B signal cable	15 feet	220-3355
I/O panel	Any drive	B signal cable	25 feet	220-3356
I/O panel	Any drive	B signal cable	50 feet	220-3357
I/O panel	First drive	A signal cable	15 feet	220-3358
I/O panel	First drive	A signal cable	25 feet	220-3359
I/O panel	First drive	A signal cable	50 feet	220-3360
Drive	Drive	A signal cable ("Daisy chain")	10 feet	220-3361




Figure 6-1. VS-300 Cable Interconnection Diagram




Figure 6-2. VS-300 Front View




Figure 6-3. VS-300 Rear View With Covers On




Figure 6-4. VS-300 Rear View With Covers Off




Figure 6-5. VS-300 Battery Backup Section




Figure 6-6. VS-300 Card Cage




Figure 6-7. VS-300 Multiline TC Back Panel Without Cables




Figure 6-8. VS-300 Multiline TC Back Panel With Cables






Figure 6-9. VS-300 Gate Array TC Back Panel Assembly




Figure 6-10. VS-300 Gate Array TC Back Panel Assembly With Cables





Figure 6-11. VS-300 CIU C.A.B./Modem Back Panel Assembly



BY 02983 F 186 2

Figure 6-12. VS-300 Global Modem Assembly 270-1020

**CHAPTER**

**7**

**TROUBLE-  
SHOOTING**

## TABLE OF CONTENTS

CHAPTER 7 TROUBLESHOOTING	<u>Page</u>
7.1	General ..... 7-1
7.2	Off-Line Diagnostics ..... 7-1
7.2.1	Power-up Diagnostics ..... 7-1
7.2.2	Accessing Off-Line Diagnostics ..... 7-2
7.2.3	Running Off-Line Diagnostics ..... 7-5
7.2.3.1	HELP Menu ..... 7-6
7.2.3.2	DCS Test Screens ..... 7-6
7.2.3.3	IOC Diagnostic Switch Settings ..... 7-8
7.2.3.3.1	Multiline TC IOC Diagnostic Switch Settings ..... 7-9
7.2.3.3.2	Gate Array TC Controller Loopback Test Switch Settings .... 7-9
7.2.3.3.3	CIU BLANC IOC Switch Settings ..... 7-10a
7.2.4	Off-Line Diagnostics Error Management ..... 7-10b
7.2.4.1	Intermittent Error Looping ..... 7-10b
7.2.4.2	I/O Bit Monitor Errors ..... 7-10c
7.2.4.2.1	MLTC IOC Loopback Test Error Codes ..... 7-10c
7.2.4.2.2	GATC Front Panel LED BIT Error Display ..... 7-11
7.2.4.3	DCS Log ..... 7-11
7.3	On-Line Diagnostics ..... 7-12
7.3.1	VS On-Line VSTEST Monitor ..... 7-12
7.3.1.1	Main Screen ..... 7-12
7.3.1.2	Log Program Output Screen ..... 7-13
7.3.1.3	Device Class Selection Screen ..... 7-13
7.3.1.4	System Configuration Screens ..... 7-13
7.3.1.5	Message Screen ..... 7-15
7.3.2	VS On-Line Workstation Exerciser (WSEX) ..... 7-15
7.3.2.1	Hardware Tested ..... 7-15
7.3.2.2	Running WSEX ..... 7-15
7.3.2.3	WSEX Automatic Tests ..... 7-16
7.3.2.4	WSEX Interactive Tests ..... 7-17
7.3.2.5	WSEX Error Codes ..... 7-17
7.3.2.6	WSEX Error Messages ..... 7-19
7.3.3	VS On-Line Disk Exerciser (DISKEX) ..... 7-19
7.3.3.1	Hardware Tested ..... 7-19
7.3.3.2	Running DISKEX ..... 7-20
7.3.3.3	DISKEX Tests ..... 7-20
7.3.3.4	DISKEX Error Codes ..... 7-21
7.3.3.5	DISKEX Error Messages ..... 7-23
7.3.4	VS On-Line Printer Exerciser (PREX) ..... 7-23
7.3.4.1	Hardware Tested ..... 7-24
7.3.4.2	Running PREX ..... 7-24
7.3.4.3	PREX Tests ..... 7-24
7.3.4.4	PREX Error Codes ..... 7-26
7.3.4.5	PREX Error Messages ..... 7-27
7.3.5	VS On-Line Tape Exerciser (TPEX) ..... 7-27
7.3.5.1	Hardware Tested ..... 7-28
7.3.5.2	Running TPEX ..... 7-28
7.3.5.3	TPEX Tests ..... 7-28

## TABLE OF CONTENTS (Cont'd)

7.3.5.4	TPEX Error Codes .....	7-29
7.4	Memory Dump Procedures .....	7-37
7.4.1	Control Mode Dump .....	7-37
7.4.1.1	Errors Requiring Control Mode Dump .....	7-37
7.4.1.2	Control Mode Dump Procedure .....	7-39
7.4.1.3	Forcing The System Into Control Mode For Dump .....	7-44
7.4.1.4	Control Mode Dump Stops .....	7-45
7.4.2	Continuable and Snapshot Dumps .....	7-46
7.4.2.1	Requirements For Continuable and Snapshot Dumps .....	7-46
7.4.2.2	Invoking The Snapshot Dump .....	7-47
7.4.2.3	Running Continuable and Snapshot Dumps .....	7-47
7.4.2.4	Continuable Dump and Automatic IPL .....	7-48
7.5	Troubleshooting Procedures .....	7-50
7.6	Error Log .....	7-58
7.7	Service Log .....	7-60
7.7.1	Accessing the Service Log .....	7-60
7.7.2	Database Options .....	7-61

## LIST OF ILLUSTRATIONS

<u>Figure</u>	<u>Title</u>	<u>Page</u>
7-1	System Console Menu .....	7-2
7-2	Workstation Emulation Menu .....	7-3
7-2a	System Console Screen in Service Mode .....	7-3a
7-3	Diagnostic Disclaimer Screen .....	7-4
7-4	DCS Diagnostic Selection Menu .....	7-5
7-5	DCS HELP Menu Screen .....	7-6
7-6	Possible DCS Diagnostic Screen .....	7-7
7-7	VS-300 IOC 4-Position Diagnostic Switch Settings .....	7-9
7-8	Multiline TC IOC 8-Position Diagnostic Switch .....	7-10
7-8a	CIU BLANC IOC External Loopback Test Switch Settings .....	7-10b
7-9	Workstation Interrupted by HELP Screen .....	7-15
7-10	WSEX Error Message Format .....	7-19
7-11	DISKEX Error Message Format .....	7-23
7-12	PREX Error Message Format .....	7-27
7-13	Console Processor Menu .....	7-40
7-14	VS Control Mode Screen .....	7-41
7-15	Control Mode Dump Device Address Screen .....	7-42
7-16	Sample Continuable Dump Screen .....	7-47
7-17	VS-300 Power Controller Board Connectors .....	7-51
7-18	Power Interconnection Diagram .....	7-53
7-19	Power Troubleshooting Flow Chart (1 of 4) .....	7-54
7-19	Power Troubleshooting Flow Chart (2 of 4) .....	7-55
7-19	Power Troubleshooting Flow Chart (3 of 4) .....	7-56

## LIST OF ILLUSTRATIONS (Cont'd)

7-19	Power Troubleshooting Flow Chart (4 of 4) .....	7-57
7-20	Error Log Screen .....	7-58
7-21	Set Error Log Defaults Screen .....	7-59
7-22	VS-300 Service Log Database Options Screen .....	7-60

## LIST OF TABLES

<u>Table</u>	<u>Title</u>	<u>Page</u>
7-1	Special Diagnostic Functions .....	7-7
7-1a	GATC Loopback Diagnostic Switch Settings .....	7-10
7-1b	MLTC IOC Loopback Test Error Codes .....	7-10c
7-2	System Configuration Screen Status Messages .....	7-13
7-3	WSEX Subtest Codes .....	7-17
7-4	WSEX Error Type Codes .....	7-18
7-5	WSEX Error Codes For All Tests .....	7-18
7-6	Additional WSEX Error Codes .....	7-19
7-7	DISKEX Subtest Codes .....	7-21
7-8	DISKEX Error Type Codes .....	7-21
7-9	DISKEX Cylinder Address Test Error Codes .....	7-21
7-10	DISKEX Data Test Error Codes .....	7-22
7-11	DISKEX Command Test Error Codes .....	7-22
7-12	DISKEX Seek Max/Min Test Error Codes .....	7-22
7-13	DISKEX System Error Codes .....	7-23
7-14	PREX Error Codes .....	7-26
7-15	TPEX Initialization Error Codes .....	7-29
7-16	Test 0 Command Test Error Codes .....	7-30
7-17	Test 1 Tape Movement Test Error Codes .....	7-34
7-18	Test 2 Variable Data Length Test Error Codes .....	7-35
7-19	Test 3 Tape Creep Test Error Codes .....	7-35
7-20	Test 4 Random Operations Test Error Codes .....	7-36
7-21	Test 5 Rewind Test Error Codes .....	7-36
7-22	Test 6 Density Check Test Error Codes .....	7-36
7-23	IPL Errors Requiring Control Mode Dump .....	7-38
7-24	VS-300 Machine Check Error Codes .....	7-39
7-25	Control Mode Stops .....	7-45

# CHAPTER 7

## TROUBLESHOOTING

### 7.1 GENERAL

This chapter provides information on diagnostics, memory dumps, power fault isolation, error log, and the service log. With these troubleshooting tools, most of the problems that occur in the system can be located and repaired. Two types of diagnostics are available in the VS-300: off-line diagnostics which are used to test the central processor (CP), memory, and input/output controllers (IOCs) at power up or front panel reset prior to initial program load (IPL) or after board replacement; and on-line diagnostics which provide general purpose utilities and exercisers for peripherals. All diagnostics should be run before turning the system over to the customer at installation or whenever system integrity is questionable.

### 7.2 OFF-LINE DIAGNOSTICS

The VS-300 off-line diagnostics are contained in an application program called the Diagnostic Control System (DCS), which runs under MSDOS in the Support Control Unit (SCU). The DCS is a collection of Central Processor (CP), Memory, and IOC diagnostics that resides on the Winchester fixed disk within the Professional Computer (PC) section of the SCU. DCS diagnostics may be run from the SCU, which consists of the PC and the SCU interface board, even when the VS system is not functioning.

#### NOTE

The customer cannot use the system while the off-line diagnostics are running.

#### 7.2.1 POWER-UP DIAGNOSTICS

At power up (or front panel reset), the DCS automatically invokes the Confidence Diagnostic, which determines, to a high degree of certainty, whether the system will IPL and run. The Confidence Diagnostic consists of the CPU Unit Diagnostic and the I/O Built-in Test (BIT) Monitor.

The CPU Unit Diagnostic is a partial test of the central processor, targeting primarily the interboard signals. The I/O BIT Monitor tests all of the IOCs installed in the system, including both the controller and device adapter sections of the boards.

If an error occurs at any point in the Confidence Diagnostic, the diagnostic halts and an error message is displayed on workstation 0, including the error code and the most likely failing field-replaceable unit (FRU).



## TROUBLESHOOTING

### 7.2.2 ACCESSING DCS DIAGNOSTICS

The DCS diagnostics are accessed from the Wang VS System Console menu. Refer to figure 7-1 below. The System Console screen appears at power up after the SCU software is loaded.

```
*** WANG VS System Console ***

SYSCON Version X.X.X           2:44 PM           Monday February 11, 1986

Press (HELP) for on-line system console information.

Use the function keys to select a command:

(1) ENTER Workstation Emulation      (8) RESET System
(2) ENTER Control Mode                (9) RESET Console

(5) AUTO IPL                          (12) SET Console Defaults
                                      (13) Set Time and Date
```

Figure 7-1. System Console Menu

#### NOTE

The position of the front panel key switch determines which of the items in the above menu are available. Available items will be highlighted. To access off-line diagnostics, the key must be in the "Remote Service" position.

The System Console screen may also be reached by the following method:

1. Press CONTROL then SHIFT + CANCEL simultaneously from the VS Operator's Console, VS Command Processor menu, or the VS Logon screen to exit workstation emulation.
2. The Workstation Emulation screen appears. Refer to figure 7-2 below.
3. Space down to "Suspend Emulation" and press EXEC.
4. The Wang VS System Console screen appears.




Figure 7-2. Workstation Emulation Menu

Certain elements of the System Console Menu are password-protected to prevent unauthorized use of some SYSCON facilities. These elements are not immediately displayed. They include (3) ENTER Service Log mode and (4) ENTER Off-line Diagnostics. To enable these and other menu picks, perform the following steps:

1. Go to the System Console screen.
2. Ensure that the keyswitch is in the "Remote Service" position.

3. Enter the following password:

CSG + current time (four digits) as displayed on the System Console screen. Example: If time is 9:30 (am or pm), enter 0930.

#### NOTE

While entering the password, the keyboard beeper will sound as each key is pressed. This is normal. It is intended to discourage unauthorized personnel from enabling the full System Console menu.

4. Several previously undisplayed menu picks will appear. Refer to figure 7-2a below. The System Console is now in the "service mode." (The service mode can be terminated by pressing PF key 10 or turning the keyswitch out of the "Remote Service" position.)

```

*** WANG VS System Console ***

SYSCON Version X.X.X           2:44 PM           Monday February 11, 1986

Press (HELP) for on-line system console information.

Use the function keys to select a command:


(1) ENTER Workstation Emulation      (8) RESET System
(2) ENTER Control Mode                (9) RESET Console
(3) ENTER Service Log Mode           (10) Terminate Service Mode
(4) ENTER Off-line Diagnostics       (11) Show Error Log
                                       (12) SET Console Defaults
(5) AUTO IPL                          (13) Set Time and Date
(29) Install Software                (32) Wang PC Emulation

```

Figure 7-2a. System Console Screen in Service Mode

## TROUBLESHOOTING

Press PF key 4 from the System Console menu and the diagnostics disclaimer screen appears. Refer to figure 7-3 below.



**Figure 7-3. Diagnostics Disclaimer Screen**

From the diagnostics disclaimer screen, press EXEC to bring up the DCS Diagnostic Selection menu. Refer to figure 7-4 below.

### NOTE

The AGU and FPU diagnostics require DCS Rev 2604 or higher.

```

mm/dd/yy          Wang VS Diagnostic Control System          hh:mm:ss
                   REV XXXX          (c) Copr. Wang Laboratories, Inc. 1985

                   _ PCI Diagnostic
                   _ SCUI Diagnostic
                   _ CP8 Static Diagnostic
                   _ CP8 Self Test Diagnostic
                   _ AGU, ESU Diagnostic
                   _ ATU Diagnostic
                   _ SCU-based MCU & Memory Diagnostic
                   _ CPU-based MCU & Memory Diagnostic
                   _ SBI Diagnostic
                   _ I/O BIT Monitor
                   _ CPU Unit Diagnostic
                   _ FPU Diagnostic

                   _ VS Environment

                   SPACE - Item Position
                   INSERT - Select
                   DELETE - Deselect
                   EXEC - Proceed

HELP is available

```

Figure 7-4. DCS Diagnostic Selection Menu

### 7.2.3 RUNNING OFF-LINE DIAGNOSTICS

#### NOTE

For best results, the diagnostics should be run in the order in which they are listed on the menu.

To choose a particular diagnostic from the DCS menu (figure 7-4 above), position the cursor next to the desired diagnostic using the SPACE BAR, press INSERT to select the diagnostic (diagnostic will be highlighted), and press EXEC to run the diagnostic. More than one diagnostic or all diagnostics may be selected at one time.

To deselect a single diagnostic, go to the DCS menu, position the cursor next to the diagnostic to be deselected, and press DELETE. The diagnostic

## TROUBLESHOOTING

will be dehighlighted on the DCS menu and will not execute until it is reselected. To deselect all selected diagnostics, press CANCEL. To terminate a diagnostic, press SHIFT + CANCEL. Also use SHIFT + CANCEL to exit the DCS program from the selection menu.

### 7.2.3.1 HELP Menu

The DCS HELP menu (figure 7-5 below) is an operator aid that allows the user to display the DCS help text file, display the currently executing diagnostic's help text file, display the DCS log file, and employ the VS Interface Utility. HELP is accessed by pressing the HELP key or SHIFT + HELP keys at any time. The function keys have no effect during the help feature but their state can be changed.

```
mm/dd/yy           Wang VS Diagnostic Control System           hh/mm/ss
                   REV XXXX           (c) Copr. Wang Laboratories, Inc. 1985
                   □□□□ □□□□ □□□□ □□□□
                   H E L P M E N U

                   ■ Display DCS help file
                   - Display current diagnostic's help file
                   - Display Log
                   - VS Interface Utility

                                     SPACE - item select
                                     EXEC  - proceed
                                     CANCEL - exit menu

X.XX.XXi
```

Figure 7-5. DCS HELP Menu Screen

### 7.2.3.2 DCS Test Screens

Once a diagnostic is selected and EXEC is pressed, a screen specific to that diagnostic is displayed. This screen provides information including the sequence number, the diagnostic rev number and name, the error count, the currently executing diagnostic or test, and the DCS status.

Most of the DCS diagnostic screens are similar with the exception of the VS Environment Diagnostic and the I/O BIT Monitor. Some diagnostics contain menus of their own which allow the user to select or deselect one or more tests within the diagnostic. Tests on these menus are selected and deselected the same way that diagnostics are selected and deselected from the DCS Selection menu. A possible diagnostic screen is shown below in figure 7-6.

mm/dd/yy	Wang VS Diagnostic Control System	hh/mm/ss
REV XXXX	(c) Copr. Wang Laboratories, Inc. 1985	
	□□□□ ■□□□ □□□□ □□□□	
Sequence: 1		Error Cnt: 1
Diagnostic: R1560 CP8 Diagnostics		
Test: Part Two		
Error Code: 201033		
Failing Unit: (1) ATU0 (2) AGU0 (3) CPU0		
DCS Status: Reporting Diagnostic Error		
Error detected by diagnostic		
CPU halted at MIA = 07D3		
HELP is available		
Press PF6 to continue from error		

Figure 7-6. Possible DCS Diagnostic Screen

The row of boxes on the third line of the screen indicates which optional functions (if any) are enabled. The boxes correspond to function keys 1 thru 16. Each function key acts as an on/off switch to enable or disable the particular action that the key controls. A filled box indicates the function is enabled; an empty box indicates the function is disabled. Table 7-1 below lists the controlling function keys, the function name, and a description of each function.

Table 7-1. Special Diagnostic Functions

PF KEY	FUNCTION	DESCRIPTION
2	Loop on Error	When an error is reported, the DCS will instruct the diagnostic to loop on the error. The DCS will also count and display the number of times the loop is executed.
3	Loop on Test	The DCS instructs the diagnostic to loop on the just completed test. The DCS counts and displays the number of times the loop is executed.

## TROUBLESHOOTING

Table 7-1. Special Diagnostic Functions (Cont'd)

PF KEY	FUNCTION	DESCRIPTION
4	Loop on Diagnostic	The DCS instructs the diagnostic to loop on itself. The DCS counts and displays the number of times the loop is executed.
5	Stop on Error	When an error is reported, the DCS stops and waits for the user to press PF key 6 before continuing the diagnostic.
6	Continue	This key is used to continue from a stop on error, to disable the current looping function without using the loop function key, and to continue from a pause state without turning off the pause function.
7	Log Screen	Enters current screen into the log.
8	Pause	The DCS will pause on requests (calls) from the diagnostic to the DCS before the requested function is performed. PF key 6 can be used to continue or the function can be disabled.
9	Diagnostic Defined	It is not used by the DCS and is dependent upon the executing diagnostic for function definition. If not defined by the diagnostic it has no effect.
10	Diagnostic Defined	
11	Diagnostic Defined	
12	Diagnostic Defined	
13	Undefined	
14	Undefined	
15	Undefined	
16	Next Diagnostic	Abort the currently executing diagnostic and load and execute the next diagnostic in the sequence.


### 7.2.3.3 IOC Diagnostic Switch Settings

Each VS-300 IOC board is equipped with a 4-position diagnostic DIP switch which is used in conjunction with the I/O Built-in Test (BIT) Monitor. The switch settings and functions are shown below in figure 7-7.



**NOTE**

For normal BIT operation, all switch positions should be OFF (left).



B-03063-FY86-1

Figure 7-7. VS-300 IOC 4-Position Diagnostic Switch Settings

**7.2.3.3.1 Multiline TC IOC Diagnostic Switch Settings**

The Multiline Telecommunications (MLTC) board contains an 8-position switch (in addition to the 4-position diagnostic switch) which is used in conjunction with the BIT. All positions of the 8-position switch must be closed (ON) to execute normal BIT routines. Refer to figure 7-8.

Two modes of operation for the Multiline BIT are selectable via the 8-position switch: Single Channel Mode and Burn In Mode.

Single Channel Mode allows the testing of one channel at a time. This mode requires that the correct loopback connector plug be installed on the channel being tested: RS-232 Loopback Connector - WLI P/N 421-0025, RS-366 (ACU) Loopback Connector - WLI P/N 420-1104, or X.21 Loopback Connector - WLI P/N 421-0010.


Burn-In Mode repeatedly executes the BIT tests until an error is encountered or the BIT is terminated by the user. To select Burn-In Mode, open switch position 8 and close all other switch positions. This mode requires 16 channels (any type) with loopback plugs installed in each channel.

**7.2.3.3.2 Gate Array TC Controller Loopback Test Switch Settings**

**CAUTION**

Do NOT run the X.21 loopback test with the RS-449 loopback connector in place. Do NOT run the RS-449 loopback test with the X.21 loopback connector in place. Failure to observe this caution will result in destruction of the board.

**TROUBLESHOOTING**



**Figure 7-8. Multiline TC IOC 8-Position Diagnostic Switch**

SW1, an 8-position DIP switch on the Gate Array Telecommunications (GATC) controller, is used to enable loopback testing and to select the interface(s) to be used for loopback testing. Refer to table 7-1a for appropriate switch settings.

**Table 7-1a. GATC Loopback Diagnostic Switch Settings**

SWITCH POSITION								FUNCTION
1	2	3	4	5	6	7	8	
1*	0	0	0	1	1	0	1	RS-232-C external loopback
0	1	0	0	1	1	0	1	RS-232-C/RS-366 external loopback
0	0	1	0	1	1	0	1	RS-449 external loopback
1	1	1	0	1	1	0	1	RS-232-C/RS-366/RS-449 external loopback
0	0	1	0	1	1	1	1	X.21 external loopback
1	1	1	0	1	1	1	1	RS-232-C/RS-366/X.21 external loopback

\*1 = switch closed; 0 = switch open

**NOTE**

1. If loopback test is selected (switch 8 in "1" closed position), ensure that appropriate loopback connectors are installed.
2. When performing external RS-232-C loopback test, shunt P1 on the 210-8712 board (R1) must be in the NULL/LOOPBACK position. If it is not, the test will fail. For R0 boards, the CLK0 pin must be reconnected with a short jumper wire. Refer to schematics.

Use only the following loopback connectors for the GATC:

- RS-232-C (WLI P/N 420-1041)
- RS-232-C/RS-366 (WLI P/N 420-1041)
- RS-449 (WLI P/N 270-3193)
- X.21 (WLI P/N 421-0010)

**NOTE**


An option for external loopback testing on power up can be exercised provided that SW1 switch settings are correct and loopback connectors are installed prior to power up or system reset.

**7.2.3.3 CIU BLANC IOC Switch Settings****CAUTION**

Do NOT run the external loopback test with live WangNet cables connected to the modem. The test will cause the WangNet contention fields to drop out of synchronization. To run the test, connect either a 40 db loopback test pad, consisting of two 20 db pads (WLI P/N 336-2002) and one 1-ft cable (WLI P/N 220-0314), or a cable simulator (WLI P/N 190-0744) to the transmit and receive connectors of the modem.

For normal power-up BIT switch settings, refer to chapter 5. For external loopback testing, use the switch settings shown in figure 7-3a.

## TROUBLESHOOTING



▣ = switch position

B-03063-FY86-2

Figure 7-8a. CIU BLANC IOC External Loopback Test Switch Settings

### 7.2.4 OFF-LINE DIAGNOSTICS ERROR MANAGEMENT

When an error occurs while the off-line diagnostics are running, the DCS displays the following additional information on the diagnostic screen:

- Error Code - a six-character code (3 bytes) consisting of the diagnostic number, the test number, and the error code.
- Failing Unit - the three most likely defective field-replaceable units (FRUs), listed in descending order of probability.
- Detailed Error Message

In addition, the DCS log will be updated and the error count will be incremented (unless DCS is looping on error). If Stop on Error is selected, the DCS will stop and wait until PF key 6 (continue) is pressed. When the DCS continues, it will check to see if Loop on Error is selected. If so, the error loop count will be adjusted and control returned to the diagnostic indicating loop on error. The appropriate status messages will be displayed by the DCS.

#### 7.2.4.1 Intermittent Error Looping

When a diagnostic comes to the end of a test, the DCS will check to see if the diagnostic was looping on error (an error occurred and Loop on Error is set). If so, this indicates that the error did not occur again. The DCS will then initiate the Loop on Test function, display an Intermittent Loop status, and indicate to the diagnostic to loop on test. When looping on an intermittent error, the test loop count and the error loop count will be affected.

### 7.2.4.2 I/O BIT Monitor Errors

I/O BIT Monitor Diagnostic errors are indicated on the diagnostic screen by an error code and the word "fail" next to the IOC slot number. An error code which may be encountered from time to time is FFFF. This code indicates that the IOC did not respond.

When the I/O BIT Monitor does not recognize an IOC, N/A (not available) will be displayed on the I/O BIT Monitor Diagnostic screen next to the I/O slot number. If an IOC board is physically present in a slot and N/A is displayed next to its slot number, the 8086 (or associated circuitry) on the board is bad and the IOC must be replaced. Some IOC failures put garbage on the I/O bus thus causing other IOCs to fail the BIT diagnostic. The bad IOC in this case will have "N/A" next to its slot number.

#### 7.2.4.2.1 MLTC IOC Loopback Test Error Codes

The following table explains error codes XX51 thru XX55, which may be encountered during the IOC loopback test. The first two digits of the error code identify the interface port number and half-panel. The table uses error code XX52 (failure in RS-232 tests) as an example.

Table 7-1b. MLTC IOC Loopback Test Error Codes

ERROR CODE	PORT NUMBER	HALF-PANEL NUMBER
0152	0	1
0252	1	1
0352	2	1
0452	3	1
0552	0	2
0652	1	2
0752	2	2
0852	3	2
0952	0	3
1052	1	3
1152	2	3
1252	3	3
1352	0	4
1452	1	4
1552	2	4
1652	3	4

## 7.2.4.2 GATC Front Panel LED BIT Error Display

## NOTE

If switch 8 of SW1 is ON (closed), the loop on program function is enabled, allowing for continuous looping through all of the tests in the diagnostic PROM. Run time is approximately 30 seconds. Successful completion of each loop is indicated by LED 7 ON and LED 8 flashing. LED 7 will be turned OFF after the memory tests have been completed on each consecutive loop.

The GATC controller assembly contains an eight-LED display that indicates the pass/fail status of the GATC BIT. The following LED display indicates a successful BIT execution:

1	2	3	4	5	6	7	8
OFF	OFF	OFF	OFF	OFF	OFF	ON	FLASHING

If any other combination is displayed, the BIT has failed. When an error occurs, the operating system (OS) cannot access the GATC.

## 7.2.4.3 DCS Log

The DCS log is used to keep a record of errors that occur while running the diagnostics. Two types of log entry formats are possible. The first format consists of what will automatically be logged at the occurrence of an error, including: the current time, the diagnostic name, test, error code, failing unit, and a condensed copy of what was displayed in the message area. The second format is a picture of the DCS screen at the time the error occurred. This screen will be logged when the PF 7 key is pressed.

## TROUBLESHOOTING

### 7.3 ON-LINE DIAGNOSTICS

In addition to the off-line and stand-alone diagnostics described above, the VS-300 contains several on-line programs that may be executed while the customer is running. These programs are a series of four exercisers that test the following peripherals: workstations, disk drives, tape drives, and printers. The diagnostics, along with a monitor program, are part of a VS on-line test package called "VSTEST" located in library @SYSTST@.

#### 7.3.1 VS ON-LINE VSTEST MONITOR

The VS On-line Monitor is the user interface for VSTEST. The monitor runs under the control of Operating System (OS) Release 6.20 and later releases. With releases prior to Release 7.20.00, however, the monitor cannot be used to do the following:

- Test workstations and printers unless they are first released via the operator's console.
- Test the disk ECC function.
- Do seek tests on disks in shared use.

The monitor allows the user to test in either of two modes:

- Non-interactive - no user intervention is required. Once started, tests run to completion automatically.
- Interactive - user intervention required to control and monitor tests.

The advantage of the non-interactive mode is its ease of use. The advantage of the interactive mode is its list of options; it allows the user to test individual device functions. The non-interactive mode is used to test workstations, disk drives, tape drives, and printers. The interactive mode is used to test only workstations, disk drives, and tape drives. Help screens displayed while the monitor is in a particular mode relate only to that mode.

The VS On-line Monitor provides a series of screens which allows the user to initiate, control, and monitor the testing process. These screens include:

- Main Screen
- Log Program Output Screen
- Device Class Selection Screen
- System Configuration Screens
- Message Screen

##### 7.3.1.1 Main Screen

The Main Screen is displayed whenever the user enters the Monitor. From it the user can go to the Log Program Output Screen, the Device Class Selection Screen, or the Message Screen. These three screens give the user access to any feature offered by the Monitor.

### 7.3.1.2 Lcg Program Output Screen

This screen allows the user to select options for logging messages received by the Monitor from VSTEST diagnostic programs during the testing process. From this screen the user can return to the Main Screen.

### 7.3.1.3 Device Class Selection Screen

This screen allows the user to deal with all devices at a time in one or more device classes. Options include: (1) initiate non-interactive testing, (2) cancel testing, or (3) select the class of devices for which to view the System Configuration Screens. From the Device Class Selection Screen, the user can go to the System Configuration Screens, the Message Screen, or back to the Main Screen.

### 7.3.1.4 System Configuration Screens

These screens allow the user to deal with one or more devices at a time in a single device class. Options include: (1) initiate non-interactive testing, (2) cancel testing, or (3) initiate interactive testing on one device at a time. From the System Configuration Screens the user can go to the Message Screen or back to the Device Class Selection Screen.

The following messages (table 7-2) may appear in the status columns of the System Configuration Screens. These messages provide information about the device or the test program associated with the device.

Table 7-2. System Configuration Screen Status Messages

STATUS MESSAGE	DEFINITION
AL	Standard ANSI-type labels (tape only).
CNCLNG	The program which has been testing the device is being cancelled.
DT	The device is detached.
ERR004	The volume on which the requested test program file resides is not mounted.
ERR008	The volume on which the requested test program file resides is being used exclusively by another task.
ERR012	The Monitor is unable to initiate the requested test program.
ERR016	The library in which the requested test program file resides cannot be found.
ERR020	The requested test program file cannot be found.
ERR024	Not used.
ERR028	Not used.
ERR032	A disk VTOC error has occurred on the volume on which the test program file resides. FDX1 and FDX2 do not agree.
ERR036	A disk VTOC error has occurred on the volume on which the test program file resides. FDX2 and FDR do not agree.



# TROUBLESHOOTING

Table 7-2. System Configuration Screen Status Messages (Cont'd)

STATUS MESSAGE	DEFINITION
ERR040	The name of the file, library, or volume associated with the requested test program has been incorrectly specified.
ERR044	The VTOC for the volume on which the requested program file resides is unreliable.
ERR048	An attempt to scratch a procedure that spawned a test program requested at an earlier time has failed.
ERR052	The requested test program is already in progress.
EX	Exclusive use (tape or disk). The volume may be accessed (read or written to) and dismounted by the mounting user only. This program is not the mounting user.
F	Fixed disk.
IL	Standard IBM-type labels (tape only).
LOADING	The requested test program is being loaded (initiated).
NL	No labels are present on the volume (disk or tape).
NM	Not mounted (disk or tape).
PR	Protected use (disk only). The volume may be read by any user but updated and dismounted by the mounting user only. This program is not the mounting user.
PRTTSK	The device (printer only) is under the control of the system printer task. It can not be determined if the device is idle, waiting for a print file, or printing.
R	Removable disk.
RLSD	The device (workstation or printer) is released from operating system control and may be acquired by any task.
RR	Restricted removal (disk only). The volume may be accessed (read or written to) by any user but dismounted by the mounting user only. This program is not the mounting user.
SH	Shared access (disk and tape). The volume may be accessed (read and written to) and dismounted by any user.
SL	Standard Wang VS labels (disk only).
SYSTEM	The device (printer only) is under the control of an unknown system task.
TESTING	The device is now being tested by a program initiated by this monitor.
TSKMGR	The device (workstation only) is under the control of the system task manager.
WP	The device (printer only) is under the control of the word processor printer task.

### 7.3.1.5 Message Screen

This screen displays the messages received by the Monitor from the test programs. From this screen the user can return to the last screen viewed.

### 7.3.2 VS ON-LINE WORKSTATION EXERCISER (WSEX)

The VS On-line Workstation Exerciser (WSEX) is a test program that verifies proper operation of workstations by exercising workstation functions. WSEX tests both the controller and the workstation.

#### 7.3.2.1 Hardware Tested

All devices which have a device class equal to "WORKSTATION" and which support normal WS I/O are supported by this program.

#### 7.3.2.2 Running WSEX

WSEX operates under the control of the VS On-line Monitor, and all user interface is through the Monitor. To run WSEX, select WORKSTATIONS from the On-line Monitor Device Class Selection screen and press RETURN. Position the cursor next to the workstation(s) you wish to test on the System Configuration screen, press PF1 (Select), type a non-blank character, and press RETURN. Normally the test program requires no user interaction other than initiating the tests. However, by pressing the HELP key at the workstation under test, options are made available to terminate testing, continue with automatic testing, or enter the interactive mode which requires user intervention. Refer to figure 7-9.




Figure 7-9. Workstation Interrupted by HELP Screen

## TROUBLESHOOTING

The tests are divided into two parts: automatic tests consisting of screen display and functional tests, and interactive tests including keystroke verification and visual attribute displays.

### 7.3.2.3 WSEX Automatic Tests

1. Screen Display Tests
  - a. Even Parity Bit Cell Test - verifies ability of every location of display memory to hold even parity data patterns.
  - b. Odd Parity Bit Cell Test - verifies ability of every location of display memory to hold odd parity data patterns.
  - c. Row Count Test - verifies that each can hold data different from another row.
  - d. Column Count Test - verifies that each column can hold data different from another column.
2. Display Control Tests
  - a. Write and Read Tab Stops - verifies that the correct maximum number of tab stops can be programmed and that tab stops are reset correctly when reprogrammed.
  - b. Write and Read Field Attribute Characters - verifies that fields, written with various attributes and then read, are set correctly.
  - c. Write with Roll Down - verifies the ability of the workstation to correctly roll down rows and to not alter the rows above the roll down row.
  - d. Write with Erase Modifiable Field to Pseudoblanks - ensures that modifiable fields can be erased to pseudoblanks by command.
  - e. Write with Erase and Protect Rest of Screen - ensures that rows below the designated row are erased and protected by the Erase and Protect command.
  - f. Read Altered with Selected Fields - verifies that selected and only selected fields can be read with the Read Altered command.
  - g. Read and Read Altered with Blinking Fields - ensures that the link attribute changes to normal when the screen is read.
  - h. Read and Read Altered with Pseudoblanks - verifies that when modifiable fields are read, all pseudoblanks within the fields are changed to blanks.
  - i. Write Selected - ensures that data, written into selected fields in first and last rows, are changed.

- j. Rotating Character Test - verifies that all locations of the display can hold all possible patterns of data.


**7.3.2.4 WSEX Interactive Tests**

These tests are invoked either by selecting I/A Tests from the On-line Monitor Device Class screen or by pressing the HELP key on the workstation under test and pressing either PF4 or the FORMAT key from the WSEX INTERRUPTED screen. All of the automatic tests are available from the interactive test screen in addition to the three interactive tests described below. The difference is that the user now has the choice of selecting one, several, or all of the automatic tests. Several options are also made available to the user including: loop on test, halt on error, continue on error, pause, etc. The three tests that require user intervention are:

1. Data Entry Into Selected Attribute Test - validates data entry into fields with various attributes. The test verifies that protected fields have not been changed, upper-case only fields contain only upper case, and numeric only fields contain only numbers, "+" and/or ".".
2. Keystroke Verification/Selected Fields Modification Test - verifies the correct recognition of function keys, confirmation of changes to field, and positioning to tab stops.
3. Cursor Positioning Test - ensures that the cursor is correctly positioned under program control.

**7.3.2.5 WSEX Error Codes**

WSEX error codes (tables 7-3 thru 7-6) are four characters long and are divided into two subfields. The first character defines the subtest that was active at the time the error occurred, the second character defines the error type, and the last two characters are type qualifiers.



**Table 7-3. WSEX Subtest Codes**

SUBTEST CODE	TEST NAME	RUN SEQUENCE
A	Write/Read Field Attribute Test	6
B	Write with Erase to Pseudoblanks Test	9
C	Cursor Position Test (I)	18
D	Data Entry into Selected Fields Test (I)	16

## TROUBLESHOOTING

**Table 7-3. WSEX Subtest Codes (Cont'd)**

SUBTEST CODE	TEST NAME	RUN SEQUENCE
E	Even Parity Display Test	1
F	Read Altered with Selected Fields Test	11
G	Read/Read Altered with Blink Test	12
H	Read/Read Altered with Pseudoblink Test	13
I	Column Count Test	4
J	Row Count Test	3
K	Keystroke Verification Test (I)	17
O	Odd Parity Display Test	2
P	Write with Erase and Protect Test	10
R	Rotating Character Test	15
S	Initial Setup Code	
T	Tab Stop Write/Read Test	5
U	Write with Roll Down Test	7
V	Write with Roll Up Test	8
W	Write Selected Test	14

**Table 7-4. WSEX Error Type Codes**

TYPE CODE	DEFINITION
V	System service (cannot acquire resource or inconsistent)
S	IOSW soft status (corrected error)
T	XIO check timeout error after 10 seconds
H	IOSW hard status (non-corrected error)
F	IOSW fatal status (hard error - cannot continue)
X	XIO return code error
C	Missing XIO check (never received check on XIO)
D	Data miscompare

The following error codes apply to all WSEX tests. Replace the asterisk with one of the subtest codes from table 7-3.

**Table 7-5. WSEX Error Codes For All Tests**

ERROR CODE	DEFINITION
*D00	Data Miscompare (read after write)
*F00	Fatal IOSW Error (cannot continue)
*H00	Hard IOSW Error
*S00	Soft IOSW Error
*T00	XIO Timed out after 20 seconds
*X??	XIO Return Code Error (??=decimal ret code)

Table 7-6. Additional WSEX Error Codes

ERROR CODE	DEFINITION
CD80	Cursor position test; cursor in wrong position
DD10	Data entry test; lower-case entry in upper case field
DD20	Data entry test; non-numeric entry in numeric field
System-related Error Codes	
SV00	Get heap memory SVC failed
SV01	Get heap memory SVC failed
SV02	Get heap memory SVC failed
SV03	Get heap memory SVC failed
SV04	Get heap memory SVC failed
SV08	Not a workstation at specified address
SV09	Not a supported workstation at specified address
SV10	Cannot reserve a workstation
SV20	Device address > 255
SV30	Cannot create message port (SYSTEM getheap problem)

### 7.3.2.6 WSEX Error Messages

WSEX error messages consist of lines of up to six fields. These fields are: unit under test address, program identifier code, error code, program title/function, routine or subtest that was active at the time of failure, and error description. Refer to the sample below in figure 7-10.

UNIT	ADDRESS	PROGRAM IDENTIFIER	PROGRAM TITLE	ACTIVE SUBTEST	ERROR DESCRIPTION
0065	WSX0	RH00	WSEX/Workstation Test,	Rotating Characters,	Hard Error

Figure 7-10. WSEX Error Message Format

### 7.3.3 VS ON-LINE DISK EXERCISER (DISKEX)

The VS On-line Disk Exerciser (DISKEX) is a test program that verifies proper disk operation by exercising disk drive functions. DISKEX tests both the controller and the drive.

#### 7.3.3.1 Hardware Tested

All devices which have a device class equal to "DISK" are supported by this program. For a device with a removable volume, DISKEX will attempt to mount a volume on that drive. If no volume is physically present, no testing is done. Only volumes which have a standard label and which allow read/write access to the exerciser are tested. If a device contains both a fixed and a removable volume, each is treated as a separate device.

## TROUBLESHOOTING

### 7.3.3.2 Running DISKEX

DISKEX operates under the control of the VSTEST On-line Monitor, and all user interface is through the Monitor. To run DISKEX, select DISKS from the On-line Monitor Device Class Selection screen and press RETURN. Position the cursor next to the disk(s) you wish to test on the System Configuration screen, press PF1 (Select), type a non-blank character, and press RETURN. No user interaction is required once the tests have been initiated.

#### NOTE

An extended disk test is performed if the operating system release is 7.10 or higher. For releases below 7.10, testing may be abridged.

### 7.3.3.3 DISKEX Tests

The following tests are currently supported by the DISKEX program:

1. Seek Max/Min Test - ensures that the OS, microcode, controller, and drive support positioning of the heads on the first and last cylinders of the disk. This test also ensures that seeks to a cylinder which does not exist are detected and inhibited.

#### NOTE

Under the current implementation, this test is performed only if the volume can be remounted By-pass Label Processing.

2. Command Test - verifies data transfer commands by ensuring that the correct block and length was written and read.
3. Cylinder Address Test - performs a butterfly pattern cylinder address test (convergent/divergent) that checks the mechanical positioning hardware, the analog controlling circuits, and the digital seek circuits.

#### NOTE

Under the current implementation, this test is performed only if the volume can be remounted By-pass Label Processing.

4. Random Data Test - consists of three subtests which ensure that all blocks within the file can hold unique data, check the write/verify and read commands, and ensure correctness of randomly written and generated data by reading it and comparing it to the original data.

7.3.3.4 DISKEX Error Codes

DISKEX error codes (tables 7-7 thru 7-13) are four characters long and are divided into two subfields. The first character defines the subtest that was active at the time the error occurred, the second character defines the error type, and the last two characters are type qualifiers.

Error Code

Definition of Field




Table 7-7. DISKEX Subtest Codes

SUBTEST CODE	TEST NAME
I	Command Test
D	Data Test
E	ECC Test
M	Seek to Max/Min Test
C	Cylinder Address Test
S	Initial Set Up Code

Table 7-8. DISKEX Error Type Codes

TYPE CODE	DEFINITION
V	System service (cannot acquire resource or inconsistent)
S	IOSW soft status (corrected error)
H	IOSW hard status (non-corrected error)
F	IOSW fatal status (hard error - cannot continue)
X	XIO return code error
Z	XIO return code error (expected code is not 12)
C	Missing XIO check (never received check on XIO)
D	Data transfer incorrect
R	Read VTOC error
M	Volume remount return code error

Table 7-9. DISKEX Cylinder Address Test Error Codes

ERROR CODE	DEFINITION
CC00	XIO complete is missing
CF00	Fatal IOSW error (intervention required)



## TROUBLESHOOTING

**Table 7-9. DISKEX Cylinder Address Test Error Codes (Cont'd)**

ERROR CODE	DEFINITION
CH00	Hard IOSW error
CS00	Soft IOSW error
CX??	XIO return code error (VOL XIO)
CM??	Volume remount error (EXIT vol IO)

**Table 7-10. DISKEX Data Test Error Codes**

ERROR CODE	DEFINITION
DC00	XIO complete is missing
DD00	Data miscompare (read data which was not written)
DF00	Fatal IOSW error (intervention required)
DH00	Hard IOSW error
DS00	Soft IOSW error
DX??	XIO return code error (FILE XIO)

**Table 7-11. DISKEX Command Test Error Codes**

ERROR CODE	DEFINITION
IC00	XIO complete is missing
ID00	Data miscompare (read data which was not written)
ID80	Read of 1 BLK modified more than 1 BLK of memory
ID90	Wrote 1 BLK but modified more than 1 file BLK
IF00	Fatal IOSW error (intervention required)
IH00	Hard IOSW error
IS00	Soft IOSW error
IR??	VTOC return code error
IX??	XIO return code error (FILE XIO)

**Table 7-12. DISKEX Seek Max/Min Test Error Codes**

ERROR CODE	DEFINITION
MC00	XIO complete is missing
MF00	Fatal IOSW error (intervention required)
MH00	Hard IOSW error
MS00	Soft IOSW error
MZ??	XIO return code should be 12, but is not
MX??	XIO return code error (VOL XIO)
MM??	Volume remount error (EXIT vol IO)

Table 7-13. DISKEX System Error Codes

ERROR CODE	DEFINITION
SV00	Get Heap memory SVC failed (buffer 0)
SV01	Get Heap memory SVC failed (buffer 1)
SV02	Get Heap memory SVC failed (buffer 2)
SV08	Not a disk device at specified address
SV20	Device address greater than 255
SV30	Cannot create message port (SYSTEM getheap problem)

### 7.3.3.5 DISKEX Error Messages

DISKEX error messages consist of lines of up to six fields. These fields are: unit under test address, program identifier code, error code, program title/function, routine or subtest that was active at the time of failure, and error description. Refer to the sample below in figure 7-11.

UNIT ADDRESS	PROGRAM IDENTIFIER	PROGRAM TITLE	ACTIVE SUBTEST	ERROR DESCRIPTION
/	/	/	/	/
/	/	/	/	/
/	/	/	/	/
/	/	/	/	/
0065	DKX0 ID00	DISKEX/Disk Exerciser, Command Test,	Data Miscompare	Error

Figure 7-11. DISKEX Error Message Format

### 7.3.4 VS ON-LINE PRINTER EXERCISER (PREX)

The VS On-line Printer Exerciser (PREX) is a test program that verifies proper printer operation by exercising printer functions. PREX tests all daisy wheel, matrix, band, and chain train printers currently recognizable by the operating system. It also attempts to support experimental printers.

The printer exerciser program requires that at least one printer recognizable to the operating system be attached to the system. The program also requires that the status of the printer to be tested is RELEASED. Beginning with OS Release 7.3 this will be done by PREX. With prior releases, the user can release a printer from either the Command Processor Menu or the Operator's Console Menu.

## TROUBLESHOOTING

### 7.3.4.1 Hardware Tested

The following printers are currently supported by PREX:

2221V	2281V	5533K	5577
2231V2	2281WR	5535	5581WD
2233	2281WCR	5535K	6581W
2233K	5521	5570	6581WC
2235	5521I	5571	DWOS20
2235K	5521IK	5573	DWOS55
2263V1	5521K	5573-1	OK555
2263V2	55312	5574	TPI1
2263V3	55312K	5574-1	XPRTW
2273V1	5533	5575	XPprt

The following printers are NOT supported by PREX:

LPS12	IP41D	5590
-------	-------	------

### 7.3.4.2 Running PREX

PREX operates under the control of the VSTEST On-line Monitor, and all user interface is through the Monitor. To run PREX, select PRINTERS from the On-line Monitor Device Class Selection screen and press RETURN. Position the cursor next to the unit number of the printer you wish to test on the System Configuration screen, press PF1 (Select), type a non-blank character, and press RETURN. No user interaction is required once the tests have been initiated.

The program produces hard copy output on the printer under test. This output should be checked and verified by the CE. The standard format for the output is as follows:

- Three blank lines
- Underscored test name
- Two blank lines
- Test header line(s) describing what will be done
- Test output
- One blank line
- Test trailer line(s) providing information on how to evaluate test output

### 7.3.4.3 PREX Tests

The VS On-line Printer Exerciser consists of the following tests:

1. HOF (Channel 1) Test - checks the ability of a printer to respond correctly to print control bytes that specify vertical format spacing to head of form.
2. Data Bus Test - checks the output of the serial interface unit and the integrity of the parallel data bus. All bit positions are tested

## TROUBLESHOOTING

- in both the ON and OFF positions. Compare test output with the bit specifications in the test headers.
3. Character Set Test - prints the entire character set of the printer and the corresponding hexadecimal values (00 thru 7F) of the characters in a four column format with appropriate header lines. Compare the output against the specifications in the appropriate printer user manual.
  4. Spiral Pattern Test - prints the entire character set in consecutive print positions on a line. Succeeding lines are printed with each character shifted by one print position to produce a spiral or diagonal effect until all characters are printed in every print position. Inspect the output for alignment, bad print positions, and any other apparent abnormality.
  5. Overstrike Test - prints three full lines, each line consisting of a different pair of dissimilar characters in the same print position. This test also verifies the ability of the printer to correctly respond to print control bytes which specify vertical movement of zero lines. Inspect the output for proper registration of the overstruck characters from one end of the line to the other.
  6. Carriage Width Test - demonstrates the carriage width of the printer by printing a series of increasing length test records which are less than, equal to, or greater than the actual carriage width. The test pattern consists of repeating groups of the characters "123456789-". Count the complete groups and add the partial groups on the right (if any) to find the actual printable line length.
  7. Vertical Format Test - checks the ability of the printer to respond correctly to print control bytes that specify spacing to a vertical tab position (channel 5). Vertical tab positions occur every six lines from top of form.

### NOTE

If the printer being tested is equipped with a Vertical Format Unit (VFU), correct results from this test depend upon having the Wang-supplied Vertical Format Tape mounted (the paper must be properly aligned). The use of any non-standard Vertical Format Tape will produce ambiguous results.

8. Print Quality Test - prints series of full-width "M" and full-height "Z" characters to aid the user in determining if the print quality adjustments are set correctly. The test informs the user about what specific faults to look for in each part of the test.
9. Matrix Pattern Test - prints a pattern consisting of 5 x 5 character blocks on matrix printers. Characters are chosen so that all elements of the dot matrix are activated.

## TROUBLESHOOTING

10. Worst Case Pattern Test - prints a series of lines consisting of a character pattern chosen to maximize print wheel rotation on daisy wheel printers.
11. Expanded Print Test - checks the ability of most matrix printers to correctly respond to print control bytes which specify double-width characters.

### 7.3.4.4 PREX Error Codes

PREX error codes (table 7-14) consist of four characters. The first two characters define the area of the program in which the error occurred:

- IN - error occurred during program startup (initialization).
- OP - error occurred in the routine that sets up the User File Block and opens the printer file.
- XP - error occurred in the routine that performs I/O to the printer.
- RP - error occurred in the routine that builds print records.

The last two characters are sequence designators and have no special significance. The most likely type of errors to occur will be I/O errors, especially error code XP05.

Table 7-14. PREX Error Codes

ERROR CODE	DEFINITION
IN00	The monitor has specified an invalid device address at task creation time. (The text portion of the error message will display the invalid device address as received from the monitor in the parameter passing area.)
IN01	The program is not able to reserve the device to be tested. The UNITRES SVC has failed for some reason. (The text portion of the error message will include the return code.)
IN02	The program is not able to create a port for the receipt of messages from the monitor. The CREATE SVC has failed for some reason other than the specification of a port name which already exists on the system. If a duplicate port name is specified, the program will retry the CREATE with other port names until successful.
IN03	The program is not able to obtain memory space required for a print buffer. The GETHEAP SVC has failed for some reason. (The text portion of the error message will include the return code.)
OP00	The device specified by the monitor for testing is not a printer.
OP01	The User File Block for the printer to be tested indicates that the file is open when it should be closed.

Table 7-14. PREX Error Codes (Cont'd)

ERROR CODE	DEFINITION
OP02	The program is unable to open the file for the printer. The OPEN SVC has failed for some reason. (The text portion of the error message will include the UFB file status bytes which are analyzed for some values in order to provide additional information.)
XP00	The program has determined that the file is not open or the User File Block is bad.
XP01	The data length specified for the call to XIO is negative.
XP02	The data length specified for the call to XIO is greater than 2048 bytes.
XP03	The call to XIO was unsuccessful. The XIO SVC has failed for some reason. (The text portion of the error message will include the return code which is analyzed for some values in order to provide additional information.)
XP04	I/O completion did not occur within the time limit.
XP05	Unexpected IOSW bit(s) set. (The IOSW is analyzed bit by bit in order to present additional text information in the message.)
RP00	Attempt to move text string into work buffer was unsuccessful.
RP01	Attempt to build a print record in the print buffer was unsuccessful.

#### 7.3.4.5 PREX Error Messages

PREX error messages consist of lines of up to five fields. These fields are: error code, program identifier code, program title/function, area of the program where the error occurred, and error description. Refer to the sample error message below in figure 7-12.

```

      ERROR CODE          PROGRAM TITLE
      /                /
      / PROGRAM IDENTIFIER /
      /                /
      /                / PROGRAM AREA
      /                / ERROR DESCRIPTION
      /                /
IN00 PRX0 PREX/Printer Exerciser, Program Startup, Parameter Error

```

Figure 7-12. PREX Error Message Format

#### 7.3.5 VS ON-LINE TAPE EXERCISER (TPEX)

The VS On-line Tape Exerciser (TPEX) is a test program that verifies proper operation of tape drives by exercising tape drive functions. TPEX tests the tape drive, the formatter, and the VS tape Input/Output Controller (IOC).

## TROUBLESHOOTING

### 7.3.5.1 Hardware Tested

TPEX tests all Kennedy and Telex tape drives configured in the VS-300 System.

### 7.3.5.2 Running TPEX

TPEX operates under the control of the VSTEST On-line Monitor, and all user interface is through the monitor. To run TPEX, select TAPES from the On-line Monitor Device Class Selection screen and press RETURN. Position the cursor next to the unit number of the tape drive you wish to test on the System Configuration screen, press PF1 (Select), type a non-blank character, and press RETURN.

#### NOTE

To decrease the time it takes to run this program, use a tape reel with 600 feet of tape.

Normally no user interaction is required once the tests have been initiated. However, TPEX may also be run in the interactive mode. In this mode, a Test Selection screen allows the selection of one or more tests.

### 7.3.5.3 TPEX Tests

1. Basic Command Code Test - performs a comprehensive check of command decode and execution circuitry and a limited check of the data transfer circuitry of the tape unit and IOC.
2. Tape Movement Test - executes all of the tape movement commands to verify that they are working. This test verifies that the tape drive is able to sense the Tape Mark character and position itself anywhere on tape.
3. Variable Data Length Test - writes and reads variable length data patterns (18 bytes to 30K bytes) to ensure that the tape drive can position the tape head and read the data correctly.
4. Tape Creep Test - exercises the ability of the tape to properly position the tape at records. Functions checked include the tape capstan servo circuitry and areas of the mechanical feed path. This test is divided into two subtests:
  - The first subtest checks for record overlap when a number of Backspace/Write commands are issued.
  - The second subtest checks the start/stop timing between records.
5. Random Operations Test - verifies correct operation of the tape subsystem using a series of commands, data, and data length values. Functions tested include Write, Read, spacing commands, random data

values (0 - 65536), and random data count values (0 - 32512).

6. Rewind Test - verifies proper rewind of the tape after End of Tape (EOT) has been sensed.
7. Write at High Density and Read at Low Density - tests the Kennedy dual density tape drive by writing at high density (1600 bpi PE mode for nine track and 800 bpi NRZI for seven track) and reading at low density (800 bpi NRZI for nine track and 556 bpi NRZI for seven track).
8. Write at Low Density and Read at High Density - tests the Kennedy dual density tape drive by writing at low density (800 bpi NRZI for nine track and 556 bpi NRZI for seven track) and reading at high density (1600 bpi PE mode for nine track and 800 bpi NRZI for seven track).

#### 7.3.5.4 TPEX Error Codes

TPEX error codes (tables 7-15 thru 7-22) are four characters long and are divided into the following three categories:

- 0000 - All characters numeric. The first character is the test number, the second character is the routine number, and the third and fourth characters are the number of the error in that routine. Most of the error codes are of this type.
- S000 - Character "S" indicates a Supervisor Call (SVC), the normal interface between user programs and and supervisory routines. The second and third characters indicate the number of the supervisor call and the last character indicates the number of the error in that supervisor call.
- DV00 - "DV" indicates a device error. The last two characters are the error number.

Table 7-15. TPEX Initialization Error Codes

ERROR CODE	DEFINITION
DV00	Device address given by user is beyond range for devices.
S000	Tried to open the tape drive and received an error indication from the Open SVC00.
S280	Device given by the user is not a tape.
S300	Tried to mount the tape drive and received an error indication from the mount SVC30.
S360	Program is unable to find a message port that is not in use.
S361	Create macro tried to create a port but received a getmem error.



## TROUBLESHOOTING

Table 7-16. Test 0 Command Test Error Codes

ERROR CODE	DEFINITION
Subtest 0 - Write, Read, and Rewind Verification	
0000	Rewind to load point and check for load point bit in the Input/Output Status Word (IOSW). If bit not set, additional message is displayed.
0001	Write of 2048 bytes to the tape drive using the data 0000 was attempted but a tape I/O error occurred.
0002	Write of 2048 bytes to the tape drive using the data A95B was attempted but a tape I/O error occurred.
0003	Write of 2048 bytes to the tape drive using the data FF00 was attempted but a tape I/O error occurred.
0004	Rewind to load point and check the load point bit in the Input Output Status Word (IOSW).
0005	Read of 2048 bytes from the tape drive expecting data 0000 was attempted. A tape I/O error or data compare error occurred.
0006	Read of 2048 bytes from the tape drive expecting data A95B was attempted. A tape I/O error or data compare error occurred.
0007	Read of 2048 bytes from the tape drive expecting data FF00 was attempted. A tape I/O error or data compare error occurred.
Subtest 1 - Erase Command Test	
0100	Rewind to load point and check for load point bit in the Input/Output Status Word (IOSW). If bit not set, additional message is displayed.
0101	Write of 2048 bytes to the tape drive using the data 3A3A was attempted. A tape I/O error or data compare error occurred.
0102	Erase Tape Command was issued to attempt to write an erase gap on tape but a tape I/O error occurred.
0103	Write of 2048 bytes to the tape drive using the data FFFF was attempted but a tape I/O error occurred.
0104	Write of 2048 bytes to the tape drive using the data 5B5B was attempted but a tape I/O error occurred.
0105	Erase Tape Command was issued to attempt to write an erase gap on tape but a tape I/O error occurred.

Table 7-16. Test 0 Command Test Error Codes (Cont'd)

ERROR CODE	DEFINITION
0106	Write of 2048 bytes to the tape drive using data C5C5 was attempted but a tape I/O error occurred.
0107	Read of 2048 bytes from the tape drive expecting data 3A3A was attempted. A tape I/O error or data compare error occurred.
0108	Read of 2048 bytes from the tape drive expecting data FFFF was attempted. A tape I/O error or data compare error occurred.
0109	Read of 2048 bytes from the tape drive expecting data 5B5B was attempted. A tape I/O error or data compare error occurred.
010A	Read of 2048 bytes from the tape drive expecting data C5C5 was attempted. A tape I/O error or data compare error occurred.
Subtest 2 - Back Space Block Test	
0200	Rewind to load point and check for load point bit in the Input/Output Status Word (IOSW). If bit not set, additional message is displayed.
0201	Write of 2048 bytes to the tape drive using the data FFFF was attempted but a tape I/O error occurred.
0202	Write of 2048 bytes to the tape drive using the data 0000 was attempted but a tape I/O error occurred.
0203	Write of 2048 bytes to the tape drive using the data A95B was attempted but a tape I/O error occurred.
0204	Back Space Block Command was attempted but a tape I/O error occurred or read of 2048 bytes from the tape drive expecting A95B was attempted and a tape I/O or data compare error occurred.
0205	Back Space Block Command was attempted twice but a tape I/O error occurred or a read of 2048 bytes was attempted twice. The first read expected data 0000 and the second read expected data A95B. A tape I/O error or a data compare error was detected.
0206	Back Space Block Command was attempted three times but a tape I/O error occurred or a read of 2048 bytes was attempted three times. The first read expected data FFFF, the second expected data 0000, and the third expected data A95B. A tape I/O error or a data compare error occurred.

## TROUBLESHOOTING

Table 7-16. Test 0 Command Test Error Codes (Cont'd)

ERROR CODE	DEFINITION
Subtest 3 - Forward Space Block Test	
0300	Rewind to load point and check for load point bit in the Input/Output Status Word (IOSW). If bit not set, additional message is displayed.
0301	Read of 2048 bytes from the tape drive expecting data FFFF was attempted. A tape I/O error or a data compare error occurred.
0302	Forward Space Block Command gave a tape I/O error when executed.
0303	Read of 2048 bytes from the tape drive expecting data A95B was attempted. A tape I/O error or data compare error occurred.
Subtest 4 - Write Tape Mark Test	
0400	Rewind to load point and check for load point bit in the Input/Output Status Word (IOSW). If bit not set, additional message is displayed.
0401	Write of three records of 2048 bytes each using the data patterns FF00, 0000, and 5BA9 was attempted but a tape I/O error occurred.
0402	Indicates a rewind and read of two records. A tape I/O error or data compare error occurred.
0403	Write Tape Mark Command was attempted at record three but a tape I/O error occurred.
0404	Tape was rewound to load point and the first two records were read expecting data FF00 and 0000. Third record, written over by the tape mark, was read and the read buffer was checked to see if data was transferred. The command in error is displayed.
Subtest 5 - Forward Space File Command Test	
0500	Rewind to load point and check for load point bit in the Input/Output Status Word (IOSW). If bit not set, additional message is displayed.
0501	Write of 2048 bytes to the tape drive using the data A95B was attempted but a tape I/O error occurred.
0502	Write Tape Mark Command was attempted at record three but a tape I/O error occurred.

Table 7-16. Test 0 Command Test Error Codes (Cont'd)

ERROR CODE	DEFINITION
0503	Write of 2048 bytes to the tape drive using the data 00FF was attempted but a tape I/O error occurred.
0504	Rewind to load point and forward space to file mark was attempted but a tape I/O error occurred or the load point status bit was not as expected.
0505	Read of 2048 bytes from the tape drive expecting data 00FF was attempted. A tape I/O error or data compare error occurred.
Subtest 6 - Back Space File Command Test	
0600	Rewind to load point and check for load point bit in the Input/Output Status Word (IOSW). If bit not set, additional message is displayed.
0600	Rewind to load point and check load point bit in IOSW.
0601	Write of 2048 bytes to the tape drive using data FFFF or Write Tape Mark Command was attempted but a tape I/O error occurred.
0602	Write of 2048 bytes to the tape drive using data 0000 or Write Tape Mark Command was attempted but a tape I/O error occurred.
0603	Write of 2048 bytes to the tape drive using data A9A9 or Write Tape Mark Command was attempted but a tape I/O error occurred.
0604	Tape I/O error occurred after the Back Space File Command was issued or the tape mark bit in the IOSW is not set.
0605	Read Tape Mark and checked to see if Tape Mark bit in IOSW was set. Read record three expecting data A9A9, performed two Back Space Files, and sensed the Tape Mark. Tape Mark status bit not as expected or incorrect length status bit not as expected.
0606	Read Tape Mark and checked to see if Tape Mark bit in the IOSW was set. Read record 2 expecting data 0000. Tape Mark status bit not as expected or incorrect length status bit not as expected.
0607	Back Space File command executed until load point sensed. If load point not sensed, additional error message displayed.

## TROUBLESHOOTING

Table 7-17. Test 1 Tape Movement Test Error Codes

ERROR CODE	DEFINITION
Subtest 0 - Write Two Files for Testing	
1000	Rewind to load point was attempted to start Tape Movement Test and failed because of rewind command error or load point bit in IOSW was not sensed.
1001	Attempted to write a file (File 1), consisting of two 2048 byte records and a Tape Mark, for the Tape Movement Test.
1002	Attempted to write a file (File 2), consisting of two 2048 byte records, a Tape Mark, an Erase gap, two more records, and two Tape Marks.
1003	Attempted to read a 2K block from File 1 and checked to see if data was correct.
1004	Attempted to back space to load point and sense the load point bit in the IOSW but a tape I/O error occurred. If load point bit not set, additional message is displayed.
1005	Attempted to position the tape at the first tape mark by issuing the Forward Space Block Command twice, but a tape I/O error occurred.
1006	Attempted to read a tape mark and checked to see if any data was transferred. Then a Back Space File to Tape mark was executed. A tape I/O error occurred after executing one of these commands.
1007	Attempted to read and check record 2 of File 1 by issuing the Back Space Block Command or the Read Command. A tape I/O error resulted.
1008	Attempted to Forward Space file to the next Tape Mark But a tape I/O error occurred.
1009	Attempted to read and check record 1 of File 1 but a tape I/O error occurred.
100A	Attempted to Forward Space File to the first Tape Mark of File 2 but a tape I/O error occurred.
100B	Attempted to sense a Tape Mark after forward spacing but a tape I/O error occurred.
100C	Attempted to sense a Tape Mark after back spacing but a tape I/O error occurred.
100D	Attempted to place the tape at the first Tape Mark of File 2 by issuing the Back Space File Command but a tape I/O error occurred.

Table 7-17. Test 1 Tape Movement Test Error Codes (Cont'd)

ERROR CODE	DEFINITION
100E	Attempted to read record 1 of File 2 after a Back Space Block and a Forward Space File to position the tape.
100F	Attempted to rewind to load point, write a record, read the record, and sense the Phase Encode (PE) ID Burst on the tape. If the ID Burst is sensed, then the PE bit in the IOSW will be set. (This is only for Telex tape drives.)
1010	Attempted to rewind to load point, write a record, read the record, and sense the Phase Encode (PE) ID Burst on the tape. If the ID Burst is sensed, then the PE bit in the IOSW will be set. (This is only for Kennedy tape drives.)

Table 7-18. Test 2 Variable Data Length Test Error Codes

ERROR CODE	DEFINITION
Subtest 0 - Write and Read Various Data Lengths	
2000	In an attempt to write and read variable length records, a tape I/O error occurred while executing a Write, Back Space Block, or Read command.
2100	In an attempt to write a 2048 byte record and read it with a data length of 256 bytes, a tape I/O error occurred while executing a Write, Back Space Block, or Read command. If the Illegal Length (IL) bit in the IOSW is not set after the read, an additional message is displayed.

Table 7-19. Test 3 Tape Creep Test Error Codes

ERROR CODE	DEFINITION
Subtest 0 - Capstan Servo Circuitry Check	
3000	Attempted to write and read records with different data lengths of 2048, 4096, 8192, and 16384 bytes. A tape I/O error occurred while executing a Write, Back Space Block, or a Read command.
3001	
3002	
Subtest 1 - Mechanical Feed Path Check	
3100	Attempted to write and read records with different data lengths of 2048, 4096, 8192, and 16384 bytes. A tape I/O
3101	

## TROUBLESHOOTING

**Table 7-19. Test 3 Tape Creep Test Error Codes (Cont'd)**

ERROR CODE	DEFINITION
3102	error occurred while executing a Write, Back Space Block, or a Read command.

**Table 7-20. Test 4 Random Operations Test Error Codes**

ERROR CODE	DEFINITION
Subtest 0 - Random Writes and Reads	
4000	Attempted to write and read records of random data lengths and random data until end of tape was sensed. A tape I/O error occurred while executing a Write, Back Space Block, or Read command.
4001	
4002	

**Table 7-21. Test 5 Rewind Test Error Codes**

ERROR CODE	DEFINITION
Subtest 0 - Timed Rewind from End of Tape	
5000	Attempted to rewind the tape from end of tape to beginning of tape and checked to ensure that the time to do it did not exceed seven minutes. A tape I/O error occurred while executing the Rewind Command. If the rewind to load point exceeds seven minutes, an additional message is displayed.

**Table 7-22. Test 6 Density Check Test Error Codes**

ERROR CODE	DEFINITION
Subtest 0 - Write at High Density and Read at Low Density	
6000	Attempted to write a 2048 byte record in high density and read it at low density. A tape I/O error occurred while executing the Write, Back Space Block, or Read Command.
6001	
6002	
Subtest 1 - Write at Low Density and Read at High Density	
6100	Attempted to write a 2048 byte record in low density and read it at high density. A tape I/O error occurred while executing the Write, Back Space Block, or Read Command.
6101	
6102	

## 7.4 MEMORY DUMP PROCEDURES

In the VS-300, there are three procedures for completing memory dumps:

- Control Mode Dump
- Continuable Dump
- Snapshot Dump

### 7.4.1 CONTROL MODE DUMP

Control Mode is a central processor state in which normal program execution is suspended and certain other facilities (mainly diagnostic and initialization) are made available to the user. The system automatically enters Control Mode when problems are encountered that prevent it from proceeding with normal operations. These problems may be either hardware or software related. The user may also force the system into Control mode. Once in Control mode, the VS-300 uses the SCU (as Workstation 0) to communicate with the user. While in Control Mode, the user may initiate a Control Mode dump. After completing the Control Mode dump, the user must reIPL the system.

The Control mode dump program copies the entire contents of main memory to another storage medium to capture the state of the system when a problem occurred. The VS-300 can use magnetic tape (except cartridge tape, 25V29), floppy diskettes, or disks for the storage medium. An analyst will use this dump information to determine the cause of the system problem.

There are two conditions under which a Control mode dump should be taken:

- The machine has experienced a fatal error and a message describing that error is displayed on Workstation 0.
- The system appears to be hung, to be looping, a task has been abnormally terminated, a dedicated system task is cancelled, or a situation has occurred where the system manager or Wang customer engineer determines a dump is necessary.

#### NOTE

All required workstation operations must be performed from Workstation 0.

#### 7.4.1.1 Errors Requiring Control Mode Dump

Table 7-36 below lists the IPL errors that require a Control Mode dump be performed. The table lists the program Control Words (PCWs) displayed on Workstation 0 as well as an explanation of each. If any one of these errors occurs, follow the Control Mode dump procedure in paragraph 7.4.1.2.



# TROUBLESHOOTING

**Table 7-23. IPL Errors Requiring Control Mode Dump**

PCW DISPLAY	ERROR MESSAGE
<u>IPL ERRORS</u>	
00000001 FFFFFFFF**	NOT ENOUGH MEMORY FOR IPL
00000002 FFFFFFFF**	IPL I/O ERROR
00000003 FFFFFFFF**	NO SYSTEM FILE ON VOLUME
00000004 FFFFFFFF**	BAD VTOC ON IPL VOLUME
00000005 FFFFFFFF**	O/S CODE SPANS 3 EXTENTS
<u>RESIDENT SYSTEM INITIALIZATION ERRORS</u>	
00000011 FFFFFFFF**	SYSINIT I/O ERROR--OPERATING SYSTEM CANNOT BE READ
00000012 FFFFFFFF**	NOT ENOUGH MEMORY FOR RESIDENT SYSTEM
00000013 FFFFFFFF**	SYSINIT PROGRAM CHECK
00000014 FFFFFFFF**	IPL DEVICE NOT INCLUDED IN SYSGEN
00000015 FFFFFFFF**	MICROCODE VERSION TOO LOW
<u>MACHINE CHECK ERROR MESSAGES</u>	
00000021 FFFFFFFF**	MAIN MEMORY PARITY ERROR
00000022 FFFFFFFF**	I/O PROCESSOR MALFUNCTION DEVICE XXX
00000023 FFFFFFFF**	I/O PROCESSOR TIME OUT
<u>NON-RESIDENT SYSINIT ERRORS</u>	
00000031 FFFFFFFF**	OPERATING SYSTEM FILE (@SYSSVC@) NOT FOUND
00000032 FFFFFFFF**	PAGING FILE FOR TASK 0 CANNOT BE CREATED/SCRATCHED
00000033 FFFFFFFF**	LINK TO SYSGEN MODULE FAILED
00000041 FFFFFFFF**	INVALID VERSION NUMBER FOR @SYSSVC@
<u>MISCELLANEOUS</u>	
FFFFFFFF FFFFFFFF**	WRONG MACHINE (VS-100 OS ON VS-300 OR VICE VERSA)
<u>NOTE:</u> ** = undefined last two bits in PCW.	

## NOTE

For a list of Operating System errors that require a Control mode dump, refer to Appendix A. If one of these errors occurs, follow the procedure in paragraph 7.4.1.2.

The following machine check error codes are defined for the VS-300:

Table 7-24. VS-300 Machine Check Error Codes

HEX CODE	REASON
01	Main memory multiple bit ECC error.
0F	Default trap taken.
10	AGU error received. Invalid state in instruction queue.
20	I/O interrupt line received with no active IOSW in the I/O processor status table.
21	Power fail interrupt received.
22	Spare control exception trap taken.
81	Translation buffer parity error.
82	Illegal state - external cache probe.
84	Illegal state - internal cache probe
90	System bus parity error.

The following conditions result in the micromachine hanging (branch to self):

- Control store parity error (IC = FE1)
- Single step microinstruction trap (IC = FE2)
- Microinstruction address compare trap (IC = FE3Z)

#### 7.4.1.2 Control Mode Dump Procedure

Throughout this procedure the following rules apply:

- Zeroes must be entered where indicated.
- When entering information defined in the procedure, begin at the current cursor position. Do not reposition the cursor.
- The asterisk (\*) represents the value of a position and must not be changed during the process of preparing the dump.
- In any place in these procedures where an instruction says "enter 0000\*\*\*\*0000", enter the zeroes and skip over the asterisks by using the cursor control keys.

Any data on the disk or tape will be written over by the dump program, so ensure that data stored on the dump medium are no longer needed. If the system has been configured with an optional dump file by using the DISKINIT program, the dump may be placed onto a disk volume as a file. Use the dump file if possible. If the dump is to be written to a preallocated dump file there is no need to be concerned about the other data stored on the medium. They will not be overwritten. However, data stored by a previous dump in a pre-allocated dump file will be overwritten. As a standard procedure after performing the dump, copy the data from the preallocated dump file to another area on disk or to another magnetic tape and then run the PATCH utility on the preallocated dump file.

## TROUBLESHOOTING

When the system experiences a fatal error and enters Control mode, the screen freezes and the keyboard locks. The message "<<<Machine Check>>>" appears on the top line of the SCU screen.

### NOTE

On W/S 0, a Control Mode dump procedure will be displayed below the "<<<Machine Check>>>" message. Ignore this procedure; it is not correct for the VS-300.

1. When the 4-letter error code appears at the top of the screen, write it down. Refer to Appendix A for an explanation of the error code. From the SCU, press CONTROL, then press SHIFT and CANCEL simultaneously to exit workstation emulation. The Workstation Emulation menu appears. Press the SPACE BAR to select "Suspend Emulation." Press EXEC and the VS-300 Console Processor menu appears. Refer to figure 7-13.

```
*** WANG VS300 CONSOLE PROCESSOR ***

SYSCON Version 1.3.0           11:06 AM           Monday August 5, 1985

Press (HELP) for on-line system console information.

Use the function keys to select command:

(1) ENTER Workstation Emulation      (8) RESET System
(2) ENTER Control Mode                (9) RESET Console
(3) ENTER Service Log Mode
(4) ENTER Off-line Diagnostics       (10) SHOW System Elements Status
(5) AUTO IPL                          (11) SET Time and Date
                                      (12) SET Console Defaults
```

Figure 7-13. Console Processor Menu

- From the VS-300 Console Processor menu, press PF key 2 to select "ENTER Control Mode." The VS Enhanced Control Mode screen appears. Refer to figure 7-14.

```

                                VS Enhanced Control Mode
                                Release 1.03.00
<Enter Command>
:
PCW: 00000000 00000000      R0:  00000000 00000000  CR0:  00000000 00000000
@PC: 00000000 00000000      R2:  00000000 00000000  CR2:  00000000 00000000
                                R4:  00000000 00000000  CR4:  00000000 00000000
                                R6:  00000000 00000000  CR6:  00000000 00000000
                                R8:  00000000 00000000  CR8:  00000000 00000000
                                R10: 00000000 00000000 CR10: 00000000 00000000
                                R12: 00000000 00000000 CR12: 00000000 00000000
                                R14: 00000000 00000000 CR14: 00000000 00000000

                                Physical Memory Display  Phys. addr = 00000000
00000000: 00000000 00000000 00000000 00000000  | .....|
00000010: 00000000 00000000 00000000 00000000  | .....|
00000020: 00000000 00000000 00000000 00000000  | .....|
00000030: 00000000 00000000 00000000 00000000  | .....|
00000040: 00000000 00000000 00000000 00000000  | .....|
00000050: 00000000 00000000 00000000 00000000  | .....|
00000060: 00000000 00000000 00000000 00000000  | .....|
00000070: 00000000 00000000 00000000 00000000  | .....|

```

Figure 7-14. VS Control Mode Screen

The cursor is on the command line, which is the colon below the message "<Enter Command>".

Enter M and press RETURN. Use the cursor control keys to move the cursor to the first digit of the second block of numbers that are directly next to the PCW prompt. For example, if the PCW number is 0000AAAA 40030000, move the cursor to the "4". Enter 0 (zero) and press RETURN.

The cursor automatically returns to the command line. Enter X and press RETURN.

- When the VS-300 Console Processor menu appears, press PF 1 to select "ENTER Workstation Emulation." Press EXEC.

## TROUBLESHOOTING

4. The message "DUMP TO PREALLOCATED FILE? YES/NO" appears on the screen. If a disk dump file, preallocated by the DISKINIT utility, is available and ready, enter YES. Otherwise, enter NO and go to Step 6.

### NOTE

Ensure that the dump disk contains a dump file, that the dump file is large enough to hold the memory contents of the system, and that the disk is ready.

5. If you responded YES to Step 4, this message appears: "PLEASE ENTER DISK LABEL". Enter the label of the disk with the preallocated dump file. If the label is good, the disk is ready, and the file is large enough, the program proceeds to Step 8.
6. If you responded NO to the question in Step 4, the SCU displays a screen similar to the one shown in Figure 7-15.

At this point, it is necessary to indicate the output device address for the dump program.

Use the default address or enter another one: 2C01

Press the ENTER key.

**Figure 7-15. Control Mode Dump Device Address Screen**

Press RETURN to use the default dump address or change the Physical Device Address (PDA) and press RETURN. The VS-300 has a default dump device set at IPL which is the lowest numbered tape. Calculate a new PDA as follows:

- a. Determine the IOC and write down the first six bits from the IOC list below.

<u>IOC</u>	<u>Binary Representation</u>
IOC 1	0010 00
IOC 2	0010 01
IOC 3	0010 10
IOC 4	0010 11
IOC 5	0011 00
IOC 6	0011 01
IOC 7	0011 10

- b. Determine the device number and write down the last ten bits. Convert the binary number to a four-digit hexadecimal number. The result is the PDA. Refer to the example below.

If the IOC used is IOC 2 (binary 0010 01) and the device number is 1 (binary 00 0000 0001), the PDA is determined as follows:

	<u>IOC Number</u> (high 6 bits)	<u>Device Number</u> (low 10 bits)		
Binary	0 0 1 0	0 1 0 0	0 0 0 0	0 0 0 1
Hexadecimal	2	4	0	1

The Physical Device Address = 2401.

7. The program displays the following message: "PLEASE MOUNT DUMP MEDIA". Physically mount the requested media.
8. The Dump program begins execution when it detects that the device is ready. The Dump program displays a blinking message: "DUMP IN PROGRESS".
9. The Dump program continues to execute. It may stop for one of three reasons:
  - a. The dump has successfully completed. This is indicated by the message: "DUMP COMPLETE -- PLEASE PRINT I/O ERROR LOG AFTER IPL". Dismount the dump volume and proceed to Step 10.
  - b. An I/O error has occurred. This is indicated by the display: "I/O ERROR DUMP NOT POSSIBLE TO COMPLETE". The dump cannot continue, but a partial dump has been completed. Dismount the dump volume and proceed to Step 10. If the dump device is tape and it is write protected, you must return to Step 1.
  - c. The mounted volume is full. Another dump volume is required. This is indicated by the display: "PLEASE MOUNT ADDITIONAL DUMP MEDIA". Dismount the full volume and proceed to Step 7 to mount another volume.
10. ReIPL the system, and print the I/O Error Log.

## TROUBLESHOOTING

11. Run the LISTVTOC utility to verify the VTOCs of all disk volumes that were on-line at the time of the system failure. Do not verify the dump disks.
12. If you used a preallocated dump file, run the PATCH utility on that file. The PATCH utility frees the dump file to be automatically overwritten at the time of the next dump. To run the PATCH utility, follow these steps:
  - a. From the VS Command Processor, press PFl, Run Program or Procedure. Specify PATCH in the PROGRAM field and press ENTER.
  - b. On the first PATCH utility screen, enter the dump file filename, library, and volume. For the preallocated dump file, the filename is @CMDUMP@ and the library is @SYSDUMP. For the OPTION field, enter VERIFY. For the ADDRESS field, enter 0. Press ENTER.
  - c. The data parameter field on the screen shows the hexadecimal code for the first 16 bytes of the file. Change the first eight digits to 0. For the OPTION field, enter REPLACE. Press ENTER.
  - d. To exit from PATCH, enter QUIT at the OPTION field.
13. Call the local Wang software analyst and send the following information:
  - The dump in machine-readable form.
  - A task dump, if one was generated.
  - The error code you wrote down in Step 1.
  - A Software Problem Report Form (800-5104).
  - The I/O Error Log.
  - An explanation of what was happening at the time the system malfunctioned and the present status of hardware and software. If the dump was a partial one, indicate that on the dump report.

### 7.4.1.3 Forcing the System Into Control Mode for Dump

If the system appears to be hung or a Control mode dump is required for some other reason, the system may be forced into Control mode by using the following procedure:

1. Exit workstation emulation. Press CONTROL, then press SHIFT and CANCEL simultaneously. From the Workstation Emulation menu, press the space bar to select Suspend Emulation and press EXEC. From the VS-300 Console Processor menu, press PF key 2 (ENTER Control Mode). The Enhanced Control Mode screen appears.
2. Record the displayed PCW for future reference.

3. Enter M 00000700 00000000 on the PCW line, and press RETURN. The starting address of the dump program is 0700.
4. Type X and press RETURN to exit from Control Mode and begin execution of the dump program. To return to workstation emulation, select Workstation Emulation from the Console Mode menu and press EXEC.
5. Follow instructions in paragraph 7.4.1.2 from Step 3.

#### 7.4.1.4 Control Mode Dump Stops

If the system encounters a problem at some point in the Control Mode dump program, a Control Mode stop will occur. The system notifies the user by displaying the PCW in one of the following formats:

- \*\*\*\*\* SSSS\*\*\*\*\* where \*\* is valid PCW information and SSSS is a code that indicates the dump program status.
- \*\*\*\*AAAA SSSS\*\*\*\*\* where \*\* and SSSS have the same meaning as above. AAAA is the resume PCW address and a pointer to a storage location. The user must modify this location in order for the dump program to continue.

#### NOTE

There may be up to a thirty second delay between Control Mode stops.

The status codes are summarized below in table 7-25.

Table 7-25. Control Mode Stops

PCW/STATUS CODE	DESCRIPTION
0000AAAA <u>40000000</u>	Dump completed successfully.
0000AAAA <u>40010000</u>	Dump in progress; continue from here.
0000AAAA <u>40020000</u>	Please mount additional dump media.
0000AAAA <u>40030000</u>	Please mount dump media.
0000AAAA <u>40040000</u>	Dump to preallocated file? The options are YES and NO.
0000AAAA <u>40050000</u>	Please enter disk label.
0000AAAA <u>40060000</u>	Enter Dump Device PDA.



## TROUBLESHOOTING

Table 7-25. Control Mode Stops (Cont'd)

PCW/STATUS CODE	DESCRIPTION
0000AAAA <u>4007</u> 0000	Must enter YES or NO only.
0000AAAA <u>4008</u> 0000	Volume Name must be alphanumeric.
0000AAAA <u>400B</u> 0000	Disk selected not found or not available.
0000AAAA <u>400C</u> 0000	Disk selected does not have Dump file.
0000AAAA <u>400D</u> 0000	Selected Disk Dump file is too small.
0000AAAA <u>400F</u> 0000	I/O error; dump not possible to complete.

For more detailed information on Control Mode Stops and instructions on how to continue the dump after a stop has occurred, refer to the VS Field Guide WLI P/N 741-1265.

### 7.4.2 CONTINUABLE AND SNAPSHOT DUMPS

A continuable dump is a type of memory dump that occurs automatically (if enabled) when certain system errors are encountered. The continuable dump provides information similar to that provided by the Control mode dump but in less time. A continuable dump does not cause system operation to halt. Instead, system operation is suspended, the continuable dump is completed, and system operation continues. During most continuable dumps, users notice only a 15-second workstation freeze. Logging off is not necessary and reIPL is not required for most continuable dump errors. For those errors requiring reIPL, an automatic reIPL is performed at the end of the dump and all users must log on again.

The snapshot dump is a continuable dump that the user invokes manually when memory dump information is needed. VS-300 operations are suspended, the dump is completed, and operations are automatically continued.

On the SYSGEN Configuration File screen of the IPL procedure (refer to paragraph 4.9.1), the prompt "Inhibit dumping continuable halts?" allows the user to enable or disable the continuable dump. If you answered NO, all continuable dumps proceed as described below. If you answered YES, continuable halts that do not require reIPL are not run. The error remains and system operations may be affected.

The continuable dump is invoked automatically when the system errors listed in Appendix A occur.

#### 7.4.2.1 Requirements for Continuable and Snapshot Dumps

Both continuable and snapshot dumps require the allocation of a special file for storing the dump information. All continuable and snapshot dump

information must be dumped to disk. Run DISKINIT to set up the file @CMDUMP@ in library @SYSDUMP. This file must be available on at least one volume at all times to ensure that the continuable or snapshot dump can be completed. If the default dump file is on a number of available volumes, the dump information is stored in the first default file that the system finds.

#### 7.4.2.2 Invoking the Snapshot Dump

The snapshot dump executes in a similar manner and provides the same information as the continuable dump. The difference between them is that the user invokes the snapshot dump manually.

To invoke the snapshot dump, perform the following procedure:

- From the VS Command Processor, press PF11 to enter Operator's Mode.
- From the Operator's Console menu, press PF14 to enter System Options.
- From the System Options menu, press PF10 to initiate the snapshot dump.

#### 7.4.2.3 Running Continuable and Snapshot Dumps

Under most conditions, the continuable dump and the snapshot dump are completed without user intervention. After they are invoked, either automatically or manually, the screen in figure 7-16 appears on Workstation 0. All other workstations freeze for the duration of the dump.




Figure 7-16. Sample Continuable Dump Screen

## TROUBLESHOOTING

When either dump is complete, the message "Dump Completed Successfully" appears on Workstation 0. Press HELP to return to the Operator's Console and the task that was running before the dump. Work can also continue as usual on other users' workstations when the dump is complete. All dump information is available through the @CMDUMP@ file on library @SYSDUMP. To save the information, run COPY from VS Command Processor PF1, Run Program. Send the dump file information to the local software analyst to report the system error.

To make the @CMDUMP@ file available for the next continuable or snapshot dump, run PATCH. This utility changes the first four bytes of a file to indicate that the file can be overwritten.

To run PATCH, follow these steps:

1. From the VS Command Processor, press PF1, Run Program or Procedure. Specify PATCH in the PROGRAM field and press ENTER.
2. On the first PATCH utility screen, enter the dump file name, library, and volume. If you used the preallocated dump file, the filename is @CMDUMP@ and the library is @SYSDUMP. For the OPTION field, enter VERIFY. For the ADDRESS field, enter 0. Press ENTER.
3. The data parameter field on the screen shows the hexadecimal code for the first 16 bytes of the file. Change the first eight digits to 0. For the OPTION field, enter REPLACE. Press ENTER.
4. To exit from PATCH, enter QUIT at the OPTION field.

If you do not run PATCH on @CMDUMP@, the next continuable or snapshot dump is interrupted. Before it can continue, you have to specify what is to be done with the dump information. Four options appear on the continuable (or snapshot) dump screen:

- Press PF1 -- Ignore the current dump and continue processing.
- Press PF3 -- Overwrite the previous dump information with the current information; the previous information would be lost.
- Press PF16 -- Enter Control mode.
- Specify another device to send the dump information; it must have the @CMDUMP@ file already allocated on library @SYSDUMP.

Once you make a selection, the continuable or snapshot dump proceeds normally. After a continuable dump is completed, send the information to the software analyst. The analyst uses the dump information to determine what caused the error.

### 7.4.2.4 Continuable Dump and Automatic IPL

There are some system errors that require reIPL after the continuable dump. In those situations, the continuable dump proceeds as described in paragraph 7.4.2.3. At its completion, the dump automatically reIPLs the system.

## TROUBLESHOOTING

During an automatic reIPL after a continuable dump, Workstation 0 displays the message "ReIPLing from device ~~XXXXXX~~." This message remains on the screen until the Wang VS logon screen appears. Then, the standard information messages appear. The configuration files last specified on the SYSGEN configuration file screen are used and the date and time are automatically updated.


When the operator's console or logon screen appears, the system is ready for use again. All users are required to log on again.

## TROUBLESHOOTING

### 7.5 TROUBLESHOOTING PROCEDURES

This section provides procedures, in flow chart form (figure 7-19), for troubleshooting power problems in the VS-300 Computer System. These flow charts are intended as a guide and not a comprehensive treatment of all possible power troubleshooting techniques. Use figures 7-17 and 7-18 below for ease in locating the various connectors on the power controller board and for cable identification. Heed the warnings that precede two of the steps in the flow charts.

**TROUBLESHOOTING**



B-02473-FY86-1

Figure 7-17. VS-300 Power Controller Board Connectors





Figure 7-18. VS-300 Power Interconnection Diagram


TROUBLESHOOTING



B-02655-FY86-2

Figure 7-19. Power Troubleshooting Flow Chart (1 of 4)






B-02655-FY86-4


Figure 7-19. Power Troubleshooting Flow Chart (2 of 4)

TROUBLESHOOTING



B-02655-FY86-3

Figure 7-19. Power Troubleshooting Flow Chart (3 of 4)



B-02655-FY86-1

Figure 7-19. Power Troubleshooting Flow Chart (4 of 4)

# TROUBLESHOOTING

## 7.6 ERROR LOG

The error log provides a means of tracking system errors and their frequency in the following areas: main memory (MM), central processor (CP), and power supply (PS). The error log is accessed from the System Console screen in the service mode. To enter the error log, perform the following:

1. Go to the System Console screen.
2. Turn the keyswitch to the "Remote Service" position.
3. Enter the following password:

CSG + current time (four digits), as displayed on the System Console screen. Example: If time is 9:30 (am or pm), enter 0930.

### NOTE

While entering the password, the keyboard beeper will sound as each key is pressed. This is normal. It is intended to discourage unauthorized personnel from enabling the full System Console menu.

4. Several previously undisplayed menu picks will appear. Refer to figure 7-2A above. The System Console is now in the "service mode." (The service mode can be terminated by pressing PF key 10 or turning the keyswitch out of the "Remote Service" position.)
5. Press PF key 11 to access the error log.

The following screen appears:

<u>Main Memory Error Log</u>						Page 1
<u>Memory Operation</u>	<u>Level</u>	<u>Address</u>	<u>Time</u>	<u>Date</u>	<u>Count</u>	<u>Comments</u>
Refresh	03	00000000	00:02:53	01-01-86	01	Multiple Bit
<hr/>						
(1) MM error log		(PREV)		Previous entries		
(2) CP error log		(NEXT)		Next entries		
(3) PS error log		(DELETE)		Delete entries		
(4) Set defaults		(16)		Exit		

Figure 7-20. Error Log Screen

## TROUBLESHOOTING

Use the various keys indicated on the screen to access other error logs, set defaults, page through a particular error log, delete entries, or exit screen.

To set error log defaults, press PF key 4. The following screen appears.

<u>Set Error Log Defaults</u>					
<u>Memory Error Rate and Error Counts</u>					
MER = X error every XXX hours				MEC = XXX errors	
PCR = X check every XXX hours				PEC = XXX errors	
<u>Voltage Ranges</u>			<u>Interrupt Status</u>		
<u>Power Supply</u>	<u>High</u>	<u>Low</u>	<u>Level</u>	<u>Element</u>	<u>Status</u>
+5VA	+0.000	+0.000	1	CPU	Enabled
+5VB	+0.000	+0.000	1	MCU	Enabled
-5V	-0.000	-0.000	1	SBI	Disabled
+12V	+00.000	+00.000	1	SCU	Enabled
-12V	-00.000	-00.000	1	PWR	Enabled
				SYSR	Enabled
<hr/>					
(1) MM error log	(9) Modify defaults	(13) Enable/disable SCU			
(2) CP error log	(10) Enable/disable CPU	(14) Enable/disable PWR			
(3) PS error log	(11) Enable/disable MCU	(15) Enable/disable SYSR			
(4) Set defaults	(12) Enable/disable SBI	(16) Exit			

Figure 7-21. Set Error Log Defaults Screen

This screen displays the count of various types of memory errors, allows entering high and low power supply voltage values, and allows enabling/disabling various system elements.

## TROUBLESHOOTING

### 7.7 SERVICE LOG

The VS-300 provides a facility for documenting the system's hardware configuration, software configuration, and maintenance history. This facility is called the "Service Log." The Service Log contains an easily accessible and modifiable database, which can prove to be a valuable aid in tracking system problems.

#### 7.7.1 ACCESSING THE SERVICE LOG

Because of the nature of the data contained in the Service Log, its access, along with several other System Console menu picks, is password-protected to prevent entry by unauthorized personnel. To enter the Service Log, perform the following:

1. Perform steps 1 thru 4 in paragraph 7.6.
2. Press PF key 3 to bring up the Service Log Database Options screen. Refer to figure 7-22 below.

<u>Professional Computer Database</u>		<u>Database Options</u>
<u>Record Definitions</u>		
<u>View Definitions</u>	<u>Comment</u>	
Hardware Config		
Hardware Config		
Software Config		
Software Config		
Maintenance History	Instructions Here	
Maintenance History	Instructions Here	
<hr/>		
<input checked="" type="checkbox"/> Access Data	<input type="checkbox"/> Create Record Definition	
<input type="checkbox"/> Edit Definition	<input type="checkbox"/> Create View Definition	REPLC - Change Database
<input type="checkbox"/> Delete Definition		EXECUTE - Select Option
		CANCEL - Exit

Figure 7-22. VS-300 Service Log Database Options Screen

### 7.7.2 DATABASE OPTIONS

The following database options (refer to figure 7-22 above) allow the user to retrieve, modify, create, and delete service log definitions and data.

1. Access Data - allows user to retrieve, create, update, and delete information pertaining to the system's hardware configuration, software configuration, and maintenance history. Press SPACEBAR to position acceptance block and cursor, and press EXEC. Press SPACEBAR to select View Definition and press EXEC. Page through multiple screenloads using the NORTH and SOUTH cursor movement keys. Use "Maintenance History" to record system problems and fixes.
2. Edit Definition - allows user to modify record definitions and comments. Also allows user to create, update, and delete field name, data type, and record length. Press SPACEBAR to position acceptance block and cursor, and press EXEC.
3. Delete Definition - allows user to erase record definitions. Press SPACEBAR to position acceptance block and cursor, and press EXEC.
4. Create Record Definition - allows user to add new record definitions and comments, as well as field name, data type, and record length. Press SPACEBAR to position acceptance block and cursor, and press EXEC.
5. Create View Definition - allows user to add new view definitions and comments, as well as field names. Press SPACEBAR to position acceptance block and cursor, and press EXEC. Use INSERT to select record definition and press EXEC.

# APPENDIX

## A



## TABLE OF CONTENTS

### APPENDIX A

	<u>Page</u>
VS-300 Signal Mnemonics .....	A-2
System Errors Requiring a Control Mode Dump .....	A-5
System Errors Causing Continuable Dump .....	A-9
Version Checking Status Error Messages .....	A-14
VS-300 I/O Controllers and Supported Devices .....	A-15
VS-300 10 Megabyte Duo-Binary Modem Channel Allocations .....	A-17

# APPENDIX A

VS-300 Signal Mnemonics, System Errors Requiring a Control  
Mode Dump, System Errors Causing Continuable Dump,  
Version Checking Status Error Messages, I/O Con-  
trollers and Supported Devices, VS-300 10 Mega-  
byte Duo-binary Modem Channel Allocations

## APPENDIX A

## VS-300 SIGNAL MNEMONICS

SIGNAL	DEFINITION
A-Port	Selects which operand is fed to A-Port
ACK	Acknowledge
AGRF	Address Generator Register File (AGU)
AGU	Address Generation Unit
ALU	Arithmetic Logic Unit
APA	Active Port Assembly
ATU	Address Translation Unit
AWS	Archiving Workstation
B-Port	Selects which operand is fed to B-Port
BCR	Bus Control Register
BLANC	Broadband Local Area Network Controller
BSR	Bus Status Register
C OUT R	Command Out Register
CA GEN	Case branch address Generator (CPU)
CAB	Contention Access Based
CHG	Page Changed flag (ATU)
CID	Command Identification
CIU	Cable Interface Unit
COMP	Comparator
CPU	Central Processing Unit
CRE	Current Ring of Execution
CSMA/CD	Carrier Sense Multiple Access Collision Detection
CSPA	Carry Save Propagate Adder
Clock	Controls instruction cycle time (microinstruction field)
DA GEN	Dispatch Address Generator
DAG	Dispatch Address Generator
DB BUFF	D-Bus Buffer. Buffers virtual address to D-Bus
DCC	Decimal Correction Constant register (CPU)
DMA	Direct memory Access
DMUX	Switches MIBR or MAC0 data to MAC1
DR	Display Register
DSA	Data Store Address
DSBS	Data Store Block Select
DSL	Data Store Latch
DVR	Diagnostic Visibility Register
DWBX	Double Word Cache Block crossing
DXAG	Dispatch Exception Address Generator
E-APA	Electric Active Port Assembly
ESU	Exponent Sign Unit. Performs exponent and sign operations
FPU	Floating Point Unit
HDLC	High Data Link Control (CIU)
IAE	Instruction Address Execute Register
ICTRL	Interrupt Controller
IDR	Identification Register
IIOC	Illegal I/O Command (SBI)
ILLMGS	Illegal Message type. SBI status
IOC	Input/Output Controllers

## VS-300 SIGNAL MNEMONICS

SIGNAL	DEFINITION
IPC-SBP	Sysbus parity error SBI status
IPCC	InterProcessor Communication Control
IPCR	InterProcessor Communication Register
IPCR	IPC Register
IQ	Instruction Queue (Latches, MUXs, and IRO-3 on the SGU)
IR MUX	Input Register Multiplexers
IRO-3	Instruction Registers 0 through 3
IR1,2	Input Registers 1 and 2
IRE	Instruction Registers Execute
IRE	Instruction Registers
ISMA	Illegal System Memory Address
ISMPA	Illegal System Memory Page Access
ITMR	Interval Timer
IVEAD	Invalid Effective Address Detect
LAT	Long Address Translation
MAC0	Microaddress Control 0 (CPU)
MAC1	Microaddress Control 1 (CPU)
MAG COMP	Magnitude Comparator. Compares CRE to read/write page protect
MC Bus	Memory Control Bus
MCIB	Memory Control Input Buffer
MCU	Memory Control Unit
MIA BUFF	Microinstruction Address Buffer
MIA DRVR	Microinstruction Address Driver
MIAC	Microinstruction Address Comparator
MIAC	Microinstruction Address Comparator (CPU)
MIBR	Microinstruction Address Branch Address Register (CPU)
MIR	Microinstruction Register
MOP-SBP	Memory Operation System Bus Parity Error. SBI status
MSRX	Microstate Register Transceiver
MSRX	Microstate Register Transceiver. Holds microaddress (CPU)
NACK(NAK)	Negative Acknowledge
NIA	Next Instruction Address
NMI	Nonmaskable Interrupt
NVRAM	NonVolatile Random Access Memory
OR1-3	Output Registers 1 through 3
PAR	Physical Address Register
PC	Professional Computer
PCI	Processor Control Interface
PCW	Program Control Word
PFLT	I/O Protection Fault. SBI status
PIAR	Physical Instruction Address Register
PRMD	Protection RAM Data
PSR	Processor State Register
PTENB	Protection RAM ENable
R/C MUX	Reference/Change Multiplexer
RAM	Random Access Memory
REF	Page Referenced flag (ATU)

## APPENDIX A

## VS-300 SIGNAL MNEMONICS

SIGNAL	DEFINITION
RTRB	Read Transport Reordering Buffer
SAIR	System Address bus Input Register
SAOR	System Address bus Output Register
SBI	System Bus Interface
SBMRPE	System Bus Memory Read Parity Error (SBI)
SBT	Start Bus Transfer. An 8086 I/O initialization command (IOC)
SCM	Support Command Mode. Single microinstruction sequencing
SCR	Support Command Register
SCR	Segment Control Register (ATU)
SCU	Support Control Unit
SCUI	Support Control Unit Interrupt Trap. Microlevel interrupt
SDIR	System Data bus Input Register
SDOR	System Data bus Output Register (SCU)
SMDE	System Memory Data Error (SBI)
SPB	Support Packet Bus. SCU diagnostic control bus
SPDR	Support Packet Data Register (CPU)
SPDR	Support Packet Data Register
SPU	Satellite Processing Unit (same as IOC or CPU)
SR REG	Save Return microaddress REGister (CPU)
SRMR	Save Return Microinstruction REGister (CPU)
SX BUFF	Sign Extend Buffer
TBBP	Translation Buffer ByPass buffer
TBTA	Translation Buffer Tag Address
TM BUFF	Translation/Memory Buffer
TRA	Trap Return Address
TSA MUX	Tag Store Address Multiplexer
TSPL	Tag Store Pipe Line
TV GEN	Trap Vector Generator (CPU)
VA BUFF	Virtual Address Buffer. Buffers address to VARs
VA MUX	Virtual Address Multiplexer
VAR	Virtual Address Register
VAR1,2	Virtual Address Registers 1 and 2
VMAD	Virtual Address illegal Address Detection. SBI status
VTPM	Valid Tag Parity Memory
WCSX	Writable Control Store register/transceiver
WIQD	Write Instruction Queue
WR-A	Working register for ALU calculations
WR-B	Working register for ALU calculations
WSO	Workstation number zero
XMAL	External Memory Address Latch
XMIA	Execute Microinstruction Address register

## SYSTEM ERRORS REQUIRING A CONTROL MODE DUMP

<u>ERROR HALT</u>	<u>EXPLANATION</u>
CLMM	An attempt has been made to set the clock comparator from the first TQEL on the timer queue, but the TQEL time value is for the next day (ie: the midnight TQEL is missing).
CLQE	An attempt has been made to set the clock comparator from the first TQEL on the timer queue, but the queue is empty.
FMIP	While searching through the available block list, the next-in-chain link was found to be pointing to the current block.
FMRC	While searching through the available block list, the next-in-chain link was found to be pointing to the current block.
FMRN	While searching through the available block list, the next-in-chain link was found to be pointing to the current block.
GMIC	An attempt has been made to obtain a block from the nonresident memory pool, but the memory chain links were found to be invalid.
GMIP	A memory block of sufficient size was found to satisfy the request, however, the block was page-aligned but not a complete page.
GMRL	While searching through the available block list, the next-in-chain link was found to be pointing to the current block.
GMRN	While searching through the available block list, the next-in-chain link was found to be pointing to the current block.
IOBA	Invalid physical address found in IAL.
IOIH	TCBFLGS3IGIGH is set. Ignore 'HELP'
IOIP	Invalid PPB chain. In attempting to locate the PPB for an IOP (for a given device), the PPB chain was found to be empty.
IOMQ	An IORE has been queued more than once on the IOQ for a device; IORE Address = IORECHN Address.
IOPS	An SIO has been attempted to a device that requires Presentation Services.

APPENDIX A

SYSTEM ERRORS REQUIRING A CONTROL MODE DUMP (CONT'D)

ERROR HALT	EXPLANATION
PCNR	The program check interrupt handler was activated, but no TCB is active.
PCNT	A program check has occurred in a 'nucleus' task (pager, IO timeout task).
PCPR	A page fault program check interrupt has occurred which is a page fault recursion error.
PGBI	Block number beyond the last extent in the pagefile. (In converting from block-in-file to block-on-volume an invalid block number was obtained.)
PGBT	The paging task was unable to block the faulting task on page frame semaphore.
PGFS	The paging task was unable to find a free page frame semaphore for the faulting task.
PGIP	An attempt has been made to reload the SCRs for the faulting TCB, however, the physical address of the RN table is invalid (indicated from the LPA instruction).
PGIV	A request has been made to mark the paging file with 'No Info' for the input virtual address (VA), but the VA is invalid (cannot be located within the RN table).
PGNS	The paging task was unable to find the required page frame semaphore in the PFSA list.
PGNW	The paging task has detected the nonreentrant use of a reentrant file (i.e., an attempt to page out to a nonwritable file).
PGPS	The paging task was unable to locate the PF semaphore used to block tasks waiting for the current page-in completion.
PGPT	The paging task was unable to locate the page table associated with this file (i.e., the block is beyond the end of the file).
PGQE	The paging task has been activated, however, all of the pager queues are empty.
PPBA	An attempt has been made to return a block to the system page pool but the block is not in use (in use bit already clear).
FPPE	A free block has been requested from the system page pool but none is available.

## SYSTEM ERRORS REQUIRING A CONTROL MODE DUMP (CONT'D)

ERROR HALT	EXPLANATION
SCEE	A nonreturnable entry has been made to the scheduler to dispatch a task and the scheduler has returned to the caller.
SCIE	The scheduler was activated but the event code supplied to the scheduler was invalid.
SCIS	A task (TCB) is being unblocked from a semaphore (SEMA) and the semaphore has an invalid type.
SGCT	While setting up and initializing the VTOC cache, a call to GETMEM to obtain space for the cache descriptor table has failed.
SGDD	The system was unable to destroy the TC scan work area after DLP initialization.
SGDI	The system was unable to destroy the IOP scan work area after IOCT initialization.
SGIS	The system was unable to create a block in heap storage for use as an IOP specification block.
SGIW	The system was unable to create a block in heap storage for use as an IOP scan work area.
SGLU	The system was unable to locate the UCB for the specified device.
SGNP	While setting up and initializing the VTOC cache, the available PFT chain was found to be empty.
SGSP	The system was unable to obtain a block through the GETBLK interface to use as a PPB for an IOP.
SGTS	The system was unable to create a block in heap storage for use as a TC specification block.
SGTW	The system was unable to create a block in heap storage for use as a TC scan work area.
SI3J	The FDR1 block for the JSI system services file indicates that there are more than three extents for the file.
SI3S	The FDR1 block for the Segment 1 SVC file indicates that there are more than three extents for the file.
SIFV	The system was unable to free the Segment 0 memory used as the volume label work area.



APPENDIX A

SYSTEM ERRORS REQUIRING A CONTROL MODE DUMP (CONT'D)

ERROR HALT	EXPLANATION
SIGV	The system was unable to allocate Segment 0 memory to prepare for volume IO (used as a volume label work area to mount accessible disks).
SIIE	An IO Error has occurred while loading the disk IOC microcode. The error is contained within LOWIOSW general and error status fields (i.e., failure was defined as 'Normal Completion' not being obtained).
SIIV	The VCB chain was discovered to be broken while the system was searching the chain during the mounting of accessible disks.
SILF	The FDR1 block for the translation library JSI system services file could not be found.
SIMB	The system was unable to allocate segment memory to read the fault tolerant bit map of a mounted volume.
SIMD	The system was unable to allocate Segment 0 memory to read FDX1 of a mounted disk volume.
SIMF	An attempt to obtain memory for the FLUB for a paging file has failed.
SIMP	An attempt to obtain memory for the system page pool descriptors (SPPD) has failed.
SIRF	During system initialization, a read fail occurred when trying to read FDR1 from the system VTOC.
SIRL	A disk read fail has occurred during disk IOC load. The reason for the error is contained within LOWIOSW general and error status fields (i.e., failure was defined as 'Normal Completion' not being obtained).
SIVC	While attempting to scratch any existing Segment 2 paging files, the system VCB chain was found to be invalid. The VCB end-of-chain was detected without locating the required VCB.
SIWS	The system was unable to release Workstation 0 to the task manager after the completion of system initialization.
USNT	An attempt was made to cancel a task on the system via ZAPTASK, but an unrecoverable error makes continuation of this service questionable (probably task not found).
BLIP	Invalid PPB chain. The PPB chain in the MCB was to be accessed to insert the newly created PPB, but the first entry on the PPB chain was zero.

## SYSTEM ERRORS CAUSING CONTINUABLE DUMP

ERROR HALT	EXPLANATION
BLNP	The system was unable to locate the PPB for the specified device.
BLNT	A call to GETBLK was made for individual block allocation but no TCB address was given in the parameter list.
CHFE	The CHECK post wait handler was unable to destroy the sub-task.
CHII	An invalid IOSW has been received from the IOP.
CHLT	The CHECK post wait handler was unable to locate the parent TCB for the requested task number.
CHNP	An attempt to locate the PPB associated with this device (R1) has failed.
CHTL	An attempt to locate the linkage table entry for translation library routine WV17STRT was unsuccessful.
CPNB	An error has been returned from GETHEAP after an attempt to obtain the command processor's buffers from the system pool.
CPPS	Presentation services failed to establish a connection with the remote system and the LOGOFF SVC was entered. However, the logoff was unsuccessful.
CPTM	For the task manager, a false logoff was set and LOGOFF SVC was entered. However, the logoff was unsuccessful.
DBIV	VCB chain invalid. While searching through the VCB chain and sorting the available volumes for paging eligibility, the system volume VCB was not located.
DPPT	The system was unable to locate the page table for a file. Given that multiple page tables exist, the system has searched all PTs chained into this FLUB and has been unable to locate the required page number within the file.
DTIB	DTI has encountered a failure in converting block-in-file to block-on-volume for Segment 2 paging file.
DTIF	DTI has encountered a FLUB not belonging to the SHARER that does not match a Segment 2 paging file FLUB owned by the user task.

APPENDIX A

SYSTEM ERRORS CAUSING CONTINUABLE DUMP (CONT'D)

ERROR HALT	EXPLANATION
DTIP	While attempting to unmap a physical page, the page frame number was found to be invalid.
DTLP	Given that multiple page tables exist, an attempt to locate a page table for a file (FLUB) has failed.
DTXE	DTI has received an error return code from XIO on attempting to write out the paging file block.
DUMP*	WM27 calls snapshot dump if the task that PC'd was a system task.
GHNP	No PFB was found within the ETCB for this GETHEAP call.
IDMA	IPC destroy was unable to cancel a mailbox alias.
IKSV	During the invoke task for one of the system tasks, a search of the VCB chain for the system volume was unsuccessful.
IRG2	A call to IWAIT to wait on a temporary mailbox did not result in a return message.
IRMM	IPC retrieve was unable to move a message body from the message buffer to the user specified area. The error response code from FAGRMAP is still held in the local variable area RETCODE (referenced through R11)
MLNF	While searching the FLUB chain, no FLUB with a name matching the file name in work area was found.
MLNO	While searching the OFB file chain, no OFB with OFDTCB = CPUTCB was located.
MLNP	The system was unable to locate the PPB for the specified device.
MLQI	During the close phase of microcode load, prior to freeing the OFB and IORE, a check was made to see if the IORE was still queued on the UCB and the IORE was found to be queued.
PCDU*	WS50 causes a task to suspend, then calls a continuable dump. It Will result in a task crash.
RAOR*	It is not possible to open or read the alias file.
*	After the continuable Dump is completed, the system continues without a reIPL.

## SYSTEM ERRORS CAUSING CONTINUABLE DUMP (CONT'D)

<u>ERROR HALT</u>	<u>EXPLANATION</u>
RARF	An attempt to obtain nonresident memory as a read buffer for the alias file has failed.
RARF*	It is not possible to read the alias file.
RAUM	An attempt to allocate memory from the heap for use in the open alias file routine as a UFB has failed.
RRMB	No message buffer was found chained to the TCB for this XTERM call.
RRNP	No PFB was found within the ETCB for this XTERM call.
RSIS	An invalid Segment 1 SVC invocation during system initialization has occurred.
SRCN	TCBINSMC is negative. The only legal values are nonnegative.
SRSN	TCBSMECBK for the resource in question is negative. The only legal values are nonnegative.
TIID	After attempting to map the debugger code for this task, an error response was returned from the MAP SVC.
TIDD	After attempting to unmap the debugger data for this task, an error response was returned from the UNMAP SVC.
TIDU	After attempting to unmap the DMS shared area for this task, an error response was returned from the UNMAP SVC.
TIID	After successfully mapping the debug code for this task, it is the wrong debug file. This was determined by checking the address at which debug should have been mapped against the address at which it was actually mapped.
TIIE	After completing the necessary task initialization, control has been returned to SYSINIT when it should not have been possible to return.
TILT	After attempting to map the linkage table for this task, an error response was returned from the MAP SVC.
*	After the continuable Dump is completed, the system continues without a reIPL.

APPENDIX A

SYSTEM ERRORS CAUSING CONTINUABLE DUMP (CONT'D)

ERROR HALT	EXPLANATION
TIMD	After attempting to map the DMS services for this task, an error response was returned from the MAP SVC.
TIMH	After attempting to map the IPC header buffers for this task, an error response was returned from the MAP SVC.
TISM	After attempting to map the Segment 1 system SVCs for this task, an error response was returned from the MAP SVC.
TISI	After attempting to unmap the Segment 1 SVCs for this task, an error response was returned from the UNMAP SVC.
TISA	After successfully mapping the system services for this task, it was impossible to find the system services address in the linkage table.
TISD	An attempt to obtain memory for the DMS vector table has failed. This table is allocated only once, when the first task is initialized.
TISM	After attempting to map the DMS shared area for this task, an error response was returned from the MAP SVC.
TISS	After attempting to map the system services for this task, an error response was returned from the MAP SVC.
TIST	An attempt to obtain memory for the TRN vector table has failed. This table is allocated only once, when the first task is initialized.
TITL	After attempting to map the translation library for this task, an error response was returned from the MAP SVC.
TIUB	After attempting to unmap the IPC bodies region for this task, an error response was returned from the UNMAP SVC.
TIUD	After attempting to unmap the DMS file for this task, an error response was returned from the UNMAP SVC.
TIUE	After completing the necessary termination functions and invoking UNLINK, control has been returned to SYSINIT when it should not have been possible to return. Exit from UNLINK should have been to the task quit code.
TIUL	After attempting to unmap the linkage table for this task, an error response was returned from the UNMAP SVC.

## SYSTEM ERRORS CAUSING CONTINUABLE DUMP (CONT'D)

ERROR HALT	EXPLANATION
IIUS	After attempting to unmap the system services for this task, an error response was returned from the UNMAP SVC.
TIUT	After attempting to unmap the translation library for this task, an error response was returned from the UNMAP SVC.
TIWD	After successfully mapping the DMS services for this task, it is shown to be the wrong SVC file. This was determined by checking the address at which DMS should have been mapped against the address at which it was actually mapped.
TIWS	After successfully mapping the Segment 1 system SVCs for this task, further checking shows it to be the wrong SVC file. This could mean that either the original 8-MB file was incorrectly mapped in or an attempt to subsequently map the 16 MB version also failed.
ULDM*	UNLINK has invoked the system service to destroy a mailbox and an error response has been returned.
ULDT	UNLINK has invoked the system service to destroy the trace buffers and an error response has been returned.
ULFP	UNLINK has invoked the system service to unfix the disk diagnostics pages that were allocated to this task and received an error response.
ULNF	UNLINK was unable to locate the current Segment 1 FLUB on the system FLUB chain in order to free the FLUB.
ULNL	UNLINK decremented the task's current link level (ETCB) and the resulting link level was negative.
ULNP	A PFB SAVE area has not been located in a level stack. A search of all this task's active process level stacks for for one which contains the PFB (comparing against stack minimum and maximum values in the stack header) has failed.
ULPC	Having adjusted the necessary stack(s), it is now no longer possible to locate any PFB via the ETCB PFB chain.
ULUM	UNLINK was attempting to unmap each MAPB on the specified MAPB chain when, for one MAPB, an error response was received from UNMAP.
*	After the continuable Dump is completed, the system continues without a reIPL.

APPENDIX A

VERSION CHECKING STATUS ERROR MESSAGES

---

<u>MESSAGE</u>	<u>DEFINITION</u>	<u>COMPONENTS</u>
(blank)	No problems are detected.	
WARNING	A version problem exists with this component, though it is not critical enough to halt system initialization.	@PRTTSK@ @SHARER@ DEVLIST
FATAL ERROR	IPL procedures cannot continue. Obtain a current, compatible version of the component and then reIPL.	@SYSGEN@ @SYSTSK@ @OPER@ @SYSCPR@ @TSKMGR@

---

## VS-300 I/O CONTROLLERS AND SUPPORTED DEVICES

This appendix lists, according to the input/output controller (IOC), the supported devices for the VS-300.

<u>VS-300 IOC</u>	<u>TYPE OF IOC</u>	<u>DEVICES SUPPORTED</u>	
23V98-1	Disk	2280V-1 30 MB fixed and removable drive	
23V98-2		2280V-2 60 MB fixed and removable drive	
23V98-3		2280V-3 90 MB fixed and removable drive	
23V98-4		2265V-1 75 MB removable drive (SMD)	
		2265V-2 288 MB removable drive (SMD)	
		2265V-3 620 MB fixed drive (FMD)	
		2267V-1 76-MB removable drive (RSD)	
		2268V-1 76 MB fixed drive (WINC)	
		2268V-2 147 MB fixed drive (WINC)	
		2375V-1, C3 454 MB fixed drive (FSD)	
		SW04 Disk Switch for all drives (except 2280V drives)	
-----			
23V97		32 port serial	2509, 9-track serial tape drive
			2529V 6400 bpi cartridge tape drive
		2238V1 Streamer tape	
		2276C-1 64KB combined archiving workstation	
		2276C-3 Combined archiving workstation	
		2860-6 Combined archiving workstation	
		2860-7 Combined archiving workstation	
		4250-VS Combined archiving workstation	
		WPC Combined archiving workstation	
		2256C 64KB combined workstation	
		4205 Monochrome combined workstation	
		4210 Monochrome DP workstation	
		4230 64KB monochrome combined workstation	
		4245 Color combined workstation	
		5300/Vs-IIS64 Combined workstation	
		5300W/Vs Combined workstation	
		5300/Vs-AL-AUD Combined workstation	
		5300/Vs-AUD Combined workstation	
		6300/Vs-64 Combined workstation, including graphics	
		5533 100-cps matrix printer	
		5535 180-cps matrix printer	
		5573 250-lpm band printer	
		5574 600-lpm band printer	
		5575 Printer-IIS/DP	
		5577V High density matrix printer	
		5577A High density matrix printer	
		6581W 40-cps daisy printer	



APPENDIX A

I/O CONTROLLERS AND SUPPORTED DEVICES

<u>VS-300 IOC</u>	<u>TYPE OF IOC</u>	<u>DEVICES SUPPORTED</u>
		6581WC-1 Printer-IIS/DP/ALLIANCE 5581WD-1 Printer-ALLIANCE DW/OS-20 20-cps daisy printer DW/OS-55 55-cps daisy printer LPS-12 Laser printer (WP only) LIS-12V Printer-IIS/DP LIS-12A Printer-ALLIANCE 6554/TCB Telecommunications Processor CIU-B WangNet SystemBand Modem 6550 Gate Array TCB
23V96	Multiline Telecommuni- cations	2110 Workstation 4220 Binary synchronous remote workstation 2246R Remote workstation 2281 Remote daisy printer 2233 Remote matrix printer 2235 Remote matrix printer 2273V-1 Remote band printer
23V95-1	Tape	2209V tape drive
23V95-2	Tape	2219V tape drive
23V79	WangBand CIU	

## VS-300 10 MEGABYTE DUO-BINARY MODEM CHANNEL ALLOCATIONS

## NOTE

When the 10 megabyte modem is used on the channel listed in the first column, devices listed under device type should not be used on the channels listed under the channel/frequency column.

10 MBPS CHANNEL	DEVICE TYPE	CHANNEL/FREQUENCY
CHANNEL 0 (216 - 228 MHz)	Global:	CH14 (209 - 217 MHz)
	Global:	CH15 (217 - 225 MHz)
	Global:	CH16 (225 - 233 MHz)
	TV:	CH J (216 - 222 MHz)
	TV:	CH K (222 - 228 MHz)
	Old Modem	(216 - 243 MHz)
CHANNEL 1 (228 - 240 MHz)	Global:	CH16 (225 - 233 MHz)
	Global:	CH17 (233 - 241 MHz)
	TV:	CH L (228 - 234 MHz)
	TV:	CH M (234 - 240 MHz)
	Old Modem	(216 - 243 MHz)
CHANNEL 2 (240 - 252 MHz)	Global:	CH17 (233 - 241 MHz)
	Global:	CH22 (241 - 249 MHz)
	Global:	CH19 (249 - 257 MHz)
	TV:	CH N (240 - 246 MHz)
	TV:	CH O (246 - 252 MHz)
	Old Modem	(216 - 243 MHz)
CHANNEL 3 (252 - 264 MHz)	Global:	CH19 (249 - 257 MHz)
	Global:	CH20 (257 - 265 MHz)
	TV:	CH P (252 - 258 MHz)
	TV:	CH Q (258 - 264 MHz)
	SIMS:	(258 - 264 MHz)
CHANNEL 4 (264 - 276 MHz)	Global:	CH20 (257 - 265 MHz)
	Global:	CH21 (265 - 273 MHz)
	Global: (Note)	CH22A (273 - 281 MHz)
	TV:	CH R (264 - 270 MHz)
	TV:	CH S (270 - 276 MHz)


## NOTE

This channel not presently available.



# SCHE- MATICS

## VS-300 SCHEMATICS



WLI P/N	Description	Number Of Sheets
210-8142	10MBPS, 5-Channel RF Modem	3
210-8310	SCU Local Comm. Option	6
210-8377	PC/LVS (PC to SCU Interface)	5
210-8391	CIU CAB (23V79)	7
210-8392	CIU BLANC IOC (23V79)	9
210-8491	MLTC IOC (23V96)	16
210-8494	RS232A Dr./Rcv. (MLTC)	2
210-8495	RS366 Dr./Rcv. (MLTC)	2
210-8496	Serial Communications Link	2
210-8497	Block Connector	2
210-8503	APA (Muxbus) Terminator	2
210-8504	APA (Active Port Assembly) (SE 8P Multiplex XCVR)	3
210-8509	BNC/TNC Active Port Assembly	3
210-8514	Low-Cost 12" Monitor	2
210-8609	Serial IOC (23V97)	8
210-8703/8703-1	Main Memory (4/8-Megabytes)	16
210-8709	Power Supply Controller	5
210-8710	SCU/PC Adapter	2
210-8715	AC Distribution	3
210-8716	DC Distribution	3
210-8717	Battery Backup	2
210-8785	SMD IOC (23V98-1/2/3/4)	9
210-8789	Telex Tape IOC (23V95-2)	6
210-8790	Kennedy Tape IOC (23V95-1)	7
210-8831	CPU	23
210-8832	Address Generation Unit	21
210-8833	Address Translation Unit	21
210-8834	Memory Control Unit	18
210-8835	Support Control Unit	15
210-8836	System Bus Interface	23
210-8837	Backplane	5
210-9225	SCU Winchester Controller	6
210-9231	CPU	23
210-9236	System Bus Interface	23
210-9237	SCU Motherboard	2
210-9245	SCU Local Comm. Data Link	9
210-9246	SCU Local Comm. Processor	6
210-9343	SCU Character Resolution	5
210-9521	SCU CPU/Memory (256K)	7



MNEMONICS	COORD
ACD	1E1
CS8	3D18
CS1	3D18
CS2	3D18
ETS	2M1
BCD1	2J1
ECS2	2J1
DSN	2M1
DTN	2J18
RESETPC	1E18
RYS	2J18
RACL	3J1
REDATA	3X1
TPL	3B12
TRCL	2J1
TS1	2M1




VPS	I C LOC	SPARE
74500	1B	2
74503	1E	2
7407	1J3	2
74574	1D	1
74512	1E5	1
577	1E3	1
LM558	1E1	1



NOTES:  
 1 ALL RESISTORS ARE 1/4W 5%, UNLESS OTHERWISE SPECIFIED.  
 2 ALL CAPS DO NOT HAVE CORES, UNLESS OTHERWISE SPECIFIED.

E REV  
 0

NO MAPS 8142



27

17

5.8

8.5

11

17

22

22

17

5.8





8.5

11

17

22

DATE	
DESIGNED BY	
CHECKED BY	
APPROVED BY	
10 MBPS	8172





10 MBRS 814A

THIS DRAWING IS THE PROPERTY OF WANG LABORATORIES, INC. IT IS TO BE USED ONLY FOR THE PROJECT AND FOR WHICH IT WAS PREPARED. IT IS NOT TO BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, INCLUDING PHOTOCOPYING, RECORDING, OR BY ANY INFORMATION STORAGE AND RETRIEVAL SYSTEM, WITHOUT THE WRITTEN PERMISSION OF WANG LABORATORIES, INC.

- NOTES
1. ALL RESISTOR VALUES IN OHMS.
  2. ALL CAPACITOR VALUES IN MICROFARADS UNLESS OTHERWISE INDICATED.
  3. ALL RESISTORS 1/4W 5% UNLESS OTHERWISE INDICATED.

MEMORICS	COCRD.
ATOC	5C14
ATOC	2K11
BPC	2A14
CLK	5G14
BACKD	2H12
+GA	-11
+GB	-12
+ACR	5F14
TORROW	3G1
TCPC	5D14
TORROW-TORROW	5A12
+RCC	2K11
PAQ-PA19	5I14
PDQ-PD7	3E1
PDQ-PD15	3F1
-RA	-K1
-RB	-K2
PDY	5J1
RESET	2B14
SAD	5G14
SIDD-SID3	5G14
-CLR	5F14



WANG LABORATORIES, INC. SCHEMATIC DIAGRAM

TITLE SINGLE BD. LOCAL COMM OPTION M/L

SCALE 1:1 SHEET 1 OF 5 SIZE 8 1/2 X 11

DRAWING NUMBER 8310 7


DATE 10/1/77

DESIGNER PBC


WANG PART NUMBER SEE CHART


REV 2 N






THIS DRAWING IS THE PROPERTY OF WANG LABORATORIES, INC. IT IS TO BE USED ONLY FOR THE PROJECT AND SYSTEM SPECIFICALLY IDENTIFIED HEREIN. IT IS NOT TO BE REPRODUCED, COPIED, OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, INCLUDING PHOTOCOPYING, RECORDING, OR BY ANY INFORMATION STORAGE AND RETRIEVAL SYSTEM, WITHOUT THE WRITTEN PERMISSION OF WANG LABORATORIES, INC.





THIS DRAWING AND THE DATA THEREON ARE UNCLASSIFIED AND ARE RELEASED UNDER E.O. 13526, DATE 08-14-2011.


14 13 12 11 10 9 8 7 6 5 4 3 2 1



22"  
17"  
11"  
8.5"  
8.5"  
11"  
17"  
22"

22"  
17"  
11"  
8.5"  
8.5"  
11"  
17"  
22"

THIS DRAWING AND THE DATA THEREON ARE THE PROPERTY OF WANG AND SHOULD NOT BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, INCLUDING PHOTOCOPYING, RECORDING, OR BY ANY INFORMATION STORAGE AND RETRIEVAL SYSTEM, WITHOUT THE WRITTEN CONSENT OF WANG. THE LIMITED LIABILITY OF WANG UNDER THIS AGREEMENT IS LIMITED TO THE EXTENT PERMITTED BY LAW TO LOCATE THE LIABILITY OF THE COMPANY TO BE RETURNED TO THE SOURCE OF THE DEFECTIVE PART.




- NOTES: UNLESS OTHERWISE SPECIFIED:
1. ALL CAPACITORS ARE .047 EXPRESSED IN MICROFARAD.
  2. ALL RESISTORS ARE 1/4W 5 PERCENT EXPRESSED IN OHMS.
  3. Q1, Q2, Q3 2N3771 TRANSISTOR M.P. NO. 375-1858.
  4. J1 2PIN HERCULEX CONN. M.P. NO. 350-8283, WITH SHUNT P2, M.P. NO. 350-1506.
  5. T1, T2 LEAD TERAHA INSULATOR M.P. NO. 376-1880.
  6. ALL 10K SIPS ARE M.P. NO. 333-8889.
  7. ALL 1K SIPS ARE M.P. NO. 333-8887.
  8. ALL 2.2K SIPS ARE M.P. NO. 333-8886.
  9. ALL 100 DIPS ARE M.P. NO. 333-8885.
  10. T1 21 375 KHZ CRYSTAL M.P. NO. 321-8899.
  11. T2 39 2 MHz CRYSTAL M.P. NO. 321-1889.
  12. WIRE USED ON DND, TND CONNECTIONS ARE TO BE AS FOLLOWS:  
28 GAUGE RED P/W 680-8382.  
28 GAUGE BLACK P/W 680-8388.

8310-2  
SINGLE DND LOCAL COM. OPTION PAL  
FOR ALL ASSOCIATED DOCUMENTS, SEE HISTORY SHEET

		BY	DATE	APPROVED BY	DATE
		JAN 1978	8/21	C. CHOR	
MODEL NO. 8310		OR		R. CHOR	
				H. CHOR	
TITLE SINGLE DND LOCAL COM. OPTION PAL ASSEMBLY DRAWING					
PARTIAL NO. 8310-2					
FINISH SEE DRAWING FOR FINISH					
		210-8310	D	83106	


THIS DRAWING AND THE DATA SHOWN THEREON ARE THE CONFIDENTIAL PROPERTY OF AND ARE PROPRIETARY TO WANG LABORATORIES, INC. THIS DRAWING AND THE DATA SHOWN THEREON MAY NOT BE MADE PUBLIC WITH-OUT THE WRITTEN CONSENT OF WANG LABORATORIES, INC. IF FOR ANY REASON THIS DRAWING IS REPRODUCED BY ANY MEANS, THE PHYSICAL CUSTODY OF THE COMPANY IS RETAINABLE UPON THE DEMAND OF WANG LABORATORIES, INC.

DO NOT SCALE



REV.	DESCRIPTION	DATE	BY	CHK.
1	SEE SMT #			

WANG PART NO.	DRAWING NO.	DESCRIPTION	DATE	APPROVED BY	DATE
			7/28	EE ENGR	
				ME ENGR	
				MG ENGR	
MATERIAL	MODEL NO.	TITLE			
	VS300	PC/LVS. INTERFACE			
		SEE CHART	D	B371	3




THIS DRAWING AND THE DATA SHOWN THEREON ARE THE CONFIDENTIAL PROPERTY OF AND ARE PROPRIETARY TO WANG LABORATORIES, INC. THE DRAWING AND THE DATA SHOWN THEREON MAY NOT BE MADE PUBLIC WITHOUT THE WRITTEN CONSENT OF WANG LABORATORIES, INC. IF FOR ANY REASON THIS DRAWING IS PERMITTED BY WANG TO LEAVE THE PHYSICAL CUSTODY OF THE COMPANY IT IS RETURNABLE UPON THE DEMAND OF WANG LABORATORIES, INC.

WANG PART NO	DRAWING NO	DESCRIPTION	BY	DATE	APPROVED BY	DATE
			OWN	7/22	ENGR	
			CHK		ENGR	
					WFG ENGR	
MATERIAL	MODEL NO	TITLE				
	VS 300	PC/L.S. INTERFACE				
FINISH	ME ENGR SPECIFICATION					
	FOR EX. AS NOTED	EE HANI				
	1/8" ± 0.005 FRAC. 1/16" ± 0.002	D 83 77 3				
	1/16" ± 0.0025	WANG PART NUMBER				
		SIZE				
		DRAWING NUMBER				
		REV				

77  
11  
10  
9  
8  
7  
6  
5  
4  
3  
2  
1  
11  
10  
9  
8  
7  
6  
5  
4  
3  
2  
1  
11  
10  
9  
8  
7  
6  
5  
4  
3  
2  
1  
11  
10  
9  
8  
7  
6  
5  
4  
3  
2  
1  
11  
10  
9  
8  
7  
6  
5  
4  
3  
2  
1  
11  
10  
9  
8  
7  
6  
5  
4  
3  
2  
1

22  
17  
11  
8.5  
8.5  
11  
17  
22




THIS DRAWING AND THE DATA SHOWN THEREON ARE THE CONFIDENTIAL PROPERTY OF AND ARE PROPRIETARY TO WANG LABORATORIES, INC. THIS DRAWING AND THE DATA SHOWED HEREIN MAY NOT BE MADE PUBLIC WITHOUT THE WRITTEN CONSENT OF WANG LABORATORIES, INC. IF FOR ANY REASON THIS DRAWING IS REPRODUCED BY ANY OTHER PARTY, THE LIABILITY OF THE COMPANY IS RETURNABLE UPON THE DEMAND OF WANG LABORATORIES, INC.

REV.	REVISION
1	SEE SHEET 4

WANG PART NO.	DRAWING NO.	DESCRIPTION	BY	DATE	APPROVED BY	DATE
			DWN LPM	4/9/38	E ENGR	
			CHK		M ENGR	
					MFG ENGR	
MATERIAL	MODEL NO.	V5300	TITLE			
	MECHANICAL SPECIFICATIONS		PC/L.S. INTERFACE			
FINISH	FOR IN AS NOTED		SEE PART	D	B377	3
	EX = 0.015 INCH ± 0.0005 INCH					
	RKX = 0.005 INCH ± 0.0002 INCH					
	SCALE	SHEET 3 OF 5	WANG PART NUMBER	REV	DRAWING NUMBER	REV





THIS DRAWING AND THE DATA SHOWN THERE ON ARE THE CONFIDENTIAL PROPERTY OF AND ARE PROPRIETARY TO WANG LABORATORIES, INC. THIS DRAWING AND THE DATA SHOWN THEREON MAY NOT BE MADE PUBLIC WITHOUT THE WRITTEN CONSENT OF WANG LABORATORIES, INC. IF FOR ANY REASON THIS DRAWING IS FURNISHED BY WANG TO LEAVE THE PHYSICAL CUSTODY OF THE COMPANY, IT IS RETURNABLE UPON THE DEMAND OF WANG LABORATORIES, INC.



I.C. TYPE	LOC.	SPARES
74ALS04	L31	2
7407	L8	4
74ALS08	L68	1
74ALS32	L35	1
	L53	1
	L54	1
	L67	1
	L72	1
74ALS74	L69	1
L4339	L70	1
74ALS02	L71	3

	PM0	PM1
PC CONNECTED VS. POWERED UP	0	0
PC CONNECTED VS. NOT POWERED UP	0	1
PC, NOT CONNECTED TO V.S.	1	1



MNEUMONICS	COORD
A0-A15	1F11
A16-A19	2F11
ALE	1B11
A10WA	1C11
AMWC	2B11
BHE	2B11
CLK	2F11
D0-D15	1A7
DEM	1H11
DT/R	1B11
HACK	1D11
IORC	1C11
IRQ0	1B1
MRDC	2B11
PAD0-PAD5	1F1
PBINT	1G3
PCE	1D11
RTCEN	2E1
RESET	1H11
RDY	3A4
SAD	1B11
SE0-S13	1G0
VSP	1D11
XAS	1B1
XDEN	1D1
XDT/R	1C1
XIOWR	1E1
XIORC	1C1
XPBOP	1E1
XDATAEN	1D1

210 = 209 + 377 OR 378
210 209 L2
8377A 8377 377-0903

E-REV  
2



NOTE:  
1. ALL RESISTORS ARE 1/4W 5% UNLESS SPECIFIED OTHERWISE

REV	DATE	BY	DESCRIPTION
1	11/11/81	...	...
2	11/11/81	...	...
3	11/11/81	...	...
4	11/11/81	...	...
5	11/11/81	...	...
6	11/11/81	...	...
7	11/11/81	...	...
8	11/11/81	...	...
9	11/11/81	...	...
10	11/11/81	...	...

WANG PART NO	DRAWING NO	DESCRIPTION	BY	DATE	APPROVED BY	DATE
			DWN	11/11/81	ENGR	
			CHK	11/11/81	ENGR	
MATERIAL	MODEL NO	TITLE				
	V. 300	PC/LVS INTERFACE				
FINISH	TOL	SEE CHART	D	8377	3	

THIS DRAWING AND THE DATA THEREON ARE THE CONFIDENTIAL PROPERTY OF WANG AND SHOULD BE KEPT AS SUCH. UNLESS OTHERWISE SPECIFIED, THIS DRAWING AND THE DATA THEREON MAY NOT BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, INCLUDING PHOTOCOPYING, RECORDING, OR BY ANY INFORMATION STORAGE AND RETRIEVAL SYSTEM, WITHOUT THE WRITTEN CONSENT OF WANG LABORATORIES, INC. IF FOR ANY REASON THIS AGREEMENT IS VIOLATED BY ANY INDIVIDUAL OR ENTITY, WANG LABORATORIES, INC. WILL BE ENTITLED TO SEEK AND OBTAIN A COURT ORDER FOR INJUNCTIVE RELIEF AND TO RECOVER DAMAGES AND COSTS OF LITIGATION. THIS DRAWING IS RETURNABLE UPON THE DEMAND OF WANG LABORATORIES, INC.


DO NOT SCALE



- NOTES: UNLESS OTHERWISE SPECIFIED
1. ALL CAPACITORS ARE .047 EXPRESSED IN MICROFARAD.
  2. ALL RESISTORS ARE 1/4W 5 PERCENT EXPRESSED IN OHMS.
  3. C62, C69, C85, C86, D3, D4, D6, D7, D8, D9, D18, L1, L29, L26, L18, L25, L64, L78, R3, R4, R12, R17, R18, R19, R20, R21, R22, R23, R24, R27, R31. COMPONENTS WILL BE LOADED ONLY IF NON VOLATILE APP IS USED.
  4. W1: ADD INSULATOR (375-1834), SCREW (658-2128), NUT (652-2885).
  5. LOAD & POS. SHUNT (358-4586) AT J8.


<b>(WANG)</b> LABORATORIES, INC. 220 WEST 42ND STREET NEW YORK, N.Y. 10018		BY	DATE	APPROVED BY	DATE
		CHK		CHK	
MODEL NO. UB-900		TITLE ASSEMBLY DRAWING PC/L V. S INTERFACE			
REV. NO. 10-113		237-8377	8377	2	

THIS DRAWING AND THE DATA SHOWN THEREON ARE THE CONFIDENTIAL PROPERTY OF, AND ARE PROPRIETARY TO, WANG LABORATORIES, INC. THIS DRAWING AND THE DATA SHOWN THEREON ARE NOT TO BE MADE PUBLIC WITHOUT THE WRITTEN CONSENT OF WANG LABORATORIES, INC. IF FOR ANY REASON THIS DRAWING IS PERMITTED BY WANG TO LEAVE THE PHYSICAL CUSTODY OF THE COMPANY, IT IS RETURNABLE UPON THE DEMAND OF WANG LABORATORIES, INC.



- NOTES
1. ALL RESISTOR VALUES IN OHMS.
  2. ALL CAPACITOR VALUES IN MICROFARADS UNLESS OTHERWISE INDICATED.
  3. ALL RESISTORS 1/4W 5% UNLESS OTHERWISE INDICATED.
  4. PARTS LIST APPEARS ON SHEET 7.


MNEMONICS	COORD
ALET	6G6
CABPBTT	6A4
CABPERR	6A4
CRASH	6C1
CYLRPBTT	6G6
CTS	2C11
DAMATCH	6A1
DCDI	5F11
DCDT	6B1
DCDZ	5F11
DSR	2C11
DTR	2A4
ENDMARD	6G5
EDT	6B1
INIT	6G6
TORD	6G6
TOWR	5G7
REHARD	6C1
REHWR	6C1
MCS0-MCS2	2A5
ON/OFF	6G6
RSETTFL	2A7
RTS	3A11
R4C	5F11
R4ERR	5H1
RXSO	5F11
SPARE1	6C6
SPARE2	6A4
SPARE3	6A4
YFL	2C11
TRID-TR17	EF1
TXC	4E11
TXNRZ1	4E1




ORIGINATED PER	DATE	CHKR	REVISION
JSW	6-18-84	KTH	02-19-85
R.B.P.	04-24-85		

<b>WANG</b> LABORATORIES, INC.		SCHEMATIC DIAGRAM	
TITLE CONTENTION		ACCESS BD M/L	
PCB NUMBER	WANG PART NUMBER	DWN	ENG
911A	210-8391	JSW	PB
SCALE	SHEET	1 OF	2
SIZE	DRAWING NUMBER	REV	
	8391	2	

THIS DRAWING AND THE DATA SHOWN THEREON ARE THE CONFIDENTIAL PROPERTY OF, AND ARE PROPRIETARY TO, WANG LABORATORIES, INC. THIS DRAWING AND THE DATA SHOWN THEREON MAY NOT BE MADE PUBLIC WITHOUT THE WRITTEN CONSENT OF WANG LABORATORIES, INC. IF FOR ANY REASON THIS DRAWING IS PERMITTED BY WANG TO LEAVE THE POSSESSION OF THE COMPANY, IT IS RETURNABLE UPON THE DEMAND OF WANG LABORATORIES, INC.




THIS DRAWING AND THE DATA THEREON ARE THE CONFIDENTIAL PROPERTY OF, AND ARE PREPARED BY, WANG LABORATORIES, INC. NO PART OF THIS DRAWING OR THE DATA THEREON MAY BE MADE PUBLIC WITHOUT THE WRITTEN CONSENT OF WANG LABORATORIES, INC. IF FOR ANY REASON THIS DRAWING IS REPRODUCED BY ANY OTHER PARTY, THE LIABILITY OF THE COMPANY IS RETURNABLE UPON THE SIGNATURE OF WANG LABORATORIES, INC.




WANG LABORATORIES, INC.	D	8391	2
	SCALE	SHEET 3 OF 7	SIZE DRAWING NUMBER REV.






THIS DRAWING AND THE DATA SHOWN THEREON ARE THE CONFIDENTIAL PROPERTY OF, AND ARE PROPRIETARY TO, WANG LABORATORIES, INC. THIS DRAWING AND THE DATA SHOWN THEREON MAY NOT BE MADE PUBLIC WITHOUT THE EXPRESS CONSENT OF WANG LABORATORIES, INC. IF FOR ANY REASON THIS DRAWING IS PERMITTED BY WANG TO LEAVE THE PHYSICAL POSSESSION OF THE COMPANY, IT IS HEREBY UNDERSTOOD THAT THE COMPANY WILL BE RESPONSIBLE FOR THE RETURN OF THIS DRAWING TO WANG LABORATORIES, INC.



THIS DRAWING AND THE DATA SHOWN THEREON ARE THE CONFIDENTIAL PROPERTY OF, AND ARE PROPRIETARY TO, WANG LABORATORIES, INC. THIS DRAWING AND THE DATA SHOWN THEREON MAY NOT BE MADE PUBLIC WITHOUT THE WRITTEN CONSENT OF WANG LABORATORIES, INC. IF FOR ANY REASON THIS DRAWING IS PERMITTED BY WANG TO LEAVE THE PHYSICAL CUSTODY OF THE COMPANY, IT IS RETURNABLE UPON THE DEMAND OF WANG LABORATORIES, INC.




THIS DRAWING AND THE DATA HEREON  
 OR ANY PART THEREOF IS THE PROPERTY OF WANG  
 LABORATORIES, INC. AND IS TO BE KEPT  
 CONFIDENTIAL. IT IS TO BE RETURNED TO  
 WANG LABORATORIES, INC. UPON THE  
 COMPLETION OF THE PROJECT FOR WHICH  
 IT WAS PREPARED. IT IS NOT TO BE  
 REPRODUCED OR TRANSMITTED IN ANY  
 FORM OR BY ANY MEANS, ELECTRONIC,  
 MECHANICAL, PHOTOCOPYING, RECORDING,  
 OR BY ANY INFORMATION STORAGE AND  
 RETRIEVAL SYSTEM, WITHOUT THE WRITTEN  
 CONSENT OF WANG LABORATORIES, INC.



- NOTES: UNLESS OTHERWISE SPECIFIED
1. ALL RESISTORS ARE 0.25 1/4W 5 PERCENT EXPRESSED IN OHMS.
  2. ALL CAPACITORS ARE .047 EXPRESSED IN MICROFARADS.
  3. SIPS ORIENTED WITH PIN 1 AT TOP

<b>(WANG)</b> LABORATORIES, INC. 220 WEST 42ND STREET NEW YORK, N.Y. 10018		BY	DATE	APPROVED BY	DATE
		CHR. J. RIGDON	2/85	E. LORR	
PARTIAL QTY. NO. 911A SEE DRAWING SPECIFICATIONS 10-11-71		TITLE ASSEMBLY DRAWING CONTENTION ACCESS BOARD M/L			
FINISH ALL SURF. TO BE FINISHED TO SPEC. 10-11-71		218-8391	<input type="checkbox"/>	8391	3




REV	DESCRIPTION	BY	DATE	APPROVED BY	DATE
1	INITIAL DESIGN	...	...	...	...
2	...	...	...	...	...
3	...	...	...	...	...
4	...	...	...	...	...
5	...	...	...	...	...
6	...	...	...	...	...
7	...	...	...	...	...
8	...	...	...	...	...
9	...	...	...	...	...
10	...	...	...	...	...
11	...	...	...	...	...
12	...	...	...	...	...
13	...	...	...	...	...
14	...	...	...	...	...
15	...	...	...	...	...
16	...	...	...	...	...
17	...	...	...	...	...
18	...	...	...	...	...
19	...	...	...	...	...
20	...	...	...	...	...
21	...	...	...	...	...
22	...	...	...	...	...
23	...	...	...	...	...
24	...	...	...	...	...
25	...	...	...	...	...
26	...	...	...	...	...
27	...	...	...	...	...
28	...	...	...	...	...
29	...	...	...	...	...
30	...	...	...	...	...
31	...	...	...	...	...
32	...	...	...	...	...
33	...	...	...	...	...
34	...	...	...	...	...
35	...	...	...	...	...
36	...	...	...	...	...
37	...	...	...	...	...
38	...	...	...	...	...
39	...	...	...	...	...
40	...	...	...	...	...
41	...	...	...	...	...
42	...	...	...	...	...
43	...	...	...	...	...
44	...	...	...	...	...
45	...	...	...	...	...
46	...	...	...	...	...
47	...	...	...	...	...
48	...	...	...	...	...
49	...	...	...	...	...
50	...	...	...	...	...
51	...	...	...	...	...
52	...	...	...	...	...
53	...	...	...	...	...
54	...	...	...	...	...
55	...	...	...	...	...
56	...	...	...	...	...
57	...	...	...	...	...
58	...	...	...	...	...
59	...	...	...	...	...
60	...	...	...	...	...
61	...	...	...	...	...
62	...	...	...	...	...
63	...	...	...	...	...
64	...	...	...	...	...
65	...	...	...	...	...
66	...	...	...	...	...
67	...	...	...	...	...
68	...	...	...	...	...
69	...	...	...	...	...
70	...	...	...	...	...
71	...	...	...	...	...
72	...	...	...	...	...
73	...	...	...	...	...
74	...	...	...	...	...
75	...	...	...	...	...
76	...	...	...	...	...
77	...	...	...	...	...
78	...	...	...	...	...
79	...	...	...	...	...
80	...	...	...	...	...
81	...	...	...	...	...
82	...	...	...	...	...
83	...	...	...	...	...
84	...	...	...	...	...
85	...	...	...	...	...
86	...	...	...	...	...
87	...	...	...	...	...
88	...	...	...	...	...
89	...	...	...	...	...
90	...	...	...	...	...
91	...	...	...	...	...
92	...	...	...	...	...
93	...	...	...	...	...
94	...	...	...	...	...
95	...	...	...	...	...
96	...	...	...	...	...
97	...	...	...	...	...
98	...	...	...	...	...
99	...	...	...	...	...
100	...	...	...	...	...

SEE CHART E 8392 4


77  
71  
11  
98  
8.5"  
11"  
17"  
22"

77  
71  
11  
98  
8.5"  
11"  
17"  
22"




NO.	DESCRIPTION	DATE	BY	DATE	BY
911A	B.L.A.N.C.				
	SEE CHART	E	8392	4	

77  
" 11  
" 58  
8.5"  
11"  
17"  
22"




" 22  
" 11  
" 58  
8.5"  
11"  
17"  
22"

NO.	REV.	DATE	APPROVED BY	DATE
911A				
B.L.A.N.C.				
SEE CHART E 8392 4				



REV	DATE	DESCRIPTION	BY	APPROVED BY	DATE
1					
2					
3					
4					
5					
6					
7					
8					
9					
10					
11					
12					
13					
14					
15					
16					
17					
18					
19					
20					
21					
22					
23					
24					
25					
26					
27					
28					
29					
30					
31					
32					
33					
34					
35					
36					
37					
38					
39					
40					
41					
42					
43					
44					
45					
46					
47					
48					
49					
50					
51					
52					
53					
54					
55					
56					
57					
58					
59					
60					
61					
62					
63					
64					
65					
66					
67					
68					
69					
70					
71					
72					
73					
74					
75					
76					
77					
78					
79					
80					
81					
82					
83					
84					
85					
86					
87					
88					
89					
90					
91					
92					
93					
94					
95					
96					
97					
98					
99					
100					





MODEL NO 911A  
 TITLE B.L.A.N.C.  
 SEE CHART E B392 4



77  
 11  
 11  
 58  
 8.5"  
 11"  
 17"  
 22"

77  
 11  
 58  
 8.5"  
 11"  
 17"  
 22"



911A	TITLE	B.L.A.N.C.
SEE CHART	E	8392 4



911A	B.L.A.N.C.	839Z	
SER CHART		839Z	








IC TYPE	LOC.	SPARES
SPARES	L62	
74LS00	L313	1
74LS21	L279	1
74LS12	L245	1
74ALS00	L31	2
74S140	L238	1
74ALS00	L179	1
74F02	L291	3
74LS02	L178	3
74ALS04	L144	1
	L157	1
74F06	L80	1
74S04	L290	4
74ALS00	L85	1
74ALS74	L270	1
74F14	L302	4
74ALS32	L254	1
	L122	2
74F12	L257	1
74ALS00	L12	1
74ALS21	L16	1
74F05	L244	3
74LS74	L162	1


MEMORICS	WORD
ACK	5E14
ASMRD	1H14
ASMRREB	1H14
BCK	CA14
BLANGBIT	1G1
BUST	5F14
CARRIER0	1G14
C1 - C2	5J14
DB0 - DB11	7J1
GRN1 - GRN3	6F1
GRN4 - GRN7	5D14
GRN8 - GRN11	5D14
MSID1 - MSID4	5G14
MSID5 - MSID8	5K14
MSID9 - MSID11	5K14
RE07	1G14
RE08 - RE09	5D14
RE10	1G14
SELECT	5G14
SPARE 21	1G1
SPARE 30	1K14
SPARE 3B	1K14
SYSTEM	7B14
TIMER	CA14
TRIO0 - TRIO7	1C14
T4CRSH	1H14
T5PCKTEND	1G1
T6PCKTEND	1H14
XALE	1I1
XION	1I1
XIONW	1I1
XION/OFF	1H1
XPBIT	1K14
XPERR	1K14
XKERR	1G14



NOTE: ALL RESISTORS ARE 1/4W 5% UNLESS SPECIFIED OTHER WISE

E-REV 2

REV	DATE	BY	CHKD
1			
2			
3			
4			
5			
6			
7			
8			
9			
10			
11			
12			
13			
14			
15			
16			
17			
18			
19			
20			
21			
22			
23			
24			
25			
26			
27			
28			
29			
30			
31			
32			
33			
34			
35			
36			
37			
38			
39			
40			
41			
42			
43			
44			
45			
46			
47			
48			
49			
50			
51			
52			
53			
54			
55			
56			
57			
58			
59			
60			
61			
62			
63			
64			
65			
66			
67			
68			
69			
70			
71			
72			
73			
74			
75			
76			
77			
78			
79			
80			
81			
82			
83			
84			
85			
86			
87			
88			
89			
90			
91			
92			
93			
94			
95			
96			
97			
98			
99			
100			



NOTES:  
 UNLESS OTHERWISE SPECIFIED  
 1. ALL CAPACITORS ARE .047 EXPRESSED IN MICROFARADS.  
 2. ALL RESISTORS ARE 1/4 WATT 5% EXPRESSED IN OHMS.  
 3. WIRED JUMPER TO BE CONNECTED FROM JPI PIN 2 TO JPI PIN 3.  
 4. USE SOCKET 376 9877 F.L.H. 11 1/2.

<b>WANG</b>		BY	DATE	APPROVED BY	DATE
		DES		E ENGR	
MODEL NO. VS300		CHK		M ENGR	
		E CONTROL		MFG ENGR	
10-213		INBOARD C:U (BLANC)			
		ASSEMBLY DRAWING			
		210-8392	C	8392	4


THIS DRAWING IS THE PROPERTY OF WANG ELECTRONIC CORPORATION. IT IS TO BE USED ONLY FOR THE PROJECT AND FOR THE PURPOSES SPECIFIED THEREIN. IT IS NOT TO BE REPRODUCED, COPIED, OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, INCLUDING PHOTOCOPYING, RECORDING, OR BY ANY INFORMATION STORAGE AND RETRIEVAL SYSTEM, WITHOUT THE WRITTEN PERMISSION OF WANG ELECTRONIC CORPORATION.

NOTES

1. ALL RESISTOR VALUES IN OHMS.
2. ALL CAPACITOR VALUES IN MICROFARADS UNLESS OTHERWISE INDICATED.
3. ALL RESISTORS 1/4W 5% UNLESS OTHERWISE INDICATED.
4. CONNECTORS SHOWN ON SHEET 15.


MNEMONICS	COORD.
ACK	12A13
ACK	12F14
BCDY	12A13
CD-CE	12K1
CDU-CDU1	7J1
GRINN-1 - GRINN-3	12I14
GRUI-GRU3	12A11
FOOD	12A12
TDD-TD4	12K1
INIT	4A14
TREROY	12A8
TU7/WEU	12F1
PTS	3C1
RUN-1 - RUN-7	12J14
ROD	12A11
RETRMRY	12A10
SPLINTY	12F1
TIMER	12F14

IC TYPE	LOCATION	SPARES
74A300	L357	2
74030	L34	3
74L300	L75	1
	L186	1
	L245	1
	L422	3
74A002	L176	2
	L244	3
	L264	3
	L358	2
74L002	L122	2
	L405	2
7403	L244	2
74A004	L56	2
	L246	2
	L273	1
	L325	4
7404	L37	5
74L004	L52	1
	L57	2
	L76	2
	L123	4
	L175	1
7406	L120	2
74A510	L189	1
	L266	1
7408	L332	2
74L508	L42	1
	L230	3
	L276	2
	L343	1
74A510	L167	1
	L278	1
	L279	2
74L510	L43	3
	L84	2
	L115	1
	L170	1
	L180	2
	L231	2
74L511	L424	1
7414	L40	2
74L520	L393	1
74A527	L117	1
74L527	L186	1
74A532	L54	1
	L77	2
	L183	1
	L277	2
74032	L126	2
74L532	L209	1
	L229	3
	L265	1
	L376	1
7430	L395	1
	L423	3
74L551	L259	1
74A374	L171	1
74L574	L402	1
	L406	1
74A586	L206	3
	L250	3
74025	L50	1
74L586	L371	1
	L404	2
SPARE3	L340	-
	L421	-




E. REV  
3 N

		SCHEMATIC DIAGRAM	
		TITLE ML TC CONTRL BD TDC VS-300	
DATE VS 300	NAME 210-8491	CHK'D BY DOR CALTA	ENGR'G. NO. DOR
SCALE 3	SHEET 1 OF 3	DATE 3	REV 3



17"  
11"  
8.5"  
8.5"  
11"  
17"

17"  
11"  
8.5"  
8.5"  
11"  
17"



17  
11  
8.5  
8.5  
11  
8.5  
11  
17

17  
11  
8.5  
8.5  
11  
8.5  
11  
17

17


11

8.5

8.5

11

17



17

11

8.5

8.5

11

17

17"

11"

8.5"

8.5"

11"

17"

17"


11"

8.5"

8.5"


11"

17"




17" 11" 8.5" 8.5" 11" 17"

17" 11" 8.5" 8.5" 11" 17"







WANG	8491	3
SCALE	DATE	REV


17"

11"  
8.5"

8.5"

11"

17"



17"

11"  
8.5"

8.5"

11"

17"

WALCO	2491	3
SCALE	DATE	DRAWING NUMBER

17"

8.5"

8.5"

11"

17"


17"

8.5"

8.5"


11"

17"



WAGO  
 E 8491 E  
 DRAWING NUMBER

14 13 12 11 10 9 8 7 6 5 4 3 2 1



WANG 8491 3  
SCALE: 1:1  
DRAFT: [unclear]  
DRAWING NUMBER: 8491  
REV: 3

17" 11" 8.5" 8.5" 11" 17"

17" 11" 8.5" 8.5" 11" 17"

17"

11"  
8.5"

8.5"

11"

17"


17"

11"  
8.5"

8.5"

11"

17"



WANG		E	8491	3
SCALE	3000	1	2	3
REV	1	2	3	4

17"


11"

8.5"

8.5"

11"

17"



17"

11"

8.5"

8.5"

11"

17"

17"

11"

8.5"

8.5"

11"

17"

17"



11"

8.5"

8.5"

11"

17"







14 13 12 11 10 9 8 7 6 5 4 3 2 1

SP1	1	2	SP2
SP3	3	4	SP4
SP5	5	6	SP6
SP7	7	8	SP8
SP9	9	10	SP10
SP11	11	12	SP12
SP13	13	14	SP14
SP15	15	16	SP16
SP17	17	18	SP18
SP19	19	20	SP20
SP21	21	22	SP22
SP23	23	24	SP24
SP25	25	26	SP26
SP27	27	28	SP28
SP29	29	30	SP30
SP31	31	32	SP32
SP33	33	34	SP34
SP35	35	36	SP36
SP37	37	38	SP38
SP39	39	40	SP40
SP41	41	42	SP42
SP43	43	44	SP44
SP45	45	46	SP46
SP47	47	48	SP48
SP49	49	50	SP50

SP51	1	2	SP52
SP53	3	4	SP54
SP55	5	6	SP56
SP57	7	8	SP58
SP59	9	10	SP60
SP61	11	12	SP62
SP63	13	14	SP64
SP65	15	16	SP66
SP67	17	18	SP68
SP69	19	20	SP70
SP71	21	22	SP72
SP73	23	24	SP74
SP75	25	26	SP76
SP77	27	28	SP78
SP79	29	30	SP80
SP81	31	32	SP82
SP83	33	34	SP84
SP85	35	36	SP86
SP87	37	38	SP88
SP89	39	40	SP90
SP91	41	42	SP92
SP93	43	44	SP94
SP95	45	46	SP96
SP97	47	48	SP98
SP99	49	50	SP100

SP101	1	2	SP102
SP103	3	4	SP104
SP105	5	6	SP106
SP107	7	8	SP108
SP109	9	10	SP110
SP111	11	12	SP112
SP113	13	14	SP114
SP115	15	16	SP116
SP117	17	18	SP118
SP119	19	20	SP120
SP121	21	22	SP122
SP123	23	24	SP124
SP125	25	26	SP126
SP127	27	28	SP128
SP129	29	30	SP130
SP131	31	32	SP132
SP133	33	34	SP134
SP135	35	36	SP136
SP137	37	38	SP138
SP139	39	40	SP140
SP141	41	42	SP142
SP143	43	44	SP144
SP145	45	46	SP146
SP147	47	48	SP148
SP149	49	50	SP150

SP151	1	2	SP152
SP153	3	4	SP154
SP155	5	6	SP156
SP157	7	8	SP158
SP159	9	10	SP160
SP161	11	12	SP162
SP163	13	14	SP164
SP165	15	16	SP166
SP167	17	18	SP168
SP169	19	20	SP170
SP171	21	22	SP172
SP173	23	24	SP174
SP175	25	26	SP176
SP177	27	28	SP178
SP179	29	30	SP180
SP181	31	32	SP182
SP183	33	34	SP184
SP185	35	36	SP186
SP187	37	38	SP188
SP189	39	40	SP190
SP191	41	42	SP192
SP193	43	44	SP194
SP195	45	46	SP196
SP197	47	48	SP198
SP199	49	50	SP200


±0V	1	2	±0V
±5V	3	4	±5V
	5	6	
	7	8	
	9	10	
TOUCHY	11	12	
	13	14	
	15	16	
	17	18	
	19	20	
	21	22	
	23	24	
±0V	25	26	±0V
±0V	27	28	±0V
±0V	29	30	±0V
±0V	31	32	±0V
±0V	33	34	±0V
±0V	35	36	±0V
±0V	37	38	±0V
±0V	39	40	±0V
±0V	41	42	±0V
±0V	43	44	±0V
±0V	45	46	±0V
±0V	47	48	±0V
±0V	49	50	±0V
±0V	51	52	±0V
±0V	53	54	±0V
±0V	55	56	±0V
±0V	57	58	±0V
±0V	59	60	±0V
±0V	61	62	±0V
±0V	63	64	±0V
±0V	65	66	±0V
±0V	67	68	±0V
±0V	69	70	±0V
±0V	71	72	±0V
±0V	73	74	±0V
±0V	75	76	±0V
±0V	77	78	±0V
±0V	79	80	±0V
±0V	81	82	±0V
±0V	83	84	±0V
±0V	85	86	±0V
±0V	87	88	±0V
±0V	89	90	±0V
±0V	91	92	±0V
±0V	93	94	±0V
±5V	95	96	±5V
±5V	97	98	±5V
±0V	99	100	±0V

±0V	1	2	±0V
±5V	3	4	±5V
	5	6	
	7	8	
	9	10	
	11	12	
	13	14	
	15	16	
	17	18	
	19	20	
	21	22	
	23	24	
	25	26	
±0V	27	28	±0V
±0V	29	30	±0V
±0V	31	32	±0V
±0V	33	34	±0V
±0V	35	36	±0V
±0V	37	38	±0V
±0V	39	40	±0V
±0V	41	42	±0V
±0V	43	44	±0V
±0V	45	46	±0V
±0V	47	48	±0V
±0V	49	50	±0V
±0V	51	52	±0V
±0V	53	54	±0V
±0V	55	56	±0V
±0V	57	58	±0V
±0V	59	60	±0V
±0V	61	62	±0V
±0V	63	64	±0V
±0V	65	66	±0V
±0V	67	68	±0V
±0V	69	70	±0V
±0V	71	72	±0V
±0V	73	74	±0V
±0V	75	76	±0V
±0V	77	78	±0V
±0V	79	80	±0V
±0V	81	82	±0V
±0V	83	84	±0V
±0V	85	86	±0V
±0V	87	88	±0V
±0V	89	90	±0V
±0V	91	92	±0V
±0V	93	94	±0V
±5V	95	96	±5V
±5V	97	98	±5V
±0V	99	100	±0V

±0V	1	2	±0V
±5V	3	4	±5V
TOU	5	6	TOU
TOU	7	8	TOU
±0V	9	10	±0V
±0V	11	12	±0V
±0V	13	14	±0V
±0V	15	16	±0V
±0V	17	18	±0V
±0V	19	20	±0V
±0V	21	22	±0V
±0V	23	24	±0V
±0V	25	26	±0V
±0V	27	28	±0V
±0V	29	30	±0V
±0V	31	32	±0V
±0V	33	34	±0V
±0V	35	36	±0V
±0V	37	38	±0V
±0V	39	40	±0V
±0V	41	42	±0V
±0V	43	44	±0V
±0V	45	46	±0V
±0V	47	48	±0V
±0V	49	50	±0V
±0V	51	52	±0V
±0V	53	54	±0V
±0V	55	56	±0V
±0V	57	58	±0V
±0V	59	60	±0V
±0V	61	62	±0V
±0V	63	64	±0V
±0V	65	66	±0V
±0V	67	68	±0V
±0V	69	70	±0V
±0V	71	72	±0V
±0V	73	74	±0V
±0V	75	76	±0V
±0V	77	78	±0V
±0V	79	80	±0V
±0V	81	82	±0V
±0V	83	84	±0V
±0V	85	86	±0V
±0V	87	88	±0V
±0V	89	90	±0V
±0V	91	92	±0V
±0V	93	94	±0V
±0V	95	96	±0V
±0V	97	98	±0V
±0V	99	100	±0V

17" 11" 8.5" 8.5" 11" 17"

17" 11" 8.5" 8.5" 11" 17"




NOTES  
 1. UNLESS OTHERWISE SPECIFIED:  
 2. ALL CAPACITORS ARE .047 EXPRESSED IN MICROFARADS.  
 3. ALL RESISTORS ARE 1/4W 5% EXPRESSED IN OHMS.  
 4. C338-C371 ARE 1/4W 5%.  
 5. LOAD 16 PIN SOCKETS WPN 376-9882-1 IN THE FOLLOWING LOCATIONS:  
 L92-L100 L125-L133 L158-L166 AND L190-L198.  
 6. LOAD 48 PIN SOCKET WPN 376-9894 IN LOCATION L242-L249.

<b>WANG</b> MODEL NO. VS 300 SEE DRAWING FOR PART NO. 10-213		BY	DATE	APPROVED BY	DATE
		DWN HSL	10-11-67	E ENGR	
FINISH SEE DRAWING FOR PART NO. 210-8491		CHK		M ENGR	
				MFS ENGR	
		TITLE MULTILINE TC ML ASSEMBLY DRAWING			
		210-8491	C	8491	3



THIS DRAWING AND THE DATA SHOWN THEREON ARE THE CONFIDENTIAL PROPERTY OF WANG LABORATORIES, INC. THIS DRAWING AND THE DATA SHOWN THEREON MAY NOT BE MADE PUBLIC WITHOUT THE WRITTEN CONSENT OF WANG LABORATORIES, INC. IF FOR ANY REASON THIS DRAWING IS PERMITTED BY WANG TO LEAVE THE PHYSICAL CUSTODY OF THE COMPANY, IT IS RETURNABLE UPON THE DEMAND OF WANG LABORATORIES, INC.




NOTES:  
UNLESS OTHERWISE SPECIFIED:  
1. ALL CAPACITORS ARE .047, EXPRESSED IN MICROFARADS.  
2. ALL RESISTORS ARE 1/4W.5%, EXPRESSED IN OHMS.




<b>WANG</b> LABORATORIES, INC. LOVELL, MASS. U.S.A.		BY	DATE	APPROVED BY	DATE
		DWN	DAL	12/05/84	E ENGR
MATERIAL		CHK		M ENGR	
		E C CONTROL		MFB ENGR	
MODEL NO. VS 300/MLTC SEE ENGR SPECIFICATIONS NO. 10-213		TITLE RS232 DRIVER/RECEIVER BD ASSEMBLY DRAWING			
FINISH		TOL. EX. AS NOTED XXX-- .010 FRAC. +/- 1/44 XXX-- .005 ANG +/- 1 30'	210-8494	C	8494 5
SCALE 1/1		SHT 1 OF 1	WANG PART NUMBER	SIZE	DRAWING NUMBER

THIS DRAWING AND THE DATA HEREON THEREON ARE THE CONFIDENTIAL PROPERTY OF WANG AND ARE LOANED TO YOU BY WANG LABORATORIES, INC. THE DRAWING AND THE DATA HEREON THEREON MAY NOT BE MADE PUBLIC WITHOUT THE WRITTEN CONSENT OF WANG LABORATORIES, INC. IF YOU ARE PLEASED TO LOAN THIS DRAWING TO ANY OTHER PERSON, YOU WILL BE RESPONSIBLE TO WANG LABORATORIES, INC. FOR THE PROTECTION OF THE CONFIDENTIALITY OF THE INFORMATION CONTAINED HEREON.

DO NOT SCALE



IC TYPE	LOCATION	SPARES
MC1488B	L2	1
MC1489A	L2	1
MC1489A	L3	2
74LS04	L5	2




E-REV  
0

REV	DATE	BY	DESCRIPTION
A	11/18/68	WJL	ORIGINAL DESIGN
B	12/10/68	WJL	REVISED FOR PCB FAB
C	1/14/69	WJL	REVISED FOR PCB FAB
D	1/14/69	WJL	REVISED FOR PCB FAB

WANG PART NO.	DRAWING NO.	DESCRIPTION	BY	DATE	APPROVED BY	DATE
VS 300		DRIVER/RECEIVER BOARD	WJL	11/18/68		
MATERIAL		MODEL NO	TITLE			
		VS 300	DRIVER/RECEIVER BOARD			
FINISH		REV. OR AS NOTED	2/8-895	D	895	


"THIS DRAWING AND THE DATA SHOWN THEREON ARE THE CONFIDENTIAL PROPERTY OF, AND ARE PROPRIETARY TO, WANG LABORATORIES, INC. THIS DRAWING AND THE DATA SHOWN THEREON MAY NOT BE MADE PUBLIC WITHOUT THE WRITTEN CONSENT OF WANG LABORATORIES, INC. IF FOR ANY REASON THIS DRAWING IS PERMITTED BY WANG TO LEAVE THE PHYSICAL CUSTODY OF THE COMPANY, IT IS RETURNABLE UPON THE DEMAND OF WANG LABORATORIES, INC."



NOTES:  
1. UNLESS OTHERWISE SPECIFIED,  
ALL CAPACITORS ARE .047, EXPRESSED IN MICROFARADS.

NO.	REV	BY	DATE	CHK	DATE
	1	BVC	1/22/84	DF	08
	2	HRH	3/22/84	DB	08
	3	FVZ	3/14/85	DB	08

<b>WANG</b> LABORATORIES, INC. LOVELL, MASS., U.S.A.		BY	DATE	APPROVED BY	DATE
MATERIAL		DWN GWC	1/28/84	E ENGR	
MODEL NO. VS 300		CHK		M ENGR	
SEE ENGR SPECIFICATIONS NO. 10-213		E C CONTROL		MFB ENGR	
FINISH		TITLE RS366 DRIVER/RECEIVER BD. ASSEMBLY DRAWING			
TOL. EX. AS NOTED XXX+/- .010 FRAC. +/- 1/64" XXX+/- .005 ANG +/- 1.50°		210-8495	C	8495	0
SCALE 1/1	SHT 1 OF 1	WANG PART NUMBER	SIZE	DRAWING NUMBER	REV




Q	APP'D	DATE	BY	CHK'D	DATE
0	ORIGINATED PER				
1	DWR #E2669				
1	REVIS'D PER				
2	ECO #35989 3/4/76				
2	REVIS'D PER				
3	ECO #36200				
3	REVIS'D PER				
4	ECO #36200				
4	REVIS'D PER				
5	ECO #36200				

NOTES:  
 1. UNLESS OTHERWISE SPECIFIED ALL CAPACITORS ARE .047µF  
 ALL RESISTORS ARE 1/4W, 5%.  
 2. LOAD 376-9011 40 PIN SOCKET IN L11-L14.

E REV 2			
WANG			
SERIAL COMMUNICATION LINK MULTILINE BD			
0	1/28/85	21φ-8496	REV 3
AAF2898	SHEET 1 OF 2		

THIS DRAWING AND THE DATA SHOWN THEREON ARE THE CONFIDENTIAL PROPERTY OF, AND ARE PROPRIETARY TO, WANG LABORATORIES, INC. THIS DRAWING AND THE DATA SHOWN THEREON MAY NOT BE MADE PUBLIC WITHOUT THE WRITTEN CONSENT OF WANG LABORATORIES, INC. IF FOR ANY REASON THIS DRAWING IS PERMITTED BY WANG TO LEAVE THE PHYSICAL CUSTODY OF THE COMPANY, IT IS RETURNABLE FOR THE DEMAND OF WANG LABORATORIES, INC.






NOTES:  
 UNLESS OTHERWISE SPECIFIED,  
 1. ALL CAPACITORS ARE .047, EXPRESSED IN MICROFARADS.  
 2. ALL RESISTORS ARE 1/4W, 5%, EXPRESSED IN OHMS.

		BY	DATE	APPROVED BY	DATE
		OWN	ANTAL	4/12/85	E ENGR
MATERIAL _____ MODEL NO. VS300 SEE ENGR SPECIFICATIONS NO. 10-213 FINISH _____ TOL. EX. AS NOTED .001/- .010 FRAC. +/- 1/40 .002/- .005 AND +/- 1/30 SCALE 1/1 SH1 OF 1		CHK		M ENGR	
		TITLE SERIAL COMM ML ASSEMBLY DRAWING		E C CONTROL	MFB ENGR
		210-8496	C	8496	3
		WANG PART NUMBER	SIZE	DRAWING NUMBER	REV



THIS DRAWING AND THE DATA SHOWN THEREON ARE THE CONFIDENTIAL PROPERTY OF AND ARE PROPRIETARY TO WANG LABORATORIES, INC. THE DRAWING AND THE DATA SHOWN THEREON MAY NOT BE MADE PUBLIC WITHOUT THE WRITTEN CONSENT OF WANG LABORATORIES, INC. IF FOR ANY REASON THIS DRAWING IS PERMITTED BY WANG TO LEAVE THE PHYSICAL CUSTODY OF THE COMPANY, IT IS RETURNABLE UPON THE DEMAND OF WANG LABORATORIES, INC.

DO NOT SCALE



E-REV


1

<b>WANG</b> WANG LABORATORIES, INC. LOWELL, MA U.S.A.		BY DWN C.A.M.	DATE 2-10-64	APPROVED BY E ENGR	DATE 2-10-64
MATERIAL	MODEL NO. 15-500	TITLE BLOCK CONNECTOR			
FINISH		210-8497	D	8497	2
SCALE		DATE	SIZE	DRAWING NUMBER	REV

D 8497

REV	DATE	BY	DESCRIPTION
1			

THIS DRAWING AND THE DATA SHOWN THEREON ARE THE CONFIDENTIAL PROPERTY OF WANG AND ARE PROPRIETARY TO WANG LABORATORIES, INC. THIS DRAWING AND THE DATA SHOWN THEREON MAY NOT BE MADE PUBLIC WITHOUT THE WRITTEN CONSENT OF WANG LABORATORIES, INC. IF FOR ANY REASON THIS DRAWING IS PERMITTED BY WANG TO LEAVE THE PHYSICAL CUSTODY OF THE COMPANY, IT IS RETURNABLE UPON THE DEMAND OF WANG LABORATORIES, INC.



NOTES: 1. MAX. LEAD PROTRUSION ON CIRCUIT SIDE .005.

<b>WANG</b> LABORATORIES, INC. LOVELL, MASS., U.S.A.		BY	DATE	APPROVED BY	DATE
		DVN DAL	11/02/64	E ENGR	
MATERIAL _____ MODEL NO. VS-300 SEE ENGR SPECIFICATIONS NO. 10-203		CHK JDL	11/09/64	H ENGR	
		E C CONTROL		MFG ENGR	
FINISH _____ TOL. EX. AS NOTED .XX+/- .010 FRACTION/1/64 .XXX+/- .005 ANG 1/2 1/32		TITLE BLOCK CONNECTOR ASSEMBLY DRAWING			
		210-8497	C	8497	2
SCALE 1/1 SH1 OF 1		WANG PART NUMBER	SIZE	DRAWING NUMBER	REV

17"  
11"  
8.5"  
8.5"  
8.5"  
17"

17"  
11"  
8.5"  
8.5"  
8.5"  
17"

7 6 5 4 3 2 1



7 6 5 4 3 2 1

E  
D  
C  
B  
A


E  
D  
C  
B  
A

11 10 9 8 7 6 5 4 3 2 1

THIS DRAWING AND THE DATA SHOWN THEREON ARE THE CONFIDENTIAL PROPERTY OF AND INFORMATION TO WANG LABORATORIES, INC. THE COMPANY AND THE DATA SHOWN THEREON MAY NOT BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, INCLUDING PHOTOCOPYING, RECORDING, OR BY ANY INFORMATION STORAGE AND RETRIEVAL SYSTEM, WITHOUT THE WRITTEN PERMISSION OF WANG LABORATORIES, INC. IF YOU ARE A CUSTOMER OF WANG LABORATORIES, YOU MAY BE PERMITTED BY WANG TO HAVE THE PHYSICAL COPIES OF THIS DRAWING FOR YOUR OWN USE ONLY. THESE COPIES ARE TO BE RETURNED TO WANG LABORATORIES, INC. UPON THE DEMAND OF WANG LABORATORIES, INC.



COMPONENT	TYPE	W.L. PT. NO.
R1-5	100Ω 1/4W 5%	350-2011
R6	180Ω 1/4W 5%	350-2019
J1	34 PIN CONN	350-0494




REV	DATE	BY	DESCRIPTION
1	11/20/77	...	...
2	1/10/78	...	...
3	1/10/78	...	...

E-REV  NOTE ALL RES. ARE 1/4W 5% UNLESS OTHERWISE SPECIFIED.

WANG PART NO.	DRAWING NO.	DESCRIPTION	BY	DATE	APPROVED BY	DATE
<b>WANG</b>	WANG LABORATORIES, INC. LOWELL, MASS.		...	11/20/77	...	...
MATERIAL	MODEL NO. P191A SILB MC	TITLE MUX BUS TERMINATOR BD	...	...	...	...
FINISH	TOL. EX. AS NOTED SEE DIM. SPEC. FOR TYPICAL SCALE 1/8" = 1"	210-8503	D	8503	1	

22" 11 10 9 8 7 6 5 4 3 2 1

"THIS DRAWING AND THE DATA SHOWN THEREON ARE THE CONFIDENTIAL PROPERTY OF WANG LABORATORIES, INC. THIS DRAWING AND THE DATA SHOWN THEREON MAY NOT BE MADE PUBLIC WITHOUT THE WRITTEN CONSENT OF WANG LABORATORIES, INC. IF FOR ANY REASON THIS DRAWING IS PERMITTED BY WANG TO LEAVE THE PHYSICAL CUSTODY OF THE COMPANY, IT IS RETURNABLE UPON THE DEMAND OF WANG LABORATORIES, INC."




NOTES:  
1. UNLESS OTHERWISE SPECIFIED,  
ALL RESISTORS ARE 1/4W, 5%, EXPRESSED IN OHMS.

BY	H.M.	BAH
OWN H.H.	11/01/62	8-24-63
CHK J.L.L.		
REVISION	DWR#E1812	ECO#29866
NO.	B / G	B / -

WANG LABORATORIES, INC. LOWELL, MASS. U.S.A.		BY	DATE	APPROVED BY	DATE
MATERIAL		OWN H.H.	11/01/62	E ENGR	
		CHK J.L.L.	11/02/62	M ENGR	
MODEL NO. P191A 920 MC		E C CONTROL		MFG ENGR	
SEE ENGR SPECIFICATIONS NO. 10-203		TITLE MUX BUS. TERMINATOR BOARD ASSEMBLY DRAWING			
FINISH		210-8503-R0	C	8503	1
TOL. EX. AS NOTED ...010 FRACTION 1/64 ...005 AND 1/32		VANG PART NUMBER		SIZE	DRAWING NUMBER
SCALE 1/1 SHY 4 OF 6					REV

THIS DRAWING AND THE DATA SHOWN THERE  
 ARE THE CONFIDENTIAL PROPERTY OF WANG  
 LABORATORIES, INC. AND ARE TO BE KEPT  
 SECRET. ANY DISCLOSURE OF THE DATA  
 HEREON TO ANY OTHER PERSON WITHOUT  
 THE WRITTEN CONSENT OF WANG LABORATORIES,  
 INC. IS PROHIBITED. THE COMPANY IS NOT  
 RESPONSIBLE FOR THE REPRODUCTION OF  
 THIS DRAWING OR THE DATA SHOWN THERE  
 BY ANY OTHER PERSON.



WANG PART NO	DRAWING NO	DESCRIPTION	BY	DATE	APPROVED BY	DATE
			OWN		ENGINEER	
			CHK		ENGINEER	
					WFG ENGR	
MATERIAL	MODEL NO P131A					
	22510					
	SEE ENGR SPECIFICATIONS					
FINISH		TITLE				
		SE 3P MULTIPLEX XEVR RD				
		SCALE	1:1			
		DATE	10-1-64			
		REV	1			

THIS DRAWING AND THE DATA SHOWN THEREON ARE THE CONFIDENTIAL PROPERTY OF WANG LABORATORIES, INC. AND WILL BE KEPT AS SUCH. THE WRITER HEREBY AGREES TO HOLD THE WRITER CURRENT AND THE JOB A-10000 IN THE EVENT OF ANY REVISIONS TO THIS DRAWING. THE WRITER HEREBY AGREES TO HOLD THE WRITER CURRENT AND THE JOB A-10000 IN THE EVENT OF ANY REVISIONS TO THIS DRAWING. THE WRITER HEREBY AGREES TO HOLD THE WRITER CURRENT AND THE JOB A-10000 IN THE EVENT OF ANY REVISIONS TO THIS DRAWING.





IC LOCAT ON	TYPE	W.L. PART NO.
L1,2,3,4	75107	376-0486
L3,8,9,11,15	HC3497	376-0877
L4,17	74LS32	376-0211
L5,16	74LS02	376-0208
L6,18	AM26LS32	376-0471
L7	74LS151	376-0214
L10	74LS138	376-0274
L12	74LS04	376-0180

COMPONENT	TYPE	W.L. PART NO.
R1-4,6	1K 1/4W 5% 330	330-3011
R5	150Ω 1/4W 5% 330	330-2016
C1-6,9-19	.047μF 50V	300-1366
C7,8	150μF 20V(T)	300-4022
J1,2	34 POS COLUMN	350-0453
J3,4	3 POS HEADER	350-0217
J5	40 PIN SKT	376-9065

IC TYPE	LOC	SPARES
74LS04	L12	5

MNEMONICS	COORD.
+LPN0	1B11
-LPN0	1B11
+LPN1	1B11
-LPN1	1B11
+LPN2	1A11
-LPN2	1A11
BNC0X	1G1
BNC0Y	1F11
BNC1X	1F1
BNC1Y	1G11
BNC2X	1E1
BNC2Y	1E11
BNC3X	1C1
BNC3Y	1F11
BNC4X	1F1
BNC4Y	1D11
BNC5X	1E1
BNC5Y	1E11
BNC6X	1D1
BNC6Y	1C11
BNC7X	1C1
BNC7Y	1D11
+DTX	1B11
-DTX	1B11
+MCDATA	1C11
-MCDATA	1C11
+CHS0	1A11
-CHS0	1B11
+CHS1	2C11
-CHS1	2C11
+CHS2	2C11
-CHS2	2C11

MNEMONICS	COORD.
-CHS2	2C11
+CHS3	2C11
-CHS3	2C11
+CHS4	2B11
-CHS4	2B11
+CHS5	2B11
-CHS5	2B11
+CHS6	2B11
-CHS6	2B11
+CHS7	2B11
-CHS7	2B11
+SDATA	1A7
-SDATA	1A7
TNC0X	1G1
TNC0Y	1F11
TNC1X	1F1
TNC1Y	1G11
TNC2X	1D1
TNC2Y	1E11
TNC3X	1C1
TNC3Y	1F11
TNC4X	1F1
TNC4Y	1D11
TNC5X	1E1
TNC5Y	1E11
TNC6X	1D1
TNC6Y	1C11
TNC7X	1B1
TNC7Y	1D11




NOTES:  
1. ALL RESISTORS ARE 1/4W 5% UNLESS OTHERWISE SPECIFIED.

NO.	REVISION	DATE	BY	DESCRIPTION
1	ORIGINATED PER	11-20-82	W.L.	ISS
2	REVISOR PER	11-20-82	W.L.	ISS
3	REVISOR PER	11-20-82	W.L.	ISS

WANG PART NO.	DRAWING NO.	DISPOSITION	BY	DATE	APPROVED BY	DATE
			DOWN	11-20-82	W.L.	11-20-82
<b>WANG</b>		WANG LABORATORIES, INC.				
MATERIAL		MODEL NO. P-31A	TITLE		SE 5P MULTIPLEX ACQ	
FINISH		SCALE		210-3004		2

THIS DRAWING AND THE DATA SHOWN THEREON ARE THE CONFIDENTIAL PROPERTY OF, AND ARE PROPRIETARY TO, WANG LABORATORIES, INC. THIS DRAWING AND THE DATA SHOWN THEREON MAY NOT BE MADE PUBLIC WITHOUT THE WRITTEN CONSENT OF WANG LABORATORIES, INC. IF FOR ANY REASON THIS DRAWING IS PERMITTED BY WANG TO LEAVE THE PHYSICAL POSSESSION OF THE COMPANY, IT IS RETURNABLE UPON THE DEMAND OF WANG LABORATORIES, INC.





NOTES:  
 1. UNLESS OTHERWISE SPECIFIED:  
 ALL CAPACITORS ARE .047UF, 300-1966.  
 ALL RESISTORS ARE 1K, 1/4W, 5%, EXPRESSED IN OHMS.

REV.	BY	DATE	CHK.	DATE
0	DWR#E1781	8/28/82	ECO#29339D	8/23/83
1			ECO#29867D	

		BY	DATE	APPROVED BY	DATE
		DWN L.L.	11/82	E ENGR R.L.	82
MATERIAL		CHK	E C CONTROL		MFG ENGR
MODEL NO. 928MC P191A		TITLE SE 8P MULTIPLEX XCVR BOARD ASSEMBLY DRAWING			
FINISH		210-8504-R1		C	8504 2
SCALE 1/1		SHEET 4 OF 6		WANG PART NUMBER	SIZE

THIS DRAWING AND THE DATA SHOWN THEREON ARE THE CONFIDENTIAL PROPERTY OF WANG LABORATORIES, INC. THIS DRAWING AND THE DATA SHOWN THEREON MAY NOT BE MADE PUBLIC WITHOUT THE WRITTEN CONSENT OF WANG LABORATORIES, INC. IF FOR ANY REASON THE DRAWING IS PERMITTED BY WANG TO LEAVE THE PHYSICAL CUSTODY OF THE COMPANY IT IS RETURNABLE UPON THE DEMAND OF WANG LABORATORIES, INC.

DO NOT SCALE



77  
11  
10  
9  
8  
7  
5  
4  
3  
2  
1  
11  
11  
8.5  
8.5  
11  
17  
22

22  
11  
11  
8.5  
8.5  
11  
17  
22

REVISION	




<b>WANG</b> LABORATORIES, INC. LITTLE ROCK, ARK. U.S.A.		BY	DATE	APPROVED BY	DATE
MATERIAL	ROBIL NO. P1914 920 MC	DWR	2/1/61	E ENGR	
FRESH	100 1000 SPECIFICATIONS	CNE		NO ENGR	
	TITLE			IMP. ENGR	
	210-8509				
	D 8509				
	2				



THIS DRAWING AND THE DATA THEREON ARE THE CONFIDENTIAL PROPERTY OF AND ARE SUPPLIED TO WANG LABORATORIES, INC. THE DRAWING AND THE DATA THEREON MAY NOT BE MADE PUBLIC WITHOUT THE WRITTEN CONSENT OF WANG LABORATORIES, INC. IF FOR ANY REASON THIS DRAWING IS PERMITTED BY WANG TO LEAVE THE PHYSICAL CUSTODY OF THE COMPANY, IT IS RETURNABLE UPON THE DEMAND OF WANG LABORATORIES, INC.

COMPONENT	TYPE	W.L. PART NO.
R1, 5, 9, 13, 17, 21, 25, 29	9 $\Omega$ , 1/4W, 5%	330-1092
R2, 6, 10, 14, 18, 22, 26, 30	390 $\Omega$ , 1/4W, 5%	330-2040
R3, 7, 11, 15, 19, 23, 27, 31	100 $\Omega$ , 1/4W, 5%	330-2011
R4, 8, 12, 16, 20, 24, 28, 32	270 $\Omega$ , 1/4W, 5%	330-2028
J1	CONN., 40 PIN	376-9065

MNEMONIC	COORD
BNC0x	1G10
BNC0y	1G10
BNC1x	1F10
BNC1y	1F10
BNC2x	1E10
BNC2y	1E10
BNC3x	1E10
BNC3y	1E10
BNC4x	1D10
BNC4y	1D10
BNC5x	1C10
BNC5y	1C10
BNC6x	1C10
BNC6y	1C10
BNC7x	1B10
BNC7y	1B10
TNC0x	1G6
TNC0y	1G6
TNC1x	1F6
TNC1y	1F6
TNC2x	1E6
TNC2y	1E6
TNC3x	1E6
TNC3y	1E6
TNC4x	1D6
TNC4y	1D6
TNC5x	1C6
TNC5y	1C6
TNC6x	1C6
TNC6y	1C6
TNC7x	1B6
TNC7y	1B6




NOTE:  
1 ALL RESISTORS ARE 1/4W 5% UNLESS OTHERWISE SPECIFIED

E-REV  
0


<b>WANG</b> LABORATORIES, INC. MODEL NO. 92BMC		BY DWE	DATE 11/22	APPROVED BY [Signature]	DATE 11/22
MATERIAL	MODEL NO. P191A 92BMC	TITLE SE B PORT APA TERM			
FINISH	REV. 10 AS NOTED REV. 2 - 11/22	8509	D	8509	2

"THIS DRAWING AND THE DATA SHOWN THEREON ARE THE CONFIDENTIAL PROPERTY OF, AND ARE PROPRIETARY TO, WANG LABORATORIES, INC. THIS DRAWING AND THE DATA SHOWN THEREON MAY NOT BE MADE PUBLIC WITHOUT THE WRITTEN CONSENT OF WANG LABORATORIES, INC. IF FOR ANY REASON THIS DRAWING IS PERMITTED BY WANG TO LEAVE THE PHYSICAL CUSTODY OF THE COMPANY, IT IS RETURNABLE UPON THE DEMAND OF WANG LABORATORIES, INC."



NOTE: UNLESS OTHERWISE SPECIFIED,  
1. ALL RESISTORS ARE 1/4W, 5%, EXPRESSED IN OHMS.

<b>WANG</b> LABORATORIES, INC. LOVELL, MASS., U.S.A.		BY	DATE	APPROVED BY	DATE
		DWN M.T.	10/92	E ENGR	
MATERIAL _____ MODEL NO. 928MC PH0217C SEE ENGR SPECIFICATIONS NO. 10-203		CHK		M ENGR	
		E C CONTROL		MFG ENGR	
FINISH _____ TOL. EX. AS NOTED .0005" .010" FRACTIONAL .0005" .005" AND .001" 30		TITLE SE 0 PORT APA TERM ASSEMBLY DRAWING			
		210-8509	C	8509	4
SCALE 1/1	SHT. OF	WANG PART NUMBER	SIZE	DRAWING NUMBER	REV



THIS DRAWING AND THE DATA SHOWN THEREON ARE THE CONFIDENTIAL PROPERTY OF WANG LABORATORIES, INC. THE DRAWING AND THE DATA SHOWN THEREON MAY NOT BE MADE PUBLIC WITHOUT THE WRITTEN CONSENT OF WANG LABORATORIES, INC. IF FOR ANY REASON THIS DRAWING IS PERMITTED BY WANG TO LEAVE THE PHYSICAL CUSTODY OF THE COMPANY, IT IS TO REMAIN THE PROPERTY OF WANG LABORATORIES, INC.



REVISION

NO.	DATE	DESCRIPTION
1	11-11-68	INITIAL DESIGN
2	11-11-68	REVISION

NOTE: 1. ALL RESISTORS ARE 1/4W 5% UNLESS SPECIFIED OTHERWISE

WANG PART NO.	DRAWING NO.	DESCRIPTION	BY	DATE	APPROVED BY	DATE
			DWH	11/11/68	E ENGR	
			CHW	11/11/68	M ENGR	
					MFG ENGR	
MATERIAL	MODEL NO.	TITLE				
	MONITOR	LOW COST 12" MONITOR				
	SEE ENGR SPECIFICATIONS					
FINISH	TOL. EX. AS NOTED	210-8514	D	8514	7	
	SEE ENGR SPECIFICATIONS					
	SCALE: 1" = 1" 1/2"	WANG PART NUMBER	VIEW	DRAWING NUMBER	REV	


"THIS DRAWING AND THE DATA SHOWN THEREON ARE THE CONFIDENTIAL PROPERTY OF, AND ARE PROPRIETARY TO, WANG LABORATORIES, INC. THIS DRAWING AND THE DATA SHOWN THEREON MAY NOT BE MADE PUBLIC WITHOUT THE WRITTEN CONSENT OF WANG LABORATORIES, INC. IF FOR ANY REASON THIS DRAWING IS PERMITTED BY WANG TO LEAVE THE PHYSICAL CUSTODY OF THE COMPANY, IT IS RETURNABLE UPON THE DEMAND OF WANG LABORATORIES, INC."



NOTES:  
 1. UNLESS OTHERWISE SPECIFIED, ALL CAPACITORS ARE EXPRESSED IN MICROFARADS. ALL RESISTORS ARE 1/4W 5% EXPRESSED IN OHMS. ALL TRANSISTORS ARE 2N3785.  
 2. INSTALL HEAT SINK 370-1886 AT L3.  
 3. E2, E3, E12 ARE WPM 418-1818-1 (APLCS). E1, E7, E11 ARE WPM 418-1817-1 (APLCS).  
 4. INSTALL FERRITE BEAD (418-1823) TO E13, AT JP4 AND E14, IS AT SP2.

J2.2 R350 J2.1  
 J2.4 R350 J2.3


<b>WANG</b> LABORATORIES INC. LOWELL, MASS. U.S.A.		BY	DATE	APPROVED BY	DATE
		DWM TCP	12/18/64	E ENGR	
MATERIAL _____ MODEL NO. <b>MONITOR</b> SEE ENGR SPECIFICATIONS NO. <b>10-203</b>		CHK		ENGR	
		E C CONTROL		MFG ENGR	
FINISH _____ TOL. EX. AS NOTED .0005" .010 FRACTION 1/64" .0005" .005 ONE 1/32" SCALE 1/1 SH1 OF 1		TITLE <b>LOW COST 12" MONITOR ASSEMBLY DRAWING</b>			
		210-8514	C	8514	6
SHEET NUMBER		SIZE	DRAWING NUMBER		REV



NO.	DESCRIPTION	REV.	DATE	BY
1	INITIAL			
2	REVISED			
3	REVISED			
4	REVISED			
5	REVISED			
6	REVISED			
7	REVISED			
8	REVISED			
9	REVISED			
10	REVISED			
11	REVISED			
12	REVISED			
13	REVISED			
14	REVISED			
15	REVISED			
16	REVISED			
17	REVISED			
18	REVISED			
19	REVISED			
20	REVISED			
21	REVISED			
22	REVISED			
23	REVISED			
24	REVISED			
25	REVISED			
26	REVISED			
27	REVISED			
28	REVISED			
29	REVISED			
30	REVISED			
31	REVISED			
32	REVISED			
33	REVISED			
34	REVISED			
35	REVISED			
36	REVISED			
37	REVISED			
38	REVISED			
39	REVISED			
40	REVISED			
41	REVISED			
42	REVISED			
43	REVISED			
44	REVISED			
45	REVISED			
46	REVISED			
47	REVISED			
48	REVISED			
49	REVISED			
50	REVISED			
51	REVISED			
52	REVISED			
53	REVISED			
54	REVISED			
55	REVISED			
56	REVISED			
57	REVISED			
58	REVISED			
59	REVISED			
60	REVISED			
61	REVISED			
62	REVISED			
63	REVISED			
64	REVISED			
65	REVISED			
66	REVISED			
67	REVISED			
68	REVISED			
69	REVISED			
70	REVISED			
71	REVISED			
72	REVISED			
73	REVISED			
74	REVISED			
75	REVISED			
76	REVISED			
77	REVISED			
78	REVISED			
79	REVISED			
80	REVISED			
81	REVISED			
82	REVISED			
83	REVISED			
84	REVISED			
85	REVISED			
86	REVISED			
87	REVISED			
88	REVISED			
89	REVISED			
90	REVISED			
91	REVISED			
92	REVISED			
93	REVISED			
94	REVISED			
95	REVISED			
96	REVISED			
97	REVISED			
98	REVISED			
99	REVISED			
100	REVISED			

SIO SVC CTRL W/L

2K-8504 E 8609 7




\* THESE DISPLAYS (7431'S) ARE USED FOR DIAGNOSTIC PURPOSES ONLY. THEY WILL NOT BE LOADED.

DESIGNED BY	REVISION NO.	REVISION DATE	APPROVED BY	DATE
W. J. B. / J. L. B.	1			
W. J. B. / J. L. B.	2			
W. J. B. / J. L. B.	3			
W. J. B. / J. L. B.	4			
W. J. B. / J. L. B.	5			
W. J. B. / J. L. B.	6			
W. J. B. / J. L. B.	7			
W. J. B. / J. L. B.	8			
W. J. B. / J. L. B.	9			
W. J. B. / J. L. B.	10			
W. J. B. / J. L. B.	11			
W. J. B. / J. L. B.	12			
W. J. B. / J. L. B.	13			
W. J. B. / J. L. B.	14			
W. J. B. / J. L. B.	15			
W. J. B. / J. L. B.	16			
W. J. B. / J. L. B.	17			
W. J. B. / J. L. B.	18			
W. J. B. / J. L. B.	19			
W. J. B. / J. L. B.	20			


77  
17  
11  
58  
8.5  
11  
17  
22  
34

77  
17  
11  
58  
8.5  
11  
17  
22  
34



NO.	REV.	DATE	BY	CHKD.	APPROVED BY
1					
2					
3					
4					
5					
6					
7					
8					
9					
10					
11					
12					
13					
14					
15					
16					
17					
18					
19					
20					
21					
22					
23					
24					
25					
26					
27					
28					
29					
30					
31					
32					
33					
34					
35					
36					
37					
38					
39					
40					
41					
42					
43					
44					
45					
46					
47					
48					
49					
50					
51					
52					
53					
54					
55					
56					
57					
58					
59					
60					
61					
62					
63					
64					
65					
66					
67					
68					
69					
70					
71					
72					
73					
74					
75					
76					
77					
78					
79					
80					
81					
82					
83					
84					
85					
86					
87					
88					
89					
90					
91					
92					
93					
94					
95					
96					
97					
98					
99					
100					


SIO DVC CNTRL M/L  
210-8609 E 8609




NO.	DATE	APPROVED BY	DATE
1			
2			
3			
4			
5			
6			
7			
8			
9			
10			
11			
12			
13			
14			
15			
16			
17			
18			
19			
20			
21			
22			
23			
24			
25			
26			
27			
28			
29			
30			
31			
32			
33			
34			
35			
36			
37			
38			
39			
40			
41			
42			
43			
44			
45			
46			
47			
48			
49			
50			
51			
52			
53			
54			
55			
56			
57			
58			
59			
60			
61			
62			
63			
64			
65			
66			
67			
68			
69			
70			
71			
72			
73			
74			
75			
76			
77			
78			
79			
80			
81			
82			
83			
84			
85			
86			
87			
88			
89			
90			
91			
92			
93			
94			
95			
96			
97			
98			
99			
100			

V5300  
SIO DVC CNTRL M/L  
8609 7







<b>WANG</b>		DATE	APPROVED BY	DATE
REV. NO.	REV. DATE	REV. BY	REV. DATE	REV. BY
1				
TITLE		210-8009 E 8609 7		
PROJECT NO.		SIQ DVC CNTRL M/L		
DRAWN BY		J. J. JONES		
CHECKED BY		J. J. JONES		
APPROVED BY		J. J. JONES		
DATE		12/16/64		



14 13 12 11 10 9 8 7 6 5 4 3 2 1

74LS00 74LS02 74LS04 74LS08 74LS09 74LS10 74LS12 74LS13 74LS14 74LS15 74LS16 74LS17 74LS18 74LS19 74LS20 74LS21 74LS22 74LS23 74LS24 74LS25 74LS26 74LS27 74LS28 74LS29 74LS30 74LS31 74LS32 74LS33 74LS34 74LS35 74LS36 74LS37 74LS38 74LS39 74LS40 74LS41 74LS42 74LS43 74LS44 74LS45 74LS46 74LS47 74LS48 74LS49 74LS50 74LS51 74LS52 74LS53 74LS54 74LS55 74LS56 74LS57 74LS58 74LS59 74LS60 74LS61 74LS62 74LS63 74LS64 74LS65 74LS66 74LS67 74LS68 74LS69 74LS70 74LS71 74LS72 74LS73 74LS74 74LS75 74LS76 74LS77 74LS78 74LS79 74LS80 74LS81 74LS82 74LS83 74LS84 74LS85 74LS86 74LS87 74LS88 74LS89 74LS90 74LS91 74LS92 74LS93 74LS94 74LS95 74LS96 74LS97 74LS98 74LS99 74LS100

LINE	LOC	QTY	SYMBOL	DESCRIPTION	REF
74LS00	L43	3	ACK	3A11	
74LS02	L233	1	APD-AD2	6E1	
74LS02	L23	1	AD2-AD2	6D1	
74LS02	L34	2	ACK	3D11	
74LS04	L291	1	BU5Y	3A11	
74LS04	L225	1	ACK	3D11	
74LS04	L291	1	ACK	3D11	
74LS04	L23	1	ACK	3D11	
74LS04	L23	1	ACK	3D11	
74LS04	L23	1	ACK	3D11	
74LS04	L23	1	ACK	3D11	
74LS08	L249	1	ACK	3D11	
74LS08	L10	2	ACK	3D11	
74LS08	L46	3	ACK	3D11	
74LS08	L23	2	ACK	3D11	
74LS10	L157	2	ACK	3D11	
74LS12	L191	1	ACK	3D11	
74LS12	L22	2	ACK	3D11	
74LS12	L181	2	ACK	3D11	
74LS12	L23	2	ACK	3D11	
74LS12	L255	3	ACK	3D11	
74LS13	L96	1	ACK	3D11	
74LS15	L175	1	ACK	3D11	
74LS15	L202	1	ACK	3D11	
74LS17	L9	1	ACK	3D11	
74LS17	L9	1	ACK	3D11	
74LS17	L49	1	ACK	3D11	
74LS17	L146	1	ACK	3D11	
74LS17	L224	1	ACK	3D11	
74LS17	L320	1	ACK	3D11	
74LS17	L94	1	ACK	3D11	
74LS17	L29	1	ACK	3D11	
74LS17	L218	2	ACK	3D11	



DATE	BY	REV	APP'D BY	DATE
10/10/77	W. J. ...	1	...	...
DESCRIPTION		SIO DVC CNTRL M/L		
PART NO.		210-0607		
REV		E 8609 7		


NOTE: ALL RES ARE 1/4W P 5% UNLESS OTHERWISE SPECIFIED

8.5" 11" 17" 22"

8.5" 11" 17" 22"

11 10 9 8 7 6 5 4 3 2 1

DO NOT SCALE



WANG		MODEL NO	V9388	DATE	5/85	DESIGNED BY	DCN
MATERIAL		SEE ENGR SPECIFICATIONS	NO 18-213	TITLE		ASSEMBLY DRAWING 910 DVC CNTRL M/L	
FINISH		SEE ENGR SPECIFICATIONS		218-8689	D	8609	8
SCALE		1" = 1"		DATE	5/85	BY	DCN

- NOTES: UNLESS OTHERWISE SPECIFIED
- 1 ALL CAPACITORS ARE .047, EXPRESSED IN MICROFARADS
  - 2 ALL RESISTORS ARE 1K, 1/4W, 5 PERCENT, EXPRESSED IN OHMS
  - 3 L127, L168 LOAD 14 PIN SOCKETS WPN 376-9801  
L232, L233 LOAD 28 PIN SOCKETS WPN 376-9815  
L244 LOAD 48 PIN SOCKET WPN 376-9811
  - 4 ALL JUMPERS ARE 24GA
  - 5 USE TENNA PROS WPN 376-9888 UNDER Y1, Y2 AND Y3

77  
17  
11  
8.5  
8.5  
11  
17  
22

22  
17  
11  
8.5  
8.5  
11  
17  
22

77  
 22  
 17  
 11  
 8.5  
 8.5  
 11  
 17  
 22

8 7 6 5 4 3 2 1

D  
 C  
 B  
 A

US-300 MEMORY MODULE INDEX

PAGE	CONTENTS
1.	ADDRESS MULTIPLEXERS AND CONTROLS
2.	RAS/CAS ENABLES AND TIMING CONTROLS JUMPER CONFIGURATION CHART
3.	DATA-IN LATCHES
4.	DATA-OUT LATCHES
5.	DATA-OUT MEMORY BUS DRIVERS
6.	32-BIT WORD ARRAY 0
7.	32-BIT WORD ARRAY 1
8.	32-BIT WORD ARRAY 2
9.	32-BIT WORD ARRAY 3
10.	32-BIT WORD ARRAY 4
11.	32-BIT WORD ARRAY 5
12.	32-BIT WORD ARRAY 6
13.	32-BIT WORD ARRAY 7
14.	INPUT/OUTPUT PIN LIST

E-REV 8703 3  
 E-REV 8703-1 3

DRAWING  
 US000000A, IXL 1.1  
 INDEX PAGE  
 LAST MODIFIED=Fri Jul 12 08:35:18 1985


(WANG) LABORATORIES, INC.	REV: 6
TITLE: US-300 MEMORY MODULE 8703	DATE: 07/11/85
ENGINEER:	PAGE: 8 OF 14

8 7 6 5 4 3 2 1

8.5  
 11  
 17  
 22

22  
17  
11  
8.5  
8.5  
11  
17  
22

REVISIONS			
REV	DESCRIPTION	APP. BY	DATE



DRAWING

VS300MEM. LOGIC. 1.1  
ADDRESS AND CONTROL SIGNALS  
LAST\_MODIFIED=Fri Jul 12 13:52:35 1985

(WANG) LABORATORIES, INC.	REV: 6
TITLE: VS-300 MEMORY MODULE 8703	DATE: 07/11/85
ENGINEER: E. MANN	PAGE: 1 OF 14

22  
17  
11  
8.5  
8.5  
11  
17  
22

7.7

22

11

17

11

11

8.5

8.5

8.5

8.5

11


11

17

17


22

22



22" 17" 11" 8.5" 8.5" 11" 17" 22"

22" 17" 11" 8.5" 8.5" 11" 17" 22"



DRAWING  
 US300EM LOGIC 1.3  
 DATA-IN LATCHES  
 LAST\_MODIFIED=Fri Jul 12 10:03:01 1985

WANG LABORATORIES, INC.	REV: 6
TITLE: US-300 MEMORY MODULE 8703	DATE: 07/11/85
ENGINEER:	PAGE: 3 OF 14



77

"L1"

"11"


"5.8"

8.5"

11"

17"

22"



REVISIONS  
 VERSION LOGIC 1.4  
 DRAWN-OUT LATCHES  
 LAST MODIFIED-Fri Jul 12 10:05:39 1985

WANG LABORATORIES, INC.	REV: 6
TITLE: VS-300 MEMORY MODULE 8703	DATE: 07/11/85
ENGINEER:	PAGE: 4 OF 14

"22"

"L1"

"11"

"5.8"

8.5"


11"

17"

22"

22"  
17"  
11"  
8.5"  
11"  
8.5"  
11"  
17"  
22"

22"  
17"  
11"  
8.5"  
11"  
8.5"  
11"  
17"  
22"




DRAWING  
 US300MEM. LOGIC 1. B  
 DATA-OUT MEMORY DRIVERS  
 LAST\_MODIFIED=Fri Jul 12 18:08:35 1985

WANG LABORATORIES, INC.	REV: 6
TITLE: US-300 MEMORY MODULE 8783	DATE: 07/11/85
ENGINEER:	PAGE: 5 OF 14


77  
 "L1  
 "L1  
 "58  
 8.5"  
 11"  
 17"  
 22"

"22  
 "L1  
 "L1  
 "58  
 8.5"  
 11"  
 17"  
 22"




DRAWING  
 US-COOPER LOGIC 1.8  
 32-BIT WORD ARRAY 8  
 LAST MODIFIED-Fri Jul 12 18:28:07 1985

WANG LABORATORIES, INC.	REV: 6
TITLE: US-300 MEMORY MODULE 8703	DATE: 07/11/85
ENGINEER:	PAGE: 6 OF 14



DRAWING  
 US300EN. LOGIC 1.7  
 30-BIT WORD ARRAY 1  
 LAST\_MODIFIED: Fri Jul 12 10:33:34 1985


WANG LABORATORIES, INC.		REV: 6
TITLE: US-300 MEMORY MODULE 8703		DATE: 07/11/85
ENGINEER:		PAGE: 7 OF 14



DRAWING  
 US000000, LOGIC, 1, 8  
 30-BIT WORD MEMORY 2  
 LAST\_MODIFIED=Fri Jul 12 18:37:49 1985

WANG LABORATORIES, INC.	REV: 6
TITLE: US-300 MEMORY MODULE 8703	DATE: 07/11/85
ENGINEER:	PAGE: 8 OF 14

77  
 17  
 11  
 8.5  
 8.5  
 11  
 17  
 22  
 22




DRAWING  
 USBOOCHEN, LOGIC, 1, 9  
 30-BIT WORD ARRAY 3  
 LAST\_MODIFIED=Fri Jul 12 18:42:17 1985

WANG LABORATORIES, INC.	REV: 6.
TITLE: US-300 MEMORY MODULE 8703	DATE: 07/11/85
ENGINEER:	PAGE: 9 OF 14

77  
 11  
 11  
 8.5  
 8.5  
 11  
 17  
 22  
 22  
 22


77  
11  
9.8  
8.5  
11  
17  
22

22  
17  
11  
9.5  
8.5  
11  
17  
22



DRAWING  
 USDOODM LOGIC 1.18  
 32-BIT WORD ARRAY 4  
 LAST\_MODIFIED=Fri Jul 12 18:47:42 1985

WANG LABORATORIES, INC.		REV: 6
TITLE: US-300 MEMORY MODULE B703		DATE: 07/11/85
ENGINEER:	PAGE: 10 OF 14	



DRAWING  
 US000EM, LOGIC, 1, 11  
 30-BIT WORD ARRAY 5  
 LAST\_MODIFIED: Fri Jul 12 18:51:54 1985

WANG LABORATORIES, INC.	REV: 6
TITLE: US-300 MEMORY MODULE 8703	DATE: 07/11/85
ENGINEER:	PAGE: 11 OF 14

77  
 11  
 11  
 8.5"  
 8.5"  
 11"  
 17"  
 22"

77  
 11  
 11  
 8.5"  
 8.5"  
 11"  
 17"  
 22"



77

11

11


11.58

8.5

11

17

22



DRAWING  
 LABORATORY LOGIC 1.12  
 32-BIT WORD ARRAY 8  
 LAST MODIFIED: Jul 12 10:53:05 1985

WRNG	LABORATORIES, INC.	REV: 6
TITLE: US-300 MEMORY MODULE 8703		DATE: 07/11/85
ENGINEER:		PAGE: 12 OF 14

22

11

11

11.58

8.5


11

17

22

77  
17  
11  
8.5  
8.5  
11  
17  
22

22  
17  
11  
8.5  
8.5  
11  
17  
22




DRAWING  
 US300MEM LOGIC 1.13  
 32-BIT WORD ARRAY 7  
 LAST\_MODIFIED-Fri Jul 12 11:00:16 1985

WANG LABORATORIES, INC.	REV: 6
TITLE: US-300 MEMORY MODULE 8703	DATE: 07/11/85
ENGINEER:	PAGE: 13 OF 14



77  
11  
8.5  
8.5  
11  
17  
22

22  
11  
8.5  
8.5  
11  
17  
22



DRAWING  
 VERIFIED LOGIC 1.14  
 FINGER CONNECTIONS  
 LAST\_MODIFIED=Fri Jul 12 11:12:03 1985

WANG LABORATORIES, INC.	REV: 6
TITLE: US-300 MEMORY MODULE 8783	DATE: 07/11/85
ENGINEER:	PAGE: 14 OF 14






WANG LABORATORIES, INC. LOWELL, MASS. U.S.A.		BY	DATE	APPROVED BY	DATE
MATERIAL		DWH	7-2-55	E ENGR	
MODEL NO.		CHE		M ENGR	
VS-300 SEE DRAWING SPECIFICATIONS				MFG ENGR	
FINISH		TITLE			
		ASSEMBLY, VS-MEMORY MODULE			
REV. 12 AS SHOWN REV. 2 REV. 3 REV. 4 REV. 5 REV. 6		210-8703	D	8703	6
WANG PART NUMBER		SIZE	DRAWING NUMBER	REV	

ALL DIMENSIONS ARE IN INCHES UNLESS OTHERWISE INDICATED.  
 DIMENSIONS ARE TO CENTER UNLESS OTHERWISE INDICATED.  
 DIMENSIONS ARE TO CENTER UNLESS OTHERWISE INDICATED.  
 DIMENSIONS ARE TO CENTER UNLESS OTHERWISE INDICATED.

NOTES


1. ALL RESISTOR VALUES IN OHMS.
2. ALL CAPACITOR VALUES IN MICROFARADS UNLESS OTHERWISE INDICATED.
3. ALL RESISTORS 1/4W 5% UNLESS OTHERWISE INDICATED.



MNEMONICS	COORD.
10V/TEMP	2114
ANODE VOLT.	211
BAT BRK-UP ON	211
BAT CUTOFF IN	211
BAT CUTOFF OUT	211
BAT PRESH	211
BATTERY	211
BATTERY IN	211
RTCEN	211
POWER	211
PWR-CTL-1	211
INIT	211
CLK	211
ERSP	211
C-PA	211
C-PS	211
LED CON (VP)	211
ER SH CON (10V)	211
L62-10	211
L62-12	211
L62-14	211
OFF LED	211
DR	211
DR LFO	211
PA00 - PA05	211
PSINT	211
RTN	211
RTN	211
POWER	211
PWR-CTL-1	211
RST ON CON	211
SYS-RST	211
VSP	211
XAS	211
XDATAEN	211
XDATA	211
XDT/R	211
XAS	211
PSINT	211
VSP (10V)	211
XDATAEN	211
RTCEN	211
INIT	211
POWER	211
+5VA	2114
+5VB	2114
-5V	2114
+12V	2114
-12V	2114
2NDVDC-5	2114
2NDVDC-H	2114
2NDVDC-RTN	2114

LINEAR & TTL SPARES

IC TYPE	LOCATION	QTY
L7339	L74	3
7406	L13	3
4126	L55	1
74F02	L29	2
74F04	L7	2
	L26	2
74F74	L23	1




E REV  
 3 N


<b>WANG</b> MICROFILM		SCHEMATIC DIAGRAM	
TITLE POWER SUPPLY CONTROLLER			
VS-100	DATE 10/1/74	ENG	DIG
E	2709	S	
SCALE	DRY	SHEET	TOTAL

17" 11" 8.5" 8.5" 11" 17"

14 13 12 11 10 9 8 7 6 5 4 3 2 1



17" 11" 8.5" 8.5" 11" 17"



A	B	C	D	DISPLAY
0	0	0	0	AF+FFPP
1	0	0	0	-5V
0	1	0	0	+12V
1	1	0	0	+5V
0	0	1	0	-5V
1	0	1	0	+5V


\* - 1/4W, 1% RESISTORS

2709 6

17" 11" 8.5" 8.5" 11" 17"




17" 11" 8.5" 8.5" 11" 17"

\* - 1/8W, 1% RESISTORS



1	2	3	4
6	E	8709	6


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K



17"  
11"  
8.5"  
8.5"  
11"  
17"

17"  
11"  
8.5"  
8.5"  
11"  
17"





77  
G

17"

11"

8.5"

8.5"

11"

17"

22"

22"

17"

11"

8.5"

8.5"


11"

17"

22"

- NOTES:  
UNLESS OTHERWISE SPECIFIED:  
1. ALL CAPACITORS ARE .047UF CERAMIC EXPRESSED IN MICROFARADS  
2. ALL RESISTORS ARE 1/4W, 5% EXPRESSED IN OHMS  
3. ALL 1% RESISTORS ARE 1/8W  
4. TP2, TP4, TP9-TP11 ARE UPM 634-1192.

<b>WANG</b>		BY	DATE	APPROVED BY	DATE
MATERIAL	MODEL NO. VS300	GM VS		ELNAR	
	10-203	CHK		ELNAR	
FINISH		E.C. CONTROL		ELNAR	
		TITLE VS300 POWER SUPPLY CONTROLLER			
		ASSEMBLY DRAWING			
		210-0709	C	8709	5




THIS DRAWING AND THE DATA SHOWN THEREON ARE THE CONFIDENTIAL PROPERTY OF WANG LABORATORIES, INC. AND ARE NOT TO BE REPRODUCED, COPIED, OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, INCLUDING PHOTOCOPYING, RECORDING, OR BY ANY INFORMATION STORAGE AND RETRIEVAL SYSTEM, WITHOUT THE WRITTEN CONSENT OF WANG LABORATORIES, INC. IF YOU ARE READING THIS DRAWING IN PRINTED BY WANG, IT IS YOUR OBLIGATION TO RETURN IT TO WANG LABORATORIES, INC. UPON THE DEMAND OF WANG LABORATORIES, INC.

REV	DATE	DESCRIPTION
1	02-22-80	ORIG. DESIGNED BY: DWA
2	03-14-80	REVISED PER: APPD: 02/22/80
3	03-14-80	REVISED PER: APPD: 03/14/80
4	03-14-80	REVISED PER: APPD: 03/14/80
5	03-14-80	REVISED PER: APPD: 03/14/80
6	03-14-80	REVISED PER: APPD: 03/14/80
7	03-14-80	REVISED PER: APPD: 03/14/80
8	03-14-80	REVISED PER: APPD: 03/14/80
9	03-14-80	REVISED PER: APPD: 03/14/80
10	03-14-80	REVISED PER: APPD: 03/14/80
11	03-14-80	REVISED PER: APPD: 03/14/80


WANG PART NO.	DRAWING NO.	DESCRIPTION	BY	DATE	APPROVED BY	DATE
			DWA	02-22-80		
			CHE			
MATERIAL	MODEL NO VS 300	TITLE				
	WE HAVE SPECIFICATIONS	VS 300 SCU-PC ADAPTER				
FORM	210-8710	D	8710	1		

THIS DRAWING AND THE DATA SHOWN THEREON ARE THE CONFIDENTIAL PROPERTY OF AND ARE PROPRIETARY TO WANG LABORATORIES, INC. THIS DRAWING AND THE DATA SHOWN THEREON MAY NOT BE MADE PUBLIC WITHOUT THE WRITTEN CONSENT OF WANG LABORATORIES, INC. IF FOR ANY REASON THIS DRAWING IS PERMITTED BY WANG TO LEAVE THE PHYSICAL CUSTODY OF THE COMPANY, IT IS RETURNABLE UPON THE DEMAND OF WANG LABORATORIES, INC.



NO.	REV	BY	DATE
1	A	DPW	5/29/84
2	B	HSL	9/24/84
3	C	GAR	12/28/84
4	D	DCT	3/13/85

<b>WANG</b> LABORATORIES, INC. LOWELL, MASS., U.S.A.		BY	DATE	APPROVED BY	DATE
		DWN DPW	5/29/84	E ENGR	
MATERIAL _____ MODEL NO. VS300 SEE ENGR SPECIFICATIONS NO. 10-203		CHK JDL		M ENGR	
		E C CONTROL		MFG ENGR	
FINISH _____ TOL. EX. AS NOTED .125" / .010 FRAC. / .125" .005" / .005 AND .125" / .125"		TITLE VS 300 SCU-PC ADAPTER ASSEMBLY DRAWING			
		210-8710	C	8710	1
SCALE 1/1	SHT 1 OF 1	WANG PART NUMBER	SIZE	DRAWING NUMBER	REV



THIS DRAWING AND THE DATA SHOWN THERE  
 ARE THE UNOFFICIAL PROPERTY OF WANG  
 LABORATORIES, INC. AND ARE LOANED TO YOU  
 FOR YOUR INFORMATION ONLY. YOU ARE NOT  
 TO REPRODUCE OR TRANSMIT THIS DRAWING  
 OR ANY PART THEREOF IN ANY MANNER  
 WITHOUT THE WRITTEN PERMISSION OF  
 WANG LABORATORIES, INC. THE COMPANY  
 ACCEPTS NO LIABILITY FOR ANY DAMAGE  
 TO PERSONS OR PROPERTY ARISING FROM  
 THE USE OF THIS DRAWING OR THE DATA  
 SHOWN THEREON.

REV	DATE	BY	CHKD	APP'D
1	11/17/52	W. J. W.		
2	11/17/52	W. J. W.		

WANG PART NO	DRAWING NO	DESCRIPTION	BY	DATE	APPROVED BY	DATE
<b>WANG</b>	WANG LABORATORIES, INC.	LOWELL MAUSA	DWN	11/17/52	E ENGR	
MATERIAL	MODEL NO	TITLE	CHK		W. J. W. ENGR	
	V5 300	AC DISTRIBUTION BOARD				
FINISH	FOR IS AS NOTED	211-8715	D	8715		
	SEE 2-003-ANG - 11-10 FINISH	SCALE	1/2" = 1"	WANG PART NUMBER	SIZE	DRAWING NUMBER

WANG LABORATORIES, INC.  
 >>>> ELECTRICAL PARTS LIST <<<<

RUN DATE: 12/17/84 14:37  
 SHEET 2 OF 2 PAGE 1

(FINAL PARTS LIST)

BOARD NO. & TITLE: C8715 AC DISTRIBUTION BOARD  
 ASSEMBLY LEVEL & TITLE: 210 8715  
 PARTS LIST REVISION (P): 1  
 ARTWORK REVISION (R): 00  
 ASSEMBLY REVISION (A): 00  
 SCHEMATIC REVISION (S): 00  
 DWR OR MOST RECENT ECO: E2511

CREATED: 09/17/84 10:50  
 LAST MODIFIED: 12/17/84 14:00 BY: NS  
 EDITING REVISION: 7


REF. DES.	WANG PART NO.	VALUE/TYPE	DESCRIPTION	DRAWING NO.	QTY.
TB1	310-1315-	8PCV03	TERMINAL BLOCK, 3 SCREW		1
J1 - JS	350-0238-	9 CONT	CONN PC HEADER UNIVERSAL RED		5
Ø1	510-8715-		PCB		1

\*\*\* END-OF-REPORT \*\*\*

<b>WANG</b> WANG LABORATORIES, INC. LOWELL, MA U.S.A.		BY	DATE	APPROVED BY	DATE
MATERIAL		DWN		E ENGR	
MODEL NO		CHK		M ENGR	
SEE ENG'G SPECIFICATIONS				MFG ENGR	
TITLE		AC DISTRIBUTION BOARD			
FINISH		TOL EX AS NOTED	210-8715	C	8715 0
		XX ± 0.10 FRAC ± 1/64			
		XXX ± 0.05 ANG ± 1' 30" FINISH			
		SCALE	SHT 2 OF 2	WANG PART NUMBER	SIZE DRAWING NUMBER REV

"THIS DRAWING AND THE DATA SHOWN THEREON ARE THE CONFIDENTIAL PROPERTY OF, AND ARE PROPRIETARY TO, WANG LABORATORIES, INC. THIS DRAWING AND THE DATA SHOWN THEREON MAY NOT BE MADE PUBLIC WITHOUT THE WRITTEN CONSENT OF WANG LABORATORIES, INC. IF FOR ANY REASON THIS DRAWING IS PERMITTED BY WANG TO LEAVE THE PHYSICAL POSSESSION OF THE COMPANY, IT IS RETURNABLE UPON THE DEMAND OF WANG LABORATORIES, INC."

ØPCV TERMINAL BARRIER STRIP.  
MOUNT COMPONENT FROM CIRCUIT SIDE.  
(SEE NOTE 2.)



NOTE:  
1. J1-J5 ARE W/P/N 350-0230.  
2. TB1 IS W/P/N 310-1315.


NO.	CHK	DATE	BY
1	✓	11/19/84	DPW
2	✓	11/21/84	HRH
3	✓	11/21/84	HRH

		BY	DATE	APPROVED BY	DATE
		DVN DPW	9/14/84	E ENGR	
MATERIAL		CHK		M ENGR	
MODEL NO. VS 300 SEE ENGR SPECIFICATIONS NO. 10-203		E C CONTROL		MFG ENGR	
FINISH		TITLE AC DISTRIBUTION BOARD ASSEMBLY DRAWING			
SCALE 1/1		210-8715	C	8715	Ø
SHT 1 OF 1		WANG PART NUMBER	SIZE	DRAWING NUMBER	REV

Grid lines and dimensions: 7, 6, 5, 4, 3, 2, 1 (horizontal); E, D, C, B, A (vertical); 17", 11", 8.5" (vertical dimensions); 17", 11", 8.5" (horizontal dimensions).

THIS DRAWING AND THE DATA SHOWN THEREON ARE THE CONFIDENTIAL PROPERTY OF AND ARE PROPRIETARY TO WANG LABORATORIES, INC. THIS DRAWING AND THE DATA SHOWN THEREON MAY NOT BE MADE PUBLIC WITHOUT THE WRITTEN CONSENT OF WANG LABORATORIES, INC. IF FOR ANY REASON THIS DRAWING IS PERMITTED BY WANG TO LEAVE THE PHYSICAL CUSTODY OF THE COMPANY, IT IS RETURNABLE UPON THE DEMAND OF WANG LABORATORIES, INC.

DO NOT SCALE



E REV  
0

REV	DATE	BY	DESCRIPTION
0	11-20-64	BCS	ORIGINATED PER DWR #E2514
1	11-22-64	DK	APP'D

WANG PART NO	DRAWING NO	DESCRIPTION	BY	DATE	APPROVED BY	DATE
			<b>WANG</b>			
		WANG LABORATORIES, INC. LOWELL, MA U.S.A.	DWN B. CHARLES	11-20-64	E ENGR	
			CHR. S. BRID	11-22-64	M ENGR	
					MFG ENGR	
MATERIAL	MODEL NO	TITLE				
	VS 300	DC DISTRIBUTION BOARD				
FINISH	TOL. EX. AS NOTED	210-8716	D	8716	0	
	PER 2-518 FRAC. ± 1/100					
	PER 2-503 W/ANG ± 1/100 FINISH					
	SCALE	SHT. 1 OF 2	WANG PART NUMBER	REV	DRAWING NUMBER	REV

17"

11"

8.5"

17"

11"

8.5"

WANG LABORATORIES, INC.

RUN DATE: 11/27/84 14:20

\*\*\*\*\* ELECTRICAL PARTS LIST \*\*\*\*\* M SHEET 2 OF 2 PAGE 1

(FINAL PARTS LIST)

BOARD NO. & TITLE: C8716 DC. DISTRIBUTION BOARD CREATED: 09/14/84 13:42  
 ASSEMBLY LEVEL & TITLE: 210 8716 LAST MODIFIED: 11/27/84 14:18 BY: LAB  
 PARTS LIST REVISION (P): 1 EDITING REVISION: 6  
 ARTWORK REVISION (R): 00  
 ASSEMBLY REVISION (A): 00  
 SCHEMATIC REVISION (S): 00  
 DWR OR MOST RECENT ECO: E2514

REF. DES.	WANG PART NO.	VALUE/TYPE	DESCRIPTION	DRAWING NO.	QTY.
T81	310-1122-	7 POS	7 POS ROI 8PCV-07 7 POS TERMINAL BLOCK		1
J11	350-0221-	15 COMT	CONN PC HEADER UNIVERSAL RED		1
J1 - J10	350-0306-	6 PIN	6 PIN MATE-N-LOK CONN.		10
Ø1	510-8716-		PCB		1

\*\*\* END-OF-REPORT \*\*\*

<b>WANG</b> WANG LABORATORIES, INC. LOWELL, MA U.S.A.		BY	DATE	APPROVED BY	DATE
MATERIAL		DWN		E ENGR	
MODEL NO		CHK		M ENGR	
SEE ENG'G SPECIFICATIONS				MFG ENGR	
FINISH		TITLE			
TOL. ER. AS NOTED		DC DISTRIBUTION BD.			
XX = 818 FRAC ± 1/64		210-8716	C	8716	0
XXX = 805 ANG ± 1° 30' FINISH		SCALE	SHT 2 OF 2	WANG PART NUMBER	SIZE DRAWING NUMBER REV

8.5"

11"

17"


8.5"

11"

17"



THIS DRAWING AND THE DATA SHOWN THEREON ARE THE CONFIDENTIAL PROPERTY OF WANG AND ARE PROPRIETARY TO WANG LABORATORIES, INC. THIS DRAWING AND THE DATA SHOWN THEREON MAY NOT BE MADE PUBLIC WITHOUT THE WRITTEN CONSENT OF WANG LABORATORIES, INC. IF FOR ANY REASON THIS DRAWING IS REPRODUCED BY WANG TO LEAVE THE PHYSICAL CUSTODY OF THE COMPANY, IT IS RETURNABLE UPON THE DEMAND OF WANG LABORATORIES, INC.



NOTES:  
 1. UNLESS OTHERWISE SPECIFIED,  
 ALL CONNECTORS ARE 6 PIN MATE-N-LOK.  
 WANG LAB # 358-8386

NO.	REV.	DPW	GAR
		DWR#2514 DCR#8839	DVR-8838

<b>WANG</b> LABORATORIES, INC. LOVELL, MASS., U.S.A.		BY	DATE	APPROVED BY	DATE
		DWN DPW	9/14/64	E ENGR	
MATERIAL		E.C. CONTROL		H ENGR	
MODEL NO. VS 300		TITLE DC DISTRIBUTION BOARD ASSEMBLY DRAWING			
FINISH		210-8716	C	8716	Ø
SCALE 1/1 SHT 1 OF 1		WANG PART NUMBER	SIZE	DRAWING NUMBER	REV.



THIS DRAWING AND THE DATA SHOWN THEREON ARE THE CONFIDENTIAL PROPERTY OF AND ARE PROPRIETARY TO WANG LABORATORIES, INC. THIS DRAWING AND THE DATA SHOWN THEREON MAY NOT BE MADE PUBLIC WITHOUT THE WRITTEN CONSENT OF WANG LABORATORIES, INC. IF FOR ANY REASON THIS DRAWING IS PERMITTED BY WANG TO LEAVE THE PHYSICAL CUSTODY OF THE COMPANY, IT IS RETURNABLE UPON THE DEMAND OF WANG LABORATORIES, INC.

DO NOT SCALE

11 10 9 8 7 5 4 3 2 1

G  
F  
E  
C  
B  
A

22  
17  
11  
8.5  
11  
17  
22




NOTE: 1. ALL RESISTORS ARE 1/4W 5% UNLESS SPECIFIED OTHERWISE

E-REV  
1

REV	DATE	BY	CHKD	APPROVED BY

WANG PART NO.	DRAWING NO.	DESCRIPTION	BY	DATE	APPROVED BY	DATE
			DWN	10/21/77		
			CHE	10/21/77		
MATERIAL	MODEL NO. VS 300	TITLE BATTERY BACK UP				

"THIS DRAWING AND THE DATA SHOWN THEREON ARE THE CONFIDENTIAL PROPERTY OF, AND ARE PROPRIETARY TO, WANG LABORATORIES, INC. THIS DRAWING AND THE DATA SHOWN THEREON MAY NOT BE MADE PUBLIC WITHOUT THE WRITTEN CONSENT OF WANG LABORATORIES, INC. IF FOR ANY REASON THIS DRAWING IS PERMITTED BY WANG TO LEAVE THE PHYSICAL CUSTODY OF THE COMPANY, IT IS RETURNABLE UPON THE DEMAND OF WANG LABORATORIES, INC."




NOTES:  
 UNLESS OTHERWISE SPECIFIED:  
 1. ALL RESISTORS ARE 1/4W 5% EXPRESSED IN OHMS  
 2. LEAD LED1 WITH A 370-0075.

		BY	DATE	APPROVED BY	DATE
		DWM		E ENGR	
MATERIAL MODEL NO. VS-300 SEE ENGR SPECIFICATIONS NO. 10-203		CHK		M ENGR	
		E C CONTROL		MFG ENGR	
FINISH TOL. EX. AS NOTED .XXX+/- .010 FRAC. +/- 1/64 .XXX+/- .005 AND +/- 1/32		TITLE BATTERY BACK UP CTRL. BD.			
		ASSEMBLY DRAWING			
SCALE 1/1	SHT 1 OF 1	210-0717	C	8717	4
DWG PART NUMBER		SIZE	DRAWING NUMBER		REV

7  
6  
5  
4  
3  
2  
1  
E  
D  
C  
B  
A  
8.5"  
11"  
17"

7  
6  
5  
4  
3  
2  
1  
E  
D  
C  
B  
A  
8.5"  
11"  
17"



NO.	REV.	DATE	APPROVED BY	DATE
1	1			
2	1			
3	1			
4	1			
5	1			
6	1			
7	1			
8	1			
9	1			
10	1			
11	1			
12	1			
13	1			
14	1			
15	1			
16	1			
17	1			
18	1			
19	1			
20	1			
21	1			
22	1			
23	1			
24	1			
25	1			
26	1			
27	1			
28	1			
29	1			
30	1			
31	1			
32	1			
33	1			
34	1			
35	1			
36	1			
37	1			
38	1			
39	1			
40	1			
41	1			
42	1			
43	1			
44	1			
45	1			
46	1			
47	1			
48	1			
49	1			
50	1			
51	1			
52	1			
53	1			
54	1			
55	1			
56	1			
57	1			
58	1			
59	1			
60	1			
61	1			
62	1			
63	1			
64	1			
65	1			
66	1			
67	1			
68	1			
69	1			
70	1			
71	1			
72	1			
73	1			
74	1			
75	1			
76	1			
77	1			
78	1			
79	1			
80	1			
81	1			
82	1			
83	1			
84	1			
85	1			
86	1			
87	1			
88	1			
89	1			
90	1			
91	1			
92	1			
93	1			
94	1			
95	1			
96	1			
97	1			
98	1			
99	1			
100	1			

5.25" DISK I/O

REV. 1


DATE: 11/11/77

BY: [Signature]

APPROVED BY: [Signature]


DATE: 11/11/77

NO. 8785 3




22"  
17"  
11"  
8.5"  
11"  
17"  
22"


REV	DATE	BY	APPROVED BY
1			
TITLE		512K DRAM I/O	
SEE QUANT		E 87B5 3	



REV	DATE	APPROVED BY	DATE
1	11/10/75		
TITLE			
LMD DISK IOC			
DRAWN BY			
E 8785 3			




SMD DISK 10C			
REV. 1	DATE	APPROVED BY	DATE
1			
SEE CHART E 8785 3			




		DATE: _____ APPROVED BY: _____ DESIGNED BY: _____ CHECKED BY: _____
TITLE: SMD DISK I/O		PART: 8785
SEE CHART E 8785		SHEET: 3






VS-300	SMD DISK IOC
SEE CHART E 8785 3	
10/1/78	



NO.	REV.	APPROVED BY	DATE
1	1		
2	1		
3	1		
4	1		
5	1		
6	1		
7	1		
8	1		
9	1		
10	1		
11	1		
12	1		
13	1		
14	1		
15	1		
16	1		
17	1		
18	1		
19	1		
20	1		
21	1		
22	1		
23	1		
24	1		
25	1		
26	1		
27	1		
28	1		
29	1		
30	1		
31	1		
32	1		
33	1		
34	1		
35	1		
36	1		
37	1		
38	1		
39	1		
40	1		
41	1		
42	1		
43	1		
44	1		
45	1		
46	1		
47	1		
48	1		
49	1		
50	1		
51	1		
52	1		
53	1		
54	1		
55	1		
56	1		
57	1		
58	1		
59	1		
60	1		
61	1		
62	1		
63	1		
64	1		
65	1		
66	1		
67	1		
68	1		
69	1		
70	1		
71	1		
72	1		
73	1		
74	1		
75	1		
76	1		
77	1		
78	1		
79	1		
80	1		
81	1		
82	1		
83	1		
84	1		
85	1		
86	1		
87	1		
88	1		
89	1		
90	1		
91	1		
92	1		
93	1		
94	1		
95	1		
96	1		
97	1		
98	1		
99	1		
100	1		

210	207	156-211	1185-141	1417-178	1200-123	1232	1240	1246	1248
WRS4	BZBS	317-3373	317-0417	317-0400	317-0428	317-0404	317-0437	317-0438	317-0338

IC TYPE	LOCATION	SPACE
MC300	L351	1
74500	L85	3
	L109	1
	L118	3
74501	L157	2
	L26	1
7400	L2	3
	L66	6
74LS00	L286	1
	L33	2
74504	L17	4
	L	3
74705	L123	1
	L181	2
74510	L113	2
	L160	1
74511	L171	1
74LS20	L189	1
74510	L36	1
74LS32	L203	1
	L236	3
74532	L83	1
74551	L84	1
74LS74	L181	1
74LS86	L97	1
74LS139	L218	1
745140	L206	1
745100	L83	1
	L106	1






MNEMONICS	COORD
ACK	3A11
ADDRESS MARK FOUND	7F14
ADDRESS MARK FOUND	7F14
BCK	3D14
+BUS0	7J1
+BUS0	7J1
+BUS1	7J1
+BUS1	7J1
+BUS2	7J1
+BUS2	7J1
+BUS3	7K1
+BUS3	7K1
+BUS4	7N1
+BUS4	7N1
+BUS5	7N1
+BUS5	7N1
+BUS6	7N1
+BUS6	7N1
+BUS7	7Z1
+BUS7	7Z1
+BUS8	7G1
+BUS8	7G1
+BUS9	7F1
+BUS9	7F1
+BUSY	3A11
+BUSY	7U14
+BUSY	7U14
CO-ES	3J1
DB0-DB31	1J1
DETECT	7A7
-FAULT	7N14
+FAULT	7N14
FPL	3A11
GRINI-GRINNE	3F14
GRN	1B1

MNEMONICS	COORD
HOLD PICK	7A5
HOLD	3A11
IMS-ICS	3N1
ID8	3Z1
-INDEX	7G14
+INDEX	7G14
-INDEX	6G14
+INDEX	6G14
-INDEX	6G14
+INDEX	6G14
-INDEX	6D14
+INDEX	6D14
-INDEX	6B14
+INDEX	6B14
INT	3C14
INTREQ	3Z1
INT	3Z1
MS	3A11
MSID0-MSID4	3U14
-ON CYLINDER	7N14
+ON CYLINDER	7N14
OPEN CABLE	7A7
-READ CLK0	6K4
+READ CLK0	6K4
-READ CLK1	6K6
+READ CLK1	6K6
-READ CLK2	6K8
+READ CLK2	6K8
-READ CLK3	6K11
+READ CLK3	6K11
-READ DATA0	6N5
+READ DATA0	6N5
-READ DATA1	6K7
+READ DATA1	6K7
-READ DATA2	6K9
+READ DATA2	6K9
-READ DATA3	6K11
+READ DATA3	6K11
RTN	1R1
RQNT-RQNT	3E14
SBC314	3N3
-SECTOR	7F14
+SECTOR	7F14
-SECTOR	6N14
+SECTOR	6N14
-SECTOR	6F14
+SECTOR	6F14
-SECTOR	6D14
+SECTOR	6D14
-SECTOR	6B14
+SECTOR	6B14
-SEEK END	6N14
+SEEK END	6N14
-SEEK END	6F14
+SEEK END	6F14
-SEEK END	6D14
+SEEK END	6D14
-SEEK END	6A14
+SEEK END	6A14
-SEEK ERROR	7Z14
+SEEK ERROR	7Z14
SELINT	3E1
-SERVO CLK0	6K4
+SERVO CLK0	6K4
-SERVO CLK1	6K6
+SERVO CLK1	6K6
-SERVO CLK2	6K8
+SERVO CLK2	6K8
-SERVO CLK3	6K11
+SERVO CLK3	6K11
-TAG1	7F1
+TAG1	7F1
-TAG2	7G1
+TAG2	7G1
-TAG3	7D1
+TAG3	7D1
-TAG4	7E1
+TAG4	7E1
-TAG5	7E1
+TAG5	7E1
-TAG6	7E1
+TAG6	7E1
TIMER	6C14

MNEMONICS	COORD
-UNIT READY	7Z14
+UNIT READY	7Z14
-UNIT SELECT	6N14
+UNIT SELECT	6N14
-UNIT SELECT	6G14
+UNIT SELECT	6G14
-UNIT SELECT	6A14
+UNIT SELECT	6A14
-US0	7B1
+US0	7B1
-US1	7C1
+US1	7C1
-US2	7K2
+US2	7K2
-US3	7D1
+US3	7D1
-WRITE CLK DEVICE0	6N1
+WRITE CLK DEVICE0	6N1
-WRITE CLK DEVICE1	6G1
+WRITE CLK DEVICE1	6G1
-WRITE CLK DEVICE2	6F1
+WRITE CLK DEVICE2	6F1
-WRITE CLK DEVICE3	6E1
+WRITE CLK DEVICE3	6E1
-WRITE PROTECT	7F14
+WRITE PROTECT	7F14

MNEMONICS	COORD
-WRITE DATA DEVICE0	6N1
+WRITE DATA DEVICE0	6N1
-WRITE DATA DEVICE1	6G1
+WRITE DATA DEVICE1	6G1
-WRITE DATA DEVICE2	6F1
+WRITE DATA DEVICE2	6F1
-WRITE DATA DEVICE3	6E1
+WRITE DATA DEVICE3	6E1
-WRITE PROTECT	7F14
+WRITE PROTECT	7F14




NO.	DESCRIPTION	DATE	BY
1	ISSUED FOR		
2	REVISION		
3	REVISION		
4	REVISION		
5	REVISION		

NO.	DESCRIPTION	DATE	BY
1	ISSUED FOR		
2	REVISION		
3	REVISION		
4	REVISION		
5	REVISION		

E-REV  
1

NO.	DESCRIPTION	DATE	BY
1	ISSUED FOR		
2	REVISION		
3	REVISION		
4	REVISION		
5	REVISION		

THIS DRAWING AND THE DATA SHOWN THERE ON ARE THE CONFIDENTIAL PROPERTY OF AND ARE PROPRIETARY TO WANG LABORATORIES, INC. THIS DRAWING AND THE DATA SHOWN THEREON MAY NOT BE MADE PUBLIC WITHOUT THE WRITTEN CONSENT OF WANG LABORATORIES, INC. IF FOR ANY REASON THIS DRAWING IS PERMITTED BY WANG TO LEAVE THE PHYSICAL CUSTODY OF THE COMPANY IT IS RETURNABLE UPON THE DEMAND OF WANG LABORATORIES, INC.



INSTALL TRANSPAD  
375-1021 UNDER Q1

CARD EXTRACTOR  
485-1255, 2 REQD.

INSTALL TRANSPAD  
375-8004 UNDER Q2


SCREW, NO. 4-40 850-2083  
NUT, HEX. NO. 4-40 852-2001

STIFFENER  
452-2772  
INSTALL CIRCUIT SIDE

- NOTES
- UNLESS OTHERWISE SPECIFIED  
ALL CAPACITORS ARE .047, EXPRESSED IN MICROFARADS.  
ALL RESISTORS ARE 1/4W, 5%, EXPRESSED IN OHMS.  
ALL CONNECTIONS ARE 350-0058.  
ALL RESISTOR NETWORKS ARE 333-0849 (58 OHMS).  
ARE - 1. 300-1830.
  - C25, 50, 85, 117, 125, 127, 128, 130, 132, 135-143, 147, 150, 157, 159, 181 ARE - 1. 300-1830.
  - L08, 24 PIN SMT. (378-8037) IN LOCATIONS L81, 81, 148, 222, 277.


<b>WANG</b> LABORATORIES, INC. LOWELL, MASS. U.S.A.		BY DWM E. REGAN	DATE 1/10/78	APPROVED BY M. ENGR	DATE
BY / LEVEL	MODEL NO. VS-300 REVISIONS	TITLE ASSEMBLY, VS-300 SMD DISK CNTRL			
FINISH	DATE 1/11/78	210-8765	D	8785	4
	DATE PART NUMBER	SIZE	DRAWING NUMBER		

77 11 10 9 8 7 5 4 3 2 1 22  
 17 17  
 11 11  
 8.5 8.5  
 8.5 8.5  
 11 11  
 17 17  
 22 22



NO.	DATE	APPROVED BY	DATE
1			
2			
3			
4			
5			
6			
7			
8			
9			
10			
11			
12			
13			
14			
15			
16			
17			
18			
19			
20			
21			
22			
23			
24			
25			
26			
27			
28			
29			
30			
31			


TITLE: Y5300 TELY TAP  
 110-8769 E 8789 7



NO.	REVISION	DATE	APPROVED BY	DATE
1				
2				
3				
4				
5				
6				
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				
26				
27				
28				
29				
30				
31				
32				
33				
34				
35				
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				
46				
47				
48				
49				
50				
51				
52				
53				
54				
55				
56				
57				
58				
59				
60				
61				
62				
63				
64				
65				
66				
67				
68				
69				
70				
71				
72				
73				
74				
75				
76				
77				
78				
79				
80				
81				
82				
83				
84				
85				
86				
87				
88				
89				
90				
91				
92				
93				
94				
95				
96				
97				
98				
99				
100				

V5300 TELLER TAPE CONTROLLER  
 210-8759  
 E


34  
77  
11  
11  
58  
8.5  
11  
17  
22



22  
11  
11  
58  
8.5  
11  
17  
22

REV	DATE	APPROVED BY	DATE
1			
2			
3			
4			
5			
6			
7			
8			
9			
10			
11			
12			
13			
14			


V5300 TELEX TAPE CONTROLLER M/L  
210-8789 E 8789 7



REV	DATE	APPROVED BY	BY
1			
2			
3			
4			
5			
6			
7			
8			
9			
10			
11			
12			
13			
14			




VS-300  
 TITLE VS-300 TELETYPE TAPE CONTROLLER M/L  
 210-8789 E 8789 7





ALPHANUMERIC	CODE
ACK	3A11
BCK0	3D19
BCT	4J16
BCT	3A11
BCT	4J16
CB-EB	3V1
CMD CLR	4K1
CMD0-7	4K1
COR	4F14
DOE	4D1
DATA#	4H11
DBG-DBG1	1K1
DD50	4H16
DD51	4H16
DIF	4F14
DREQ	4G16
D50	4H1
D51	4G1
DZT	4V19
EAM	4H16
ERR	4E14
ERRA0-ERRA7	4E14
ESD0	4E1
ESC0	4E1
ERR	4F14
FFP	4J16
HOLD	3A11
TREN	4C14
IDB	4F14
IOO-IO3	3K1
IO4	3J1
IO4T	3C14
IO/REQ	3J1
IPC RDY	3I1
IOV	4D1
ITB	3A11
MS100-MS104	3J19
QVR	4F14
QNL	4E14
RDM	4E14
RDT	4E14
RF1	4E14
REV	4H16
REQN	1K1
RNR	4Z14
RPE	4F14
R001-R007	3F16
RWB	4Z14
SEL IN	1E1
SYN	4E1
TFT	4F1
TFT	4F1
TMR	3C14
WRM	4E14


74LS00	LS6	2
74LS00	L111	1
74LS02	L47	1
	L48	3
7402	L116	3
74S02	L134	3
74LS04	L65	1
	L84	2
74S04	L131	1
	L136	2
	L76	3
74F04	L93	1
	L118	2
	L129	2
74C6	L7	1
74LS08	L57	1
74S08	L12	1
74F08	L73	1
74F08	L83	1
74LS10	L78	2
74LS11	L128	1
7411	L169	1
74LS14	L63	3
74S14	L156	1
74S14	L172	1
74LS32	L49	2
7432	L88	1
74LS51	L87	1
74S1	L74	1
	L108	1
	L145	1
74S74	L81	1
74LS84	L32	2
	L77	1
74LS139	L195	1
	L199	1
74S240	L133	1
7404	L90	2



REV 2


NOTE 1. ALL RES. ARE 1/8W 5% UNLESS OTHERWISE SPECIFIED.

REV	DATE	APPROVED BY	DATE
VS-300			
VS-300 TELEX TAPE CONTROLLER M/L			
80-8783	E	8783	7



- NOTES:
- UNLESS OTHERWISE SPECIFIED:  
ALL CAPACITORS ARE EXPRESSED IN MICROFARADS,  $\mu$  0.01, 0.05, 0.1, 0.5, 1, 5, 10, 50, 100, 500, 1000.  
ALL RESISTORS ARE EXPRESSED IN OHMS, 1/4W, 5% PER CENT.
  - C14, C17, C18, C19, C20, C21, C22, C23, C24, C25, C26, C27, C28, C29, C30, C31, C32, C33, C34, C35, C36, C37, C38, C39, C40, C41, C42, C43, C44, C45, C46, C47, C48, C49, C50, C51, C52, C53, C54, C55, C56, C57, C58, C59, C60, C61, C62, C63, C64, C65, C66, C67, C68, C69, C70, C71, C72, C73, C74, C75, C76, C77, C78, C79, C80, C81, C82, C83, C84, C85, C86, C87, C88, C89, C90, C91, C92, C93, C94, C95, C96, C97, C98, C99, C100, C101, C102, C103, C104, C105, C106, C107, C108, C109, C110, C111, C112, C113, C114, C115, C116, C117, C118, C119, C120, C121, C122, C123, C124, C125, C126, C127, C128, C129, C130, C131, C132, C133, C134, C135, C136, C137, C138, C139, C140, C141, C142, C143, C144, C145, C146, C147, C148, C149, C150, C151, C152, C153, C154, C155, C156, C157, C158, C159, C160, C161, C162, C163, C164, C165, C166, C167, C168, C169, C170, C171, C172, C173, C174, C175, C176, C177, C178, C179, C180, C181, C182, C183, C184, C185, C186, C187, C188, C189, C190, C191, C192, C193, C194, C195, C196, C197, C198, C199, C200, C201, C202, C203, C204, C205, C206, C207, C208, C209, C210, C211, C212, C213, C214, C215, C216, C217, C218, C219, C220, C221, C222, C223, C224, C225, C226, C227, C228, C229, C230, C231, C232, C233, C234, C235, C236, C237, C238, C239, C240, C241, C242, C243, C244, C245, C246, C247, C248, C249, C250, C251, C252, C253, C254, C255, C256, C257, C258, C259, C260, C261, C262, C263, C264, C265, C266, C267, C268, C269, C270, C271, C272, C273, C274, C275, C276, C277, C278, C279, C280, C281, C282, C283, C284, C285, C286, C287, C288, C289, C290, C291, C292, C293, C294, C295, C296, C297, C298, C299, C300, C301, C302, C303, C304, C305, C306, C307, C308, C309, C310, C311, C312, C313, C314, C315, C316, C317, C318, C319, C320, C321, C322, C323, C324, C325, C326, C327, C328, C329, C330, C331, C332, C333, C334, C335, C336, C337, C338, C339, C340, C341, C342, C343, C344, C345, C346, C347, C348, C349, C350, C351, C352, C353, C354, C355, C356, C357, C358, C359, C360, C361, C362, C363, C364, C365, C366, C367, C368, C369, C370, C371, C372, C373, C374, C375, C376, C377, C378, C379, C380, C381, C382, C383, C384, C385, C386, C387, C388, C389, C390, C391, C392, C393, C394, C395, C396, C397, C398, C399, C400, C401, C402, C403, C404, C405, C406, C407, C408, C409, C410, C411, C412, C413, C414, C415, C416, C417, C418, C419, C420, C421, C422, C423, C424, C425, C426, C427, C428, C429, C430, C431, C432, C433, C434, C435, C436, C437, C438, C439, C440, C441, C442, C443, C444, C445, C446, C447, C448, C449, C450, C451, C452, C453, C454, C455, C456, C457, C458, C459, C460, C461, C462, C463, C464, C465, C466, C467, C468, C469, C470, C471, C472, C473, C474, C475, C476, C477, C478, C479, C480, C481, C482, C483, C484, C485, C486, C487, C488, C489, C490, C491, C492, C493, C494, C495, C496, C497, C498, C499, C500, C501, C502, C503, C504, C505, C506, C507, C508, C509, C510, C511, C512, C513, C514, C515, C516, C517, C518, C519, C520, C521, C522, C523, C524, C525, C526, C527, C528, C529, C530, C531, C532, C533, C534, C535, C536, C537, C538, C539, C540, C541, C542, C543, C544, C545, C546, C547, C548, C549, C550, C551, C552, C553, C554, C555, C556, C557, C558, C559, C560, C561, C562, C563, C564, C565, C566, C567, C568, C569, C570, C571, C572, C573, C574, C575, C576, C577, C578, C579, C580, C581, C582, C583, C584, C585, C586, C587, C588, C589, C590, C591, C592, C593, C594, C595, C596, C597, C598, C599, C600, C601, C602, C603, C604, C605, C606, C607, C608, C609, C610, C611, C612, C613, C614, C615, C616, C617, C618, C619, C620, C621, C622, C623, C624, C625, C626, C627, C628, C629, C630, C631, C632, C633, C634, C635, C636, C637, C638, C639, C640, C641, C642, C643, C644, C645, C646, C647, C648, C649, C650, C651, C652, C653, C654, C655, C656, C657, C658, C659, C660, C661, C662, C663, C664, C665, C666, C667, C668, C669, C670, C671, C672, C673, C674, C675, C676, C677, C678, C679, C680, C681, C682, C683, C684, C685, C686, C687, C688, C689, C690, C691, C692, C693, C694, C695, C696, C697, C698, C699, C700, C701, C702, C703, C704, C705, C706, C707, C708, C709, C710, C711, C712, C713, C714, C715, C716, C717, C718, C719, C720, C721, C722, C723, C724, C725, C726, C727, C728, C729, C730, C731, C732, C733, C734, C735, C736, C737, C738, C739, C740, C741, C742, C743, C744, C745, C746, C747, C748, C749, C750, C751, C752, C753, C754, C755, C756, C757, C758, C759, C760, C761, C762, C763, C764, C765, C766, C767, C768, C769, C770, C771, C772, C773, C774, C775, C776, C777, C778, C779, C780, C781, C782, C783, C784, C785, C786, C787, C788, C789, C790, C791, C792, C793, C794, C795, C796, C797, C798, C799, C800, C801, C802, C803, C804, C805, C806, C807, C808, C809, C810, C811, C812, C813, C814, C815, C816, C817, C818, C819, C820, C821, C822, C823, C824, C825, C826, C827, C828, C829, C830, C831, C832, C833, C834, C835, C836, C837, C838, C839, C840, C841, C842, C843, C844, C845, C846, C847, C848, C849, C850, C851, C852, C853, C854, C855, C856, C857, C858, C859, C860, C861, C862, C863, C864, C865, C866, C867, C868, C869, C870, C871, C872, C873, C874, C875, C876, C877, C878, C879, C880, C881, C882, C883, C884, C885, C886, C887, C888, C889, C890, C891, C892, C893, C894, C895, C896, C897, C898, C899, C900, C901, C902, C903, C904, C905, C906, C907, C908, C909, C910, C911, C912, C913, C914, C915, C916, C917, C918, C919, C920, C921, C922, C923, C924, C925, C926, C927, C928, C929, C930, C931, C932, C933, C934, C935, C936, C937, C938, C939, C940, C941, C942, C943, C944, C945, C946, C947, C948, C949, C950, C951, C952, C953, C954, C955, C956, C957, C958, C959, C960, C961, C962, C963, C964, C965, C966, C967, C968, C969, C970, C971, C972, C973, C974, C975, C976, C977, C978, C979, C980, C981, C982, C983, C984, C985, C986, C987, C988, C989, C990, C991, C992, C993, C994, C995, C996, C997, C998, C999, C1000.

<b>WANG</b> ELECTRONICS, INC. LITTLE ROCK, ARK. 72202		BY DAN P. RYER	CHKD E. EMMER	APPROVED BY W. J. LEARY	DATE
MODEL NO. VS-300 REV. 10-253		TITLE ASSEMBLY DRAWING TELEX TAPE CONTROLLER			
DRAWN BY E. EMMER		210-8789		D 8789 9	




NO.	DATE	BY	APPROVED BY	DATE
240-8750	E 8750			5

KENNEDY TAPE

77  
22  
11  
17  
11  
8.5  
17  
22


22  
17  
11  
8.5  
17  
22

DO NOT USE SOCKET  
PINS 1, 2, 21, 28 WHEN  
USING (2171)




NO.	DATE	APPROVED BY	REV.
1	10/1/70		
2	10/1/70		
3	10/1/70		
4	10/1/70		
5	10/1/70		


KENNEDY TAPE  
210-8730 E 8730 5



DATE	BY	APPROVED BY	DATE
KENNEDY TAPE			
	20-8790	E	8790
			5




NO.	REVISION	DATE	APPROVED BY	DATE
1				
KENNEDY TAPE				
210-8790 E 8790				




DATE	BY	APP'D BY	REV
10-1-68	J. Kennedy	J. Kennedy	1
KENNEDY TAPE			
210-8790	8790	5	

TYPE	IC LOCATION	SPARES
74ALS02	L143	2
74ALS02	L274	2
74ALS139	L350	1
74ALS139	L271	1
74ALS139	L266	1
74ALS139	L269	1
74ALS139	L284	1
74ALS139	L305	1
74ALS00	L255A	2
74ALS04	L64	3
74ALS04	L135	2
74ALS04	L268	2
74ALS02	L309	3
74ALS04	L271	1
74ALS08	L265	1
74ALS08	L232A	2
74ALS20	L260	1
74ALS367	L145	2
74LS6	L11	3
74LS6	L144	3
74LS6	L269	2
74ALS12	L270	1
SPARE	L1A, 1-9, 24-35, 25A, 26A, 53A, 54-56, 58, 60-62, 74A, 74-B3, 102A, 103A, 103-111, 129A, 130A, 131-133, 154A, 156A, 178, 181A, 183A, 207A, 231A, 321A	

MEMORICLS	COUNT
REC	3411
BCRD	3048
BSY	3811
CS-LS	1311
CR	3614
LED-DB31	1K1
DBY	4014
DCO-DCI	5U1
DCN	5U1
EDT	5K1
EDT	4014
ERASE	5K1
FBY	4014
FEN	5U1
FPT	6414
FMR	5K1
GRIN	3514
GRD	1B1
GO	5K1
HOLD	3411
HER	5K1
IO	4814
IOO-EO3	3K1
IO2	3K1
INIT	7C14
IOREQ	3E1
IOCRDY	3C1
LDP	4C14
LWD	4E1
MS100-MS104	3U14
MS	3411
NRZ/PE	4814
OFFLINE	5U1
ONE	4014
ADD-AD7	4K14
ADP	4E14
ADY	4D14
REV	5K1
REGN	1K1
REWIND	5K1
REWIND	3E14
RSTR	4E14
RWD	4C14
SEL INIT	3E1
TADT	5U1
TACE	5U1
TIMER	3C14
WDP	4T1
WDD-WD7	4K1
WRT	5K1
WTR	4E14
WRM	5K1



C1, 14, 3, 5, 27, 27A, 28A, 28-55, 55A, 56-70, 71A, 71-97, 97A, 100A, 100-126, 126A, 127A, 129-131, 134A, 136-137, 137-152, 152A, 153, 154A, 163-167, 170, 172-178, 178A, 180, 181A, 190-200, 201A, 202-203, 203A, 204A, 205-206, 208-213, 213A, 215, 25A, 26, 236, 236A, 238, 238A, 239-253, 255A, 257, 257A, 258-277, 277A, 279-280




NOTE: ALL RES ARE UNLESS UNLESS OTHERWISE SPECIFIED

REV	DATE	APPROVED BY	DATE
VS-200			
KENNEDY TAPE			
210-6790	E 8790	5	



**WANG**  
 WANG LABS KENNEDY TAPE CONTROLLER  
 ASSEMBLY DRAWING  
 REV. 8 PER E.C.O. NO. 37821 9 OCT. 65

NOTES  
 1. UNLESS OTHERWISE SPECIFIED  
 ALL CAPACITORS ARE .047, EXPRESSED IN MICROFARADS.  
 ALL RESISTORS ARE 2.2K, 1/4W, 5% EXPRESSED IN OHMS.  
 2. C154-162, 168, 169, 171, 181-189, 201, 204, 207 ARE .1.  
 3. R31, 63, 70 ARE 1K 5%.



8790-1 COMPONENT SIDE

CARD EXTRACTOR  
 465-1255, 2 REED.

210-8190

615-2810 LABEL

350-0090

2395-1

SCREW, NO. 4-40 650-2100  
 NUT, HEX. NO. 4-40 652-2003  
 SELF LO 5 REED.

615-2825 LABEL

E-REV


STIFFENER  
 452-2772  
 INSTALL CIRCUIT SIDE

615-2828 LABEL

17"  
 11"  
 8.5"  
 8.5"  
 11"  
 17"

17"  
 11"  
 8.5"  
 8.5"  
 11"  
 17"

2831



US-XXX CPU INDEX

PAGE	CONTENTS
1.	CLOCK ISLAND
2.	MICRO-INSTRUCTION REGISTER
3.	COMMAND FUNCTIONS
4.	TRAP STACK, CASE_ON(ARGUMENT)
5.	MICRO-INSTRUCTION ADDRESS GENERATOR
6.	REGISTER FILE DATA SELECT, A-REGISTER FILE
7.	B-REGISTER FILE
8.	REGISTER FILE ADDRESS GENERATOR
9.	A-PORT INPUTS
10.	PROCESSOR STATE REGISTER, PROGRAM CONTROL WORD
11.	B-PORT INPUTS
12.	A-PORT, B-PORT INPUT SELECT CONTROL STORE BANK SELECT
13.	ARITHMETIC LOGIC UNIT
14.	BUFFERED FILE DATA AND ALU RESULT NEXT INSTRUCTION ADDRESS
15.	ALU SHIFTER
16.	MICRO-TEST SELECT
17.	CONTROL STORE READ/WRITE CONTROL
18.	CONTROL STORE
19.	EXTERNAL SIGNAL BUFFERS
20.	CPU SUPPORT LINK AND SUPPORT PACKET BUS
21.	CPU INPUT/OUTPUT PIN LIST


E-REV  
3

WANG LABORATORIES, INC.	REV: R6
TITLE: US-XXX CPU	DATE: 02/13/84
ENGINEER:	PAGE: 0 OF 21




7.7  
11  
8.5  
8.5  
11  
17  
22


22  
17  
11  
8.5  
8.5  
11  
17  
22




WANG LABORATORIES, INC.	REV: 6
TITLE: VS-XXX CPU	DATE: 7/5/83
ENGINEER:	PAGE: 2 OF 2/



WANG LABORATORIES, INC.	REV: 6
TITLE: US-XXX CPU	DATE: 7/6/83
ENGINEER:	PAGE: 3 OF 21




WANG LABORATORIES, INC.	REV: 6
TITLE: US-XXX CPU	DATE: 7/11/83
ENGINEER:	PAGE: 4 OF 21



WANG LABORATORIES, INC.	REV: 6
TITLE: VS-XXX CPU	DATE: 7/12/83
ENGINEER:	PAGE: 5 OF 21

7.7  
11  
9.8  
8.5  
11  
17  
22

22  
17  
11  
9.8  
8.5  
11  
17  
22



WANG LABORATORIES, INC.		REV: 6
TITLE: US-XXX CPU		DATE: 7/14/83
ENGINEER:		PAGE: 8 OF 21



77

11.71

11

5.8

8.5

11

17

22

22

11.71

11


5.8

8.5

11


17

22



WANG LABORATORIES, INC.      REV: 6  
 TITLE: US-XXX CPU              DATE: 7/14/83  
 ENGINEER:                          PAGE: 7 OF 21





WANG LABORATORIES, INC.		REV: 6
TITLE: VS-XXX CPU		DATE: 7/18/83
ENGINEER:		PAGE: 8 OF 2/

77

77

11

11

11

11

5.8

5.8

8.5

8.5

11


11

17

17


22

22




WANG LABORATORIES, INC.	REV: 6
TITLE: US-XXX CPU	DATE: 7/18/83
ENGINEER:	PAGE: 10 OF 21






WANG LABORATORIES, INC.		REV: 6
TITLE: US-XXX CPU		DATE: 7/18/83
ENGINEER:		PAGE: 12 OF 21




WANG LABORATORIES, INC.	REV: 6
TITLE: US-XXX CPU	DATE: 7/20/83
ENGINEER:	PAGE: 13 OF 21




WANG LABORATORIES, INC.	REV: 6
TITLE: US-XXX CPU	DATE: 7/20/83
ENGINEER:	PAGE: 14 OF 27






(WANG) LABORATORIES, INC.      REV: 6  
 TITLE: VS-XXX CPU              DATE: 7/20/83  
 ENGINEER:                          PAGE: 15 OF 27


22"      17"      8.5"      11"      11"      5.8"      11"      11"      22"



WANG LABORATORIES, INC.	REV: 6
TITLE: US-XXX CPU	DATE: 7/20/53
ENGINEER:	PAGE: 18 OF 21















WANG LABORATORIES, INC.	REV: 6
TITLE: US-XXX CPU	DATE: 7/20/83
ENGINEER:	PAGE: 17 OF 21



WANG LABORATORIES, INC.	REV: 6
TITLE: US-XXX CPU	DATE: 7/20/83
ENGINEER:	PAGE: 18 OF 21


77  
17  
11  
9.8  
8.5  
11  
17  
22

22  
17  
11  
9.8  
8.5  
11  
17  
22




NOTE: WHEN 18K X 17 CONTROL STORE RAMS ARE INSTALLED:  
 1. INSERT WANG PART NO. 376-8816, 74F81834, IN L188.  
 2. INSERT WANG PART NO. 376-8876, 74F258, IN L288.

WANG LABORATORIES, INC.		REV: 6
TITLE: VS-XXX CPU		DATE: 7/20/83
ENGINEER:		PAGE: 19 OF 21



WANG LABORATORIES, INC.	REV: 6
TITLE: US-XXX CPU	DATE: 7/20/83
ENGINEER:	PAGE: 20 OF 21



CONNECTOR A

- A-001 GND
- A-002 +5V
- A-003 XPPWR
- A-004 FPUID
- A-005 FPCOE
- A-006 FPCOE
- A-007 FPCOE
- A-008 FPCOE
- A-009 FPCOE
- A-010 FPCOE
- A-011 FPCOE
- A-012 FPCOE
- A-013 FPCOE
- A-014 FPCOE
- A-015 FPCOE
- A-016 FPCOE
- A-017 FPCOE
- A-018 FPCOE
- A-019 FPCOE
- A-020 FPCOE
- A-021 FPCOE
- A-022 FPCOE
- A-023 FPCOE
- A-024 FPCOE
- A-025 FPCOE
- A-026 FPCOE
- A-027 FPCOE
- A-028 FPCOE
- A-029 FPCOE
- A-030 FPCOE
- A-031 FPCOE
- A-032 FPCOE
- A-033 FPCOE
- A-034 FPCOE
- A-035 FPCOE
- A-036 FPCOE
- A-037 FPCOE
- A-038 FPCOE
- A-039 FPCOE
- A-040 FPCOE
- A-041 FPCOE
- A-042 FPCOE
- A-043 FPCOE
- A-044 FPCOE
- A-045 FPCOE
- A-046 FPCOE
- A-047 FPCOE
- A-048 FPCOE
- A-049 FPCOE
- A-050 FPCOE
- A-051 FPCOE
- A-052 FPCOE
- A-053 FPCOE
- A-054 FPCOE
- A-055 FPCOE
- A-056 FPCOE
- A-057 FPCOE
- A-058 FPCOE
- A-059 FPCOE
- A-060 FPCOE
- A-061 FPCOE
- A-062 FPCOE
- A-063 FPCOE
- A-064 FPCOE
- A-065 FPCOE
- A-066 FPCOE
- A-067 FPCOE
- A-068 FPCOE
- A-069 FPCOE
- A-070 FPCOE
- A-071 FPCOE
- A-072 FPCOE
- A-073 FPCOE
- A-074 FPCOE
- A-075 FPCOE
- A-076 FPCOE
- A-077 FPCOE
- A-078 FPCOE
- A-079 FPCOE
- A-080 FPCOE
- A-081 FPCOE
- A-082 FPCOE
- A-083 FPCOE
- A-084 FPCOE
- A-085 FPCOE
- A-086 FPCOE
- A-087 FPCOE
- A-088 FPCOE
- A-089 FPCOE
- A-090 FPCOE
- A-091 FPCOE
- A-092 FPCOE
- A-093 FPCOE
- A-094 FPCOE
- A-095 FPCOE
- A-096 FPCOE
- A-097 FPCOE
- A-098 FPCOE
- A-099 FPCOE
- A-100 FPCOE

CONNECTOR B

- B-001 GND
- B-002 +5V
- B-003 MEMCLK
- B-004 GND
- B-005 GND
- B-006 GND
- B-007 GND
- B-008 GND
- B-009 GND
- B-010 GND
- B-011 GND
- B-012 GND
- B-013 GND
- B-014 GND
- B-015 GND
- B-016 GND
- B-017 GND
- B-018 GND
- B-019 GND
- B-020 GND
- B-021 GND
- B-022 GND
- B-023 GND
- B-024 GND
- B-025 GND
- B-026 GND
- B-027 GND
- B-028 GND
- B-029 GND
- B-030 GND
- B-031 GND
- B-032 GND
- B-033 GND
- B-034 GND
- B-035 GND
- B-036 GND
- B-037 GND
- B-038 GND
- B-039 GND
- B-040 GND
- B-041 GND
- B-042 GND
- B-043 GND
- B-044 GND
- B-045 GND
- B-046 GND
- B-047 GND
- B-048 GND
- B-049 GND
- B-050 GND
- B-051 GND
- B-052 GND
- B-053 GND
- B-054 GND
- B-055 GND
- B-056 GND
- B-057 GND
- B-058 GND
- B-059 GND
- B-060 GND
- B-061 GND
- B-062 GND
- B-063 GND
- B-064 GND
- B-065 GND
- B-066 GND
- B-067 GND
- B-068 GND
- B-069 GND
- B-070 GND
- B-071 GND
- B-072 GND
- B-073 GND
- B-074 GND
- B-075 GND
- B-076 GND
- B-077 GND
- B-078 GND
- B-079 GND
- B-080 GND
- B-081 GND
- B-082 GND
- B-083 GND
- B-084 GND
- B-085 GND
- B-086 GND
- B-087 GND
- B-088 GND
- B-089 GND
- B-090 GND
- B-091 GND
- B-092 GND
- B-093 GND
- B-094 GND
- B-095 GND
- B-096 GND
- B-097 GND
- B-098 GND
- B-099 GND
- B-100 GND


CONNECTOR C

- C-001 GND
- C-002 +5V
- C-003 RESET
- C-004 DB18
- C-005 DB18
- C-006 DB18
- C-007 DB18
- C-008 DB18
- C-009 DB18
- C-010 DB18
- C-011 DB18
- C-012 DB18
- C-013 DB18
- C-014 DB18
- C-015 DB18
- C-016 DB18
- C-017 DB18
- C-018 DB18
- C-019 DB18
- C-020 DB18
- C-021 DB18
- C-022 DB18
- C-023 DB18
- C-024 DB18
- C-025 DB18
- C-026 DB18
- C-027 DB18
- C-028 DB18
- C-029 DB18
- C-030 DB18
- C-031 DB18
- C-032 DB18
- C-033 DB18
- C-034 DB18
- C-035 DB18
- C-036 DB18
- C-037 DB18
- C-038 DB18
- C-039 DB18
- C-040 DB18
- C-041 DB18
- C-042 DB18
- C-043 DB18
- C-044 DB18
- C-045 DB18
- C-046 DB18
- C-047 DB18
- C-048 DB18
- C-049 DB18
- C-050 DB18
- C-051 DB18
- C-052 DB18
- C-053 DB18
- C-054 DB18
- C-055 DB18
- C-056 DB18
- C-057 DB18
- C-058 DB18
- C-059 DB18
- C-060 DB18
- C-061 DB18
- C-062 DB18
- C-063 DB18
- C-064 DB18
- C-065 DB18
- C-066 DB18
- C-067 DB18
- C-068 DB18
- C-069 DB18
- C-070 DB18
- C-071 DB18
- C-072 DB18
- C-073 DB18
- C-074 DB18
- C-075 DB18
- C-076 DB18
- C-077 DB18
- C-078 DB18
- C-079 DB18
- C-080 DB18
- C-081 DB18
- C-082 DB18
- C-083 DB18
- C-084 DB18
- C-085 DB18
- C-086 DB18
- C-087 DB18
- C-088 DB18
- C-089 DB18
- C-090 DB18
- C-091 DB18
- C-092 DB18
- C-093 DB18
- C-094 DB18
- C-095 DB18
- C-096 DB18
- C-097 DB18
- C-098 DB18
- C-099 DB18
- C-100 DB18

CONNECTOR J1

- D-001 GND
- D-002 DB18
- D-003 DB18
- D-004 DB18
- D-005 DB18
- D-006 DB18
- D-007 DB18
- D-008 DB18
- D-009 DB18
- D-010 DB18
- D-011 DB18
- D-012 DB18
- D-013 DB18
- D-014 DB18
- D-015 DB18
- D-016 DB18
- D-017 DB18
- D-018 DB18
- D-019 DB18
- D-020 DB18
- D-021 DB18
- D-022 DB18
- D-023 DB18
- D-024 DB18
- D-025 DB18
- D-026 DB18
- D-027 DB18
- D-028 DB18
- D-029 DB18
- D-030 DB18
- D-031 DB18
- D-032 DB18
- D-033 DB18
- D-034 DB18
- D-035 DB18
- D-036 DB18
- D-037 DB18
- D-038 DB18
- D-039 DB18
- D-040 DB18
- D-041 DB18
- D-042 DB18
- D-043 DB18
- D-044 DB18
- D-045 DB18
- D-046 DB18
- D-047 DB18
- D-048 DB18
- D-049 DB18
- D-050 DB18
- D-051 DB18
- D-052 DB18
- D-053 DB18
- D-054 DB18
- D-055 DB18
- D-056 DB18
- D-057 DB18
- D-058 DB18
- D-059 DB18
- D-060 DB18
- D-061 DB18
- D-062 DB18
- D-063 DB18
- D-064 DB18
- D-065 DB18
- D-066 DB18
- D-067 DB18
- D-068 DB18
- D-069 DB18
- D-070 DB18
- D-071 DB18
- D-072 DB18
- D-073 DB18
- D-074 DB18
- D-075 DB18
- D-076 DB18
- D-077 DB18
- D-078 DB18
- D-079 DB18
- D-080 DB18
- D-081 DB18
- D-082 DB18
- D-083 DB18
- D-084 DB18
- D-085 DB18
- D-086 DB18
- D-087 DB18
- D-088 DB18
- D-089 DB18
- D-090 DB18
- D-091 DB18
- D-092 DB18
- D-093 DB18
- D-094 DB18
- D-095 DB18
- D-096 DB18
- D-097 DB18
- D-098 DB18
- D-099 DB18
- D-100 DB18

(WANG) LABORATORIES, INC.	REV: 6
TITLE: US-XXX CPU	DATE: 1/29/84
ENGINEER:	PAGE: 21 OF 21



77  
17"  
11"  
8.5"

22"  
17"  
11"  
8.5"

8.5"  
11"

8.5"  
11"

17"

17"

22"

22"

- NOTES:
- UNLESS OTHERWISE SPECIFIED:  
ALL CAPACITORS ARE .047UF EXPRESSED IN MICROFARADS.  
ALL RESISTORS ARE 1/4W .5% EXPRESSED IN OHMS.
  - INSTALL JUMPER PLS 88V1374-9129\* 3 PLCS ON L58.
  - 16X117 RAM CHIPS REPLACE 16X84 RAM CHIPS AND ASSOCIATED .1 CAPACITORS.
  - FIN 1 OF ALL SIPS FACE TOWARDS THE STIFFENER.
  - REFERENCE SCHEMATIC LAYOUT CHART OR PARTS LIST FOR JUMPER CONFIGURATION.

SEE NOTE 4.  
#38 GAUGE SOLID TWISTED PAIR WIRE- APPROX. 5 TURNS PER [1/4] SHOWN AS SEPARATE WIRE ONLY TO ILLUSTRATE CONNECTIONS!!!  
USE #28 GAUGE BUSH (#145-688-9827) FOR REMAINING CONNECTIONS.

SEE NOTE 5

MOD CIRCUIT SIDE  
GROUND BAR 458-1715  
INSULATOR FISH PAPER 14 3/8" X 1 1/4" 615-8443

		BY	DATE	APPROVED BY	DATE
		DWN DCT	7-1-64	E ENBR	
MATERIAL		CHK		H ENBR	
MODEL NO. VS-300		E.C. CONTROL			
SEE SCHEMATIC LAYOUT CHART OR PARTS LIST FOR JUMPER CONFIGURATION NO. 10-214		TITLE VS300 CPU			
FINISH		210-8931	C	8831	6



#8832 R 02

E-REV #04

ADDRESS GENERATION UNIT (AGU) INDEX

1. AGU REGISTER FILE
2. EA(00:31) CALCULATION
3. IR0, IR1 IQ INPUT MUX
4. IR2 IQ INPUT MUX
5. IQ REGISTERS, IRE
6. VAR1, VAR2
7. VA MUX
8. VAR, FP LONG EA, SS NWAY
9. IQ CONTROL, INSTRUCTION DECODING
10. ESU REGISTER FILE ADDRESSING
11. ESU REGISTER FILE, EALU
12. ESU CONTROL STORE, MIR
13. DISPATCH ADDRESS LOGIC
14. EA(01:07) CALCULATION
15. PULL-UP RESISTORS
16. AGU CLOCKS, INVERTERS, BUFFERS
17. BVA, DB, BUFFERS
18. REAL-TIME CLOCK
19. BACKPLANE AND CONNECTORS

DRAWING LAST MODIFIED Mon Aug 28 09:03:14 1985

WANG LABORATORIES, INC.	REV: 8832R0204
TITLE: US-300 AGU SCHEMATICS	DATE: 08/15/85
ENGINEER: W. S. ZUK X76272	PAGE: 0 OF 19

77

77

11

11

11

11

8.5

8.5

8.5

8.5

11


11

17

17


22

22



22" 17" 11" 8.5" 11" 8.5" 17" 22"

22" 17" 11" 8.5" 11" 8.5" 17" 22"



DRAWING LAST MODIFIED Wed Jun 5 14:58:31 1985

WANG LABORATORIES, INC.	REV: 00000002
TITLE: VS-300 AGU SCHEMATICS	DATE: 03/06/85
ENGINEER:	PAGE: 2 OF 19

77

"11

"11


"5.8

8.5"

11"

17"

22"



REWORKING LAST MODIFIED Jun 5 15:01:04 1985

WANG LABORATORIES, INC.		REV: 6883282
TITLE: US-300 AQU SCHEMATICS		DATE: 01/19/85
ENGINEER:		PAGE: 3 OF 19

"22

"11

"11

"5.8

8.5"

11"

17"

22"

77

17"

11"


8.5"

8.5"

11"

17"

22"



DEBATING LAST MODIFIED Jun 5 15:03:21 1985

WANG LABORATORIES, INC.	REV: 6663062
TITLE: VS-300 FGU SCHEMATICS	DATE: 01/18/85
ENGINEER:	PAGE: 4 OF 19

22"

17"

11"


8.5"

8.5"

11"

17"

22"



DRAWING LAST MODIFIED Wed Jun 5 15:06:24 1985

WANG LABORATORIES, INC.		REV: 08832002
TITLE: US-300 AGU SCHEMATICS		DATE: 03/06/85
ENGINEER:		PAGE: 5 OF 19

77

"11"

"11"


"5.8"

8.5"

11"

17"

22"



DEBATING LAST MODIFIED Jun 5 15:00:10 1985

WANG LABORATORIES, INC. REV: 48932982

TITLE: VS-380 RGU SCHEMATICS DATE: 01/22/85

ENGINEER: PAGE: 6 OF 19

"22"

"11"

"11"

"5.8"

8.5"

11"

17"

22"

77

22"

11"

11"

8.5"

8.5"

17"

17"

11"

11"

8.5"

8.5"

11"

11"

8.5"

8.5"

11"

11"

8.5"

8.5"

11"

11"

8.5"

8.5"

11"


11"

8.5"

8.5"

11"

11"




DRAWING LAST MODIFIED Jun 5 15:12:30 1985  
 WANG LABORATORIES, INC.  
 TITLE: V5-300 ACU SCHEMATICS  
 REV: 49832982  
 DATE: 01/18/85  
 ENGINEER:  
 PAGE: 7 OF 19



7.7  
11  
11  
9.8  
8.5  
11  
8.5  
17  
22

22  
17  
11  
9.8  
8.5  
11  
17  
22



DRAWING LAST\_MODIFIED=Wed Jun 5 15:15:37 1985

WANG LABORATORIES, INC.	REV: 0832R02
TITLE: US-300 AGU SCHEMATICS	DATE: 05/31/85
ENGINEER:	PAGE: 8 OF 19



77

22

11

11

11

11

5.8

5.8

8.5

8.5

11


11

17

17


22

22




DRAWING, LGRT, MODIFIED-Mon Aug 28 09:35:34 1985

WANG	LABORATORIES, INC.	REV: 883R82E34
TITLE:	U3-300 AGU SCHEMATICS	DATE: 08/15/85
ENGINEER:		PAGE: 10 OF 19



DRAWING LAST MODIFIED Mon Aug 28 00:55:25 1985

WANG LABORATORIES, INC.	REV: 8832R02E04
TITLE: US-300 AGU SCHEMATICS	DATE: 08/15/85
ENGINEER:	PAGE: 11 OF 19



7.7  
17"  
11"  
8.5"  
8.5"  
11"  
17"  
22"

22"  
17"  
11"  
8.5"  
8.5"  
11"  
17"  
22"

WANG LABORATORIES, INC.		REV: 8832R82E04
TITLE: VS-300 AGU SCHEMATICS		DATE: 08/15/85
ENGINEER:		PAGE: 12 OF 19

DRAWING LAST\_MODIFIED=Mon Aug 26 10:31:48 1985

77

11

11


5.8

8.5

11

17

22



DEBAILING, LAST MODIFIED Jun 5 14:38:12 1985

WANG LABORATORIES, INC.	REV: A983282
TITLE: US-300 RCU SCHEMATICS	DATE: 03/01/85
ENGINEER: /	PAGE: 13 OF 19

77

11

11

5.8

8.5


11

17

22

22" 17" 11" 8.5" 8.5" 11" 17" 22"

22" 17" 11" 8.5" 8.5" 11" 17" 22"




\_DRAWING\_LAST\_MODIFIED=Wed Jun 5 14:39:54 1985

WANG LABORATORIES, INC.		REV: 003202
TITLE: US-300 AGU SCHEMATICS		DATE: 11/21/83
ENGINEER:		PAGE: 14 OF 19

77  
17  
11  
9.8  
8.5  
11  
17  
22

22  
17  
11  
9.8  
8.5  
11  
17  
22




DRAWING LAST MODIFIED=Wed Jun 5 14:41:15 1985

(WANG) LABORATORIES, INC.	REV: 00832082
TITLE: VS-300 AGU SCHEMATICS	DATE: 05/31/85
ENGINEER:	PAGE: 15 OF 19



77  
17  
11  
9.8  
8.5  
11  
17  
22

22  
17  
11  
9.8  
8.5  
11  
17  
22




DRAWING LAST\_MODIFIED=Wed Jun 5 14:43:09 1985

WANG LABORATORIES, INC.	REV: #8832R82
TITLE: US-300 AGU SCHEMATICS	DATE: 05/31/85
ENGINEER:	PAGE: 16 OF 19


7.7  
17  
11  
8.5  
8.5  
11  
17  
22

22  
17  
11  
8.5  
8.5  
11  
17  
22



WANG LABORATORIES, INC.	REV: 0032002
TITLE: US-300 AGU SCHEMATICS	DATE: 05/31/85
ENGINEER:	PAGE: 17 OF 19

DRAWING LAST MODIFIED Wed Jun 5 14:45:32 1985



DRAWING LAST\_MODIFIED=Mon Aug 26 10:40:10 1985

WANG LABORATORIES, INC.	REV: 08032002
TITLE: US-300 AGU SCHEMATICS	DATE: 05/31/85
ENGINEER:	PAGE: 18 OF 19

77

" 11 "

" 11 "


" 5.8 "

8.5"

11"

17"

22"



REVISIONS LAST MODIFIED: Jun 5 14:53:06 1985

WANG LABORATORIES, INC.	REV: 4883R82
TITLE: US-300 AGU SCHEMATICS	DATE: 05/23/85
ENGINEER:	PRG: 19 OF 19

" 22 "

" 11 "

" 11 "


" 5.8 "

8.5"

11"

17"

22"



THIS DRAWING AND THE DATA THEREON ARE THE PROPERTY OF WANG AND COMPANY, INC. AND ARE TO BE USED ONLY FOR THE PROJECT AND FOR THE QUANTITY SPECIFIED THEREON. ANY REUSE OR REPRODUCTION OF THIS DRAWING WITHOUT THE WRITTEN CONSENT OF WANG AND COMPANY IS PROHIBITED. IF YOU ARE REPRODUCING THIS DRAWING, YOU MUST OBTAIN THE WRITTEN CONSENT OF WANG AND COMPANY. THE COMPANY WILL BE RESPONSIBLE FOR THE PROTECTION OF THIS DRAWING.

NOTES:  
 1. UNLESS OTHERWISE SPECIFIED,  
 ALL CAPACITORS ARE 50VUF EXPRESSED IN MICROFARADS.  
 ALL SIPS ARE 300 EXPRESSED IN OHMS.

<b>WANG</b>		BY	DATE	APPROVED BY	DATE
MATERIAL	MODEL NO. VS300	OWN DCI		E ENGR	
	10-214	CHR		M ENGR	
		E. C. CONTROL		MFG ENGR	
FINISH		TITLE VS300 AGU			
		214-8832	C	8832	6

# VS-300 ATU INDEX

PAGE #	CONTENTS
1.	VIRTUAL ADDRESS BUFFERS, TRANSLATION BUFFER BYPASS, X-BUS TRANSCEIVER, X-BUS LATCH, TRANSLATION BUFFER PARITY GEN.
2.	TRANSLATION BUFFER STORE, TRANSLATION BUFFER PARITY CHECK, TRANSLATION BUFFER TAG COMPARE
3.	PHYSICAL ADDRESS REG. (PAR), PHYSICAL INSTRUCTION ADDRESS REG. (PIAR), PHYSICAL ADDRESS MUX
4.	WRITE INSTRUCTION QUEUE DETECT, CURRENT RING OF EXECUTION, PROTECTION CHECKS, TRANSLATION BUFFER TAG BUFFER
5.	ADDRESS TRANSLATION BUFFER CONTROL, X-BUS CONTROL
6.	OCTAL FILL ADDR. REG, SYSTEM ADDR BUFFERS, INTER PROCESSOR COMMUNICATIONS REG, EXTERNAL MEMORY ADDR REG, CACHE ADDR DRIVERS, R/C ADDR DRIVERS
7.	CACHE TAG ADDR MUX, CACHE TAG DATA STORE, CACHE TAG PARITY LOGIC, CACHE TAG COMPARE LOGIC
8.	CACHE DATA STORE, CACHE PARITY DATA STORE, CACHE PARITY CHECK
9.	SYSTEM DATA BUS TRANSCEIVER, CACHE DATA STORE LATCH, CACHE PARITY DATA STORE LATCH
10.	WRITE REORDERING AND MERGE BUFFER
11.	READ REORDERING BUFFER
12.	D-BUS TRANSCEIVERS, SIGN EXTEND, ZERO FILL
13.	SYSTEM BUS INTERFACE CONTROL LOGIC
14.	CACHE CONTROLS
15.	MEMORY OP DECODING
16.	STATE MACHINES, EXTERNAL WRITE DETECTION
17.	IPC CONTROLS, RC TABLE, ATU CONTROL REG.
18.	CLOCK DRIVERS, INTERFACE BUFFERS
19.	I/O PIN LIST

E-REV

2

(WANG) LABORATORIES, INC.	REV: 4
TITLE: VS-300 ATU 8833	DATE: 7: 19: 85
ENGINEER: S. W. OLSON	PAGE: 8 OF 19

77

22

11

17

11

11

5.8

5.8

8.5

8.5

11


11

17

17

22

22



77

22

17

17

11

11

5.8

5.8

8.5

8.5

11


11

17

17

22


22



DRAWING VS000ATU.LOGIC.1.2  
 TRANSLATION BUF, TB TAG, TB PARITY  
 LAST\_MODIFIED=Wed Jul 17 09:45:48 1985



77  
11  
11  
5.8  
8.5  
11  
17  
22



22  
17  
11  
5.8  
8.5  
11  
17  
22


DRAWING: US00XATU.LOGIC.1.3  
PAR, PIAR, PA MUX  
LAST\_MODIFIED=Wed Jul 17 09:51:13 1985

WANG LABORATORIES, INC.	REV: 4
TITLE: US-300 ATU 8833	DATE: 7:19:85
ENGINEER:	PAGE: 3 OF 19




77  
 17  
 11  
 9.8  
 8.5  
 11  
 17  
 22

22  
 17  
 11  
 9.8  
 8.5  
 11  
 17  
 22



DRAWING V51000ATU.LOIC.1.5  
 D-BUS SEL DECODE, ADDR TRANS CONTROL, X-BUS CONTROL  
 LAST\_MODIFIED=Wed Jul 17 18:30:23 1985

WANG LABORATORIES, INC.	REV: 4
TITLE: VS-300 ATU 8833	DATE: 7:19:85
ENGINEER:	PAGE: 5 OF 19



DRAWING US300ATU.LGIC.1.B  
 OCTAL FULL ADDR REG, EXTERNAL ADDR REG, IPC REG  
 SYSTEM ADDRESS DRIVER, CACHE ADDRESS DRIVERS, RC ADDR DRIVER  
 LAST\_MODIFIED=Wed Jul 17 10:38:42 1985

WANG LABORATORIES, INC.	REV: 4
TITLE: US-300 ATU 8833	DATE: 7: 18: 85
ENGINEER:	PAGE: 8 OF 19

77

22"

17"

17"

11"

11"

8.5"

8.5"

8.5"

8.5"

11"


11"

17"

17"

22"

22"




DRAWING: V800ATU.LOGIC.1.7  
 TAG ADDR MUX, TAG DATA STORE  
 TAG PARITY, TAG COMPARE LOGIC  
 LAST\_MODIFIED=Wed Jul 17 10:47:41 1985

WANG LABORATORIES, INC.	REV: 4
TITLE: V8-300 ATU 8833	DATE: 7:19:85
ENGINEER:	PAGE: 7 OF 19


77  
17"  
11"  
8.5"  
8.5"  
11"  
17"  
22"

22"  
17"  
11"  
8.5"  
8.5"  
11"  
17"  
22"



DRAWING US-300 ATU LOGIC 1.0  
CACHE DATA STORE, CACHE PARITY CHECK  
LAST MODIFIED: Wed Jul 17 11:02:11 1985

WANG LABORATORIES, INC.	REV: 4
TITLE: US-300 ATU 8833	DATE: 7:19:85
ENGINEER:	PAGE: 8 OF 19



DRAWING: US000ATU.LOGIC.1-B  
 SYSTEM DATA CURSOR, DATA STORE LATCH, DATA STORE PARITY LATCH  
 LAST\_MODIFIED=Thu Jul 18 09:36:45 1985


WANG LABORATORIES, INC.	REV: 4
TITLE: US-300 ATU 8833	DATE: 7:19:85
ENGINEER:	PAGE: 9 OF 19

77  
 11  
 11  
 5.8  
 8.5  
 11  
 17  
 22

22  
 17  
 11  
 8.5  
 8.5  
 11  
 17  
 22

77  
11  
9.8  
8.5  
11  
17  
22


22  
11  
9.8  
8.5  
11  
17  
22



DRAWING: US300ATU.LOGIC.1.10  
WRITE REORDERING & MERGE BUFFER  
LAST\_MODIFIED: Wed Jul 17 11:07:06 1985

WANG LABORATORIES, INC.	REV: 4
TITLE: US-300 ATU 8833	DATE: 7:19:85
ENGINEER:	PAGE: 10 OF 19






DRAWING: USPOKATU.LOGIC.1.11  
 READ REORDERING BUFFER  
 LAST\_MODIFIED=Thu Jul 18 09:48:35 1985

WANG LABORATORIES, INC.	REV: 4
TITLE: VS-300 ATU 8833	DATE: 7:19:85
ENGINEER:	PAGE: 11 OF 19

77  
 "11"  
 "5.8"  
 8.5"  
 11"  
 17"  
 22"

"22"  
 "17"  
 "11"  
 "5.8"  
 8.5"  
 11"  
 17"  
 22"



DRAWING: VS000ATU.LOGIC.1.12  
 0-BUS XCVES, SIGN EXTEND, ZERO FILL  
 LAST\_MODIFIED=Wed Jul 17 13:22:47 1985

WANG LABORATORIES, INC.	REV: 4
TITLE: VS-300 ATU 8833	DATE: 7:18:85
ENGINEER:	PAGE: 12 OF 19

77

22

11

17

11

11

9.8

9.8

8.5

8.5

11


11

17

17

22

22




DRAWING US000ATU.LOGIC.1.13  
 LAST\_MODIFIED=Wed Jul 17 13:29:53 1985

WANG LABORATORIES, INC.	REV: 4
TITLE: US-300 ATU 8833	DATE: 7:19:85
ENGINEER:	PAGE: 13 OF 19

77  
 17  
 11  
 8.5  
 8.5  
 11  
 17  
 22

22  
 17  
 11  
 8.5  
 8.5  
 11  
 17  
 22



DRAWING: V5000ATU, LOGIC, 1.14  
 LAST\_MODIFIED: Wed Jul 17 13:36:12 1985  
 (WANG) LABORATORIES, INC. REV: 1  
 TITLE: V5-300 ATU 8633 DATE: 7:19:85  
 ENGINEER: PAGE: 14 OF 19



77

22

11

17

11

11

5.8

8.5

8.5

8.5

11


11

17

17

22

22



DRAWING: US000ATU.LOGIC.1.18  
 LAST\_MODIFIED: Wed Jul 17 15:18:38 1985

WANG LABORATORIES, INC.	REV: 4
TITLE: US-300 ATU 8833	DATE: 7:19:85
ENGINEER:	PAGE: 18 OF 19

77

22

11

11

5.8

5.8

8.5

8.5

11


11

17

17


22

22



DRAWING: US300ATU.LOGIC.1.17  
 REF: CHNG TABLE, IPC CONTROL, ATU CONTROL REG  
 LAST\_MODIFIED=Wed Jul 17 15:28:05 1985

WANG LABORATORIES, INC.	REV: 4
TITLE: VS-300 ATU 8833	DATE: 7:19:85
ENGINEER:	PAGE: 17 OF 19



DRAWING  
 CLOCK DRIVERS, INTERFACE BUFFERS  
 LAST MODIFIED Wed Jul 17 15:35:18 1985

WANG LABORATORIES, INC.		REV: 4
TITLE: VS-300 ATU 8833		DATE: 7:19:85
ENGINEER:		PAGE: 18 OF 19

VS3000ATU.LOGIC.1.18



77

22

17

17

11

11

5.8

5.8

8.5

8.5

11


11

17

17


22

22



WANG LABORATORIES, INC.		REV: 4
TITLE: US-300 ATU 8833		DATE: 7:18:85
ENGINEER: S. W. OLSON		PAGE: 18 OF 19

DRAWING: US000ATU.LOGIC.1.18  
 I/O PIN LIST  
 LAST\_MODIFIED=Wed Jul 17 15:48:30 1985




STIFFENER 452-3884  
 4-48 3/8" 3/8" PHH HD. 458-2188 (5 PL.)  
 4-48 SELF LOCKING NUT 452-2883 (5 PL.)

STIFFENER WIRE HOLDER 452-2774  
 4-48 3/8 PHH HD. 458-2131  
 4-48 SELF LOCKING NUT 452-2883  
 COMP. SIDE

615-2821  
 LABEL I.O.

615-2828  
 LABEL REV.

EXTRACTOR  
 405-1255  
 (2 PLC 8)



CIRCUIT SIDE  
 458-1708 GROUND  
 615-0463 INSULATOR FISH PAPER

NOTES  
 1. UNLESS OTHERWISE SPECIFIED,  
 ALL CAPACITORS ARE .001UF EXPRESSED IN MICROFARADS.  
 ALL RESISTORS ARE 1/4W 5% EXPRESSED IN OHMS.  
 ALL SIPS ARE 2% EXPRESSED IN OHMS.  
 2. PIN 1 OF ALL SIP PACKAGES FACE TOWARDS  
 THE STIFFENER.

<b>WANG</b>		BY	DATE	APPROVED BY	DATE
		Dwn DCT		E ENGR	
MATERIAL	MODEL NO. VS300	E L CONTRL	VS300 ATU		
		TITLE			
FINISH		210-8833	C	8833	4

22"

17"

11"

8.5"

8.5"

11"

17"

22"

22"

17"

11"

8.5"

8.5"

11"

17"

22"

US-300 MCU INDEX

PAGE	CONTENTS
1.	MEMORY CONTROLLER ADDRESS JUMPER CONFIGURATION CHART
2.	WRITE DATA LATCHES
3.	WRITE DATA MULTIPLEXER
4.	READ DATA LATCHES (00:31)
5.	READ DATA LATCHES (32:63)
6.	SYNDROME BIT GENERATION
7.	ERROR DETECTION AND CORRECTION
8.	WRITE CHECK-BIT MULTIPLEXER, ADDRESS/DATA MULTIPLEXER
9.	MEMORY BUS DRIVERS
10.	REFRESH ADDRESS COUNTER
11.	SUPPORT PACKET BUS AND SUPPORT CONTROL REGISTER
12.	ERROR LOG, CHANGE TABLE, WRITE/READ CHECK-BIT REGISTERS
13.	SYSTEM DATA BUS TRANSCEIVERS, MEMCLK DRIVERS BUSY, WAIT, AND UMA CONTROLS
14.	DECODE AND CONTROL
15.	MEMORY AND REGISTERED CONTROLS
16.	INPUT/OUTPUT PIN LIST

DRAWING


US300MCU, IDX. 1.1  
INDEX PAGE

LAST\_MODIFIED=Thu Jul 11 11:18:31 1985

WANG LABORATORIES, INC.	REV: 4
TITLE: US-300 MCU 8834	DATE: 07/11/85
ENGINEER:	PAGE: 0 OF 16

7.7  
17  
11  
8.5  
8.5  
11  
17  
22

2.2  
17  
11  
8.5  
8.5  
11  
17  
22




WANG LABORATORIES, INC. REV: 4  
 TITLE: VS-300 MCU 8834 DATE: 07/11/85  
 ENGINEER: E. MANN PAGE: 1 OF 16

DRAWING:  
 VS300MCU LOGIC 1.1  
 MEMORY CONTROLLER ADDRESS  
 LAST\_MODIFIED=Thu Jul 11 14:31:25 1985

7.7  
11  
8.5  
8.5  
11  
17  
22

22  
17  
11  
8.5  
8.5  
11  
17  
22




DRAWING  
V8000MCU LOGIC 1.2  
WRITE DATA LATCHES  
LAST\_MODIFIED=Thu Jul 11 14:34:21 1985

WANG LABORATORIES, INC.	REV: 4
TITLE: US-300 MCU 8834	DATE: 07/11/85
ENGINEER:	PAGE: 2 OF 16

77  
17  
11  
9.8  
8.5  
11  
17  
22

22  
17  
11  
9.8  
8.5  
11  
17  
22




DRAWING  
 V8004MCU, LOGIC 1.3  
 WRITE DATA MULTIPLEXER  
 LAST\_MODIFIED=Thu Jul 11 14:38:38 1985

WANG LABORATORIES, INC.		REV: 4
TITLE: VS-300 MCU	8834	DATE: 07/11/85
ENGINEER:		PAGE: 3 OF 16

77  
17  
11  
8.5  
8.5  
11  
17  
22

22  
17  
11  
8.5  
8.5  
11  
17  
22



DRAWING  
 V8000MCU LOGIC 1.4  
 READ DATA LATCHES (80431)  
 LAST\_MODIFIED=Thu Jul 11 14:38:34 1985

WANG LABORATORIES, INC.		REV: 4
TITLE: VS-300 MCU	8834	DATE: 07/11/85
ENGINEER:		PAGE: 4 OF 16

77

11

11


8.5

11

8.5

17

22



VLSI LOGIC, LOC. 11, 8  
 REV'D DATA SHEETS (281 83)  
 LAST MODIFIED: THU JUL 11 14:40:38 1985

WANG LABORATORIES, INC.		REV: 4
TITLE: VS-300 MCU	8834	DATE: 07/11/85
ENGINEER:		PAGE: 5 OF 18

22

11

11

8.5

11

8.5


17

22



77  
17  
11  
8.5  
8.5  
11  
17  
22

22  
17  
11  
8.5  
8.5  
11  
17  
22




DRAWING  
 V8009MCU, LOGIC 1.8  
 SYNCHRONIC BIT GENERATION  
 LAST MODIFIED=THU JUL 11 14:43:17 1985

WANG LABORATORIES, INC.		REV: 4
TITLE: US-300 MCU	8834	DATE: 07/11/85
ENGINEER:		PAGE: 6 OF 16

77  
 17  
 11  
 8.5  
 8.5  
 11  
 17  
 22

22  
 17  
 11  
 8.5  
 8.5  
 11  
 17  
 22




DRAWING  
 VIDEO MCU LOGIC 1.7  
 ERROR DETECTION AND CORRECTION  
 LAST\_MODIFIED=Thu Jul 11 14:52:28 1985

WANG LABORATORIES, INC.	REV: 4
TITLE: US-300 MCU 8834	DATE: 07/11/85
ENGINEER:	PAGE: 7 OF 16

77  
 17  
 11  
 8.5  
 8.5  
 11  
 17  
 22

22  
 17  
 11  
 8.5  
 8.5  
 11  
 17  
 22




DRAWING  
 US300MCU LOGIC 1.8  
 WCB FLK  
 MKD FLK  
 LAST\_MODIFIED=Thu Jul 11 14:54:31 1985

WANG LABORATORIES, INC.		REV: 4
TITLE: US-300 MCU	8834	DATE: 07/11/85
ENGINEER:		PAGE: 8 OF 16

7.7  
11  
8.5  
8.5  
11  
17  
22

22  
11  
8.5  
8.5  
11  
17  
22




DRAWING  
 US300MCU LOGIC 1.9  
 MEMORY BUS DRIVERS  
 LAST MODIFIED=Thu Jul 11 14:56:51 1985

WANG LABORATORIES, INC.	REV: 4
TITLE: US-300 MCU 8834	DATE: 07/11/85
ENGINEER:	PAGE: 9 OF 16

77  
11  
9.8  
8.5  
11  
17  
22


22  
11  
9.5  
8.5  
11  
17  
22



DRAWING  
 V80000001 LOGIC 1.18  
 REFRESH ADDRESS COUNTER  
 LAST\_MODIFIED=Thu Jul 11 15:15:18 1985

WANG LABORATORIES, INC.		REV: 4
TITLE: VS-300 MCU	8834	DATE: 07/11/85
ENGINEER:		PAGE: 10 OF 18

77  
11  
11  
8.5  
8.5  
11  
17  
22




22  
11  
11  
8.5  
8.5  
11  
17  
22

DRAWING  
 US300MCU LOGIC 1.11  
 SUPPORT CONTROL REGISTER  
 LAST\_MODIFIED=Fri Jul 12 13:27:48 1985

WANG LABORATORIES, INC.		REV: 4
TITLE: US-300 MCU	8834	DATE: 07/11/85
ENGINEER:		PAGE: 11 OF 16

7.7  
 11  
 9.8  
 8.5  
 11  
 17  
 22


7.7  
 11  
 9.8  
 8.5  
 11  
 17  
 22



DRAWING  
 US300MCU LOGIC 1.18  
 CHANGE TABLE  
 ERROR LOG  
 HW/RD CHECKIT REQD  
 LAST\_MODIFIED=Thu Jul 11 18:18:28 1985

WANG LABORATORIES, INC.		REV: 4
TITLE: US-300 MCU	8834	DATE: 07/11/85
ENGINEER:		PAGE: 12 OF 16

77  
17  
11  
8.5  
8.5  
11  
17  
22



22  
17  
11  
8.5  
8.5  
11  
17  
22

DRAWING  
 US300MCU, LOGIC, 1.13  
 SYSTEM DATA BUS TRANSCEIVERS  
 LAST\_MODIFIED=Fri Jul 12 13:42:08 1985

WANG LABORATORIES, INC.		REV: 4
TITLE: US-300 MCU	8834	DATE: 07/11/85
ENGINEER:		PAGE: 13 OF 16



77

22

17

17

11

11

5.8

5.8

8.5

8.5

11


11

17

17

22

22




DRAWING  
 VLSI/ICU LOGIC 1.14  
 DECODE AND CONTROL  
 LAST\_MODIFIED=Fri Jul 12 13:20:43 1985

WANG LABORATORIES, INC.		REV: 4
TITLE: US-300 MCU	8834	DATE: 07/11/85
ENGINEER:		PAGE: 14 OF 16

77  
17  
11  
9.8  
8.5  
11  
8.5  
17  
22

22  
17  
11  
9.8  
8.5  
11  
8.5  
17  
22



DRAWING  
V80000MCU, LOGIC 1.18  
MEMORY AND REGISTER CONTROL  
LAST\_MODIFIED=Fri Jul 12 13:15:55 1985

WANG LABORATORIES, INC.		REV: 4
TITLE: US-300 MCU 8834	DATE: 07/11/85	
ENGINEER:	PAGE: 15 OF 16	

77  
17  
11  
8.5  
8.5  
11  
17  
22

22  
17  
11  
8.5  
8.5  
11  
17  
22

CONNECTOR A

A-001 GND  
A-003 +5V  
A-005  
A-007 GND  
A-008 MEM00\*  
A-011 GND  
A-013 MEM07\*  
A-015 GND  
A-017 MEM00\*  
A-018 MEM00\*  
A-021 SPS\*  
A-023 MEM00\*  
A-025 GND  
A-027 MEM02\*  
A-029 SPS\*  
A-031 MEM04\*  
A-033 SPS\*  
A-035 GND  
A-037 MEM02\*  
A-039 SPS\*  
A-041 MEM00\*  
A-043 SPS\*  
A-045 MEM10\*  
A-047 GND  
A-049 SPS\*  
A-051 MEM12\*  
A-053 SPS\*  
A-055 MEM14\*  
A-057 GND  
A-059 MEM10\*  
A-061 SPS\*  
A-063 SPS\*  
A-065 MEM10\*  
A-067 GND  
A-069 MEM00\*  
A-071 SPS\*  
A-073 MEM02\*  
A-075 SPS\*  
A-077 GND  
A-079 MEM04\*  
A-081 SPS\*  
A-083 MEM00\*  
A-085 SPS\*  
A-087 MEM00\*  
A-089 GND  
A-091 SPS\*  
A-093 MEM00\*  
A-095 SPS\*  
A-097 +5V  
A-099 GND

A-002 GND  
A-004 +5V  
A-006  
A-008 MEM04\*  
A-012 GND  
A-014 MEM00\*  
A-016 SPS\*  
A-018 MEM00\*  
A-020 SPS\*  
A-022 MEM00\*  
A-024 SPS\*  
A-026 MEM01\*  
A-028 SPS\*  
A-030 MEM03\*  
A-032 SPS\*  
A-034 SPS\*  
A-036 MEM00\*  
A-038 SPS\*  
A-040 MEM07\*  
A-042 GND  
A-044 MEM00\*  
A-046 SPS\*  
A-048 SPS\*  
A-050 MEM11\*  
A-052 GND  
A-054 MEM13\*  
A-056 SPS\*  
A-058 MEM13\*  
A-060 SPS\*  
A-062 SPS\*  
A-064 GND  
A-066 MEM17\*  
A-068 SPS\*  
A-070 MEM10\*  
A-072 MEM01\*  
A-074 GND  
A-076 SPS\*  
A-078 MEM02\*  
A-080 SPS\*  
A-082 MEM00\*  
A-084 GND  
A-086 MEM07\*  
A-088 SPS\*  
A-090 SPS\*  
A-092 MEM00\*  
A-094 GND  
A-096 MEM01\*  
A-098 +5V  
A-100 GND

CONNECTOR B

B-001 GND  
B-003 +5V  
B-005 GND  
B-007 OPEN  
B-009 GND  
B-011 SPS\*  
B-013 GND  
B-015 WAIT\*  
B-017 GND  
B-019 RFRSH\*  
B-021 RFRSH\*  
B-023 GND  
B-025 MATCHED\*  
B-027 GND  
B-029 GND  
B-031 GND  
B-033 WAIT\*  
B-035 BUSY\*  
B-037 UPR\*  
B-039 GND  
B-041 GND  
B-043 GND  
B-045 GND  
B-047 GND  
B-049 GND  
B-051 GND  
B-053 SPS\*  
B-055 SPS\*  
B-057 SPS\*  
B-059 SPS\*  
B-061 GND  
B-063 SPS\*  
B-065 SPS\*  
B-067 SPS\*  
B-069 SPS\*  
B-071 SPS\*  
B-073 SPS\*  
B-075 SPS\*  
B-077 SPS\*  
B-079 SPS\*  
B-081 SPS\*  
B-083 SPS\*  
B-085 GND  
B-087 SPS\*  
B-089 SPS\*  
B-091 SPS\*  
B-093 SPS\*  
B-095 SPS\*  
B-097 +5V  
B-099 GND

B-002 GND  
B-004 +5V  
B-006 MEM02\*  
B-008 GND  
B-010 GND  
B-012 GND  
B-014 GND  
B-016 GND  
B-018 GND  
B-020 GND  
B-022 GND  
B-024 MEM00\*  
B-026 GND  
B-028 FAST  
B-030 GND  
B-032 GND  
B-034 HCB\*  
B-036 HCB\*  
B-038 HCB\*  
B-040 HCB\*  
B-042 GND  
B-044 GND  
B-046 GND  
B-048 GND  
B-050 GND  
B-052 GND  
B-054 GND  
B-056 GND  
B-058 GND  
B-060 SPS\*  
B-062 SPS\*  
B-064 SPS\*  
B-066 SPS\*  
B-068 GND  
B-070 SPS\*  
B-072 SPS\*  
B-074 SPS\*  
B-076 SPS\*  
B-078 SPS\*  
B-080 GND  
B-082 SPS\*  
B-084 SPS\*  
B-086 SPS\*  
B-088 SPS\*  
B-090 SPS\*  
B-092 GND  
B-094 SPS\*  
B-096 SPS\*  
B-098 +5V  
B-100 GND


CONNECTOR C

C-001 GND  
C-003 +5V  
C-005 RESET\*  
C-007 MEM00\*  
C-009 SPS\*  
C-011 SPS\*  
C-013 MEM00\*  
C-015 SPS\*  
C-017 MEM07\*  
C-019 SPS\*  
C-021 MEM00\*  
C-023 GND  
C-025 SPS\*  
C-027 MEM41\*  
C-029 SPS\*  
C-031 SPS\*  
C-033 GND  
C-035 MEM40\*  
C-037 SPS\*  
C-039 SPS\*  
C-041 MEM47\*  
C-043 GND  
C-045 MEM40\*  
C-047 SPS\*  
C-049 MEM51\*  
C-051 SPS\*  
C-053 GND  
C-055 MEM53\*  
C-057 MEM54\*  
C-059 MEM55\*  
C-061 SPS\*  
C-063 MEM57\*  
C-065 SPS\*  
C-067 SPS\*  
C-069 MEM50\*  
C-071 SPS\*  
C-073 MEM51\*  
C-075 SPS\*  
C-077 SPS\*  
C-079 MEM53\*  
C-081 SPS\*  
C-083 XSLC\*  
C-085 MEM72\*  
C-087 SPS\*  
C-089 MEM74\*  
C-091 SPS\*  
C-093 MEM70\*  
C-095 GND  
C-097 +5V  
C-099 GND

C-002 GND  
C-004 +5V  
C-006 MEM32\*  
C-008 SPS\*  
C-010 MEM34\*  
C-012 SPS\*  
C-014 GND  
C-016 MEM30\*  
C-018 SPS\*  
C-020 MEM30\*  
C-022 SPS\*  
C-024 MEM40\*  
C-026 SPS\*  
C-028 MEM42\*  
C-030 SPS\*  
C-032 SPS\*  
C-034 MEM44\*  
C-036 SPS\*  
C-038 MEM40\*  
C-040 SPS\*  
C-042 SPS\*  
C-044 MEM40\*  
C-046 SPS\*  
C-048 MEM50\*  
C-050 SPS\*  
C-052 SPS\*  
C-054 SPS\*  
C-056 SPS\*  
C-058 MEM54\*  
C-060 SPS\*  
C-062 MEM58\*  
C-064 GND  
C-066 MEM50\*  
C-068 SPS\*  
C-070 SPS\*  
C-072 MEM50\*  
C-074 GND  
C-076 MEM52\*  
C-078 SPS\*  
C-080 MEM71\*  
C-082 SPS\*  
C-084 GND  
C-086 MEM73\*  
C-088 SPS\*  
C-090 MEM70\*  
C-092 INTR\*  
C-094 MEM77\*  
C-096 SPS\*  
C-098 +5V  
C-100 GND

DRAWING  
V8000MCU LOGIC 1.10  
FINGER CONNECTIONS  
LAST\_MODIFIED=Fri Jul 12 09:31:35 1985

WANG LABORATORIES, INC.		REV: 4
TITLE: VS-300 MCU	8834	DATE: 07/11/85
ENGINEER:		PAGE: 16 OF 16



THIS BOARD IS TO BE USED IN THE VS300 MCU. IT IS A SINGLE-SIDED BOARD WITH ALL COMPONENTS ON THE COMPONENT SIDE. THE BOARD IS TO BE MOUNTED ON A PCB WITH THE FOLLOWING DIMENSIONS: 22" X 17". THE BOARD IS TO BE MOUNTED ON A PCB WITH THE FOLLOWING DIMENSIONS: 22" X 17".


SCREW 458-2100  
NUT 452-2003  
(2 PLC'S)

615-2005 STIFFENER 452-2772 (INSTALL CAT. SIDE)

615-2000 LABEL I.O.

615-2020 LABEL REV

EXTRACTOR 445-1235 (2 PLC'S)



ADD CIRCUIT SIDE  
GROUND BAR 458-1112  
INSULATOR FISH PAPER 16 1/8" X 11 1/2" 615-8843

NOTES:  
1. UNLESS OTHERWISE SPECIFIED:  
ALL CAPACITORS ARE .001 EXPRESSED IN MICROFARADS.  
CAPACITORS C488-483 ARE .01UF 50V WPN. 388-4834.  
RESISTORS ARE EXPRESSED IN OHMS.  
RESISTORS R14-R17 ARE 1K WPN. 338-5811.  
RESISTORS R51-R11, R8 ARE 220/330 WPN. 333-8887 LOAD PIN 1 TOWARDS BOTTOM OF BOARD.  
RESISTORS R912, 13 ARE 270 WPN. 333-8844.  
RESISTOR R514, 18 IS WPN. 333-8837.  
INSTALL WPN. 374-9824 AT LOCATION L67, 133.  
2. REFERENCE SCHEMATIC PARTS LIST FOR JUMPER CONFIGURATIONS. JUMPERS ARE WPN 374-9129.

<b>WANG</b>		BY	DATE	APPROVED BY	DATE
MATERIAL	MODEL NO. VS300	DW	DCI	E	ENGR
FINISH	10-214	CHK		M	ENGR
		E C CONTROL		MFG	ENGR
		TITLE VS300 MCU			
		210-8834	C	8834	4

VS-300 SCU

SUPPORT CONTROL UNIT

8835 Rev 02

INDEX

1. TITLE PAGE
2. PCI INTERFACE
3. STATUS AND CONTROL REGISTERS, INTERRUPT, INITIALIZE
4. SAOR REG, SA BUFFER, SYSTEM ADDRESS DRIVERS
5. SA IN BUFFER, SAIR REG, SAIR BUFFER, SDOR REG
6. SYSTEM DATA BUS DRIVERS, SPARE GATES
7. SPB SERIAL REGISTER, SYSTEM DATA OUTPUT CONTROL
8. SUPPORT PACKET BUS CONTROL LOGIC
9. SYSTEM BUS CONTROL LOGIC, CLOCK BUFFERS
10. IPC RESPONSE LOGIC, SYSTEM BUS BUSY DRIVER
11. SYSTEM BUS TERMINATORS
12. SDIR REG, XSDIR REG
13. BACKPLANE CONNECTOR
14. BLOCK DIAGRAM

DRAWING:

TITLE=VS-300 SCU 8835 R02

ABBREV=SCU


VSXXXSCU.LOGIC.1.1

LAST\_MODIFIED=Mon Mar 18 12:07:27 1985

E-REV

1


WANG LABORATORIES, INC.	REV: 4
TITLE: VS-300 SCU 8835R02	DATE: 2/8/85
ENGINEER:	PAGE: 1 OF 14



HEX	READ	WRITE
00	STATUS 1	-
02	STATUS 2	-
04	-	-
08	-	-
0A	CTRL 1	CTRL 1
0C	CTRL 2	CTRL 2
0E	SPB CTRL	SPB CTRL
0C	SPB DATA	SPB DATA
10	/	SYSCHD
12	/	SPBCHD
14	/	SPBCHD
16	/	SPBCHD
18	/	-
1A	/	-
1C	/	-
1E	/	-
20	ADDRESS OUT 00.15	ADDRESS OUT 00.15
22	ADDRESS OUT 16.31	ADDRESS OUT 16.31
24	-	-
26	-	-
28	DATA OUT 00.15	DATA OUT 00.15
2A	DATA OUT 16.31	DATA OUT 16.31
2C	DATA OUT 32.47	DATA OUT 32.47
2E	DATA OUT 48.63	DATA OUT 48.63
30	ADDRESS IN 00.15	/
32	ADDRESS IN 16.31	/
34	-	/
36	-	/
38	DATA IN 00.15	/
3A	DATA IN 16.31	/
3C	DATA IN 32.47	/
3E	DATA IN 48.63	/

DRAWING  
 PCI DECODE  
 PCI BUS DRIVERS  
 VSXXXSCU.LOGIC.1.2  
 LAST\_MODIFIED=Mon Mar 18 10:54:29 1985

WANG LABORATORIES, INC.	REV: 4
TITLE: VS-300 SCU 8835	DATE:
ENGINEER:	PAGE: 2 OF 4




DRAWING

SCU STATUS AND CONTROL REGISTERS  
 VSXXXSCU.LOGIC.1.3  
 LAST\_MODIFIED=Mon Mar 18 10:56:13 1985

WANG LABORATORIES, INC.	REV: 4
TITLE: VS-300 SCU 8835	DATE:
ENGINEER:	PAGE: 3 OF 14

77  
17  
11  
5.8  
8.5  
11  
17  
22

22  
17  
11  
5.8  
8.5  
11  
17  
22




DRAWING  
 VSXXXSCU.LOGIC.1.4  
 LAST\_MODIFIED=Mon Mar 18 10:57:40 1985

(WANG) LABORATORIES, INC.	REV: 4
TITLE: VS-300 SCU 8835	DATE:
ENGINEER:	PAGE: 4 OF 14



22"  
17"  
11"  
8.5"  
11"  
8.5"  
11"  
22"



SUDC BYPASS CAPACITORS  
 15 MFD, 20 VDC TANTALUM C1, C3, C177, C189  
 0.047 MFD CERAMIC C4 TO C176, C178 TO C188


DRAWING  
 VSXXXSCU. LOGIC. 1.5  
 LAST\_MODIFIED=Mon Mar 18 10:59:28 1985

WANG LABORATORIES, INC.	REV: 4
TITLE: VS-300 SCU 8835	DATE:
ENGINEER:	PAGE: 5 OF 4

22"  
17"  
11"  
8.5"  
11"  
8.5"  
11"  
22"

7.7  
11  
11  
8.5  
8.5  
11  
17  
22

22  
17  
11  
8.5  
8.5  
11  
17  
22




DRAWING  
 V9300SCU LOGIC 1.8  
 LAST\_MODIFIED=Thu Jun 8 11:35:48 1985


WANG LABORATORIES, INC.	REV: 4
TITLE: V9-300 SCU 8835	DATE:
ENGINEER:	PAGE: 8 OF 14

7.7  
 11  
 9.8  
 8.5  
 11  
 17  
 22

22  
 11  
 9.8  
 8.5  
 11  
 17  
 22




↑  
 L7  
 SHIFT DIRECTION



DRAWING  
 SDO BUS CONTROL  
 SPB INTERFACE  
 USXXXSCU.LOGIC.1.7  
 LAST\_MODIFIED=Mon Mar 18 11:03:00 1985

WANG LABORATORIES, INC.	REV: 4
TITLE: US-300 SCU 8835	DATE:
ENGINEER:	PAGE: 7 OF 4




DRAWING.

SPB CONTROL  
 VSXXXSCU.LOGIC.1.B  
 LAST\_MODIFIED=Mon Mar 18 11:04:13 1985

WANG	LABORATORIES, INC.	REV: 4
TITLE:	VS-300 SCU 8835	DATE:
ENGINEER:		PAGE: 8 OF 14


7.7  
 17  
 11  
 9.8  
 8.5  
 11  
 8.5  
 17  
 22



DRAWING  
 SYSTEM BUS CONTROL  
 VS000SCU.LOGIC.1.9  
 LAST\_MODIFIED=Thu Jun 8 13:52:05 1985

WANG LABORATORIES, INC.	REV: 4
TITLE: VS-300 SCU 8835	DATE:
ENGINEER:	PAGE: 9 OF 14

22  
 17  
 11  
 9.8  
 8.5  
 11  
 8.5  
 17  
 22




DRAWING

SYSTEM BUS IPC RESPONSE LOGIC  
 VSXXXSCU.LOGIC.1.10  
 LAST\_MODIFIED=Mon Mar 18 10:45:59 1985

WANG LABORATORIES, INC.	REV: 4
TITLE: VS-300 SCU 8835	DATE:
ENGINEER:	PAGE: 10 OF 14

7.7  
"L1"  
"L1"  
"5.8"  
B  
8.5"  
11"  
17"  
22"




"L1"  
"L1"  
"5.8"  
C  
8.5"  
11"  
17"  
22"

DRAWING

VSXXXSCU.LOGIC.1.11  
LAST\_MODIFIED=Mon Mar 18 10:47:02 1985

(WANG) LABORATORIES, INC.	REV: 4
TITLE: VS-300 SCU 8835	DATE:
ENGINEER:	PAGE: 11 OF 14



**DRAWING**

USXXXSCU.LOGIC.1.12


LAST\_MODIFIED=Thu Jun 8 13:45:00 1985

WANG LABORATORIES, INC.	REV: 4
TITLE: US-300 SCU 8835	DATE:
ENGINEER:	PAGE:12 OF 14



77  
 11  
 11  
 5.8  
 8.5  
 11  
 17  
 22

22  
 11  
 11  
 8.5  
 8.5  
 11  
 17  
 22



DRAWING  
 BACKPLANE CONNECTOR  
 VSXXXSCU.LOGIC.1.13  
 LAST\_MODIFIED=Mon Jun 10 10:58:44 1985

(WANG) LABORATORIES, INC.	REV: 4
TITLE: VS-300 SCU 8835	DATE:
ENGINEER:	PAGE: 130F/4

77

11

11


5.8

8.5

11

17

22



DRAWING  
 USXXXSCU.LOGIC.1.14  
 LAST\_MODIFIED=Fri Mar 8 14:30:33 1985

(WANG) LABORATORIES, INC.	REV: 4
TITLE: US-300 SCU 8835	DATE:
ENGINEER:	PAGE: 14 OF 14

77

11

11


5.8

8.5

11


17

22



NOTES: UNLESS OTHERWISE SPECIFIED  
 1. ALL ROOMS ARE 1/4" W/ 3" PARENT COMPRESSED IN ONE  
 2. ALL CORNER ROOMS ARE 1/4" W/ 3" PARENT COMPRESSED IN TWO  
 3. NOT LOCKED: 818, 819, 821, 822, 823, 824, 825, 826, 827, 828, 829, 830, 831, 832, 833, 834, 835, 836, 837, 838, 839, 840, 841, 842, 843, 844, 845, 846, 847, 848, 849, 850, 851, 852, 853, 854, 855, 856, 857, 858, 859, 860, 861, 862, 863, 864, 865, 866, 867, 868, 869, 870, 871, 872, 873, 874, 875, 876, 877, 878, 879, 880, 881, 882, 883, 884, 885, 886, 887, 888, 889, 890, 891, 892, 893, 894, 895, 896, 897, 898, 899, 900, 901, 902, 903, 904, 905, 906, 907, 908, 909, 910, 911, 912, 913, 914, 915, 916, 917, 918, 919, 920, 921, 922, 923, 924, 925, 926, 927, 928, 929, 930, 931, 932, 933, 934, 935, 936, 937, 938, 939, 940, 941, 942, 943, 944, 945, 946, 947, 948, 949, 950, 951, 952, 953, 954, 955, 956, 957, 958, 959, 960, 961, 962, 963, 964, 965, 966, 967, 968, 969, 970, 971, 972, 973, 974, 975, 976, 977, 978, 979, 980, 981, 982, 983, 984, 985, 986, 987, 988, 989, 990, 991, 992, 993, 994, 995, 996, 997, 998, 999, 1000

		PROJECT NO. 100-300	
		DATE 10-21-73	
DRAWN BY: [Name]		CHECKED BY: [Name]	
SCALE: [Scale]		DATE: [Date]	
PROJECT: RESEARCH BUILDING		SHEET NO. 8835	
DATE: 10-21-73		SHEET NO. 8835	



22" 17" 11" 8.5" 11 10 9 8 7 6 5 4 3 2 1

11 10 9 8 7 6 5 4 3 2 1 11 10 9 8 7 6 5 4 3 2 1

22" 17" 11" 8.5" 11 10 9 8 7 6 5 4 3 2 1


US-300 SBI 8836R1  
SYSTEM BUS INTERFACE

<u>SHEET</u>	<u>DESCRIPTION</u>
01	TITLE PAGE
02	BLOCK DIAGRAM
03	BLOCK DIAGRAM
04	IO ID AND COMMAND BUFFERS, SYSTEM BUS CONTROL DRIVERS AND RECEIVERS.
05	IO OPERATION-RECEIVE
06	SYSTEM BUS REQUEST AND GRANT LOGIC
07	TIMER, IO BUS GRANT, IO OUTPUT LATCH CONTROL
08	IREQ, IPC RESPONSE SYSTEM BUS BUSY, IPC READY INPUT.
09	IPC RESPONSE LOGIC, IPC IOHOLD LOGIC.
10	SBI STATUS.
11	SBI SUPPORT PACKET BUS.
12	IO BUS COMMAND/ID OUTPUT, IO DATA OUTPUT CONTROL
13	IO COMMAND/ID TRANCEIVERS, IO BUS TERMINATORS.
14	SYSTEM BUS ADDRESS OUT REGISTER AND ADDRESS OUT LATCH, SYS ADDR OUT/IN BUFFERS.
15	SYSTEM BUS DATA OUT REGISTER AND DATA OUT LATCH.
16	IO PROTECTION, TEST/SET BUFFER.
17	SPB STATUS BUFFER, SPB ERROR LOG, WRITE BYTE COPY BUFFER.
18	SYSTEM BUS DATA IN REGISTER AND DATA IN LATCH.
19	SYSTEM BUS TERMINATION, SYSTEM DATA BUS TRANCEIVERS.
20	IO BUS DATA DRIVERS/RECEIVERS
21	BACK PLANE CONNECTOR.
22	SPARE GATES

DRAWING  
TITLE=USXXXSBI  
ABBREV=SBI  
LAST\_MODIFIED=Mon Aug 26 11:08:19 1985  
USXXXSBI.LOGIC.1.1

E-REV  
1

(WANG) LABORATORIES, INC.	REV: /
TITLE: US-300 SBI 8836R1	DATE: 8/26/85
ENGINEER: B. J. PATEL, P. A. MORRISON	PAGE: 1 OF 22




DRAWING  
 USBOOKSBI...1.2  
 LAST\_MODIFIED=Wed Mar 13 11:17:55 1985  

WANG LABORATORIES, INC.	REV: /
TITLE: SBI	DATE:
ENGINEER:	PAGE: 2 OF 22

77  
 11  
 11  
 8.5"  
 8.5"  
 11"  
 17"  
 22"

22  
 11  
 11  
 8.5"  
 8.5"  
 11"  
 17"  
 22"




22"  
17"  
11"  
8.5"  
8.5"  
11"  
17"  
22"

22"  
17"  
11"  
8.5"  
8.5"  
11"  
17"  
22"


22"  
17"  
11"  
8.5"  
8.5"  
11"  
17"  
22"

22"  
17"  
11"  
8.5"  
8.5"  
11"  
17"  
22"




DRAWING  
 USXXXXBI...1.4  
 LAST\_MODIFIED=Thu Mar 14 15:07:50 1985

WANG LABORATORIES, INC.		REV: /
TITLE: SBI		DATE:
ENGINEER:		PAGE: 4 OF 22








$SREQ = IOEDGE \cdot (S+D \cdot IOIN+T \cdot IOIN \cdot QIOIN+SELFTM \cdot SELFTM \cdot IOIN)$   
 $SET SREQ = SREQ \cdot QREQ \cdot SSTART$   
 $CLR SREQ = SSTART$   
 $SET REQ = SREQ+SBICYCLE \cdot SBYT \cdot T \cdot SREQ$   
 $CLR REQ = SBYT \cdot QREQ \cdot SREQ$   
 $SET SBYT = SBYT \cdot SREQ \cdot (DF+CLF) \cdot REQ \cdot SACK \cdot (BLOCK+PRIN \cdot BLOCK)$   
 $CLR SBYT = (FULL+SPC+QLE) \cdot (IOEDGE+GRANT+X-INHLD)$






**DEBANKING**  
 V5000SBI..1.5  
 LAST\_MODIFIED=Mon Aug 28 13:48:25 1985

WANG LABORATORIES, INC.		REV: /
TITLE: SBI		DATE:
ENGINEER:		PAGE: 6 OF 22















SYSTEM BUS CONTROL



DIVIDE BY 256 13.8 MICROSEC OUTPUT PERIOD




GRANT = AICORC (Z-HOLD + IPC-DHOLD) (ZEMISSY + XEMISSY) X-DHOLD (XCF + ILE) IOENB




DRAWING  
 LAST\_MODIFIED=Fri Aug 23 15:22:13 1935  
 VSXXXSBI.LOGIC.1.7

WANG LABORATORIES, INC.	REV:
TITLE: SBI	DATE:
ENGINEER:	PAGE: 7 OF 22



**DRAWING**  
 US00XSBI.LOGIC.1.8  
 LAST\_MODIFIED=Mon Aug 28 08:41:13 1985

WANG LABORATORIES, INC.		REV:
TITLE: SBI		DATE:
ENGINEER:		PAGE: 8 OF 22



DRAWING  
 VEROSSET, LOGIC 1.8  
 LAST\_MODIFIED=Thu Mar 14 15:21:18 1985

WANG LABORATORIES, INC.	REV: 1
TITLE: SBI	DATE:
ENGINEER:	PAGE: 9 OF 22


22"  
 17"  
 11"  
 8.5"  
 8.5"  
 11"  
 17"  
 22"

22"  
 17"  
 11"  
 8.5"  
 8.5"  
 11"  
 17"  
 22"



7.7  
11  
8.5  
8.5  
11  
17  
22


22  
11  
8.5  
8.5  
11  
17  
22



WANG LABORATORIES, INC.  
 TITLE: SBI  
 ENGINEER:  
 REV: 1  
 DATE:  
 PAGE: 11 OF 22

SBI-SUPPORT PACKET BUS





SBI IOBUS INTERFACE

DRAWING

VS000SBI.LOGIC.1.13  
 LAST\_MODIFIED=Mon Aug 28 14:09:05 1985

WANG LABORATORIES, INC.	REV: 1
TITLE: SBI	DATE:
ENGINEER:	PAGE: 13 OF 22



77

"L1

"11


"5.8

8.5"

11"

17"

22"



SYSTEM ADDRESS REGISTER, OUTPUT DRIVER, INPUT BUFFER

DRAWING

USPOOSBI LOGIC 1.14

LAST MODIFICATION Aug 28 10:01:48 1985

WANG LABORATORIES, INC.

TITLE: SBI

ENGINEER:

REV: 1

DATE:

PRG: 14 OF 22

"22

"L1

"11

"5.8

8.5"


11"

17"

22"

7.7  
17"  
11"  
8.5"  
8.5"  
11"  
17"  
22"


22"  
17"  
11"  
8.5"  
8.5"  
11"  
17"  
22"



SYSTEM DATA OUTPUT REGISTER

DRAWING  
VSD00XSB1.LOGIC.1.15  
LAST\_MODIFIED=Thu Mar 14 14:53:08 1985

WANG LABORATORIES, INC.		REV:
TITLE: SBI		DATE:
ENGINEER:		PAGE: 15 OF 22




DRAWING


USX00SBI.1.16  
 LAST\_MODIFIED=Thu Mar 14 14:53:42 1985

WANG LABORATORIES, INC.		REV:
TITLE: SBI		DATE:
ENGINEER:		PAGE: 16 OF 22

77  
17  
11  
8.5  
8.5  
11  
17  
22

22  
17  
11  
8.5  
8.5  
11  
17  
22






SYSTEM DATA INPUT REGISTER, IO BUFFER

DRAWING

VS000SBI.LOGIC.1.18

LAST\_MODIFIED=Thu Mar 14 15:08:58 1985


WANG LABORATORIES, INC.	REV: 1
TITLE: SBI	DATE:
ENGINEER:	PAGE: 18 OF 22



77  
 17"  
 11"  
 8.5"  
 8.5"  
 11"  
 17"  
 22"

22"  
 17"  
 11"  
 8.5"  
 8.5"  
 11"  
 17"  
 22"

NOTE: THIS RESISTOR IS PLACED PHYSICALLY BETWEEN C38P18 AND L34P18.




DRAWING  
 IO DATA BUS DRIVERS  
 V5000SBI...1.20  
 LAST\_MODIFIED=Mon Aug 28 14:10:11 1985

WANG LABORATORIES, INC.	REV: /
TITLE: SBI	DATE:
ENGINEER:	PAGE: 20 OF 22

22"  
17"  
11"  
8.5"  
8.5"  
11"  
17"  
22"

22"  
17"  
11"  
8.5"  
8.5"  
11"  
17"  
22"



CONNECTOR A

CONNECTOR B

CONNECTOR C

A-001 GND  
A-002 +5V  
A-003  
A-007  
A-008 IPCROY2a  
A-011 GND  
A-013 IPCROY4a  
A-018 IPCROY3a  
A-017 IPCROY7a  
A-018 IPCROY7a  
A-021 SP83a  
A-023 SP83a  
A-028 IPCROY9a  
A-028 IPCROY11a  
A-027 IPCROY12a  
A-028 SP83a  
A-031 GND  
A-033 SP83a  
A-035 IOCB8a  
A-037 IOCB8a  
A-038 IOCB8a  
A-040 SP11a  
A-041 GND  
A-043 SP11a  
A-045 SP11a  
A-047 IOCB8a  
A-048 IOCB8a  
A-051 SP14a  
A-053 GND  
A-055 SP15a  
A-056 IOCB18a  
A-057 IOCB18a  
A-058 IOCB13a  
A-061 SP18a  
A-063 SP18a  
A-065 IOCB18a  
A-067 IOCB17a  
A-068 IOCB18a  
A-071 SP22a  
A-073 IOCB28a  
A-075 SP24a  
A-077 IOCB22a  
A-079 SP25a  
A-081 IOCB23a  
A-083 SP28a  
A-085 IOCB28a  
A-087 SP27a  
A-088 IOCB28a  
A-091 SP38a  
A-093 IOCB38a  
A-095 SP31a  
A-097 +5V  
A-098 GND

A-002 GND  
A-004 +5V  
A-005  
A-007 TINTPa  
A-012 IPCROY1a  
A-012 IPCROY3a  
A-014 SP88a  
A-018 IPCROY3a  
A-018 SP81a  
A-028 IPCROY8a  
A-028 GND  
A-024 SP84a  
A-028 IPCROY18a  
A-028 SP88a  
A-038 IPCROY13a  
A-032 IPCROY14a  
A-034 SP87a  
A-038 IPCROY18a  
A-038 SP88a  
A-042 IOCB8a  
A-042 IOCB3a  
A-048 IOCB8a  
A-048 SP13a  
A-048 SP13a  
A-052 IOCB7a  
A-054 IOCB8a  
A-056 IOCB8a  
A-058 SP18a  
A-060 IOCB11a  
A-062 SP17a  
A-064 GND  
A-064 IOCB14a  
A-068 SP28a  
A-068 IOCB18a  
A-072 SP21a  
A-072 GND  
A-074 IOCB18a  
A-078 SP23a  
A-078 IOCB21a  
A-082 SP28a  
A-082 GND  
A-084 IOCB8a  
A-088 IOCB8a  
A-088 SP28a  
A-092 SP28a  
A-094 GND  
A-098 IOCB28a  
A-098 IOCB11a  
A-098 +5V  
A-100 GND

B-001 GND  
B-002 +5V  
B-003  
B-007  
B-008 SBTa  
B-011  
B-012 BIOCB8  
B-014  
B-018 BIOCB8  
B-018 BIOCB8  
B-018 GND  
B-018 BIOCB8  
B-022  
B-024  
B-028 GND  
B-028  
B-027 SP17a  
B-028 SP87a  
B-031 SP87a  
B-033  
B-033 WAITa  
B-035 SLBYa  
B-037 VPPa  
B-038 IOCB8  
B-041 PROUTa  
B-043 AC08  
B-045 T8a  
B-047 GND  
B-048 GND  
B-051  
B-053  
B-056 SP88a  
B-058 SP88a  
B-058 SP81a  
B-058 SP84a  
B-061 GND  
B-063  
B-063 SP87a  
B-065 SP81a  
B-067 SP89a  
B-069 SP81a  
B-071 SP81a  
B-073 SP81a  
B-075 GND  
B-078 SP22a  
B-077 SP81a  
B-079 SP81a  
B-081 SP81a  
B-083 SP81a  
B-085 SP82a  
B-087 GND  
B-089 SP24a  
B-090 SP25a  
B-091 SP27a  
B-093 SP28a  
B-095 SP81a  
B-097 +5V  
B-098 GND

B-002 GND  
B-004 +5V  
B-008 MEHOLKa  
B-007 GND  
B-010 BIOCB8  
B-012  
B-014  
B-018  
B-018 GND  
B-022  
B-024  
B-028 GND  
B-028  
B-027  
B-028  
B-032 GND  
B-034  
B-034 IOHOLDa  
B-036 HCL1a  
B-038 HCL2a  
B-042 HCL3a  
B-044 PRINa  
B-046  
B-048 GND  
B-048  
B-052  
B-054  
B-058 GND  
B-060 SP88a  
B-062 SP83a  
B-064 SP88a  
B-066 SP88a  
B-068 GND  
B-072 SP81a  
B-074 SP81a  
B-078 SP81a  
B-078 SP81a  
B-078 SP81a  
B-078 SP81a  
B-078 SP81a  
B-082 GND  
B-084 SP88a  
B-086 SP82a  
B-088 SP82a  
B-090 SP82a  
B-092 GND  
B-094 SP82a  
B-096 SP82a  
B-098 +5V  
B-100 GND

C-001 GND  
C-002 +5V  
C-008 ID1a  
C-007 GND  
C-008 SP83a  
C-011 SP84a  
C-013 SP88a  
C-018 GND  
C-017 SELINITa  
C-018 SP87a  
C-021 SP87a  
C-023 SP87a  
C-028 GND  
C-028 SP87a  
C-027 SP87a  
C-028 SP87a  
C-031 SP87a  
C-033 SP87a  
C-035 IOHOLDa  
C-036 GND  
C-037 SP87a  
C-038 SP87a  
C-041 GND  
C-043 SP87a  
C-045 SP87a  
C-047 IOCB8a  
C-047 SP87a  
C-048 SP87a  
C-051 IOCB8a  
C-058 SP87a  
C-058 SP87a  
C-060 SP87a  
C-062 SP87a  
C-064 SP87a  
C-066 SP87a  
C-068 SP87a  
C-070 SP87a  
C-071 SP87a  
C-073 SP87a  
C-075 SP87a  
C-077 SP87a  
C-078 SP87a  
C-081 SP87a  
C-083 SP87a  
C-085 SP87a  
C-087 SP87a  
C-089 SP87a  
C-091 SP87a  
C-093 SP87a  
C-095 SP87a  
C-097 SP87a  
C-098 GND

C-002 GND  
C-004 +5V  
C-008 ID1a  
C-008 SP84a  
C-012 ID2a  
C-014 ID3a  
C-018 ID4a  
C-018 SP88a  
C-022 GND  
C-024 SP88a  
C-028 SP88a  
C-032 SP88a  
C-034 SP88a  
C-036 SP88a  
C-038 SP88a  
C-042 SP88a  
C-044 SP88a  
C-048 SP88a  
C-048 SP88a  
C-052 SP88a  
C-054 SP88a  
C-058 SP88a  
C-062 SP88a  
C-064 SP88a  
C-068 SP88a  
C-072 SP88a  
C-074 SP88a  
C-078 SP88a  
C-082 SP88a  
C-084 SP88a  
C-088 SP88a  
C-092 SP88a  
C-094 SP88a  
C-098 SP88a  
C-100 SP88a

DRAWING  
USXXXSBI..1.21  
LAST\_MODIFIED=Mon Aug 29 18:33:18 1985


WANG LABORATORIES, INC.		REV: 1
TITLE: SBI		DATE:
ENGINEER:		PAGE: 21 OF 22

BACKPLANE CONNECTOR



22"  
17"  
11"  
8.5"  
8.5"  
11"  
17"  
22"


22"  
17"  
11"  
8.5"  
8.5"  
11"  
17"  
22"



DRAWING  
 USDOOSBI. LOGIC. 1. 22  
 LAST\_MODIFIED=Mon Aug 28 16:52:41 1985


WANG LABORATORIES, INC.		REV: /
TITLE:	SBI	DATE:
ENGINEER:		PAGE: 22 OF 22

SPARE GATES



77  
G  
F  
E  
D  
C  
B  
A

22"  
17"  
11"  
8.5"  
8.5"  
11"  
17"  
22"



NOTES:  
1. UNLESS OTHERWISE SPECIFIED:  
ALL CAPACITORS ARE .047UF EXPRESSED IN MICROFARADS.  
ALL RESISTORS ARE 1/4W 5% EXPRESSED IN OHMS.  
ALL SIPS WITH + SHOULD BE LOADED BACKWARDS  
PIN 1 OF SIP SHOULD BE IN PIN18 ON PCB.  
2. R56A, R57A, R58A, R59A, AND R59A ARE NOT LOADED.  
3. REFERENCE ASSEMBLY PRINT AND/OR SCHEMATICS  
FOR JUMPER CONFIGURATIONS.  
JUMPERS ARE 374-9129.

<b>WANG</b>		BY	DATE	APPROVED BY	DATE	
MATERIAL	MODEL NO.	OWN	ECT	E	ENGR	
	VS300	CHA		H	ENGR	
	10-214	E	C	CONTROL	M	ENGR
		TITLE VS300 SBI				
FINISH		210-8836	C	8836	3	

77

22

17

17

11

11

8.5

8.5

8.5

8.5

11


11

17

17

22

22



CONN. A


CONN. B

CONN. C

DRAWING NUMBER: 1000-1-1  
 LAST MODIFIED: JUN 9 12 00 PM 1988  
 MFG LABORATORIES, INC. REV. 02  
 TITLE: US-300 BROUPLANE 8837 DATE: 8-4-88  
 ENGINEER: JEFF HARR PAGE: 1 OF 4

77  
77  
11  
8.5  
8.5  
11  
17  
22

22  
17  
11  
8.5  
8.5  
11  
17  
22



DRAWING: USXXXPL LOGIC 1.2  
 LAST REVISED: JUN 4 1988

LABORATORIES, INC.	REV: 02
TITLE: US-300 BACKPLANE	DATE: 6-4-85
ENGINEER: JEFF HARRIS	PAGE: 2 OF 4



7.7

22"

17"

17"

11"

11"

8.5"

8.5"

8.5"

8.5"

11"


11"

17"

17"


22"

22"



HUNG LABORATORIES, INC. REV: 02  
 TITLE: VS-300 BROOKLINE 3/3/85 DATE: 8-4-85  
 ENGINEER: JEFF HAAS PAGE: 4 OF 4

22" 17" 11" 8.5" 8.5" 11" 17" 22"




NOTES UNLESS OTHERWISE SPECIFIED IN QUOTE:  
 1. ALL DIMS ARE UNLESS OTHERWISE SPECIFIED.  
 2. ALL DIMS ARE UNLESS OTHERWISE SPECIFIED.  
 3. ALL DIMS ARE UNLESS OTHERWISE SPECIFIED.  
 4. ALL DIMS ARE UNLESS OTHERWISE SPECIFIED.  
 5. ALL DIMS ARE UNLESS OTHERWISE SPECIFIED.  
 6. ALL DIMS ARE UNLESS OTHERWISE SPECIFIED.  
 7. ALL DIMS ARE UNLESS OTHERWISE SPECIFIED.  
 8. ALL DIMS ARE UNLESS OTHERWISE SPECIFIED.  
 9. ALL DIMS ARE UNLESS OTHERWISE SPECIFIED.  
 10. ALL DIMS ARE UNLESS OTHERWISE SPECIFIED.

<b>AWANG</b>	MODEL NO. VS300	DATE	APPROVED BY	DATE
	REV. 10-213	DESIGNED BY	DATE	DATE
MATERIAL	BACKPLANE PL	DESIGNED BY	DATE	DATE
FINISH	ASSEMBLY DRAWING	DESIGNED BY	DATE	DATE
	210-8837-R2 C	DESIGNED BY	DATE	DATE
	8837	DESIGNED BY	DATE	DATE
	4	DESIGNED BY	DATE	DATE


22" 17" 11" 8.5" 8.5" 11" 17" 22"

THIS DRAWING AND THE DATA THEREIN ARE THE CONFIDENTIAL PROPERTY OF WANG LABORATORIES, INC. AND THE INFORMATION CONTAINED HEREIN IS UNCLASSIFIED. ANY REPRODUCTION OR TRANSMISSION OF THIS DRAWING OR THE DATA THEREIN WITHOUT THE WRITTEN CONSENT OF WANG LABORATORIES, INC. IS PROHIBITED. THIS DRAWING IS THE PROPERTY OF WANG LABORATORIES, INC. AND IS TO BE KEPT IN THE CUSTODY OF THE COMPANY. IT IS RETURNABLE UPON THE DEMAND OF WANG LABORATORIES, INC.




WANG	WANG LABORATORIES, INC.	DATE	APPROVED BY	DATE
DESIGNED BY	CHKD BY	DATE	APPROVED BY	DATE
MODEL NO. P400674	FBC			
TITLE: WINCHESTER CONTROLLER				
SEE CHART D 9225 11				






THIS DRAWING AND THE DATA HEREIN ARE THE PROPERTY OF WANG LABORATORIES, INC. AND ARE NOT TO BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, INCLUDING PHOTOCOPYING, RECORDING, OR BY ANY INFORMATION STORAGE AND RETRIEVAL SYSTEM. THE INFORMATION CONTAINED HEREIN IS UNCLASSIFIED EXCEPT WHERE SHOWN OTHERWISE. DATE 8/1/84 BY SP-10/STP/STP

WANG PART NO.	DRAWING NO.	DESCRIPTION	BY	DATE	APPROVED BY	DATE
			DWH	8/1/84	E ENGR	
			CHK		M ENGR	
					MFG ENGR	
MATERIAL		MODEL NO PNO0674	TITLE			
		PBC	WINCHESTER CONTROLLER			
FINISH		SEECHART	D	9225	11	



WANG PART NO.	DRAWING NO.	DESCRIPTION	BY	DATE	APPROVED BY	DR. E.
			DAWN J.S.	9/24/71	ENGR	
			ONE		M ENGR	
					MFG ENGR	
TITLE			WINCHESTER CONTROLLER			
MATERIAL			SEE CHART			
FINISH			D 9225 11			



THE DRAWING AND THE DATA SHOWN THEREON ARE THE CONFIDENTIAL PROPERTY OF WANG LABORATORIES, INC. THE DRAWING AND THE DATA SHOWN THEREON MAY NOT BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, INCLUDING PHOTOCOPYING, RECORDING, OR BY ANY INFORMATION STORAGE AND RETRIEVAL SYSTEM, WITHOUT THE WRITTEN PERMISSION OF WANG LABORATORIES, INC.


WANG PART NO.	REVISION NO.	DESCRIPTION	BY	DATE	APPROVED BY	DATE
9225	1	WINCHESTER CONTROLLER	DWN	11/87	ENG	
MATERIAL			CHK		M ENGR	
MODEL NO. PNO 67A					MPS ENGR	
PBC						
TITLE						
SEE CHART						
D 9225						
11						

THIS DRAWING AND THE DATA THEREON ARE THE CONFIDENTIAL PROPERTY OF WANG AND PROPRIETARY TO WANG LABORATORIES INC. THIS DRAWING AND THE DATA THEREON MAY NOT BE MADE PUBLIC IN WHOLE OR IN PART WITHOUT THE WRITTEN CONSENT OF WANG LABORATORIES INC. IF FOR ANY REASON THIS DRAWING IS REPRODUCED BY SOMEONE TO LEAVE THE PHYSICAL CUSTODY OF THE COMPANY, IT IS RETURNABLE UPON THE DEMAND OF WANG LABORATORIES INC.

DO NOT SCALE


MNEMONICS	COORD.
A10WC	2E11
A0	2G7
A1, A2	2G10
AB-A11	2G11
A3	2E11
BNE	2G5
DACT1-DACT5	2G2
-DIRECTION	3G1
DREQ1-DREQ3	2E1
-DRS	3G5
-DRYSEL	1B1
DO-D7	2B11
DB-DIS	2G6
-H0SEL0	1C1
-H0SEL1	1B1
-H0SEL2	3G1
-INDEX	3G6
IORC	2E11
IRQ5-IRQ7	2D1
+MFMR	3C11
-MFMR	3C11
+MPMW	3G1
-MPMW	3G1

MNEMONICS	COORD.
-READY	1G3
RESET	2E11
-RWC	1C1
SAB	2F11
-SEEK COMPLETE	1G3
SID0-SID3	2F11
-STEP	3F1
-TRACK#	1G3
-WRITE FAULT	1G3
-WTG	3F1
CLK	2D11



WINCHESTER DRIVE JUMPER CONFIGURATION


SIZE	VENDOR	PIN	PIN
10MEG	ALL	NOT REQUIRED	
30MEG	ATAS1	J3-1	J4-2
30MEG	QUANTUM	J3-2	J4-2



WANG PART NO.	DRAWING NO.	DESCRIPTION	BY	DATE	APPROVED BY	DATE
			DWN	3/2/77	E. ENCH. ALLEN	1/2/77
			CHK. G...	2/1/76	M. LING	
MATERIAL	MODEL NO. P40067A	PBC	TITLE			
	NO DIMENSIONS SPECIFICATIONS		WINCHESTER CONTROLLER			
FINISH	SEE CHART	D	9225	11		

THIS DRAWING AND THE DATA SHOWN THEREON ARE THE CONFIDENTIAL PROPERTY OF, AND ARE PROPRIETARY TO, WANG LABORATORIES, INC. THIS DRAWING AND THE DATA SHOWN THEREON MAY NOT BE MADE PUBLIC WITHOUT THE WRITTEN CONSENT OF WANG LABORATORIES, INC. IF FOR ANY REASON THIS DRAWING IS PERMITTED BY WANG TO LEAVE THE PHYSICAL CUSTODY OF THE COMPANY, IT IS RETURNABLE UPON THE DEMAND OF WANG LABORATORIES, INC.

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95	96	97	98	99	100
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	-----



L65 PIN 2 — C81 — toV  
 L65 PIN 10 — C80 — toV

- NOTES:
- UNLESS OTHERWISE SPECIFIED:  
 ALL CAPACITORS ARE .047 P/N 300-1966, EXPRESSED IN MICROFARADS.  
 ALL RESISTORS ARE 1/4W, 5%, EXPRESSED IN OHMS.  
 ALL RESISTOR NETWORKS ARE 333-0037.
  - IC PAD (376-9000) MUST BE INSTALLED PRIOR TO Y1.
  - .10 MIN. DIMENSION HAS BEEN DESIGNATED TO AVOID OVERLAP FROM ADJACENT SHIELD.

		BY	DATE	APPROVED BY	DATE
		OWN S.M.	12/82	E ENGR K.D.	12/82
MATERIAL		CHK A.W.	8/14/83	M ENGR	
MODEL NO. PHOG67A PBC		E C CONTROL		MFG ENGR	
SEE ENGR SPECIFICATIONS NO. 10-213		TITLE WINCHESTER CONTROLLER BOARD ASSEMBLY DRAWING			
FINISH		TOL. EX. AS NOTED	210-9225-R1	C	9225 5
SCALE 1/1 SHT 4 OF 9		WANG PART NUMBER	SIZE	DRAWING NUMBER	REV


US-XXX CPU INDEX

PAGE	CONTENTS
1.	CLOCK ISLAND
2.	MICRO-INSTRUCTION REGISTER
3.	COMMAND FUNCTIONS
4.	TRAP STACK, CASE_ON(ARGUMENT)
5.	MICRO-INSTRUCTION ADDRESS GENERATOR
6.	REGISTER FILE DATA SELECT, A-REGISTER FILE
7.	B-REGISTER FILE
8.	REGISTER FILE ADDRESS GENERATOR
9.	A-PORT INPUTS
10.	PROCESSOR STATE REGISTER, PROGRAM CONTROL WORD
11.	B-PORT INPUTS
12.	A-PORT, B-PORT INPUT SELECT CONTROL STORE BANK SELECT
13.	ARITHMETIC LOGIC UNIT
14.	BUFFERED FILE DATA AND ALU RESULT NEXT INSTRUCTION ADDRESS
15.	ALU SHIFTER
16.	MICRO-TEST SELECT
17.	CONTROL STORE READ/WRITE CONTROL
18.	CONTROL STORE
19.	EXTERNAL SIGNAL BUFFERS
20.	CPU SUPPORT LINK AND SUPPORT PACKET BUS
21.	CPU INPUT/OUTPUT PIN LIST

WANG LABORATORIES, INC.	REV: R0.0
TITLE: US-300 CPU INDEX 9231	DATE: 02/13/84
ENGINEER:	PAGE: 1 OF 1

77  
"L1  
"11  
"9'8  
"C  
"B  
"A  
8.5"  
11"  
17"  
22"

"22  
"L1  
"11  
"9'8  
"C  
"B  
"A  
8.5"  
11"  
17"  
22"




REVISIONS			
REV	DESCRIPTION	APP. BY	DATE

PROCESSOR CONFIGURATION	JP1	JP2	JP3	JP4	JP5	JP6	JP7	JP8
SINGLE	IN	OUT	IN	OUT	OUT	IN	IN	IN
DYADIC	OUT	IN	OUT	IN	IN	OUT	OUT	OUT
QUADRADIC	OUT	IN	OUT	IN	IN	OUT	OUT	OUT

WANG LABORATORIES, INC. REV: 0.00  
TITLE: VS-300 CPU 9231 DATE: 6/28/83  
ENGINEER: PAGE: 1 OF 21

77  
"L1"  
"11"  
"9.8"  
8.5"  
11"  
17"  
22"

"22"  
"L1"  
"11"  
"9.8"  
8.5"  
11"  
17"  
22"




WANG LABORATORIES, INC.	REV: 0.00
TITLE: VS-300 CPU 9231	DATE: 7/5/83
ENGINEER:	PAGE: 2 OF 21




77  
"L1"  
"L1"  
"9.8"  
"B"  
"8.5"  
"11"  
"17"  
"22"

"22"  
"L1"  
"L1"  
"8.5"  
"11"  
"17"  
"22"



WANG LABORATORIES, INC.		REV: 0.00
TITLE: US-300 CPU 9231		DATE: 7/6/83
ENGINEER:		PAGE: 3 OF 21




WANG LABORATORIES, INC.	REV: 0.00
TITLE: US-300 CPU 9231	DATE: 7/11/83
ENGINEER:	PAGE: 4 OF 21




77  
"L1"  
"11"  
"5'8"  
8.5"  
11"  
17"  
22"

"22"  
"L1"  
"11"  
"5'8"  
8.5"  
11"  
17"  
22"




WANG LABORATORIES, INC.	REV: 0.00
TITLE: US-300 CPU 9231	DATE: 7/14/83
ENGINEER:	PAGE: 6 OF 21



WANG LABORATORIES, INC.		REV: 0.00
TITLE: VS-300 CPU 9231		DATE: 7/14/83
ENGINEER:		PAGE: 7 OF 21


77  
"11"  
"9'8"  
8.5"  
11"  
17"  
22"

"22"  
"11"  
"9'8"  
8.5"  
11"  
17"  
22"



WANG LABORATORIES, INC.	REV: 0.00
TITLE: VS-300 CPU 9231	DATE: 7/14/83
ENGINEER:	PAGE: 8 OF 21





WANG LABORATORIES, INC.		REV: 0.00
TITLE: US-300 CPU 9231		DATE: 7/18/83
ENGINEER:		PAGE: 10 OF 21


77  
 11  
 11  
 8.5  
 8.5  
 11  
 17  
 22

77  
 11  
 11  
 8.5  
 8.5  
 11  
 17  
 22



77  
17  
11  
9.8  
8.5  
11  
17  
22


22  
17  
11  
9.8  
8.5  
11  
17  
22




WANG LABORATORIES, INC.		REV: 0.00
TITLE: US-300 CPU 9231		DATE: 7/18/83
ENGINEER:		PAGE: 11 OF 21

77  
11  
58  
8.5  
11  
17  
22


22  
11  
58  
8.5  
11  
17  
22



WANG LABORATORIES, INC.	REV: 0.00
TITLE: US-300 CPU 9231	DATE: 7/18/83
ENGINEER:	PAGE: 12 OF 21




(WANG) LABORATORIES, INC.	REV: 0.00
TITLE: VS-300 CPU 9231	DATE: 7/20/83
ENGINEER:	PAGE: 13 OF 21



WANG LABORATORIES, INC.	REV: 0.00
TITLE: US-300 CPU 9231	DATE: 7/20/83
ENGINEER:	PAGE: 14 OF 21






WANG LABORATORIES, INC.		REV: 0.00
TITLE: US-300 CPU 9231		DATE: 7/20/83
ENGINEER:		PAGE: 18 OF 21

77  
 11  
 11  
 8.5  
 8.5  
 11  
 11  
 17  
 17  
 22  
 22  
 22

77  
 17  
 11  
 8.5  
 8.5  
 11  
 17  
 22




22  
 17  
 11  
 8.5  
 8.5  
 11  
 17  
 22

WANG LABORATORIES, INC.		REV: 0.00
TITLE: US-300 CPU 9231		DATE: 7/20/83
ENGINEER:		PAGE: 17 OF 21


77  
"11"  
"5'8"  
8.5"  
11"  
17"  
22"

"22"  
"11"  
"5'8"  
8.5"  
11"  
17"  
22"




WANG LABORATORIES, INC.	REV: 0.00
TITLE: US-300 CPU 8231	DATE: 7/20/83
ENGINEER:	PAGE: 18 OF 21





NOTE: WHEN 16K X 17 CONTROL STORE RAMS ARE INSTALLED:  
 1. INSERT WANG PART NO. 378-0816, 74681634, IN L186.  
 2. INSERT WANG PART NO. 378-0876, 747258, IN L262.

WANG LABORATORIES, INC.		REV: 0.00
TITLE: VS-300 CPU 9231		DATE: 7/20/83
ENGINEER:		PAGE: 19 OF 21



NOTE:  
1. WHEN CPU IS CONFIGURED IN A UNIPROCESSOR SYSTEM INSERT JUMPERS JP8 AND JP11.

WANG LABORATORIES, INC.	REV: 0.00
TITLE: VS-300 CPU 9231	DATE: 7/20/83
ENGINEER:	PAGE: 20 OF 21

CONNECTOR A

A-001 GND  
 A-003 +5U  
 A-005 XMP008  
 A-007 FPUDKs  
 A-008 FPCC0s  
 A-011 BFCTCh  
 A-013 FPCC1s  
 A-015 PIAPC  
 A-017 FPUI0  
 A-019 BLVRR2s  
 A-021 BLVRR1s  
 A-023 BFDD1  
 A-025 GND  
 A-027 FPUIs  
 A-029 FPUI3s  
 A-031 BI4s  
 A-033 BI0s  
 A-035 BI0s  
 A-037 XMP007  
 A-039 CCHCK  
 A-041 XMP009  
 A-043 INTAs  
 A-045 XMP011  
 A-047 GND  
 A-049 DAB3s  
 A-051 DAB4s  
 A-053 DAB5s  
 A-055 DAB6s  
 A-057 GND  
 A-059 PROTFS  
 A-061 FPUI4s  
 A-063 FPUI5s  
 A-065 LATs  
 A-067 OPCDs  
 A-069 OPOLs  
 A-071 SCOLFes  
 A-073 BPHTBs  
 A-075 SCGTEs  
 A-077 LLTAs  
 A-079 INTFs  
 A-081 IRBUs  
 A-083 IR1Us  
 A-085 IR2Us  
 A-087 IV0Ns  
 A-089 JPNAs  
 A-091 EXTCLK  
 A-093 GND  
 A-095 CLKs  
 A-097 +5U  
 A-099 GND

A-002 GND  
 A-004 +5U  
 A-006 XMP001  
 A-008 XMP002  
 A-010 XMP003  
 A-012 XMP004  
 A-014 XMP005  
 A-016 XMP006  
 A-018 XMP009  
 A-020 GND  
 A-022 XMP004  
 A-024 XMP005  
 A-026 XMP006  
 A-028 XMP007  
 A-030 XMP008  
 A-032 GND  
 A-034 BI0s  
 A-036 BI0s  
 A-038 XMP009  
 A-040 IO0Ns  
 A-042 XMP009  
 A-044 XMP010  
 A-046 DAB0s  
 A-048 DAB1s  
 A-050 DAB2s  
 A-052 GND  
 A-054 DAB5s  
 A-056 DAB7s  
 A-058 DAB8s  
 A-060 DAB9s  
 A-062 DAL0s  
 A-064 ATUDs  
 A-066 AGUDs  
 A-068 PCRs  
 A-070 BPH4s  
 A-072 CDRs  
 A-074 XCS08  
 A-076 BACDK  
 A-078 FPs  
 A-080 FPUI2s  
 A-082 XMP0s  
 A-084 GND  
 A-086 RI  
 A-088 XCS01  
 A-090 MECLK1s  
 A-092 BI0SPs  
 A-094 GND  
 A-096 EXTCLK  
 A-098 +5U  
 A-100 GND

CONNECTOR B

B-001 GND  
 B-003 +5U  
 B-005 EOPUCLKs  
 B-007 GND  
 B-009 EUs  
 B-011 MECLK2s  
 B-013 FC080s  
 B-015 GND  
 B-017 GND  
 B-019 FC084s  
 B-021 FC088s  
 B-023 FC092s  
 B-025 GND  
 B-027 FC096s  
 B-029 SPTBs  
 B-031 BLPIARs  
 B-033 EPC453s  
 B-035 IR088  
 B-037 IR011  
 B-039 GND  
 B-041 IR014  
 B-043 GND  
 B-045 AOKTs  
 B-047 TSTs  
 B-049 BATTUONs  
 B-051 BLPCMs  
 B-053 BLPARs  
 B-055 IRE01s  
 B-057 IRE03s  
 B-059 IRE05s  
 B-061 IRE07s  
 B-063 GND  
 B-065 IRE10s  
 B-067 IRE12s  
 B-069 IRE13s  
 B-071 IRE15s  
 B-073 IRE17s  
 B-075 GND  
 B-077 IRE20s  
 B-079 IRE22s  
 B-081 IRE23s  
 B-083 IRE25s  
 B-085 IRE27s  
 B-087 GND  
 B-089 IRE30s  
 B-091 IRE32s  
 B-093 IRE34s  
 B-095 GND  
 B-097 IRE38s  
 B-099 +5U  
 B-100 GND

B-002 GND  
 B-004 +5U  
 B-006 MECLK4s  
 B-008 GND  
 B-010 XH0As  
 B-012 GND  
 B-014 FC087s  
 B-016 FC090s  
 B-018 FC093s  
 B-020 MECLK3s  
 B-022 FC097s  
 B-024 FC099s  
 B-026 BLN1As  
 B-028 BTRAPs  
 B-030 BPC452s  
 B-032 BPS0s  
 B-034 IR089  
 B-036 IR010  
 B-038 IR012  
 B-040 IR013  
 B-042 IR015  
 B-044 SCUNs  
 B-046 BPC40As  
 B-048 GND  
 B-050 BLLMs  
 B-052 IRE09s  
 B-054 IRE11s  
 B-056 GND  
 B-058 IRE14s  
 B-060 IRE16s  
 B-062 IRE18s  
 B-064 IRE19s  
 B-066 IRE21s  
 B-068 IRE24s  
 B-070 IRE26s  
 B-072 IRE28s  
 B-074 IRE31s  
 B-076 IRE33s  
 B-078 IRE35s  
 B-080 IRE37s  
 B-082 BPC40Bs  
 B-084 IRE39s  
 B-086 IRE41s  
 B-088 IRE43s  
 B-090 IRE45s  
 B-092 IRE47s  
 B-094 IRE49s  
 B-096 IRE51s  
 B-098 IRE53s  
 B-100 GND

CONNECTOR C

C-001 GND  
 C-003 +5U  
 C-005 RESETs  
 C-007 DB01s  
 C-009 DB01s  
 C-011 GND  
 C-013 DB03s  
 C-015 DB03s  
 C-017 GND  
 C-019 DB04s  
 C-021 BFD03s  
 C-023 GND  
 C-025 DB07s  
 C-027 BFD03s  
 C-029 BFD11s  
 C-031 DB09s  
 C-033 BFD13s  
 C-035 BFD13s  
 C-037 BFD14s  
 C-039 BFD15s  
 C-041 BFD15s  
 C-043 DB14s  
 C-045 DB14s  
 C-047 BFD19s  
 C-049 DB15s  
 C-051 DB15s  
 C-053 DB19s  
 C-055 BFD22s  
 C-057 DB17s  
 C-059 DB19s  
 C-061 BFD25s  
 C-063 DB19s  
 C-065 BFD26s  
 C-067 GND  
 C-069 BFD29s  
 C-071 GND  
 C-073 DB25s  
 C-075 DB29s  
 C-077 DB29s  
 C-079 DB29s  
 C-081 XSLCs  
 C-083 DB29s  
 C-085 DB29s  
 C-087 BFD0s  
 C-089 DBLRs  
 C-091 DB01s  
 C-093 SLD0s  
 C-095 +5U  
 C-097 GND


C-002 GND  
 C-004 +5U  
 C-006 DB00s  
 C-008 BFD00s  
 C-010 BFD01s  
 C-012 BFD02s  
 C-014 DB02s  
 C-016 BFD04s  
 C-018 BFD04s  
 C-020 DB05s  
 C-022 BFD07s  
 C-024 DB09s  
 C-026 BFD09s  
 C-028 BFD10s  
 C-030 BFD10s  
 C-032 BFD12s  
 C-034 DB10s  
 C-036 DB12s  
 C-038 BFD15s  
 C-040 BFD15s  
 C-042 BFD17s  
 C-044 DB13s  
 C-046 BFD18s  
 C-048 DB15s  
 C-050 BFD20s  
 C-052 BFD21s  
 C-054 GND  
 C-056 BFD23s  
 C-058 BFD24s  
 C-060 GND  
 C-062 DB20s  
 C-064 BFD27s  
 C-066 DB22s  
 C-068 BFD26s  
 C-070 BFD30s  
 C-072 DB23s  
 C-074 DB24s  
 C-076 PUFs  
 C-078 GND  
 C-080 DB27s  
 C-082 GND  
 C-084 DB29s  
 C-086 SLCAs  
 C-088 DB29s  
 C-090 DB29s  
 C-092 DB29s  
 C-094 INTRs  
 C-096 GND  
 C-098 TSL0s  
 C-100 +5U

CONNECTOR J1

D-001 GND  
 D-003 BR01s  
 D-005 BR01s  
 D-007 GND  
 D-009 BR05s  
 D-011 BR05s  
 D-013 GND  
 D-015 BR05s  
 D-017 BR10s  
 D-019 GND  
 D-021 BR13s  
 D-023 BR14s  
 D-025 GND  
 D-027 BR17s  
 D-029 BR18s  
 D-031 GND  
 D-033 BR20s  
 D-035 BR21s  
 D-037 GND  
 D-039 BR25s  
 D-041 BR25s  
 D-043 GND  
 D-045 BR29s  
 D-047 BR29s  
 D-049 GND

D-002 BR00s  
 D-004 GND  
 D-006 BR03s  
 D-008 BR04s  
 D-010 GND  
 D-012 BR07s  
 D-014 BR08s  
 D-016 GND  
 D-018 BR11s  
 D-020 BR12s  
 D-022 GND  
 D-024 BR15s  
 D-026 BR16s  
 D-028 BR19s  
 D-030 BR20s  
 D-032 GND  
 D-034 BR23s  
 D-036 BR23s  
 D-038 BR24s  
 D-040 GND  
 D-042 BR27s  
 D-044 BR28s  
 D-046 GND  
 D-048 BR30s  
 D-050 BR31s

WANG LABORATORIES, INC.		REV: 0.00
TITLE: US-300 CPU 9231		DATE: 1/29/84
ENGINEER:		PAGE: 21 OF 21



- NOTES:
1. UNLESS OTHERWISE SPECIFIED, ALL CAPACITORS ARE .047UF EXPRESSED IN MICROFARADS. ALL RESISTORS ARE 1/4W 5% EXPRESSED IN OHMS.
  2. INSTALL JMPA PLG ASSY(374-9129) 3 PLCS ON LSB.
  3. 16KX17 RAM CHIPS REPLACE 16KX4 RAM CHIPS AND ASSOCIATED 1 CAPACITORS.
  4. PIN 1 OF ALL SIPS FACE TOWARDS THE STIFFENER.
  5. REF. SCHEMATIC LOADING CHART OR PARTS LIST FOR JUMPER CONFIGURATION.
  6. RESISTORS R524A, F-28-29, R531 ARE 220/330 4PH 333-8887. LOAD PIN 1 TOWARDS BOTTOM OF BOARD.

		BY	DATE	APPROVED BY	DATE
		DVN DPW	11 55	E ENGR	
MATERIAL MODEL NO. VS-300 SEE CHANGE SHEET 10-214 FINISH		CHK		M ENGR	
		E.C. CONTROL		MFG ENGR	
		TITLE VS300 CPU M/W			
		210-9231	C	9231	0
		SCALE 1/2"	SHEET 1 OF 1	DATE 11 55 68	REV.

US-300 SBI 9236R0  
 SYSTEM BUS INTERFACE


SHEET DESCRIPTION

- 01 TITLE PAGE
- 02 BLOCK DIAGRAM
- 03 BLOCK DIAGRAM
- 04 IO COMMAND/ID INPUT REGISTER/LATCH.  
SYSTEM COMMAND DRIVER/RECEIVER.
- 05 IO INPUT OPERATION CONTROL.
- 06 SYSTEM ADDRESS ENABLE AND BUSY LOGIC.  
MCLK BUFFER  
IOCLK GENERATOR
- 07 TIMER.  
IO BUS GRANT.  
IO OUTPUT LATCH CONTROL.  
SYSTEM DATA OUTPUT CONTROL.
- 08 IOREQ F/F.  
IPC RESPONSE SYSTEM BUS BUSY F/F.  
IPC READY INPUT MUX.
- 09 IPC RESPONSE LOGIC.  
IPC IOHOLD LOGIC.
- 10 SBI STATUS.
- 11 SBI SUPPORT PACKET BUS.
- 12 IO COMMAND/ID OUTPUT REGISTER/LATCH.  
IO DATA OUTPUT ENABLE.
- 13 IO COMMAND/ID TRANCEIVERS.  
IO BUS TERMINATORS.
- 14 SYSTEM ADDRESS OUT REGISTER/LATCH.  
SYSTEM ADDRESS DRIVERS/RECEIVERS.
- 15 SYSTEM DATA OUT REGISTER/LATCH.
- 16 IO PROTECTION RAM.  
TEST/SET BUFFER.
- 17 SPB STATUS BUFFER/ERROR LOG.  
WRITE BYTE COPY BUFFER.
- 18 SYSTEM DATA IN REGISTER/LATCH.
- 19 SYSTEM DATA TRANCEIVERS.  
SYSTEM BUS TERMINATION.
- 20 IO DATA DRIVERS/RECEIVERS.
- 21 BACK PLANE CONNECTOR.
- 22 SPARE GATES.

9236R0

DRAWING  
 TITLE=USXXXSBI  
 ABBREV=SBI  
 LAST\_MODIFIED=Fri Jun 14 13:37:06 1985  
 USXXXSBI.LOGIC.1.1

WANG LABORATORIES, INC.	REV: R0
TITLE: US300 SBI 9236	DATE: 6/14/85
ENGINEER: B.J. PATEL, P.A. MORRISON	PAGE: 1 OF 22



DRAWING  
 USXXXSBI..1.2  
 LAST\_MODIFIED=Mon Jun 3 12:58:49 1985

WANG LABORATORIES, INC.	REV: R0
TITLE: US300 SBI 9236	DATE: 6/14/85
ENGINEER:	PAGE: 2 OF 22

77

22

11

11

11

11

58

58

8.5"

8.5"

11"


11"

17"

17"


22"

22"



DRAWING  
 USXXXSBI.LOGIC.1.3  
 LAST\_MODIFIED= Tue Jun 4 14:02:27 1985

WANG LABORATORIES, INC.	REV: R0
TITLE: VS300 SBI 9236	DATE: 6/14/85
ENGINEER:	PAGE: 3 OF 22




DRAWING  
 USXXXSBI..1.4  
 LAST\_MODIFIED=Mon Jun 17 12:22:10 1985

WANG LABORATORIES, INC.	REV: R0
TITLE: US300 SBI 9236	DATE: 6/14/85
ENGINEER:	PAGE: 4 OF 22



77  
 11  
 11  
 9.8  
 8.5  
 11  
 17  
 22

22  
 11  
 11  
 9.5  
 8.5  
 11  
 17  
 22




SET ASBIBSY ((IOS+IOT), IOEB00+SELFTIN), IOIN#, IOEDGE, OLE#  
 ,(SBCYCLE#+SBSYI+TSREAD)  
 RESET ASBIBSY (BSBIBSY+SBCYCLE#, OREQ#+SDF, TSREAD#), IOEDGE

DRAWING

VSXXXSBI.LOGIC.1.5

LAST\_MODIFIED=Mon Jun 17 12:23:51 1985

WANG LABORATORIES, INC.	REV: R0
TITLE: VS300 SBI 9236	DATE: 6/14/85
ENGINEER:	PAGE: 5 OF 22



SET BSREQ = (SREQS+SREQDT), OREG, SBSTART\*  
CLR BSREQ = SBSTART

SET REQ = SREQS+SREQDT+SBCYCLE, SBSYI\*, TSBREAD  
CLR REQ = SBSTART, OREG\*, SREQS\*, SREQDT\*

SREQDT = (I00T, QAP+SELFTIN), IOIN, IOEDGE, (ET\*+QIOIN)

SET SBSYO = SBSYI\*, SRESP\*, (J\*+CLF), OREG, SBCYCLE\*, (SLOCKI+PRIN, SLOCKI\*)  
(HART\*+CHGSR\*, (FALLT\*+QFNOP))

IOLOCK	JP1	JP2	JP3	JP4
120 NS	OUT	IN	IN	OUT
100 NS	(AUT	IN	OUT	IN
240 NS	IN	OUT	OUT	IN


**DRAWING**

VSXXXSBI...1.B  
LAST\_MODIFIED=Mon Jun 17 12:25:21 1985

(WANG) LABORATORIES, INC.	REV: R0
TITLE: VS300 SBI 9236	DATE: 6/14/85
ENGINEER:	PAGE: 6 OF 22

**SYSTEM BUS CONTROL**


77  
 11  
 11  
 9.8  
 8.5  
 11  
 17  
 22










DRAWING  
 LAST\_MODIFIED=Mon Jun 17 12:27:12 1985  
 VSXXXSBI.LOGIC.1.7

(WANG) LABORATORIES, INC.	REV: R0
TITLE: VS300 SBI 9236	DATE: 6/14/85
ENGINEER:	PAGE: 7 OF 22

22  
 11  
 11  
 9.8  
 8.5  
 11  
 17  
 22



JUMPER SETTING JP1 JP2 JP3 JP4 JP5 JP6 JP7 JP8  
 SBI ID=HEX B IN OUT OUT IN IN OUT IN OUT




DRAWING  
 USXXXSBI.LOGIC.1.B  
 LAST\_MODIFIED=Mon Jun 17 12:28:57 1985

SET IOPENDING = IOEDGE\*. (GSDF+GSIPCIN(IPCR\*+FHESG))  
 IOPENDING = IOEDGE\*. (GSDF+GSIPCIN(IPCR\*+FHESG))  
 CLR IOREQ = IOEDGE. (ZHOLD\*(QIPC-IHOLD). X-IHOLD\*. (XDF\*+ILE+IOENB). IOPENDING\*. GSDF\*. (GSIPCIN\*+IPCR.FHESG\*. (SBRBYO+TIOCBSY)))  
 SET IOREQ = IOEDGE. (IOPENDING+GSDF+GSIPCIN. (TIOCBSY\*+IPCR\*+FHESG))  
 CLR IOREQ = IOEDGE. (ZHOLD\*(QIPC-IHOLD). X-IHOLD\*. (XDF\*+ILE+IOENB). IOPENDING\*. GSDF\*. (GSIPCIN\*+IPCR.FHESG\*. (SBRBYO+TIOCBSY)))

SET SBRBYO = GSIPCIN. IPCR. FHESG\*. (IOEDGE\*+TIOCBSY\*. AIOREQ\*)  
 CLR SBRBYO = TIOCBSY. IOEDGE+AIOREQ. IOEDGE

WANG LABORATORIES, INC.	REV: R0
TITLE: US300 SBI 9236	DATE: 6/14/85
ENGINEER:	PAGE: 8 OF 22

77  
"L1  
"L1  
"5'8  
C  
B  
8.5"  
11"  
17"  
22"



GSDF = SBCYCLE, TSMRITE, SBSYI, (BMCB + BIOIPC, SMMAI, QSBSTART + QSMMAI, QSBSTART)

TARGETBSY = IMATCH, ((DF + IPCR-PND), SRBSYO + TIOCBSY, FMESSG, IPCR, IOEDGE)


SHORT-IPC = UMATCH, (IPCR + FMESSG + TIOCBSY, SRBSYO, IOEDGE, AIOREQ)

LONG IPC = IOEDGE, AIOREQ, TIOCBSY, SRBSYO

DRAWING  
V5300SBI.LOGIC.1.8  
LAST\_MODIFIED=Mon Jun 17 12:30:29 1985

WANG LABORATORIES, INC.	REV: R0
TITLE: V5300 SBI 9236	DATE: 6/14/85
ENGINEER:	PAGE: 9 OF 22

"22  
"L1  
"L1  
"5'8  
C  
B  
8.5"  
11"  
17"  
"22




DRAWING  
 USXXXSBI.LOGIC.1.10  
 LAST\_MODIFIED=Mon Jun 17 11:56:34 1985  


WANG LABORATORIES, INC.	REV: R0
TITLE: US300 SBI 9236	DATE: 6/14/85
ENGINEER:	PAGE: 10 OF 22

7.7" 7.7" 11" 11" 8.5" 8.5" 11" 11" 17" 17" 22" 22"

77  
 "L1  
 "11  
 "5.8  
 B  
 8.5"  
 11"  
 17"  
 22"




"22  
 "L1  
 "11  
 "5.8  
 B  
 8.5"  
 11"  
 17"  
 22"



DRAWING  
VSXXXSBI.LOGIC.1.12  
LAST\_MODIFIED=Mon Jun 17 12:01:46 1985

WANG LABORATORIES, INC.	REV: R0
TITLE: VS300 SBI 9236	DATE: 6/14/85
ENGINEER:	PAGE: 12 OF 22






SBI IOBUS INTERFACE

DRAWING

VSXXXSBI.LOGIC.1.13

LAST\_MODIFIED=Mon Jun 17 12:07:23 1985

(WANG) LABORATORIES, INC.	REV: R0
TITLE: VS300 SBI 9236	DATE: 6/14/85
ENGINEER:	PAGE: 13 OF 22



SYSTEM ADDRESS REGISTER, OUTPUT DRIVER, INPUT BUFFER

DRAWING


VSXXXSBI.LOGIC.1.14

LAST\_MODIFIED=Mon Jun 17 12:09:19 1985

WANG LABORATORIES, INC.	REV: R0
TITLE: VS300 SBI 9236	DATE: 6/14/85
ENGINEER:	PAGE: 14 OF 22

77  
 11  
 11  
 9.8  
 8.5  
 11  
 17  
 22

22  
 11  
 11  
 9.8  
 8.5  
 11  
 17  
 22

















SYSTEM DATA OUTPUT REGISTER

DRAWING

VSXXXSBI.LOGIC - 15  
 LAST\_MODIFIED=Mon Jun 17 12:11:08 1985

WANG LABORATORIES, INC.	REV: R0
TITLE: VS300 SBI 9236	DATE: 6/14/85
ENGINEER:	PAGE: 15 OF 22

6 7 8 5 4 3 2 1



DRAWING


USXXXSBI...1.18  
 LAST\_MODIFIED=Mon Jun 17 12:12:54 1985

WANG LABORATORIES, INC.	REV: R0
TITLE: VS300 SBI 9236	DATE: 6/14/85
ENGINEER:	PAGE: 16 OF 22

6 7 8 5 4 3 2 1

7.7  
 11  
 11  
 5.8  
 8.5  
 11  
 17  
 22

22  
 11  
 11  
 5.8  
 8.5  
 11  
 17  
 22




DRAWING

VSXXXSBI.LOGIC.1.17

LAST\_MODIFIED=Mon Jun 17 12:14:37 1985

WANG LABORATORIES, INC.	REV: R0
TITLE: VS300 SBI 9236	DATE: 6/14/85
ENGINEER:	PAGE: 17 OF 22



DRAWING


USXXXSBI.LOGIC.1.18  
 LAST\_MODIFIED=Mon Jun 17 12:17:06 1985

WANG LABORATORIES, INC.	REV: R0
TITLE: US300 SBI 9236	DATE: 6/14/85
ENGINEER:	PAGE: 18 OF 22

SYSTEM DATA INPUT REGISTER, IO BUFFER

77  
"L1  
"L1  
"S'8  
8.5"  
11"  
17"  
22"

"22  
"L1  
"L1  
"S'8  
8.5"  
11"  
17"  
22"




DRAWING

VSXXXSBI.LOGIC.1.19  
LAST\_MODIFIED=Mon Jun 17 12:20:04 1985

WANG LABORATORIES, INC.	REV: R0
TITLE: VS300 SBI 9236	DATE: 6/14/85
ENGINEER:	PAGE: 19 OF 22

SYSTEM BUS TERMINATORS



DRAWING  
 IO DATA BUS DRIVERS  
 VSXXXSBI..1.20  
 LAST\_MODIFIED=Mon Jun 17 12:00:06 1985

WANG LABORATORIES, INC.	REV: R0
TITLE: VS300 SBI 9236	DATE: 6/14/85
ENGINEER:	PAGE: 20 OF 22



CONNECTOR A

CONNECTOR B

CONNECTOR C

A-001 GND  
 A-003 +5V  
 A-006 GND  
 A-007 IPCRDY2\*  
 A-011 GND  
 A-013 IPCRDY4\*  
 A-015 IPCRDY6\*  
 A-017 IPCRDY7\*  
 A-021 SA02\*  
 A-023 SA03\*  
 A-025 IPCRDY9\*  
 A-027 IPCRDY11\*  
 A-029 IPCRDY12\*  
 A-031 SA05\*  
 A-033 SA06\*  
 A-035 SA08\* X1 IOB00\*  
 A-037 SA09\* X2 IOB01\*  
 A-039 SA10\*  
 A-043 SA11\* X6 IOB05\*  
 A-045 SA11\* X7 IOB06\*  
 A-049 SA14\*  
 A-051 GND  
 A-053 SA15\* X11 IOB10\*  
 A-055 SA15\* X13 IOB12\*  
 A-059 SA15\* X14 IOB13\*  
 A-063 SA16\*  
 A-065 SA19\* X18 IOB15\*  
 A-067 SA19\* X18 IOB17\*  
 A-069 SA19\* X19 IOB18\*  
 A-071 SA22\* X21 IOB20\*  
 A-075 SA24\* X23 IOB22\*  
 A-079 SA24\* X24 IOB23\*  
 A-081 SA26\* X26 IOB25\*  
 A-085 SA27\* X28 IOB27\*  
 A-089 SA28\* X29 IOB28\*  
 A-091 SA30\* X31 IOB30\*  
 A-095 SA31\*  
 A-097 +5V  
 A-099 GND

A-002 GND  
 A-004 +5V  
 A-008 TINTP\*  
 A-010 IPCRDY1\*  
 A-012 IPCRDY3\*  
 A-014 SA00\*  
 A-016 IPCRDY5\*  
 A-018 SA01\*  
 A-020 IPCRDY8\*  
 A-022 GND  
 A-024 SA04\*  
 A-026 IPCRDY10\*  
 A-028 SA05\*  
 A-030 IPCRDY13\*  
 A-032 IPCRDY14\*  
 A-034 SA07\*  
 A-036 IPCRDY15\*  
 A-038 SA08\* X3 IOB02\*  
 A-040 SA08\* X4 IOB03\*  
 A-042 SA08\* X5 IOB04\*  
 A-046 SA12\*  
 A-048 SA13\* X8 IOB07\*  
 A-050 SA13\* X9 IOB08\*  
 A-052 SA16\* X12 IOB11\*  
 A-054 SA16\* X12 IOB09\*  
 A-056 SA17\* X15 IOB14\*  
 A-058 SA20\* X17 IOB16\*  
 A-060 SA21\*  
 A-062 SA21\* X20 IOB19\*  
 A-064 SA23\* X22 IOB21\*  
 A-066 SA25\* X25 IOB24\*  
 A-068 SA25\* X27 IOB26\*  
 A-070 SA25\*  
 A-072 SA25\* X25 IOB24\*  
 A-074 SA25\* X27 IOB26\*  
 A-076 SA25\* X25 IOB24\*  
 A-078 SA25\* X27 IOB26\*  
 A-080 SA25\*  
 A-082 SA25\*  
 A-084 GND X30 IOB29\*  
 A-086 SA25\* X32 IOB31\*  
 A-088 +5V  
 A-100 GND

B-001 GND  
 B-003 +5V  
 B-005 GND  
 B-007 TPSBISDT\*  
 B-009 TPSBIIOPC\*  
 B-011 TPSBIIIOE\*  
 B-013 TPSBIIIOI\*  
 B-015 TPSBIIOLF\*  
 B-017 TPSBIIIOI\*  
 B-019 TPSBIIIOI\*  
 B-021 TPSBIIIOI\*  
 B-023 TPSBIIIOI\*  
 B-025 TPSBIIOLF\*  
 B-027 TPSBIIOLF\*  
 B-029 TPSBIIOLF\*  
 B-031 TPSBIIOLF\*  
 B-033 WAIT\*  
 B-035 BUSY\*  
 B-037 VMA\*  
 B-039 LOCK\*  
 B-041 PROUT\*  
 B-043 ACK\*  
 B-045 TB\*  
 B-047 GND  
 B-049 GND  
 B-051 GND  
 B-053 SDP0\*  
 B-055 SDP0\*  
 B-057 SDP1\*  
 B-059 SDP4\*  
 B-061 GND  
 B-063 SDP7\*  
 B-065 SDP1\*  
 B-067 SDP9\*  
 B-069 SD11\*  
 B-071 SD12\*  
 B-073 SD14\*  
 B-075 SDP2\*  
 B-077 SD18\*  
 B-079 SD18\*  
 B-081 SD18\*  
 B-083 SD18\*  
 B-085 SD22\*  
 B-087 GND  
 B-089 SD24\*  
 B-091 SD25\*  
 B-093 SD27\*  
 B-095 SD28\*  
 B-097 SD31\*  
 B-099 +5V  
 B-100 GND

B-002 GND  
 B-004 +5V  
 B-006 MEHCLK\*  
 B-008 GND  
 B-010 TPSBIIIPC\*  
 B-012 TPSBIIERR\*  
 B-014 GND  
 B-016 GND  
 B-018 GND  
 B-020 GND  
 B-022 GND  
 B-024 GND  
 B-026 GND  
 B-028 GND  
 B-030 GND  
 B-032 GND  
 B-034 MCB\*  
 B-036 MCB\*  
 B-038 MCB\*  
 B-040 MCB\*  
 B-042 PRIN\*  
 B-044 GND  
 B-046 GND  
 B-048 GND  
 B-050 GND  
 B-052 GND  
 B-054 GND  
 B-056 GND  
 B-058 SD02\*  
 B-060 SD03\*  
 B-062 SD05\*  
 B-064 SD06\*  
 B-066 SD08\*  
 B-068 GND  
 B-070 SD10\*  
 B-072 SD13\*  
 B-074 SD14\*  
 B-076 SD15\*  
 B-078 SD17\*  
 B-080 GND  
 B-082 SD20\*  
 B-084 SD21\*  
 B-086 SD23\*  
 B-088 SDP3\*  
 B-090 SD26\*  
 B-092 GND  
 B-094 SD29\*  
 B-096 SD30\*  
 B-098 +5V  
 B-100 GND

C-001 GND  
 C-003 +5V  
 C-005 X33 ID0\*  
 C-007 GND  
 C-009 SD32\*  
 C-011 SD34\*  
 C-013 GND  
 C-015 SD35\* X36 SELINIT\*  
 C-017 SD37\*  
 C-019 BCKO  
 C-021 GND  
 C-023 GND  
 C-025 SDP5\* X40 C1\*  
 C-027 SD41\* X41 C2\*  
 C-029 SD41\* X43 IOHOLD\*  
 C-031 GND  
 C-033 SD44\* X48 IOBUSY\*  
 C-035 SD44\* X47 SBIBUSY\*  
 C-037 SD46\* X48 IOBUSY\*  
 C-039 SD48\* X47 SBIBUSY\*  
 C-041 SD48\* X48 IOIREQ\*  
 C-043 SD48\* X49 GRO\*  
 C-045 SD50\* X49 GRO\*  
 C-047 SD53\*  
 C-049 SD53\*  
 C-051 SD55\*  
 C-053 SD55\* X50 R007\*  
 C-055 SD55\* X52 IOPWR\*  
 C-057 SD55\* X52 IOPWR\*  
 C-059 SD55\* X52 IOPWR\*  
 C-061 SD55\* X52 IOPWR\*  
 C-063 SD55\* X52 IOPWR\*  
 C-065 SD55\* X52 IOPWR\*  
 C-067 SD55\* X52 IOPWR\*  
 C-069 SD55\* X52 IOPWR\*  
 C-071 SD55\* X52 IOPWR\*  
 C-073 SD55\* X52 IOPWR\*  
 C-075 SD55\* X52 IOPWR\*  
 C-077 SD55\* X52 IOPWR\*  
 C-079 SD55\* X52 IOPWR\*  
 C-081 SD55\* X52 IOPWR\*  
 C-083 SD55\* X52 IOPWR\*  
 C-085 SD55\* X52 IOPWR\*  
 C-087 SD55\* X52 IOPWR\*  
 C-089 SD55\* X52 IOPWR\*  
 C-091 SD55\* X52 IOPWR\*  
 C-093 SD55\* X52 IOPWR\*  
 C-095 SD55\* X52 IOPWR\*  
 C-097 SD55\* X52 IOPWR\*  
 C-099 SD55\* X52 IOPWR\*

C-002 GND  
 C-004 +5V  
 C-006 X34 ID1\*  
 C-008 SDP4\* X35 ID2\*  
 C-010 SD33\* X36 ID3\*  
 C-012 SD33\* X37 ID4\*  
 C-014 SD33\* X38 ID4\*  
 C-016 SD33\* X39 C0\*  
 C-018 SD33\* X39 C0\*  
 C-020 SD33\* X39 C0\*  
 C-022 SD33\* X39 C0\*  
 C-024 SD33\* X39 C0\*  
 C-026 SD33\* X39 C0\*  
 C-028 SD33\* X39 C0\*  
 C-030 SD33\* X39 C0\*  
 C-032 SD33\* X39 C0\*  
 C-034 SD33\* X39 C0\*  
 C-036 SD33\* X39 C0\*  
 C-038 SD33\* X39 C0\*  
 C-040 SD33\* X39 C0\*  
 C-042 SD33\* X39 C0\*  
 C-044 SD33\* X39 C0\*  
 C-046 SD33\* X39 C0\*  
 C-048 SD33\* X39 C0\*  
 C-050 SD33\* X39 C0\*  
 C-052 SD33\* X39 C0\*  
 C-054 SD33\* X39 C0\*  
 C-056 SD33\* X39 C0\*  
 C-058 SD33\* X39 C0\*  
 C-060 SD33\* X39 C0\*  
 C-062 SD33\* X39 C0\*  
 C-064 SD33\* X39 C0\*  
 C-066 SD33\* X39 C0\*  
 C-068 SD33\* X39 C0\*  
 C-070 SD33\* X39 C0\*  
 C-072 SD33\* X39 C0\*  
 C-074 SD33\* X39 C0\*  
 C-076 SD33\* X39 C0\*  
 C-078 SD33\* X39 C0\*  
 C-080 SD33\* X39 C0\*  
 C-082 SD33\* X39 C0\*  
 C-084 SD33\* X39 C0\*  
 C-086 SD33\* X39 C0\*  
 C-088 SD33\* X39 C0\*  
 C-090 SD33\* X39 C0\*  
 C-092 SD33\* X39 C0\*  
 C-094 SD33\* X39 C0\*  
 C-096 SD33\* X39 C0\*  
 C-098 SD33\* X39 C0\*  
 C-100 SD33\* X39 C0\*

DRAWING

USXXXSBI..1.21

LAST\_MODIFIED=Mon Jun 17 12:05:13 1985

WANG LABORATORIES, INC.	REV: R0
TITLE: VS300 SBI 9236	DATE: 6/14/85
ENGINEER:	PAGE:21 OF 22

BACKPLANE CONNECTOR

22"

22"

17"

17"

11"

11"

8.5"

8.5"

8.5"

8.5"

11"


11"


17"

17"

22"


22"





NOTES:  
 1. UNLESS OTHERWISE SPECIFIED,  
 ALL CAPACITORS ARE 50%UF EXPRESSED IN MICROFARADS.  
 ALL RESISTORS ARE 1/4W 5% EXPRESSED IN OHMS.  
 2. R56A R57A R510A R511A R512A ARE NOT LOADED.  
 3. REFERENCE ASSEMBLY PRINT AND/OR SCHEMATICS FOR JUMPER CONFIGURATIONS.  
 JUMPERS ARE 374-9124.

<b>WANG</b>		BY	DATE	APPROVED BY	DATE
		CHM		E ENGR	
MATERIAL	MODEL NO.	E C CONTROL			
	VS300	HFD ENGR			
FINISH	10-214	TITLE			
		VS300 SBI			
		214-9236	C	9236	0




COMPONENT	TYPE	WL PART NO
R1	1K 1/4W 5%	330-3011
R2,5,6,9,11,17-25	47.7L 1/4W 5%	330-1048
C1-4	.1UF 50V	300-1B33
C5-19	470PF 50V	300-1063
J1	CONN, 5 PIN	350-0238
J2	CONN, 3 PIN	350-J217
J3	CONN, 2 PIN	350-0218
J4	CONN, 96 PIN	350-0492
J5-9	CONN, 86 PIN	350-0473

NOTE:  
 1. UNLESS OTHERWISE SPECIFIED,  
 ALL RESISTORS ARE IN OHMS 1/4W 5%  
 2. C1, C18, C19, C20, C21, R2A, R2B, R2C,  
 R2D ARE NOT LOADED AT THIS TIME FOR  
 E.C.O. 29223.

<b>WANG</b>		DATE	APPROVED BY	DATE
MOTHER BOARD		210-9237	E	9237
REV		1		

UNLIMITED PER  
 OWNER BY 4158  
 AMP-D-117-1-67  
 REVISED BY 4158  
 4-6-67

"THIS DRAWING AND THE DATA SHOWN THEREON ARE THE CONFIDENTIAL PROPERTY OF, AND ARE PROPRIETARY TO, WANG LABORATORIES, INC. THIS DRAWING AND THE DATA SHOWN THEREON MAY NOT BE MADE PUBLIC WITHOUT THE WRITTEN CONSENT OF WANG LABORATORIES, INC. IF FOR ANY REASON THIS DRAWING IS PERMITTED BY WANG TO LEAVE THE PHYSICAL CUSTODY OF THE COMPANY, IT IS RETURNABLE UPON THE DEMAND OF WANG LABORATORIES, INC."




NOTES: 1. UNLESS OTHERWISE SPECIFIED, ALL RESISTORS ARE 47 OHM 1/4W. 5% EXPRESSED IN OHMS. CONNECTORS J5-J9 ARE 350-0473. CAPACITORS C5-C10 ARE 470 PF. P/N 300-1003.

NO.	REVISION	DATE	BY	APPROVED BY
1	DWR#E2125	7-28-83	EBA	SJM
2	ECO # 29229, 29896	7-22-83	SJM	GWC
3	ECO #30143	11-1-83	GWC	


<b>WANG</b> LABORATORIES, INC. LOWELL, MASS., U.S.A.		BY	DATE	APPROVED BY	DATE
MATERIAL		DWN E. ACHESON	7-28-83	E ENGR	
MODEL NO. PBC H0067A		CHK		M ENGR	
SEE ENGR SPECIFICATIONS NO. 10-213		E C CONTROL		MFG ENGR	
FINISH		TITLE MULTILAYER MOTHER BOARD ASSEMBLY DRAWING			
TOL. EX. AS NOTED		210-9237-R3	C	9237	3
SCALE 1/1 SH 4 OF 8		WANG PART NUMBER	SIZE	DRAWING NUMBER	

Grid lines and dimensions: 6, 5, 4, 3, 2, 1 (horizontal); E, D, C, B, A (vertical). Dimensions: 8.5", 11", 17" (vertical); 8.5", 11" (horizontal).

THIS DRAWING AND THE DATA SHOWN THEREON ARE THE CONFIDENTIAL PROPERTY OF, AND ARE PROPRIETARY TO, WANG LABORATORIES. NO PART OF THIS DRAWING AND THE DATA SHOWN THEREON MAY BE MADE PUBLIC WITHOUT THE WRITTEN CONSENT OF WANG LABORATORIES, INC. IF FOR ANY REASON THIS DRAWING IS PERMITTED BY WANG TO LEAVE THE PHYSICAL POSSESSION OF THE COMPANY, IT IS RETURNABLE UPON THE DEMAND OF WANG LABORATORIES, INC.



- NOTES
1. ALL RESISTOR VALUES IN OHMS.
  2. ALL CAPACITOR VALUES IN MICROFARADS UNLESS OTHERWISE INDICATED.
  3. ALL RESISTORS 1/4W 5% UNLESS OTHERWISE INDICATED.



MNEMONIC	COORD
ATCRC	5B11
APWC	2C11
BPC	2C11
CLK	2A11
BACKD	2A11
DLRESTART	4A1
HACK	2B11
I/OADDRESSMATCH	5A7
I/OERROR	6B1
TORC	5D11
PRDC	2C11
PA0-PA7, PA16-PA19	3G11
PAB-PA15	6D11
PARITYERROR	6A1
PARITYCONTROL	6C11
PDD-PD15	6E1
PTRY	5F11
RCYCLE	3C1
RDY	2B1

MNEMONIC	COORD
RESET	5A11
SAD	5D11
ST00-S1D3	5C11
ZAD-ZA15	5E1
ZBUSAK	3E11
ZBUSRD	4G1
ZCRSEL	3E11
ZCRTWT	3E1
ZDLREQ	4F1
ZDD-ZD7	5G1
ZRD	4F1
ZRESET	5A11
ZRAT	5G1
ZB0000PRESENT	5E1
4CLK	3A11
*GA	5B1
*GB	5B1
-RA	5B1
-RB	5A1


E REV

1


NO	REVISION	DATE	BY	CHKD	APPD	ECO NO.	CHKD	APPD
1	ORIGINATED PER	7-29-83	KTH	PCD	PCD	11-17-83	KTH	PCD
2	REVISED PER	11-17-83	KTH	PCD	PCD	12-29-83	KTH	PCD
3	REVISED PER	01-09-84	KTH	PCD	PCD	05-09-84	KTH	PCD
4	REVISED PER	05-09-84	KTH	PCD	PCD	07-05-84	AB	PCD
5	REVISED PER	07-05-84	AB	PCD	PCD	08-14-84	JSW	PCD

<b>WANG</b> LABORATORIES, INC.		SCHEMATIC DIAGRAM	
TITLE		PC LOCAL COMM DL BC	
NO. NUMBER	PBTA	WANG PART NUMBER	OWN WITH CHG
	PBC	210-9245	ENG
SCALE		SIZE	
SHEET 1 OF 8		DRAWING NUMBER	

THIS DRAWING AND THE DATA SHOWN THEREON ARE THE CONFIDENTIAL PROPERTY OF, AND ARE PROPRIETARY TO, WANG LABORATORIES, INC. THIS DRAWING AND THE DATA SHOWN THEREON MAY NOT BE MADE PUBLIC WITHOUT THE WRITTEN CONSENT OF WANG LABORATORIES, INC. IF FOR ANY REASON THIS DRAWING IS PERMITTED BY WANG TO LEAVE THE PHYSICAL CONTROL OF THE COMPANY, IT IS RETURNABLE UPON THE DEMAND OF WANG LABORATORIES, INC.



THIS DRAWING AND THE DATA SHOWN THEREON ARE THE CONFIDENTIAL PROPERTY OF, AND ARE PROPRIETARY TO, WANG LABORATORIES, INC. THIS DRAWING AND THE DATA SHOWN THEREON ARE NOT TO BE MADE PUBLIC WITHOUT THE WRITTEN CONSENT OF WANG LABORATORIES, INC. IF FOR ANY REASON THIS DRAWING IS REPRODUCED BY ANY OTHER PARTY, IT IS THE RESPONSIBILITY OF THE COMPANY, IT IS REPRODUCIBLE UPON THE DEMAND OF WANG LABORATORIES, INC.




NO	REVISION	SEE SHEET 1

<b>WANG</b> LABORATORIES, INC.		D	9245	6
SCALE	SHEET 3 OF 8	SIZE	DRAWING NUMBER	REV




THIS DRAWING AND THE DATA SHOWN THEREON ARE THE CONFIDENTIAL PROPERTY OF, AND ARE PROPRIETARY TO, WANG LABORATORIES, INC. THIS DRAWING AND THE DATA SHOWN THEREON MAY NOT BE MADE PUBLIC WITHOUT THE WRITTEN CONSENT OF WANG LABORATORIES, INC. IF FOR ANY REASON THIS DRAWING IS REPRODUCED BY ANYONE, THE PHYSICAL COPIES OF THIS DRAWING, IF ANY, ARE RETURNABLE UPON THE DEMAND OF WANG LABORATORIES, INC.




<b>WANG</b> LABORATORIES, INC.		D	9245	6
SCALE	SHEET 4 OF 8	SIZE	DRAWING NUMBER	REV.

THIS DRAWING AND THE DATA SHOWN THEREON ARE THE CONFIDENTIAL PROPERTY OF, AND ARE PROPRIETARY TO, WANG LABORATORIES, INC. THIS DRAWING AND THE DATA SHOWN THEREON MAY NOT BE MADE PUBLIC WITHOUT THE WRITTEN CONSENT OF WANG LABORATORIES, INC. IF FOR ANY REASON THIS DRAWING IS PERMITTED BY WANG TO LEAVE THE POSSESSION OF THE COMPANY, IT IS RETURNABLE UPON THE DEMAND OF WANG LABORATORIES, INC.




THIS DRAWING AND THE DATA THEREON ARE THE CONFIDENTIAL PROPERTY OF WANG LABORATORIES, INC. AND THE PROPRIETARY TRADE LIBRARY OF WANG LABORATORIES, INC. IT IS STRICTLY CONFIDENTIAL AND NOT TO BE MADE PUBLIC WITHOUT THE WRITTEN CONSENT OF WANG LABORATORIES, INC. IF FOR ANY REASON THIS DRAWING IS PERMITTED BY WANG TO LEAVE THE POSSESSION, CUSTODY OF THE COMPANY, IT IS RETURNABLE UPON THE DEMAND OF WANG LABORATORIES, INC.



NO	REVISION

THIS DRAWING AND THE DATA THEREON ARE THE CONFIDENTIAL PROPERTY OF, AND ARE PROPRIETARY TO, WANG LABORATORIES, INC. THIS DRAWING AND THE DATA THEREON MAY NOT BE MADE PUBLIC WITHOUT THE WRITTEN CONSENT OF WANG LABORATORIES, INC. IF FOR ANY REASON THIS DRAWING IS PERMITTED BY WANG TO LEAVE THE PHYSICAL POSSESSION OF THE COMPANY, IT IS RETURNABLE UPON THE DEMAND OF WANG LABORATORIES, INC.



NO	REVISIONS

	LABORATORIES, INC.	D	9245	E
	SCALE			

THIS DRAWING AND THE DATA THEREON ARE THE CONFIDENTIAL PROPERTY OF, AND ARE PROPRIETARY TO, WANG LABORATORIES, INC. NO PART OF THIS DRAWING OR THE DATA THEREON MAY BE MADE PUBLIC WITHOUT THE WRITTEN CONSENT OF WANG LABORATORIES, INC. IF FOR ANY REASON THIS DRAWING IS PERMITTED BY WANG TO LEAVE THE POSSESSION OF THE COMPANY, IT IS RETURNABLE TO THE COMPANY AT THE DEMAND OF WANG LABORATORIES, INC.

IC LOCATION	TYPE	W.L. PART NO.
L1-L9	7454116-20JL	377-0345
L20-L28	4864-2	377-0417
L10-L12, L29-L31, L69	745257	376-0131
L13, L32, L38	745241	376-0506
L14, L57	745393	376-0307
L15, L34, L72-L74, L88, L90, L91, L94, L99	74574	376-0202
L16	745164	376-0236
L17, L67	74527	376-0245
L18, L51, L93	74500	376-0228
L19, L86, L96	74574	376-0155
L33, L100	74532	376-0205
L35, L95, L97	745125	376-0486
L36, L64, L87	74504	376-0180
L37, L84	74508	376-0153
L39, L44, L47, L78, L81	745244	376-0288
L40, L41, L45	745374	376-0286
L42, L43, L101	745257	376-0204
L46	745280	376-0246
L48, L60	745273	376-0302

IC LOCATION	TYPE	W.L. PART NO.
L49, L50	74585	376-0259
L52, L53, L65, L70, L85	74532	376-0211
L54, L71	74508	376-0200
L55, L76	74504	376-0197
L56, L83	74502	376-0199
L58	75107	376-0146
L59	2001	397-0508
L61	745373	376-0306
L62, L77, L79, L80	745373	376-0310
L63, L98	745138	376-0294
L66	74505	376-0555
L68	74520	376-0230
L75	75113	376-0256
L82	74586	376-0231
L89	74511	376-0237
L92, L102-L104	SPARE	



COMPONENT	TYPE	W.L. PART NO.	QTY
C1-C4	100UF 20V (T)	300-4067	4
C5-C22, C33-C41	.1UF 50V	300-1833	27
C23-C32, C42-C70, C72-C88, C90-C105, C108-C116	.047UF 50V	300-1966	81
C71	1UF 35V 10%	300-4110	1
C89	.01UF 25V	300-1903	1
C101A	330PF	300-1834	1
C106, C107	33PF 500V	300-1033	2
C117	560PF 10% 500V	300-1560	1
R1, R9-R11	22 1/4W 5%	330-1023	4
R2-R8, R12-R19, R37	100 1/4W 5%	330-2011	16
R20, R21	1.5K 1/4W 5%	330-3016	2
R22, R23, R25, R28, R35, R39, R40, R43, R48, R52	1K 1/4W 5%	330-3011	10
R24	2.2K 51P	333-0806	1
R26, R30, R47, R49, R50, R51, R53	2.2K 1/4W 5%	330-3023	7
R27	10K 1/4W 5%	330-4011	1
R29	91 1/4W 5%	330-1092	1
R30	390 1/4W 5%	330-2040	1
R31, R32, R34, R41, R44	330 1/4W 5%	330-2034	5
R33, R42, R45	10 1/4W 5%	330-1011	3
R38	270 1/4W 5%	330-2028	1
R46	4.7K 1/4W 5%	330-3048	1
J9	40 PIN SKT	376-9011	1
J3	CONN BNC	350-1036	1
J4	CONN TNC	350-2078	1
Q1-Q3	SPS 6551	375-1050	3
SW1		325-0040	1
F1	17.1 MHZ	321-0018	1
	CONN TNC	350-2078	1
	CONN BNC	350-1036	1
	GND LUG	654-1011	2
	R. F. SHIELD	458-3086	1
	SCREW 3/8" 8-32	650-4120	2
	NUT 8-32	652-0029	2
	EJECTOR	465-1250	1
	LBL, REMOVE LOCAL CONN	615-2201	1
	LBL, R.F. SHIELD 8245/9245	615-2204	1
	WIRE 22GA BLK	600-0300	A/R
	WIRE 22GA RED	600-0302	A/R

- NOTES
1. ALL RESISTOR VALUES IN OHMS.
  2. ALL CAPACITOR VALUES IN MICROFARADS UNLESS OTHERWISE INDICATED.
  3. ALL RESISTORS 1/4W 5% UNLESS OTHERWISE INDICATED.

E REV  
1

REV	DATE
1	11/18/58
2	

<b>WANG</b> LABORATORIES, INC. 300 W. 4TH ST. NEW YORK, N.Y.		SCHEMATIC DIAGRAM	
MODEL NUMBER P67A PBC		WANG PART NUMBER 210-9245	
TITLE PC LOCAL CONN TO 80		OWN KTH [CHK] ENG [CHK] DRP [CHK]	
SCALE 1/1		SHEET 8 OF 8	
SIZE D		DRAWING NUMBER 9245 8	



LABEL WANG P/N 615-2281


LABEL WANG P/N 615-2284

L1-L9 SEE NOTE 3.

RF SHIELD (458-3096)  
SCREW NO. 0-32 X 3/8  
2 PLCS. (1650-4120)  
NUT HEX. NO. 0-32  
2 PLCS. (1652-0029)

L20-L28 SEE NOTE 3.

WIRE 30GA  
400-0170  
WIRE 30GA RED  
652-0302



REV.	DATE	BY	CHK	APP.
1				
2				
3				
4				
5				
6				

1. THIS DRAWING IS THE PROPERTY OF WANG COMPUTER SYSTEMS, INC. AND IS TO BE KEPT IN CONFIDENCE. IT IS TO BE USED ONLY FOR THE PURPOSES INTENDED AND IS NOT TO BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, INCLUDING PHOTOCOPYING, RECORDING, OR BY ANY INFORMATION STORAGE AND RETRIEVAL SYSTEM.

2. ALL DIMENSIONS ARE IN INCHES UNLESS OTHERWISE SPECIFIED.

3. ALL DIMENSIONS ARE TO CENTER UNLESS OTHERWISE SPECIFIED.


4. TORQUE SPEC TO 18 INCHES, ORIENT AND SPREAD LOG TO 9.00 POSITION.

5. TORQUE SPEC TO 18 INCHES, ORIENT AND SPREAD LOG TO 9.00 POSITION.

6. 1/16 MIN. DIMENSION HAS BEEN DESIGNATED TO AVOID OVERLAP FROM ADJACENT SHIELDS.

		DATE	REVISED	BY	CHK
		DATE	REVISED	BY	CHK
MATERIAL	MODEL NO.	TITLE LOCAL COMM DATA M/C			
	PBC	ASSEMBLY DRAWING			
FINISH	10-213	218 9245-41	C	9245	4

THIS DRAWING AND THE DATA SHOWN THERE ON ARE THE CONFIDENTIAL PROPERTY OF AND ARE PROPRIETARY TO WANG LABORATORIES, INC. THIS DRAWING AND THE DATA SHOWN THEREON MAY NOT BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, INCLUDING PHOTOCOPYING, RECORDING, OR BY ANY INFORMATION STORAGE AND RETRIEVAL SYSTEM, WITHOUT THE WRITTEN CONSENT OF WANG LABORATORIES, INC. IF FOR ANY REASON THIS DRAWING IS PERMITTED BY WANG TO LEAVE THE PHYSICAL CUSTODY OF THE COMPANY, IT IS RETURNABLE UPON THE DEMAND OF WANG LABORATORIES, INC.




WANG PART NO	DRAWING NO	DESCRIPTION	BY	DATE	APPROVED BY	DATE
			DWN	1/72	ENGR	
			CHK		M ENGR	
					MFG ENGR	
MATERIAL		MODEL NO FHS-77	TITLE			
FINISH		MI ENGR SPECIFICATIONS	1/2" WAVE FRONT TOLERANCE			
		TOL EA AS NOTED	D 924			
		FR = 0.10 FRAC = 1/16	SCALE			
		RES = 0.05 AND 1/32 FINISH	WANG PART NUMBER			
		SCALE	SIZE			
			DRAWING NUMBER			
			REV			





THIS DRAWING AND THE DATA SHOWN THERE ON ARE THE CONFIDENTIAL PROPERTY OF WANG AND ARE PROPRIETARY TO WANG LABORATORIES, INC. THIS DRAWING AND THE DATA SHOWN HEREIN MAY NOT BE MADE PUBLIC WITHOUT THE WRITTEN CONSENT OF WANG LABORATORIES, INC. IF FOR ANY REASON THIS DRAWING IS PLANNED BY HAND TO LEAVE THE PHYSICAL CUSTODY OF THE COMPANY, IT IS RETURNABLE UPON THE DEMAND OF WANG LABORATORIES, INC.



WANG PART NO	DRAWING NO	DESCRIPTION	BY	DATE	APPROVED BY	DATE
			OWN	1/27/64	ENGR	
			CHK		M ENGR	
					MFG ENGR	
MATERIAL			TITLE			
MODEL NO P1103471			PC LOCAL COMM. L. B. P.			
FINISH			SCALE			
TOL. EX. AS NOTED			SEE DRAWING			
EX. & DIM. FRAC. 1/16			D			
SEE & DIM. ANG. & 1/16			D			
SCALE 1/8" = 1"			REV			

77 11 10 9 8 7 5 4 3 2 1 22

11 17 11 5.8 8.5 11 17 22

DO NOT SCALE




IRQ2 IRQ3 IRQ4 IRQ5 IRQ6 IRQ7

THIS DRAWING AND THE DATA SHOWN THERE ON ARE THE CONFIDENTIAL PROPERTY OF AND ARE PROPRIETARY TO WANG LABORATORIES, INC. THIS DRAWING AND THE DATA SHOWN THEREIN MAY NOT BE MADE PUBLIC WITHOUT THE WRITTEN CONSENT OF WANG LABORATORIES, INC. IF FOR ANY REASON THIS DRAWING IS PERMITTED BY WANG TO LEAVE THE PHYSICAL CUSTODY OF THE COMPANY, IT IS RELEASABLE UPON THE DEMAND OF WANG LABORATORIES, INC.

MNEMONICS	COORD
A0-A7	ZF11
AIOWC	ZE11
CLK	3G5
DD-D7	ZC11
DL RESTART	1B11
DT/R	ZB11
HACK	ZC11
ZC ADDR MATCH	ZE11
IORC	ZC11
IRQ1-IRQ7	3A5
PARITY CONTROL	3F1
PARITY ERROR	3B11
PINT	3G1
RDY	3D1
RESET	1C11
SAD	ZC11
ZA0-ZA15	1G8
Z BUSAK	3G1
Z BUSRD	1E11
Z CRT SEL	3G1
Z CRT WT	ZB11
ZD0-ZD7	ZG5
ZRD	3G1
Z RESET	3G1
Z REQ	3G1
Z WAIT	1F11
ZB0 B0 PRESENT	ZG11
ACLK	1E11

I.C. TYPE	LOCATION	SPARES
74500	L19	3
74502	L8	3
74LS04	L68	4
74504	L51	2
74505	L59	3
74LS08	L21	1
	L78	2
74510	L5	2
74511	L16	2
74LS27	L32	2
74LS32	L33	1
	L72	2
74LS74	L56	1
7602	L9	1
74LS125	L64	1
SPARE	L1,17,18,35,52,55,69	

Z10 = 209 + 377 * A 378			
Z10	209	L5D	L67
3246-A	9246	377-0371	377-0368



NOTE: ALL RES. ARE 1/4W 5% UNLESS OTHERWISE SPECIFIED.

E-REV



REV	DATE	BY	CHKD	APP'D	DESCRIPTION
1	11/1/77	DMR	ELI	ELI	ORIGINAL P/LR
2	11/1/77	DMR	ELI	ELI	APP'D. 3005B
3	11/1/77	DMR	ELI	ELI	REVISED PER ECO# 3005B
4	11/1/77	DMR	ELI	ELI	REVISED PER ECO# 31585
5	11/1/77	DMR	ELI	ELI	REVISED PER ECO# 31585
6	11/1/77	DMR	ELI	ELI	REVISED PER ECO# 31585
7	11/1/77	DMR	ELI	ELI	REVISED PER ECO# 31585
8	11/1/77	DMR	ELI	ELI	REVISED PER ECO# 31585
9	11/1/77	DMR	ELI	ELI	REVISED PER ECO# 31585
10	11/1/77	DMR	ELI	ELI	REVISED PER ECO# 31585

<b>WANG</b> WANG LABORATORIES, INC. TOWELL, MASS. U.S.A.		BY	DATE	APPROVED BY	DATE
MATERIAL		DMR	11/1/77	ELI	11/1/77
MODEL NO 171-123-773		CHKD	11/1/77	ELI	11/1/77
SEE DRAWING SPECIFICATIONS		TITLE		PC LOCAL COMM CP. - 1286	
FINISH		101 SEE 11 NOTED		D 1286	
DATE		11/1/77		DRAWING NUMBER	

77 11 10 9 8 7 5 4 3 2 1 22

THIS DRAWING AND THE DATA SHOWN THERE  
 ARE THE CONFIDENTIAL PROPERTY OF WANG  
 LABORATORIES, INC. THE DRAWING AND THE DATA SHOWN  
 HEREIN MAY NOT BE MADE PUBLIC WITHOUT  
 THE WRITTEN CONSENT OF WANG LABORATORIES,  
 INC. IF FOR ANY REASON THIS DRAWING IS  
 PERMITTED BY WANG TO LEAVE THE PHYSICAL  
 CUSTODY OF THE COMPANY, IT IS RETURNABLE  
 UPON THE DEMAND OF WANG LABORATORIES,  
 INC.

DO NOT SCALE

ITEM NO.	WANG PART NO.	DESCRIPTION	REFERENCE DESIGNATION(S)	QTY.	ITEM NO.	WANG PART NO.	DESCRIPTION	REFERENCE DESIGNATION(S)	QTY.	ITEM NO.	WANG PART NO.	DESCRIPTION	REFERENCE DESIGNATION(S)	QTY.
53														
52	376-0288	IC 74LS244	22, 24, 48, 64, 75, 83	6										
51	376-0286	IC 74LS374	637-47, 58	12										
50	376-0285	IC 74LS245	627, 49	2										
49														
48	376-0289	IC 74LS30	670, 80	2										
47	376-0285	IC 74LS27	634	1										
46	376-0238	IC 74510	65	1										
45														
44	376-0228	IC 74500	619	1										
43	376-0225	IC 74LS11	616	1										
42	176-0211	IC 74LS32	630, 31, 33, 72, 76	5										
41														
40	376-0209	IC 74LS02	63, 65	2										
39	376-0202	IC 74574	634	1										
38	376-0197	IC 74504	651	1										
37														
36	376-0180	IC 74LS04	649, 79	2										
35	376-0160	IC 74LS175	623, 24	2										
34	376-0155	IC 74LS74	623, 56, 60, 71, 77	5										
33														
32	376-0153	IC 74LS08	62, 20, 21, 78	4										
31	376-0104	IC 7402	69	1	84	615-2213	1. AER. P.F. SHIELD		1					
30	376-0056	IC 7407	614	1	83	651-0027	HEX NUT 6-32		2					
29					82									
28					81									
27	375-1050	TS12 SPS6551	71	1	80									
26					79									
25					78									
24	333-0906	RES. 2.2K 51P	R3, 10-13	5	77	450-4120	SCREW #8-32 1/2"		2					
23					76									
22					75									
21					74	751-5140	SHIELD (RF)		1					
20					73									
19	330-5440	RES. 150K 1/4W 5%	R1	1	72									
18					71	465-1-50	RESISTOR		1					
17	330-4011	RES. 15K 1/4W 5%	R9	1	70									
16	330-3798	RES. 4.7K 1/4W 5%	R14, 15	2	69									
15	330-3761	RES. 2K 1/4W 5%	R8	1	68	266 SHAKT	IC 280A-16	157	1					
14					67	265 SHAKT	IC 280A CP1	157	1					
13	330-3011	RES. 1K 1/4W 5%	R2, 4, 5	3	66									
12	330-2034	RES. 330Ω 1/4W 5%	R7	1	65									
11	330-1011	RES. 10Ω 1/4W 5%	R6	1	64	376-3015	SKT 28PIN	650	1					
10					63	376-3011	SKT 40PIN	667	1					
9					62	37-0555	IC 74LS15	659	1					
8					61									
7	300-3033	CAP. 100UF 25V(1)	C2, 3	2	60	376-0436	IC 74LS125	668	1					
6	300-1766	CAP. 0.01UF 50V	C5-12, 14-35, 37-51	45	59	376-0316	IC 74LS279	646, 50, 54	2					
5					58	376-0310	IC 74LS279	631, 52	2					
4	300-1333	CAP. 10UF 50V	C1, 4	2	57									
3	300-1100	CAP. 1000PF 500V	C13	1	56	376-0306	IC 74LS179	613	1					
2	300-1033	CAP. 33PF 500V	C36	1	55	376-0217	IC 74LS240	636	1					
1					54	376-0214	IC 74LS233	627, 44, 45, 46, 47, 48, 49, 50, 51, 52, 53, 54, 55, 56, 57, 58, 59, 60, 61, 62, 63, 64, 65, 66, 67, 68, 69, 70, 71, 72, 73, 74, 75, 76, 77, 78, 79, 80, 81, 82, 83, 84, 85, 86, 87, 88, 89, 90, 91, 92, 93, 94, 95, 96, 97, 98, 99, 100	14					

REVISION	DATE	BY	DATE	APPROVED BY	DATE
1					
MATERIAL		MODEL NO.	TITLE	DATE	
FINISH		SCALE	DRG. NO.	DATE	

WANG LABORATORIES, INC. LOWELL, MASS. 01854

BY: [Signature] DATE: [Date]


APPROVED BY: [Signature] DATE: [Date]

WANG PART NO. 376-0214 DESCRIPTION: IC 74LS233 REFERENCE DESIGNATION(S): 627, 44, 45, 46, 47, 48, 49, 50, 51, 52, 53, 54, 55, 56, 57, 58, 59, 60, 61, 62, 63, 64, 65, 66, 67, 68, 69, 70, 71, 72, 73, 74, 75, 76, 77, 78, 79, 80, 81, 82, 83, 84, 85, 86, 87, 88, 89, 90, 91, 92, 93, 94, 95, 96, 97, 98, 99, 100 QTY: 14

22 11 10 9 8 7 5 4 3 2 1 22

THIS DRAWING AND THE DATA SHOWN HEREON ARE THE PROPERTY OF WANG LABORATORIES, INC. THIS DRAWING AND THE DATA SHOWN HEREON ARE NOT TO BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, INCLUDING PHOTOCOPYING, RECORDING, OR BY ANY INFORMATION STORAGE AND RETRIEVAL SYSTEM, WITHOUT THE WRITTEN CONSENT OF WANG LABORATORIES, INC. AND IF FOR ANY REASON THIS DRAWING IS REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, INCLUDING PHOTOCOPYING, RECORDING, OR BY ANY INFORMATION STORAGE AND RETRIEVAL SYSTEM, WITHOUT THE WRITTEN CONSENT OF WANG LABORATORIES, INC. IT IS HEREBY AGREED THAT THE USER SHALL INDEMNIFY AND HOLD HARMLESS WANG LABORATORIES, INC. FROM AND AGAINST ALL SUCH REPRODUCTION OR TRANSMISSION.


DO NOT SCALE




- NOTES: UNLESS OTHERWISE SPECIFIED
1. ALL CAPS ARE .047 CER CAPS WPM# 300-1466 EXPRESSED IN MICROFARADS
  2. ALL RESISTORS ARE 1/4W 5 PERCENT EXPRESSED IN OHMS
  3. L67 LOAD 48 PIN SOCKET WPM# 376-4011  
L50 LOAD 28 PIN SOCKET WPM# 376-4015
  4. 10 MIN DESIGNATED TO PREVENT OVERLAP FROM ADJACENT SHIELD

REV	DATE	BY	CHKD	APP'D
1	02/18/83	JJR	JJR	JJR
2	12/11/83	JJR	JJR	JJR
3	05/26/84	JJR	JJR	JJR
4	05/27/84	JJR	JJR	JJR

WANG LABORATORIES, INC.	
218 9246 R1	9246
DATE	REV
BY	CHKD
APP'D	APP'D






IBM		DATE	APPROVED BY	DATE
DRAWING NO. PH00L7A PBC		DATE	DATE	DATE
TITLE		DATE	DATE	DATE
CHARACTER RES		DATE	DATE	DATE
SEE CHART D 9343		DATE	DATE	DATE
REV. 9		DATE	DATE	DATE


77  
"L1"  
"L1"  
"58"  
8.5"  
11"  
17"  
22"

"22"  
"L1"  
"L1"  
"58"  
8.5"  
11"  
17"  
22"



THIS DRAWING AND THE DATA HEREIN THEREOF ARE THE PROPRIETARY PROPERTY OF AND ARE PREPARED BY AND FOR THE USE OF THE AIR FORCE. NO PART OF THIS DRAWING IS TO BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, INCLUDING PHOTOCOPYING, RECORDING, OR BY ANY INFORMATION STORAGE AND RETRIEVAL SYSTEM, WITHOUT THE WRITTEN PERMISSION OF THE AIR FORCE. THE AIR FORCE WILL NOT BE RESPONSIBLE FOR ANY DAMAGE TO PERSONS OR PROPERTY, OR FOR ANY CONSEQUENCES ARISING FROM THE USE OF THIS DRAWING IN ANY MANNER, INCLUDING THE USE OF THIS DRAWING FOR UNAUTHORIZED PURPOSES. THE AIR FORCE WILL NOT BE RESPONSIBLE FOR ANY DAMAGE TO PERSONS OR PROPERTY, OR FOR ANY CONSEQUENCES ARISING FROM THE USE OF THIS DRAWING IN ANY MANNER, INCLUDING THE USE OF THIS DRAWING FOR UNAUTHORIZED PURPOSES.

WANG		BY	DATE	APPROVED BY	DATE
MODEL NO. P11007A		DATE	DATE	DATE	DATE
TITLE		DATE	DATE	DATE	DATE
CHARACTER RES		DATE	DATE	DATE	DATE
SEE CHART		DATE	DATE	DATE	DATE
D		DATE	DATE	DATE	DATE
9343		DATE	DATE	DATE	DATE
9		DATE	DATE	DATE	DATE



The schematic and the data sheet should be used for component identification and the component's pinout should be used for component location. The schematic and the data sheet should be used for component identification and the component's pinout should be used for component location. The schematic and the data sheet should be used for component identification and the component's pinout should be used for component location.

WYLE LABORATORIES INC. LABORATORY DIV.		BY	DATE	APPROVED BY	DATE
MODEL NO. PH0067A PCB		CHK	9/1/54	E. INHOE	
TITLE <b>CHARACTER RES</b>		NO. TO BE BUILT	SEE CHART	D	9343
PARTS SEE CHART		NO. TO BE BUILT	SEE CHART	D	9343
DRAWN BY DATE		NO. TO BE BUILT	SEE CHART	D	9343






SEE SHEET 4

THIS DRAWING AND THE DATA THEREON ARE THE CONFIDENTIAL PROPERTY OF WANG AND SHOULD BE KEPT AS SUCH. ANY DISCLOSURE OF THIS DRAWING AND THE DATA THEREON TO ANY OTHER PERSON OR ENTITY WITHOUT THE WRITTEN CONSENT OF WANG LABORATORIES, INC. IS STRICTLY PROHIBITED. THE DRAWING IS HEREBY ISSUED TO YOU TO LEAVE THE PHYSICAL POSSESSION OF THE COMPANY. IT IS TO REMAIN THE PROPERTY OF WANG LABORATORIES.

MEMORANICS	COORD.
A1-A16	1G11
ARQWC	2B11
AMWC	2B11
BITMAP	2A7
BLANKD	2B1
CLK 0MHz	3A11
DO-DIS	1D11
DCLK	2A6
DEN	2C11
DT/A	1A11
GHVIDEO	2G3
HACK	2B11
HSYNC	1A7
ID	1F11
IRQ3	1A4
IOAC	2B11
M PAGE	2A11
MRDC	2B11
RESET	2B11
RDY	1B1
SAD	1D11
S100-S103	1G10

TYPE	LOCATION	SPARE#
74504	L37	1
74508	L1A	3
74532	L56	1
7474	L55	1
74586	L36	1
74393	L34	1

210 = 209 + 377 OR 378			
210	209	L62	
9343A	9343	377-0473	



NOTE:  
1. ALL RES. 1/4W 5% UNLESS OTHERWISE SPECIFIED.

E-REV  
2


DATE	BY	DATE	APPROVED BY	DATE
1/1/78	WANG	1/1/78	WANG	1/1/78
1/1/78	WANG	1/1/78	WANG	1/1/78

WANG LABORATORIES, INC.  
MODEL NO. P10067A  
PBC  
TITLE: CHARACTER RES  
SEE CHART D 9343 9






77  
11  
11  
98  
8.5"  
11"  
17"  
22"



22  
17  
11  
8.5"  
11"  
17"  
22"

NO.	DESCRIPTION	QTY	UNIT PRICE	TOTAL PRICE
1	8080-1	1	10.00	10.00
2	8255-1	1	5.00	5.00
3	8255-2	1	5.00	5.00
4	8255-3	1	5.00	5.00
5	8255-4	1	5.00	5.00
6	8255-5	1	5.00	5.00
7	8255-6	1	5.00	5.00
8	8255-7	1	5.00	5.00
9	8255-8	1	5.00	5.00
10	8255-9	1	5.00	5.00
11	8255-10	1	5.00	5.00
12	8255-11	1	5.00	5.00
13	8255-12	1	5.00	5.00
14	8255-13	1	5.00	5.00
15	8255-14	1	5.00	5.00
16	8255-15	1	5.00	5.00
17	8255-16	1	5.00	5.00
18	8255-17	1	5.00	5.00
19	8255-18	1	5.00	5.00
20	8255-19	1	5.00	5.00
21	8255-20	1	5.00	5.00
22	8255-21	1	5.00	5.00
23	8255-22	1	5.00	5.00
24	8255-23	1	5.00	5.00
25	8255-24	1	5.00	5.00
26	8255-25	1	5.00	5.00
27	8255-26	1	5.00	5.00
28	8255-27	1	5.00	5.00
29	8255-28	1	5.00	5.00
30	8255-29	1	5.00	5.00
31	8255-30	1	5.00	5.00
32	8255-31	1	5.00	5.00
33	8255-32	1	5.00	5.00
34	8255-33	1	5.00	5.00
35	8255-34	1	5.00	5.00
36	8255-35	1	5.00	5.00
37	8255-36	1	5.00	5.00
38	8255-37	1	5.00	5.00
39	8255-38	1	5.00	5.00
40	8255-39	1	5.00	5.00
41	8255-40	1	5.00	5.00
42	8255-41	1	5.00	5.00
43	8255-42	1	5.00	5.00
44	8255-43	1	5.00	5.00
45	8255-44	1	5.00	5.00
46	8255-45	1	5.00	5.00
47	8255-46	1	5.00	5.00
48	8255-47	1	5.00	5.00
49	8255-48	1	5.00	5.00
50	8255-49	1	5.00	5.00
51	8255-50	1	5.00	5.00
52	8255-51	1	5.00	5.00
53	8255-52	1	5.00	5.00
54	8255-53	1	5.00	5.00
55	8255-54	1	5.00	5.00
56	8255-55	1	5.00	5.00
57	8255-56	1	5.00	5.00
58	8255-57	1	5.00	5.00
59	8255-58	1	5.00	5.00
60	8255-59	1	5.00	5.00
61	8255-60	1	5.00	5.00
62	8255-61	1	5.00	5.00
63	8255-62	1	5.00	5.00
64	8255-63	1	5.00	5.00
65	8255-64	1	5.00	5.00
66	8255-65	1	5.00	5.00
67	8255-66	1	5.00	5.00
68	8255-67	1	5.00	5.00
69	8255-68	1	5.00	5.00
70	8255-69	1	5.00	5.00
71	8255-70	1	5.00	5.00
72	8255-71	1	5.00	5.00
73	8255-72	1	5.00	5.00
74	8255-73	1	5.00	5.00
75	8255-74	1	5.00	5.00
76	8255-75	1	5.00	5.00
77	8255-76	1	5.00	5.00
78	8255-77	1	5.00	5.00
79	8255-78	1	5.00	5.00
80	8255-79	1	5.00	5.00
81	8255-80	1	5.00	5.00
82	8255-81	1	5.00	5.00
83	8255-82	1	5.00	5.00
84	8255-83	1	5.00	5.00
85	8255-84	1	5.00	5.00
86	8255-85	1	5.00	5.00
87	8255-86	1	5.00	5.00
88	8255-87	1	5.00	5.00
89	8255-88	1	5.00	5.00
90	8255-89	1	5.00	5.00
91	8255-90	1	5.00	5.00
92	8255-91	1	5.00	5.00
93	8255-92	1	5.00	5.00
94	8255-93	1	5.00	5.00
95	8255-94	1	5.00	5.00
96	8255-95	1	5.00	5.00
97	8255-96	1	5.00	5.00
98	8255-97	1	5.00	5.00
99	8255-98	1	5.00	5.00
100	8255-99	1	5.00	5.00

CPU/MEMORY  
9521



		DATE: 11/15/67 DRAWN BY: J. W. BERRY CHECKED BY: J. W. BERRY APPROVED BY: J. W. BERRY
TITLE: CPU/MEMORY		PART NO: 9521
REV: 11		QTY: 11

14  
13  
12  
11  
10  
9  
8  
7  
6  
5  
4  
3  
2  
1


77  
11  
58  
8.5"  
11"  
17"  
22"

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K


14  
13  
12  
11  
10  
9  
8  
7  
6  
5  
4  
3  
2  
1

77  
11  
58  
8.5"  
11"  
17"  
22"

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K



<b>WANG</b>		DATE	APPROVED BY	DATE
PROJECT NO. 210-9521		DATE	APPROVED BY	DATE
TITLE		DATE	APPROVED BY	DATE
CPU/MEMORY		DATE	APPROVED BY	DATE
REV. 1.0		DATE	APPROVED BY	DATE
210-9521		E 9521	IF	




QTY	DESCRIPTION	REF. DESIG.	MANUFACTURER
1	8080	U1	INTEL
1	RAM 1K1	U2	RAM
1	RAM 1K2	U3	RAM
1	ROM 1K1	U4	ROM
1	ROM 1K2	U5	ROM
1	FLOPPY CS	U6	RAM
1	74LS10	U7	RAM
1	74LS132	U8	RAM
1	74LS176	U9	RAM
1	74LS177	U10	RAM
1	74LS178	U11	RAM
1	74LS179	U12	RAM
1	74LS175	U13	RAM
1	74LS174	U14	RAM
1	74LS173	U15	RAM
1	74LS172	U16	RAM
1	74LS171	U17	RAM
1	74LS170	U18	RAM
1	74LS169	U19	RAM
1	74LS168	U20	RAM
1	74LS167	U21	RAM
1	74LS166	U22	RAM
1	74LS165	U23	RAM
1	74LS164	U24	RAM
1	74LS163	U25	RAM
1	74LS162	U26	RAM
1	74LS161	U27	RAM
1	74LS160	U28	RAM
1	74LS159	U29	RAM
1	74LS158	U30	RAM
1	74LS157	U31	RAM
1	74LS156	U32	RAM
1	74LS155	U33	RAM
1	74LS154	U34	RAM
1	74LS153	U35	RAM
1	74LS152	U36	RAM
1	74LS151	U37	RAM
1	74LS150	U38	RAM
1	74LS149	U39	RAM
1	74LS148	U40	RAM
1	74LS147	U41	RAM
1	74LS146	U42	RAM
1	74LS145	U43	RAM
1	74LS144	U44	RAM
1	74LS143	U45	RAM
1	74LS142	U46	RAM
1	74LS141	U47	RAM
1	74LS140	U48	RAM
1	74LS139	U49	RAM
1	74LS138	U50	RAM
1	74LS137	U51	RAM
1	74LS136	U52	RAM
1	74LS135	U53	RAM
1	74LS134	U54	RAM
1	74LS133	U55	RAM
1	74LS132	U56	RAM
1	74LS131	U57	RAM
1	74LS130	U58	RAM
1	74LS129	U59	RAM
1	74LS128	U60	RAM
1	74LS127	U61	RAM
1	74LS126	U62	RAM
1	74LS125	U63	RAM
1	74LS124	U64	RAM
1	74LS123	U65	RAM
1	74LS122	U66	RAM
1	74LS121	U67	RAM
1	74LS120	U68	RAM
1	74LS119	U69	RAM
1	74LS118	U70	RAM
1	74LS117	U71	RAM
1	74LS116	U72	RAM
1	74LS115	U73	RAM
1	74LS114	U74	RAM
1	74LS113	U75	RAM
1	74LS112	U76	RAM
1	74LS111	U77	RAM
1	74LS110	U78	RAM
1	74LS109	U79	RAM
1	74LS108	U80	RAM
1	74LS107	U81	RAM
1	74LS106	U82	RAM
1	74LS105	U83	RAM
1	74LS104	U84	RAM
1	74LS103	U85	RAM
1	74LS102	U86	RAM
1	74LS101	U87	RAM
1	74LS100	U88	RAM
1	74LS99	U89	RAM
1	74LS98	U90	RAM
1	74LS97	U91	RAM
1	74LS96	U92	RAM
1	74LS95	U93	RAM
1	74LS94	U94	RAM
1	74LS93	U95	RAM
1	74LS92	U96	RAM
1	74LS91	U97	RAM
1	74LS90	U98	RAM
1	74LS89	U99	RAM
1	74LS88	U100	RAM

CPU MEMORY







LOADING CHART

120K 9521	LOAD L3,L4,L13,L14,L25,L31,L35,L41,L47 L9,L10,L19,L20,L26,L32,L36,L42,L40	615-2457 (CPU 120 KB)
256K 9521-1	LOAD L3-L6,L9-L16,L19-L22,L25-L28,L31-L30 L41-L44,L47-L50	615-2458 (CPU 256 KB)
512K 9521-2	LOAD L3,L4,L13,L14,L25,L31,L35,L41,L47 L9,L10,L19,L20,L26,L32,L36,L42,L40	615-2510 (CPU 512 KB)
1MEG 9521-3	LOAD L3-L6,L9-L16,L19-L22,L25-L28,L31-L30 L41-L44,L47-L50	615-2519 (CPU 1 MEG)

- NOTES: UNLESS OTHERWISE SPECIFIED
- 1 ALL CAPACITORS ARE 5% EXPRESSED IN MICROFARADS
  - 2 ALL RESISTORS ARE 1/4W 5 PERCENT EXPRESSED IN OHMS
  - 3 R68 R61 20K 1/8W 1 PERCENT
  - 4 R63 R64 10K 1/8W 1 PERCENT
  - 5 R62 R75 2.2K 1/8W 1 PERCENT
  - 7 C1-C8,C10-C13,C15-C18,C20-C23,C25-C32,C34-C37,C39-C42  
C51,C44,C186,C115 ARE 10F 50V CER C P/N 380-1033
  - 8 L3-L6,L9-L16,L19-L22,L25-L28,L31-L30,L41-L44,L47-L50 ARE  
64KX1 DRAMS (6665-3,4564-3,2164-3,4164-3,2664-3,8264-3,3764-3)  
OR 256KX1 DRAMS (6256,58256)
  - 9 SEE LOADING CHART FOR DIFFERENT LOADING VARIATIONS  
J1 J2 ARE JUMPERS P/N 680-1027
  - 10 SEE LOADING CHART FOR DIFFERENT LOADING VARIATIONS
  - 11 L44 L115 LOAD 20 PIN SOCKET P/N 376-1015
  - 12 L75,L90,L100 LOAD 40 PIN SOCKET P/N 376-1011
  - 13 X1 LOAD SLEEVING FOR XTAL 5/8 INCH P/N 605-0117
  - 14 E1 THRU E6 ARE FERRITE BEADS, WPM 410-1016

<b>WANG</b>		DATE	APPROVED BY	DATE
MODEL NO PBC SEE CHANGE NOTIFICATION # 10-213		DATE	APPROVED BY	DATE
TITLE CPU/MEMORY ASSEMBLY DRAWING		DATE	APPROVED BY	DATE
210-9521-R3		DATE	APPROVED BY	DATE
952111		DATE	APPROVED BY	DATE



**WANG**

LABORATORIES, INC

---

ONE INDUSTRIAL AVENUE, LOWELL, MASSACHUSETTS 01851. TEL (617) 459 5000. TWX 710 343 6769. TELEX 94 7421

PRINTED IN U.S.A.

**END**